

# **SOLIDWORKS API (VB6 COM) — Reference (83/102): Simulation3DContactFeatureData- SimulationSpringFeatureData**

SOLIDWORKS API Documentation (converted from CHM)

# Simulation3DContactFeatureData (Type)

SOLIDWORKS Type Library  
Simulation3DContactFeatureData Object

Object Model

Simulation3DContactFeatureData

SOLIDWORKS Type Library  
Simulation3DContactFeatureData Object Members

Public Properties

- ContactComponents
- DynamicFrictionCoefficient
- DynamicFrictionVelocity
- Exponent
- FrictionOption
- MaterialID
- MaxDamping
- Penetration
- RestitutionCoefficient
- SpecifyMaterial
- StaticFrictionCoefficient
- StaticFrictionVelocity
- Stiffness
- UseRestitutionCoefficient

SOLIDWORKS Type Library  
ContactComponents Property (Simulation3DContactFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property ContactComponents As Variant

SOLIDWORKS Type Library  
DynamicFrictionCoefficient Property (Simulation3DContactFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property DynamicFrictionCoefficient As Double

SOLIDWORKS Type Library  
DynamicFrictionVelocity Property (Simulation3DContactFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property DynamicFrictionVelocity As Double

SOLIDWORKS Type Library  
Exponent Property (Simulation3DContactFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Exponent As Double
```

SOLIDWORKS Type Library

**FrictionOption Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property FrictionOption As Long
```

SOLIDWORKS Type Library

**MaterialID Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property MaterialID( _  
    ByVal WhichOne As Long _  
    ) As Long
```

SOLIDWORKS Type Library

**MaxDamping Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property MaxDamping As Double
```

SOLIDWORKS Type Library

**Penetration Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property Penetration As Double
```

SOLIDWORKS Type Library

**RestitutionCoefficient Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property RestitutionCoefficient As Double
```

SOLIDWORKS Type Library

**SpecifyMaterial Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property SpecifyMaterial As Boolean
```

SOLIDWORKS Type Library

**StaticFrictionCoefficient Property (Simulation3DContactFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property StaticFrictionCoefficient As Double
```

SOLIDWORKS Type Library

StaticFrictionVelocity Property (Simulation3DContactFeatureData)



Visual Basic for Applications (VBA)

Public Property StaticFrictionVelocity As Double

SOLIDWORKS Type Library

Stiffness Property (Simulation3DContactFeatureData)



Visual Basic for Applications (VBA)

Public Property Stiffness As Double

SOLIDWORKS Type Library

UseRestitutionCoefficient Property (Simulation3DContactFeatureData)



Visual Basic for Applications (VBA)


Public Property UseRestitutionCoefficient As Boolean

# SimulationDamperFeatureData (Type)

SOLIDWORKS Type Library

SimulationDamperFeatureData Object

Object Model



SOLIDWORKS Type Library

SimulationDamperFeatureData Object Members

Public Methods

|                                                                                   |                              |
|-----------------------------------------------------------------------------------|------------------------------|
|  | <a href="#">GetEndPoints</a> |
|  | <a href="#">SetEndPoints</a> |

Public Properties

|                                                                                   |                                                 |
|-----------------------------------------------------------------------------------|-------------------------------------------------|
|  | <a href="#">BaseComponent</a>                   |
|  | <a href="#">DampingConstant</a>                 |
|  | <a href="#">ExponentOfDamperForceExpression</a> |
|  | <a href="#">LoadReferences</a>                  |
|  | <a href="#">Type</a>                            |

SOLIDWORKS Type Library

BaseComponent Property (SimulationDamperFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BaseComponent As Component2
```

SOLIDWORKS Type Library

DampingConstant Property (SimulationDamperFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DampingConstant As Double
```

SOLIDWORKS Type Library

ExponentOfDamperForceExpression Property (SimulationDamperFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ExponentOfDamperForceExpression As Long
```

SOLIDWORKS Type Library

GetEndPoints Method (SimulationDamperFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEndPoints( _  
    ByRef PDirDisp1 As Object, _  
    ByRef PDirDisp2 As Object, _
```

```
ByRef Type1 As Long, _  
ByRef Type2 As Long _  
) As Boolean
```

SOLIDWORKS Type Library

**LoadReferences Property (SimulationDamperFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property LoadReferences As Variant
```

SOLIDWORKS Type Library

**SetEndPoints Method (SimulationDamperFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetEndPoints( _  
ByVal PDirDisp1 As Object, _  
ByVal PDirDisp2 As Object _  
) As Boolean
```

SOLIDWORKS Type Library

**Type Property (SimulationDamperFeatureData)**



Syntax


Visual Basic for Applications (VBA)

```
Public Property Type As Long
```

# SimulationForceFeatureData (Type)

SOLIDWORKS Type Library  
SimulationForceFeatureData Object

Object Model



SOLIDWORKS Type Library  
SimulationForceFeatureData Object Members

Public Methods

|                                                                                   |                                           |
|-----------------------------------------------------------------------------------|-------------------------------------------|
|  | <a href="#">GetEndPoints</a>              |
|  | <a href="#">GetFunctionHarmonicValues</a> |
|  | <a href="#">GetFunctionStepValues</a>     |
|  | <a href="#">GetInterpolatedValue</a>      |
|  | <a href="#">LoadSplineData</a>            |
|  | <a href="#">SetEndPoints</a>              |
|  | <a href="#">SetFunctionHarmonicValues</a> |
|  | <a href="#">SetFunctionStepValues</a>     |

Public Properties

|                                                                                     |                                            |
|-------------------------------------------------------------------------------------|--------------------------------------------|
|  | <a href="#">ActionDirection</a>            |
|  | <a href="#">ActionLocation</a>             |
|  | <a href="#">ActionType</a>                 |
|  | <a href="#">ExternalState</a>              |
|  | <a href="#">ForceFunctionType</a>          |
|  | <a href="#">ForceType</a>                  |
|  | <a href="#">FunctionConstantValue</a>      |
|  | <a href="#">FunctionExpression</a>         |
|  | <a href="#">FunctionInterpolatedValues</a> |
|  | <a href="#">InterpolationScheme</a>        |
|  | <a href="#">LoadReferences</a>             |
|  | <a href="#">ReactionLocation</a>           |
|  | <a href="#">ReferenceComponent</a>         |
|  | <a href="#">ReverseDirection</a>           |

SOLIDWORKS Type Library  
ActionDirection Property (SimulationForceFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property ActionDirection As Object

SOLIDWORKS Type Library  
ActionLocation Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property ActionLocation As Object

SOLIDWORKS Type Library

ActionType Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property ActionType As Long

SOLIDWORKS Type Library

ExternalState Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property ExternalState As Boolean

SOLIDWORKS Type Library

ForceFunctionType Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property ForceFunctionType As Long

SOLIDWORKS Type Library

ForceType Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property ForceType As Long

SOLIDWORKS Type Library

FunctionConstantValue Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property FunctionConstantValue As Double

SOLIDWORKS Type Library

FunctionExpression Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property FunctionExpression As String

SOLIDWORKS Type Library

FunctionInterpolatedValues Property (SimulationForceFeatureData)



Visual Basic for Applications (VBA)

Public Property FunctionInterpolatedValues As Variant

SOLIDWORKS Type Library

GetEndPoints Method (SimulationForceFeatureData)

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEndPoints( _  
    ByRef PDirDisp1 As Object, _  
    ByRef PDirDisp2 As Object, _  
    ByRef Type1 As Long, _  
    ByRef Type2 As Long _  
) As Boolean
```

SOLIDWORKS Type Library

**GetFunctionHarmonicValues Method (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFunctionHarmonicValues( _  
    ByRef Amplitude As Double, _  
    ByRef Frequency As Double, _  
    ByRef Average As Double, _  
    ByRef PhaseShift As Double _  
) As Boolean
```

SOLIDWORKS Type Library

**GetFunctionStepValues Method (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFunctionStepValues( _  
    ByRef F1InitialValue As Double, _  
    ByRef T1StartStepTime As Double, _  
    ByRef F2InitialValue As Double, _  
    ByRef T2EndStepTime As Double _  
) As Boolean
```

SOLIDWORKS Type Library

**GetInterpolatedValue Method (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetInterpolatedValue( _  
    ByVal Time As Double _  
) As Double
```

SOLIDWORKS Type Library

**InterpolationScheme Property (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property InterpolationScheme As Long
```

SOLIDWORKS Type Library

**LoadReferences Property (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property LoadReferences As Variant
```

SOLIDWORKS Type Library

**LoadSplineData Method (SimulationForceFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function LoadSplineData( _  
    ByVal Value As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

**ReactionLocation Property (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property ReactionLocation As Object
```

SOLIDWORKS Type Library

**ReferenceComponent Property (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferenceComponent As Component2
```

SOLIDWORKS Type Library

**ReverseDirection Property (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

**SetEndPoints Method (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function SetEndPoints( _  
    ByVal PDirDisp1 As Object, _  
    ByVal PDirDisp2 As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

**SetFunctionHarmonicValues Method (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFunctionHarmonicValues( _  
    ByVal Amplitude As Double, _  
    ByVal Frequency As Double, _  
    ByVal Average As Double, _  
    ByVal PhaseShift As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

**SetFunctionStepValues Method (SimulationForceFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFunctionStepValues( _  
    ByVal F1InitialValue As Double, _  
    ByVal T1StartStepTime As Double, _  
    ByVal F2InitialValue As Double, _  
    ByVal T2EndStepTime As Double _  
    ) As Boolean
```



# SimulationGravityFeatureData (Type)

SOLIDWORKS Type Library

SimulationGravityFeatureData Object

Object Model

SimulationGravityFeatureData

SOLIDWORKS Type Library

SimulationGravityFeatureData Object Members

Public Properties

Axis

DirectionReference

ReverseDirection

Strength

SOLIDWORKS Type Library

Axis Property (SimulationGravityFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Axis As Long

SOLIDWORKS Type Library

DirectionReference Property (SimulationGravityFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property DirectionReference As Object

SOLIDWORKS Type Library

ReverseDirection Property (SimulationGravityFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property ReverseDirection As Boolean

SOLIDWORKS Type Library

Strength Property (SimulationGravityFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Strength As Double

# SimulationLinearSpringFeatureData (Type)

SOLIDWORKS Type Library  
SimulationLinearSpringFeatureData Object

Object Model

SimulationLinearSpringFeatureData

SOLIDWORKS Type Library  
SimulationLinearSpringFeatureData Object Members

Public Methods

- GetEndPoints
- SetEndPoints

Public Properties

- FreeLength
- SpringConstant

SOLIDWORKS Type Library  
FreeLength Property (SimulationLinearSpringFeatureData)

Syntax

```
Visual Basic for Applications (VBA)  
  
Public Property FreeLength As Double
```

SOLIDWORKS Type Library  
GetEndPoints Method (SimulationLinearSpringFeatureData)

Syntax

```
Visual Basic for Applications (VBA)  
  
Public Sub GetEndPoints(  
    ByRef PDirDisp1 As Object, _  
    ByRef PDirDisp2 As Object, _  
    ByRef Type1 As Long, _  
    ByRef Type2 As Long _  
)
```

SOLIDWORKS Type Library  
SetEndPoints Method (SimulationLinearSpringFeatureData)

Syntax

```
Visual Basic for Applications (VBA)  
  
Public Sub SetEndPoints(  
    ByVal PDirDisp1 As Object, _  
    ByVal PDirDisp2 As Object _  
)
```

SOLIDWORKS Type Library  
SpringConstant Property (SimulationLinearSpringFeatureData)


Syntax

```
Visual Basic for Applications (VBA)  
  
Public Property SpringConstant As Double
```

# SimulationMotorFeatureData (Type)

SOLIDWORKS Type Library  
SimulationMotorFeatureData Object

Object Model



SOLIDWORKS Type Library  
SimulationMotorFeatureData Object Members

Public Methods

|                                                                                   |                                      |
|-----------------------------------------------------------------------------------|--------------------------------------|
|  | <a href="#">ConstantSpeedMotor</a>   |
|  | <a href="#">DistanceMotor</a>        |
|  | <a href="#">GetInterpolatedValue</a> |
|  | <a href="#">InterpolatedMotor</a>    |
|  | <a href="#">LoadSplineData</a>       |
|  | <a href="#">OscillatingMotor</a>     |

Public Properties

|                                                                                     |                                     |
|-------------------------------------------------------------------------------------|-------------------------------------|
|   | <a href="#">DirectionReference</a>  |
|  | <a href="#">DriveType</a>           |
|  | <a href="#">Expression</a>          |
|  | <a href="#">ExternalState</a>       |
|  | <a href="#">InterpolationScheme</a> |
|  | <a href="#">LoadReferences</a>      |
|  | <a href="#">Location</a>            |
|  | <a href="#">Magnitude</a>           |
|  | <a href="#">MotionType</a>          |
|  | <a href="#">MotorType</a>           |
|  | <a href="#">RelativeComponent</a>   |
|  | <a href="#">ReverseDirection</a>    |
|  | <a href="#">SplineData</a>          |
|  | <a href="#">Velocity</a>            |

SOLIDWORKS Type Library  
ConstantSpeedMotor Method (SimulationMotorFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Sub ConstantSpeedMotor( _
    ByVal Speed As Double _
)
```

SOLIDWORKS Type Library  
DirectionReference Property (SimulationMotorFeatureData)



## Syntax

Visual Basic for Applications (VBA)

Public Property DirectionReference As Object

SOLIDWORKS Type Library

**DistanceMotor Method (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Sub DistanceMotor( _  
    ByVal Displacement As Double, _  
    ByVal StartTime As Double, _  
    ByVal Duration As Double _  
)
```

SOLIDWORKS Type Library

**DriveType Property (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

Public Property DriveType As Long

SOLIDWORKS Type Library

**Expression Property (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

Public Property Expression As String

SOLIDWORKS Type Library

**ExternalState Property (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

Public Property ExternalState As Boolean

SOLIDWORKS Type Library

**GetInterpolatedValue Method (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetInterpolatedValue( _  
    ByVal Time As Double _  
) As Double
```

SOLIDWORKS Type Library

**InterpolatedMotor Method (SimulationMotorFeatureData)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Sub InterpolatedMotor( _  
    ByVal DriveType As Long, _  
    ByVal InterpolationScheme As Long _  
)
```

SOLIDWORKS Type Library

**InterpolationScheme Property (SimulationMotorFeatureData)**



Visual Basic for Applications (VBA)

Public Property InterpolationScheme As Long

SOLIDWORKS Type Library

LoadReferences Property (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

Public Property LoadReferences As Variant

SOLIDWORKS Type Library

LoadSplineData Method (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

```
Public Function LoadSplineData( _  
    ByVal Value As String _  
) As Boolean
```

SOLIDWORKS Type Library

Location Property (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

Public Property Location As Object

SOLIDWORKS Type Library

Magnitude Property (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

Public Property Magnitude As Double

SOLIDWORKS Type Library

MotionType Property (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

Public Property MotionType As Long

SOLIDWORKS Type Library

MotorType Property (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

Public Property MotorType As Long

SOLIDWORKS Type Library

OscillatingMotor Method (SimulationMotorFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub OscillatingMotor( _  
    ByVal Displacement As Double, _  
    ByVal Frequency As Double _  
)
```

SOLIDWORKS Type Library

**RelativeComponent Property (SimulationMotorFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property RelativeComponent As Component2
```

SOLIDWORKS Type Library

**ReverseDirection Property (SimulationMotorFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

**SplineData Property (SimulationMotorFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property SplineData As Variant
```

SOLIDWORKS Type Library

**Velocity Property (SimulationMotorFeatureData)**




Visual Basic for Applications (VBA)

```
Public Property Velocity As Double
```

# SimulationSpringFeatureData (Type)

SOLIDWORKS Type Library  
SimulationSpringFeatureData Object



SOLIDWORKS Type Library  
SimulationSpringFeatureData Object Members

## Public Methods

- [GetEndPoints](#)
- [SetEndPoints](#)

## Public Properties

- [BaseComponent](#)
- [CoilDiameter](#)
- [DampingConstant](#)
- [ExponentOfDamperForceExpression](#)
- [ExponentOfSpringForceExpression](#)
- [FreeAngle](#)
- [FreeLength](#)
- [HasDamper](#)
- [LoadReferences](#)
- [NumberOfCoils](#)
- [ReverseDirection](#)
- [SpringConstant](#)
- [Type](#)
- [UpdateToModelChanges](#)
- [WireDiameter](#)

SOLIDWORKS Type Library  
BaseComponent Property (SimulationSpringFeatureData)

## Syntax

Visual Basic for Applications (VBA)

```
Public Property BaseComponent As Component2
```

SOLIDWORKS Type Library  
CoilDiameter Property (SimulationSpringFeatureData)

## Syntax

Visual Basic for Applications (VBA)

```
Public Property CoilDiameter As Double
```

SOLIDWORKS Type Library

## DampingConstant Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property DampingConstant As Double
```

## SOLIDWORKS Type Library

## ExponentOfDamperForceExpression Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property ExponentOfDamperForceExpression As Long
```

## SOLIDWORKS Type Library

## ExponentOfSpringForceExpression Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property ExponentOfSpringForceExpression As Long
```

## SOLIDWORKS Type Library

## FreeAngle Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property FreeAngle As Double
```

## SOLIDWORKS Type Library

## FreeLength Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property FreeLength As Double
```

## SOLIDWORKS Type Library

## GetEndPoints Method (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEndPoints( _  
    ByRef PDirDisp1 As Object, _  
    ByRef PDirDisp2 As Object, _  
    ByRef Type1 As Long, _  
    ByRef Type2 As Long _  
) As Boolean
```

## SOLIDWORKS Type Library

## HasDamper Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property HasDamper As Boolean
```

## SOLIDWORKS Type Library

## LoadReferences Property (SimulationSpringFeatureData)

### Syntax

Visual Basic for Applications (VBA)

Public Property LoadReferences As Variant

SOLIDWORKS Type Library

**NumberOfCoils Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property NumberOfCoils As Long

SOLIDWORKS Type Library

**ReverseDirection Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReverseDirection As Boolean

SOLIDWORKS Type Library

**SetEndPoints Method (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

```
Public Function SetEndPoints( _  
    ByVal PDirDisp1 As Object, _  
    ByVal PDirDisp2 As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

**SpringConstant Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property SpringConstant As Double

SOLIDWORKS Type Library

**Type Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property Type As Long

SOLIDWORKS Type Library

**UpdateToModelChanges Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property UpdateToModelChanges As Boolean

SOLIDWORKS Type Library

**WireDiameter Property (SimulationSpringFeatureData)**



Visual Basic for Applications (VBA)

Public Property WireDiameter As Double