

SOLIDWORKS API (VB6 COM) — Reference (84/102): Sketch-SketchBlockDefinition

SOLIDWORKS API Documentation (converted from CHM)

Sketch (Type)

SOLIDWORKS Type Library

Sketch Object

Object Model

Sketch

- GetSplineParams4 (SplineParamData)
- IEnumSketchHatches (EnumSketchHatches)
- IEnumSketchPoints (EnumSketchPoints)
- IEnumSketchSegments (EnumSketchSegments)
- IEnumSketchTextSegments (EnumSketchSegments)
- IGetContourEdges (Edge)
- IGetSketchBlockInstances (SketchBlockInstance)
- IGetSketchContours (SketchContour)
- IGetSketchPaths (SketchPath)
- IGetSketchPictures (SketchPicture)
- IGetSketchPoints2 (SketchPoint)
- IGetSketchRegions (SketchRegion)
- IGetSketchSlots (SketchSlot)
- ModelToSketchTransform (MathTransform)
- RelationManager (SketchRelationManager)

SOLIDWORKS Type Library

Sketch Object Members

Public Methods

- [AutoDimension](#)
- [AutoDimension2](#)
- [AutoTraceSketchPicture](#)
- [CheckFeatureUse](#)
- [ConstrainAll](#)
- [GetArcCount](#)
- [GetArcs](#)
- [GetArcs2](#)
- [GetAutomaticSolve](#)
- [GetConstrainedStatus](#)
- [GetContourEdgeCount](#)

	<u>GetContourEdges</u>
	<u>GetDetachSegmentOnDrag</u>
	<u>GetEllipseCount</u>
	<u>GetEllipses</u>
	<u>GetEllipses2</u>
	<u>GetEllipses3</u>
	<u>GetLineCount</u>
	<u>GetLineCount2</u>
	<u>GetLines</u>
	<u>GetLines2</u>
	<u>GetParabolaCount</u>
	<u>GetParabolas</u>
	<u>GetParabolas2</u>
	<u>GetPolyLineCount</u>
	<u>GetPolylines</u>
	<u>GetReferenceEntity</u>
	<u>GetSketchBlockInstanceCount</u>
	<u>GetSketchBlockInstances</u>
	<u>GetSketchContourCount</u>
	<u>GetSketchContours</u>
	<u>GetSketchHatches</u>
	<u>GetSketchPathCount</u>
	<u>GetSketchPaths</u>
	<u>GetSketchPictureCount</u>
	<u>GetSketchPictures</u>
	<u>GetSketchPoints</u>
	<u>GetSketchPoints2</u>
	<u>GetSketchPointsCount</u>
	<u>GetSketchPointsCount2</u>
	<u>GetSketchRegionCount</u>
	<u>GetSketchRegions</u>
	<u>GetSketchSegments</u>
	<u>GetSketchSlotCount</u>
	<u>GetSketchSlots</u>
	<u>GetSketchTextSegments</u>
	<u>GetSplineCount</u>
	<u>GetSplineInterpolateCount</u>
	<u>GetSplineParams</u>
	<u>GetSplineParams2</u>
	<u>GetSplineParams3</u>
	<u>GetSplineParams4</u>
	<u>GetSplineParams5</u>
	<u>GetSplineParamsCount</u>

	<u>GetSplineParamsCount2</u>
	<u>GetSplineParamsCount3</u>
	<u>GetSplines</u>
	<u>GetSplinesInterpolate</u>
	<u>GetUserPoints</u>
	<u>GetUserPoints2</u>
	<u>GetUserPointsCount</u>
	<u>IEnumSketchHatches</u>
	<u>IEnumSketchPoints</u>
	<u>IEnumSketchSegments</u>
	<u>IEnumSketchTextSegments</u>
	<u>IGetArcs</u>
	<u>IGetArcs2</u>
	<u>IGetContourEdges</u>
	<u>IGetEllipses</u>
	<u>IGetEllipses2</u>
	<u>IGetEllipses3</u>
	<u>IGetLines</u>
	<u>IGetLines2</u>
	<u>IGetParabolas</u>
	<u>IGetParabolas2</u>
	<u>IGetPolylines</u>
	<u>IGetSketchBlockInstances</u>
	<u>IGetSketchContours</u>
	<u>IGetSketchPaths</u>
	<u>IGetSketchPictures</u>
	<u>IGetSketchPoints2</u>
	<u>IGetSketchRegions</u>
	<u>IGetSketchSlots</u>
	<u>IGetSplineParams</u>
	<u>IGetSplineParams2</u>
	<u>IGetSplineParams3</u>
	<u>IGetSplines</u>
	<u>IGetSplinesInterpolate</u>
	<u>IGetUserPoints</u>
	<u>IGetUserPoints2</u>
	<u>InsertRouteLine</u>
	<u>Is3D</u>
	<u>IsBoundingBoxSketch</u>
	<u>IsDerived</u>
	<u>IsShared</u>
	<u>IsSketchEditable</u>
	<u>MergePoints</u>

 SetAutomaticSolve
 SetDetachSegmentOnDrag
 SetEntityCount
 SetSketchEditable
 SetWorkingPlaneOrientation

Public Properties

 IModelToSketchXform
 ModelToSketchTransform
 ModelToSketchXform
 RelationManager

SOLIDWORKS Type Library

AutoDimension Method (Sketch)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AutoDimension(_ ByVal <i>EntitiesToDimension</i> As Long, _ ByVal <i>HorizontalScheme</i> As Long, _ ByVal <i>HorizontalPlacement</i> As Long, _ ByVal <i>VerticalScheme</i> As Long, _ ByVal <i>VerticalPlacement</i> As Long _) As Long</pre>

SOLIDWORKS Type Library

AutoDimension2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AutoDimension2(_ ByVal <i>EntitiesToDimension</i> As Long, _ ByVal <i>HorizontalScheme</i> As Long, _ ByVal <i>HorizontalPlacement</i> As Long, _ ByVal <i>VerticalScheme</i> As Long, _ ByVal <i>VerticalPlacement</i> As Long _) As Long</pre>

SOLIDWORKS Type Library

AutoTraceSketchPicture Method (Sketch)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Sub AutoTraceSketchPicture()</pre>

SOLIDWORKS Type Library

CheckFeatureUse Method (Sketch)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function CheckFeatureUse(_ ByVal <i>FeatureType</i> As Long, _ ByRef <i>OpenCount</i> As Long, _ ByRef <i>ClosedCount</i> As Long _) As Long</pre>

SOLIDWORKS Type Library

ConstrainAll Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ConstrainAll() As Long
```

SOLIDWORKS Type Library

GetArcCount Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArcCount() As Long
```

SOLIDWORKS Type Library

GetArcs Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArcs() As Variant
```

SOLIDWORKS Type Library

GetArcs2 Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArcs2() As Variant
```

SOLIDWORKS Type Library

GetAutomaticSolve Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAutomaticSolve() As Boolean
```

SOLIDWORKS Type Library

GetConstrainedStatus Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConstrainedStatus() As Long
```

SOLIDWORKS Type Library

GetContourEdgeCount Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetContourEdgeCount() As Long
```

SOLIDWORKS Type Library

GetContourEdges Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetContourEdges( _  
    ByVal Xform As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetDetachSegmentOnDrag Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDetachSegmentOnDrag() As Boolean
```

SOLIDWORKS Type Library

GetEllipseCount Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEllipseCount() As Long
```

SOLIDWORKS Type Library

GetEllipses Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEllipses() As Variant
```

SOLIDWORKS Type Library

GetEllipses2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEllipses2() As Variant
```

SOLIDWORKS Type Library

GetEllipses3 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEllipses3() As Variant
```

SOLIDWORKS Type Library

GetLineCount Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLineCount() As Long
```

SOLIDWORKS Type Library

GetLineCount2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLineCount2( _  
    ByVal CrossHatchOption As Integer _  
    ) As Long
```

SOLIDWORKS Type Library

GetLines Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

Public Function GetLines() As Variant

SOLIDWORKS Type Library

GetLines2 Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLines2( _  
    ByVal CrossHatchOption As Integer _  
) As Variant
```

SOLIDWORKS Type Library

GetParabolaCount Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetParabolaCount() As Long
```

SOLIDWORKS Type Library

GetParabolas Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetParabolas() As Variant
```

SOLIDWORKS Type Library

GetParabolas2 Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetParabolas2() As Variant
```

SOLIDWORKS Type Library

GetPolyLineCount Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPolyLineCount( _  
    ByRef PointCount As Long _  
) As Long
```

SOLIDWORKS Type Library

GetPolylines Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPolylines() As Variant
```

SOLIDWORKS Type Library

GetReferenceEntity Method (Sketch)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReferenceEntity( _  
    ByRef LEntityType As Long _  
) As Object
```

SOLIDWORKS Type Library

GetSketchBlockInstanceCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchBlockInstanceCount() As Long
```

SOLIDWORKS Type Library

GetSketchBlockInstances Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchBlockInstances() As Variant
```

SOLIDWORKS Type Library

GetSketchContourCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchContourCount() As Long
```

SOLIDWORKS Type Library

GetSketchContours Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchContours() As Variant
```

SOLIDWORKS Type Library

GetSketchHatches Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchHatches() As Variant
```

SOLIDWORKS Type Library

GetSketchPathCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPathCount() As Long
```

SOLIDWORKS Type Library

GetSketchPaths Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPaths() As Variant
```

SOLIDWORKS Type Library

GetSketchPictureCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPictureCount() As Long
```

SOLIDWORKS Type Library

GetSketchPictures Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPictures() As Variant
```

SOLIDWORKS Type Library

GetSketchPoints Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPoints() As Variant
```

SOLIDWORKS Type Library

GetSketchPoints2 Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPoints2() As Variant
```

SOLIDWORKS Type Library

GetSketchPointsCount Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPointsCount() As Long
```

SOLIDWORKS Type Library

GetSketchPointsCount2 Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPointsCount2() As Long
```

SOLIDWORKS Type Library

GetSketchRegionCount Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchRegionCount() As Long
```

SOLIDWORKS Type Library

GetSketchRegions Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchRegions() As Variant
```

SOLIDWORKS Type Library

GetSketchSegments Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchSegments() As Variant
```

SOLIDWORKS Type Library

GetSketchSlotCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchSlotCount() As Long
```

SOLIDWORKS Type Library

GetSketchSlots Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchSlots() As Variant
```

SOLIDWORKS Type Library

GetSketchTextSegments Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSketchTextSegments() As Variant
```

SOLIDWORKS Type Library

GetSplineCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplineCount( _  
    ByRef PointCount As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetSplineInterpolateCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplineInterpolateCount( _  
    ByRef PointCount As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetSplineParams Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplineParams() As Variant
```

SOLIDWORKS Type Library

GetSplineParams2 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplineParams2() As Variant
```

SOLIDWORKS Type Library

GetSplineParams3 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplineParams3( _  
    ByVal ForceNonPeriodic As Boolean _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSplineParams4 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParams4( _  
    ByVal ForceNonPeriodic As Boolean _  
    ) As SplineParamData
```

SOLIDWORKS Type Library

GetSplineParams5 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParams5( _  
    ByVal ForceNonPeriodic As Boolean, _  
    ByVal Index As Long _  
    ) As Object
```

SOLIDWORKS Type Library

GetSplineParamsCount Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParamsCount( _  
    ByRef Size As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetSplineParamsCount2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParamsCount2( _  
    ByRef Size As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetSplineParamsCount3 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParamsCount3( _  
    ByVal ForceNonPeriodic As Boolean, _  
    ByRef Size As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetSplines Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplines() As Variant
```

SOLIDWORKS Type Library

GetSplinesInterpolate Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetSplinesInterpolate() As Variant
```

SOLIDWORKS Type Library

GetUserPoints Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetUserPoints() As Variant
```

SOLIDWORKS Type Library

GetUserPoints2 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetUserPoints2() As Variant
```

SOLIDWORKS Type Library

GetUserPointsCount Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function GetUserPointsCount() As Long
```

SOLIDWORKS Type Library

IEnumSketchHatches Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IEnumSketchHatches() As EnumSketchHatches
```

SOLIDWORKS Type Library

IEnumSketchPoints Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IEnumSketchPoints() As EnumSketchPoints
```

SOLIDWORKS Type Library

IEnumSketchSegments Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IEnumSketchSegments() As EnumSketchSegments
```

SOLIDWORKS Type Library

IEnumSketchTextSegments Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IEnumSketchTextSegments() As EnumSketchSegments
```

SOLIDWORKS Type Library

IGetArcs Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetArcs() As Double
```

SOLIDWORKS Type Library

IGetArcs2 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetArcs2( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetContourEdges Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetContourEdges( _  
    ByRef Xform As Double, _  
    ByVal EdgeCount As Long _  
) As Edge
```

SOLIDWORKS Type Library

IGetEllipses Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetEllipses() As Double
```

SOLIDWORKS Type Library

IGetEllipses2 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetEllipses2() As Double
```

SOLIDWORKS Type Library

IGetEllipses3 Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetEllipses3( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetLines Method (Sketch)



Visual Basic for Applications (VBA)

```
Public Function IGetLines() As Double
```

SOLIDWORKS Type Library

IGetLines2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetLines2( _  
    ByVal CrossHatchOption As Integer, _  
    ByVal ArraySize As Long _  
    ) As Double
```

SOLIDWORKS Type Library

IGetParabolas Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetParabolas() As Double
```

SOLIDWORKS Type Library

IGetParabolas2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetParabolas2( _  
    ByVal ArraySize As Long _  
    ) As Double
```

SOLIDWORKS Type Library

IGetPolylines Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPolylines() As Double
```

SOLIDWORKS Type Library

IGetSketchBlockInstances Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchBlockInstances( _  
    ByVal Count As Long _  
    ) As SketchBlockInstance
```

SOLIDWORKS Type Library

IGetSketchContours Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchContours( _  
    ByVal Count As Long _  
    ) As SketchContour
```

SOLIDWORKS Type Library

IGetSketchPaths Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPaths( _  
    ByVal Count As Long _  
    ) As SketchPath
```

SOLIDWORKS Type Library

IGetSketchPictures Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPictures( _  
    ByVal Count As Long _  
) As SketchPicture
```

SOLIDWORKS Type Library

IGetSketchPoints2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPoints2( _  
    ByVal Count As Long _  
) As SketchPoint
```

SOLIDWORKS Type Library

IGetSketchRegions Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchRegions( _  
    ByVal Count As Long _  
) As SketchRegion
```

SOLIDWORKS Type Library

IGetSketchSlots Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchSlots( _  
    ByVal Count As Long _  
) As SketchSlot
```

SOLIDWORKS Type Library

IGetSplineParams Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplineParams() As Double
```

SOLIDWORKS Type Library

IGetSplineParams2 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplineParams2() As Double
```

SOLIDWORKS Type Library

IGetSplineParams3 Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplineParams3( _  
    ByVal ForceNonPeriodic As Boolean _  
) As Double
```

SOLIDWORKS Type Library

IGetSplines Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplines() As Double
```

SOLIDWORKS Type Library

IGetSplinesInterpolate Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplinesInterpolate() As Double
```

SOLIDWORKS Type Library

IGetUserPoints Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserPoints() As Double
```

SOLIDWORKS Type Library

IGetUserPoints2 Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserPoints2( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IModelToSketchXform Property (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Property IModelToSketchXform As Double
```

SOLIDWORKS Type Library

InsertRouteLine Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertRouteLine( _  
    ByVal ItemsToConnect As Variant, _  
    ByVal Reverse As Variant, _  
    ByVal AlternatePath As Variant, _  
    ByVal AlongXYZ As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

Is3D Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function Is3D() As Boolean
```

SOLIDWORKS Type Library

IsBoundaryBoxSketch Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBoundingBoxSketch() As Boolean
```

SOLIDWORKS Type Library

IsDerived Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsDerived() As Boolean
```

SOLIDWORKS Type Library

IsShared Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsShared() As Boolean
```

SOLIDWORKS Type Library

IsSketchEditable Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSketchEditable() As Boolean
```

SOLIDWORKS Type Library

MergePoints Method (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Function MergePoints( _  
    ByVal Distance As Double _  
) As Boolean
```

SOLIDWORKS Type Library

ModelToSketchTransform Property (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ModelToSketchTransform As MathTransform
```

SOLIDWORKS Type Library

ModelToSketchXform Property (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ModelToSketchXform As Variant
```

SOLIDWORKS Type Library

RelationManager Property (Sketch)



Syntax

Visual Basic for Applications (VBA)

```
Public Property RelationManager As SketchRelationManager
```

SOLIDWORKS Type Library

SetAutomaticSolve Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetAutomaticSolve( _  
    ByVal SolveFlag As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetDetachSegmentOnDrag Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDetachSegmentOnDrag( _  
    ByVal Detach As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetEntityCount Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetEntityCount( _  
    ByVal EntityType As Long, _  
    ByVal EntityCount As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetSketchEditable Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSketchEditable( _  
    ByVal Editable As Boolean _  
    )
```

SOLIDWORKS Type Library

SetWorkingPlaneOrientation Method (Sketch)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetWorkingPlaneOrientation( _  
    ByVal OriginX As Double, _  
    ByVal OriginY As Double, _  
    ByVal OriginZ As Double, _  
    ByVal XAxisX As Double, _  
    ByVal XAxisY As Double, _  
    ByVal XAxisZ As Double, _  
    ByVal YAxisX As Double, _  
    ByVal YAxisY As Double, _  
    ByVal YAxisZ As Double, _  
    ByVal NormalX As Double, _  
    ByVal NormalY As Double, _  
    ByVal NormalZ As Double _  
    ) As Boolean
```

SketchArc (Type)

SOLIDWORKS Type Library

SketchArc Object

Object Model

SketchArc

IGetCenterPoint2 (SketchPoint)

IGetEndPoint2 (SketchPoint)

IGetStartPoint2 (SketchPoint)

SOLIDWORKS Type Library

SketchArc Object Members

Public Methods

	GetCenterPoint
	GetCenterPoint2
	GetEndPoint
	GetEndPoint2
	GetNormalVector
	GetRadius
	GetRotationDir
	GetStartPoint
	GetStartPoint2
	IGetCenterPoint
	IGetCenterPoint2
	IGetEndPoint
	IGetEndPoint2
	IGetNormalVector
	IGetStartPoint
	IGetStartPoint2
	IsCircle
	SetRadius

SOLIDWORKS Type Library

GetCenterPoint Method (SketchArc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCenterPoint() As Variant
```

SOLIDWORKS Type Library

GetCenterPoint2 Method (SketchArc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCenterPoint2() As Object
```

SOLIDWORKS Type Library

GetEndPoint Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetEndPoint() As Variant
```

SOLIDWORKS Type Library

GetEndPoint2 Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetEndPoint2() As Object
```

SOLIDWORKS Type Library

GetNormalVector Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetNormalVector() As Variant
```

SOLIDWORKS Type Library

GetRadius Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetRadius() As Double
```

SOLIDWORKS Type Library

GetRotationDir Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetRotationDir() As Integer
```

SOLIDWORKS Type Library

GetStartPoint Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetStartPoint() As Variant
```

SOLIDWORKS Type Library

GetStartPoint2 Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function GetStartPoint2() As Object
```

SOLIDWORKS Type Library

IGetCenterPoint Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetCenterPoint() As Double
```

SOLIDWORKS Type Library

IGetCenterPoint2 Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetCenterPoint2() As SketchPoint
```

SOLIDWORKS Type Library

IGetEndPoint Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetEndPoint() As Double
```

SOLIDWORKS Type Library

IGetEndPoint2 Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetEndPoint2() As SketchPoint
```

SOLIDWORKS Type Library

IGetNormalVector Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetNormalVector() As Double
```

SOLIDWORKS Type Library

IGetStartPoint Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetStartPoint() As Double
```

SOLIDWORKS Type Library

IGetStartPoint2 Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IGetStartPoint2() As SketchPoint
```

SOLIDWORKS Type Library

IsCircle Method (SketchArc)



Visual Basic for Applications (VBA)

```
Public Function IsCircle() As Integer
```

SOLIDWORKS Type Library

SetRadius Method (SketchArc)




Visual Basic for Applications (VBA)

```
Public Function SetRadius( _  
    ByVal Radius As Double _  
    ) As Boolean
```

SketchBlockDefinition (Type)

SOLIDWORKS Type Library
SketchBlockDefinition Object

Object Model



SOLIDWORKS Type Library
SketchBlockDefinition Object Members

Public Methods

	GetArcCount
	GetArcs
	GetDisplayDimensionCount
	GetDisplayDimensions
	GetEllipseCount
	GetEllipses
	GetFeature
	GetInstanceCount
	GetInstances
	GetLineCount
	GetLines
	GetNoteCount
	GetNotes
	GetParabolaCount
	GetParabolas
	GetSketch
	GetSplineCount
	GetSplineInterpolateCount
	GetSplineParams
	GetSplineParamsCount
	GetSplines
	GetSplines2
	GetSplinesInterpolate
	GetUserPoints

 GetUserPointsCount
 IGetArcs
 IGetDisplayDimensions
 IGetEllipses
 IGetInstances
 IGetLines
 IGetNotes
 IGetParabolas
 IGetSplineParams
 IGetSplines
 IGetSplines2
 IGetSplinesInterpolate
 IGetUserPoints
 Save

Public Properties

 FileName
 InsertionPoint
 LinkToFile

SOLIDWORKS Type Library

FileName Property (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)
Public Property FileName As String

SOLIDWORKS Type Library

GetArcCount Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)
Public Function GetArcCount() As Long

SOLIDWORKS Type Library

GetArcs Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)
Public Function GetArcs() As Variant

SOLIDWORKS Type Library

GetDisplayDimensionCount Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)
Public Function GetDisplayDimensionCount() As Long

SOLIDWORKS Type Library

GetDisplayDimensions Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplayDimensions() As Variant
```

SOLIDWORKS Type Library

GetEllipseCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetEllipseCount() As Long
```

SOLIDWORKS Type Library

GetEllipses Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetEllipses() As Variant
```

SOLIDWORKS Type Library

GetFeature Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library

GetInstanceCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetInstanceCount() As Long
```

SOLIDWORKS Type Library

GetInstances Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetInstances() As Variant
```

SOLIDWORKS Type Library

GetLineCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetLineCount() As Long
```

SOLIDWORKS Type Library

GetLines Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetLines() As Variant
```

SOLIDWORKS Type Library

GetNoteCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetNoteCount() As Long
```

SOLIDWORKS Type Library

GetNotes Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetNotes() As Variant
```

SOLIDWORKS Type Library

GetParabolaCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetParabolaCount() As Long
```

SOLIDWORKS Type Library

GetParabolas Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetParabolas() As Variant
```

SOLIDWORKS Type Library

GetSketch Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetSketch() As Sketch
```

SOLIDWORKS Type Library

GetSplineCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetSplineCount( _  
    ByRef PointCount As Long _  
) As Long
```

SOLIDWORKS Type Library

GetSplineInterpolateCount Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetSplineInterpolateCount( _  
    ByRef ArraySize As Long _  
) As Long
```

SOLIDWORKS Type Library

GetSplineParams Method (SketchBlockDefinition)



Visual Basic for Applications (VBA)

```
Public Function GetSplineParams() As Variant
```

SOLIDWORKS Type Library

GetSplineParamsCount Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplineParamsCount( _  
    ByRef ArraySize As Long _  
) As Long
```

SOLIDWORKS Type Library

GetSplines Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplines() As Variant
```

SOLIDWORKS Type Library

GetSplines2 Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplines2() As Variant
```

SOLIDWORKS Type Library

GetSplinesInterpolate Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSplinesInterpolate() As Variant
```

SOLIDWORKS Type Library

GetUserPoints Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserPoints() As Variant
```

SOLIDWORKS Type Library

GetUserPointsCount Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserPointsCount() As Long
```

SOLIDWORKS Type Library

IGetArcs Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetArcs( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetDisplayDimensions Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDisplayDimensions( _  
    ByVal Count As Long _  
) As DisplayDimension
```

SOLIDWORKS Type Library

IGetEllipses Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEllipses( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetInstances Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetInstances( _  
    ByVal Count As Long _  
) As SketchBlockInstance
```

SOLIDWORKS Type Library

IGetLines Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetLines( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetNotes Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNotes( _  
    ByVal Count As Long _  
) As Note
```

SOLIDWORKS Type Library

IGetParabolas Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetParabolas( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetSplineParams Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplineParams( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetSplines Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplines( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetSplines2 Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplines2( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetSplinesInterpolate Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSplinesInterpolate( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetUserPoints Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserPoints( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

InsertionPoint Property (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Property InsertionPoint As MathPoint
```

SOLIDWORKS Type Library

LinkToFile Property (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Property LinkToFile As Boolean
```

SOLIDWORKS Type Library

Save Method (SketchBlockDefinition)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Save( _  
    ByVal FileName As String _  
) As Boolean
```