

SOLIDWORKS API (VB6 COM) — Reference (87/102): SketchPicture-SldWorks

SOLIDWORKS API Documentation (converted from CHM)

SketchPicture (Type)

SOLIDWORKS Type Library

SketchPicture Object

Object Model

SketchPicture

GetFeature (Feature)

GetPointOnSketchFromPixel (MathPoint)

SOLIDWORKS Type Library

SketchPicture Object Members

Public Methods

- Flip
- GetFeature
- GetOrigin
- GetPixelmap
- GetPixelmapSize
- GetPointOnSketchFromPixel
- GetSize
- GetTransparency
- IGetPixelmap
- SetOrigin
- SetSize
- SetTransparency

Public Properties

- Angle
- Flipped

SOLIDWORKS Type Library

Angle Property (SketchPicture)

Syntax

Visual Basic for Applications (VBA)

Public Property Angle As Double

SOLIDWORKS Type Library

Flip Method (SketchPicture)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Flip( _  
    ByVal SideToSide As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

Flipped Property (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

Public Property Flipped As Boolean

SOLIDWORKS Type Library

GetFeature Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

Public Function GetFeature() As [Feature](#)

SOLIDWORKS Type Library

GetOrigin Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetOrigin( _  
    ByRef X As Double, _  
    ByRef Y As Double _  
)
```

SOLIDWORKS Type Library

GetPixelmap Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

Public Function GetPixelmap() As Variant

SOLIDWORKS Type Library

GetPixelmapSize Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPixelmapSize( _  
    ByRef Width As Long, _  
    ByRef Height As Long _  
) As Long
```

SOLIDWORKS Type Library

GetPointOnSketchFromPixel Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPointOnSketchFromPixel( _  
    ByVal Row As Long, _  
    ByVal Column As Long _  
) As MathPoint
```

SOLIDWORKS Type Library

GetSize Method (SketchPicture)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetSize( _  
    ByRef Width As Double, _  
    ByRef Height As Double _  
)
```

GetTransparency Method (SketchPicture) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub GetTransparency( _  
    ByRef Style As Long, _  
    ByRef Transparency As Double, _  
    ByRef MatchingColor As Long, _  
    ByRef MatchingTolerance As Double _  
)
```

IGetPixelmap Method (SketchPicture) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetPixelmap( _  
    ByVal Count As Long _  
) As Integer
```

SetOrigin Method (SketchPicture) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetOrigin( _  
    ByVal X As Double, _  
    ByVal Y As Double _  
) As Boolean
```

SetSize Method (SketchPicture) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetSize( _  
    ByVal Width As Double, _  
    ByVal Height As Double, _  
    ByVal AspectRatioLocked As Boolean _  
) As Boolean
```

SetTransparency Method (SketchPicture) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetTransparency( _  
    ByVal Style As Long, _  
    ByVal Transparency As Double, _  
    ByVal MatchingColor As Long, _  
    ByVal MatchingTolerance As Double _  
) As Boolean
```

SketchPoint (Type)

SOLIDWORKS Type Library

SketchPoint Object

Object Model

SketchPoint

GetSketch (Sketch)

GetSketchSlot (SketchSlot)

IGetRelations (SketchRelation)

SOLIDWORKS Type Library

SketchPoint Object Members

Public Methods

	DeSelect
	GetCoords
	GetFramePointTangent
	GetID
	GetRelations
	GetRelationsCount
	GetSketch
	GetSketchSlot
	IGetFramePointTangent
	IGetID
	IGetRelations
	ISetFramePointTangent
	Select
	Select2
	Select3
	Select4
	SelectByMark
	SetCoords
	SetFramePointTangent

Public Properties

	Color
	Layer
	LayerOverride
	Status
	Type
	X
	Y
	Z



SOLIDWORKS Type Library

Color Property (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Color As Long
```

SOLIDWORKS Type Library

DeSelect Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelect() As Boolean
```

SOLIDWORKS Type Library

GetCoords Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoords() As Double
```

SOLIDWORKS Type Library

GetFramePointTangent Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFramePointTangent( _  
    ByRef Status As Boolean _  
    ) As Variant
```

SOLIDWORKS Type Library

GetID Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetID() As Variant
```

SOLIDWORKS Type Library

GetRelations Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelations() As Variant
```

SOLIDWORKS Type Library

GetRelationsCount Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelationsCount() As Long
```

SOLIDWORKS Type Library

GetSketch Method (SketchPoint)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketch() As Sketch
```

SOLIDWORKS Type Library

GetSketchSlot Method (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Function GetSketchSlot() As SketchSlot
```

SOLIDWORKS Type Library

IGetFramePointTangent Method (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Function IGetFramePointTangent( _  
    ByRef Status As Boolean _  
) As Double
```

SOLIDWORKS Type Library

IGetID Method (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Function IGetID() As Long
```

SOLIDWORKS Type Library

IGetRelations Method (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Function IGetRelations( _  
    ByVal Count As Long _  
) As SketchRelation
```

SOLIDWORKS Type Library

ISetFramePointTangent Method (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Function ISetFramePointTangent( _  
    ByRef ToVector As Double _  
) As Boolean
```

SOLIDWORKS Type Library

Layer Property (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Property Layer As String
```

SOLIDWORKS Type Library

LayerOverride Property (SketchPoint)



Visual Basic for Applications (VBA)

```
Public Property LayerOverride As Integer
```

Select Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal AppendFlag As Boolean _  
    ) As Boolean
```

Select2 Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Select2( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long _  
    ) As Boolean
```

Select3 Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Select3( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long, _  
    ByVal Callout As Callout _  
    ) As Boolean
```

Select4 Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Select4( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
    ) As Boolean
```

SelectByMark Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SelectByMark( _  
    ByVal AppendFlag As Boolean, _  
    ByVal Mark As Long _  
    ) As Boolean
```

SetCoords Method (SketchPoint) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetCoords( _  
    ByVal Xx As Double, _  
    ByVal Yy As Double, _  
    ByVal Zz As Double _  
    ) As Boolean
```

SetFramePointTangent Method (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFramePointTangent( _  
    ByVal ToVector As Variant _  
) As Boolean
```

Status Property (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Status As Long
```

Type Property (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Type As Long
```

X Property (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property X As Double
```

Y Property (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Y As Double
```

Z Property (SketchPoint)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Z As Double
```

SketchRegion (Type)

SOLIDWORKS Type Library
SketchRegion Object

Object Model



SOLIDWORKS Type Library
SketchRegion Object Members

Public Methods

 [DeSelect](#)

 [GetEdges](#)

 [GetEdgesCount](#)

 [GetFirstLoop](#)

 [IGetEdges](#)

 [Select](#)

 [Select2](#)

Public Properties

 [Sketch](#)

SOLIDWORKS Type Library
DeSelect Method (SketchRegion)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelect() As Boolean
```

SOLIDWORKS Type Library
GetEdges Method (SketchRegion)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdges() As Variant
```

SOLIDWORKS Type Library
GetEdgesCount Method (SketchRegion)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdgesCount() As Long
```

SOLIDWORKS Type Library
GetFirstLoop Method (SketchRegion)



Visual Basic for Applications (VBA)

```
Public Function GetFirstLoop() As Loop2
```

SOLIDWORKS Type Library

IGetEdges Method (SketchRegion)



Visual Basic for Applications (VBA)

```
Public Function IGetEdges( _  
    ByVal Count As Long _  
    ) As Edge
```

SOLIDWORKS Type Library

Select Method (SketchRegion)



Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

Select2 Method (SketchRegion)



Visual Basic for Applications (VBA)

```
Public Function Select2( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
    ) As Boolean
```

SOLIDWORKS Type Library

Sketch Property (SketchRegion)



Visual Basic for Applications (VBA)

```
Public Property Sketch As Sketch
```

SketchRelation (Type)

SOLIDWORKS Type Library
SketchRelation Object

Object Model

SketchRelation

SOLIDWORKS Type Library
SketchRelation Object Members

Public Methods

	GetDefinitionEntities
	GetDefinitionEntities2
	GetDisplayDimension
	GetEntities
	GetEntitiesCount
	GetEntitiesType
	GetRelationType
	IGetDefinitionEntities
	IGetDefinitionEntities2
	IGetEntities
	IGetEntitiesType
	ReplaceEntity

Public Properties

	Suppressed
---	----------------------------

SOLIDWORKS Type Library
GetDefinitionEntities Method (SketchRelation)

Syntax

Visual Basic for Applications (VBA)
Public Function GetDefinitionEntities() As Variant

SOLIDWORKS Type Library
GetDefinitionEntities2 Method (SketchRelation)

Syntax

Visual Basic for Applications (VBA)
Public Function GetDefinitionEntities2() As Variant

SOLIDWORKS Type Library
GetDisplayDimension Method (SketchRelation)

Syntax

Visual Basic for Applications (VBA)
Public Function GetDisplayDimension() As Object

SOLIDWORKS Type Library
GetEntities Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function GetEntities() As Variant
```

SOLIDWORKS Type Library

GetEntitiesCount Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function GetEntitiesCount() As Long
```

SOLIDWORKS Type Library

GetEntitiesType Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function GetEntitiesType() As Variant
```

SOLIDWORKS Type Library

GetRelationType Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function GetRelationType() As Long
```

SOLIDWORKS Type Library

IGetDefinitionEntities Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function IGetDefinitionEntities( _  
    ByVal NumEntities As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetDefinitionEntities2 Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function IGetDefinitionEntities2( _  
    ByVal NumEntities As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetEntities Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function IGetEntities( _  
    ByVal NumEntities As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetEntitiesType Method (SketchRelation)



Visual Basic for Applications (VBA)

```
Public Function IGetEntitiesType( _  
    ByVal NumEntities As Long _  
) As Long
```

SOLIDWORKS Type Library

ReplaceEntity Method (SketchRelation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReplaceEntity( _  
    ByVal OldEntity As Object, _  
    ByVal NewEntity As Object _  
) As Boolean
```

SOLIDWORKS Type Library

Suppressed Property (SketchRelation)

Syntax


Visual Basic for Applications (VBA)

```
Public Property Suppressed As Boolean
```

SketchRelationManager (Type)

SOLIDWORKS Type Library
SketchRelationManager Object

Object Model



SOLIDWORKS Type Library
SketchRelationManager Object Members



Public Methods

	AddRelation
	DeleteAllRelations
	DeleteRelation
	GetAllowedRelations
	GetRelations
	GetRelationsCount
	IAddRelation
	IGetAllowedRelations
	IGetAllowedRelationsCount
	IGetRelations

SOLIDWORKS Type Library
AddRelation Method (SketchRelationManager)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AddRelation( _
    ByVal Entities As Variant, _
    ByVal RelationType As Long _
) As SketchRelation
```

SOLIDWORKS Type Library
DeleteAllRelations Method (SketchRelationManager)

Syntax

```
Visual Basic for Applications (VBA)

Public Function DeleteAllRelations() As Boolean
```

SOLIDWORKS Type Library
DeleteRelation Method (SketchRelationManager)

Syntax

```
Visual Basic for Applications (VBA)

Public Function DeleteRelation( _
    ByVal ThisRelation As SketchRelation _
```

) As Boolean

SOLIDWORKS Type Library

GetAllowedRelations Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAllowedRelations( _  
    ByVal Entities As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetRelations Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelations( _  
    ByVal Filter As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetRelationsCount Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelationsCount( _  
    ByVal Filter As Long _  
) As Long
```

SOLIDWORKS Type Library

IAddRelation Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddRelation( _  
    ByVal NumEntities As Long, _  
    ByRef EntityArray As Object, _  
    ByVal RelationType As Long _  
) As SketchRelation
```

SOLIDWORKS Type Library

IGetAllowedRelations Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAllowedRelations( _  
    ByVal NumEntities As Long, _  
    ByRef EntityArray As Object, _  
    ByVal NumAllowedRelations As Long _  
) As Long
```

SOLIDWORKS Type Library

IGetAllowedRelationsCount Method (SketchRelationManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAllowedRelationsCount( _  
    ByVal NumEntities As Long, _  
    ByRef EntityArray As Object _  
    ) As Long
```

SOLIDWORKS Type Library

IGetRelations Method (SketchRelationManager)



Syntax

Visual Basic for Applications (VBA)


```
Public Function IGetRelations( _  
    ByVal Filter As Long, _  
    ByVal Count As Long _  
    ) As SketchRelation
```

SketchSegment (Type)

SOLIDWORKS Type Library

SketchSegment Object

Object Model



SOLIDWORKS Type Library

SketchSegment Object Members

Public Methods

 CreateWireBody
 DeSelect
 EqualSegment
 GetConstraints
 GetCurve
 GetID
 GetLength
 GetName
 GetRelations
 GetRelationsCount
 GetSketch
 GetSketchPathCount
 GetSketchPaths
 GetSketchSlot
 GetType
 IGetConstraints
 IGetConstraintsCount
 IGetCurve
 IGetID
 IGetRelations
 IGetSketchPaths
 IsBendLine
 JogLine
 Select

 Select2
 Select3
 Select4
 SelectByMark
 SelectChain
 SplitEntity

 Public Properties

 Color
 ConstructionGeometry
 Layer
 LayerOverride
 Status
 Style
 Width

SOLIDWORKS Type Library

Color Property (SketchSegment)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Color As Long
```

SOLIDWORKS Type Library

ConstructionGeometry Property (SketchSegment)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property ConstructionGeometry As Boolean
```

SOLIDWORKS Type Library

CreateWireBody Method (SketchSegment)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateWireBody() As Body2
```

SOLIDWORKS Type Library

DeSelect Method (SketchSegment)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelect() As Boolean
```

SOLIDWORKS Type Library

EqualSegment Method (SketchSegment)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function EqualSegment( _
    ByVal SketchType As Integer, _
    ByVal SegmentPoints As Integer _
) As Boolean
```

SOLIDWORKS Type Library

GetConstraints Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConstraints() As Variant
```

SOLIDWORKS Type Library

GetCurve Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCurve() As Object
```

SOLIDWORKS Type Library

GetID Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetID() As Variant
```

SOLIDWORKS Type Library

GetLength Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLength() As Double
```

SOLIDWORKS Type Library

GetName Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetName() As String
```

SOLIDWORKS Type Library

GetRelations Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelations() As Variant
```

SOLIDWORKS Type Library

GetRelationsCount Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelationsCount() As Long
```

SOLIDWORKS Type Library

GetSketch Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketch() As Sketch
```

SOLIDWORKS Type Library

GetSketchPathCount Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPathCount() As Long
```

SOLIDWORKS Type Library

GetSketchPaths Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchPaths() As Variant
```

SOLIDWORKS Type Library

GetSketchSlot Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSketchSlot() As SketchSlot
```

SOLIDWORKS Type Library

GetType Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

IGetConstraints Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetConstraints() As String
```

SOLIDWORKS Type Library

IGetConstraintsCount Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetConstraintsCount() As Long
```

SOLIDWORKS Type Library

IGetCurve Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetCurve() As Curve
```

SOLIDWORKS Type Library

IGetID Method (SketchSegment)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetID() As Long
```

SOLIDWORKS Type Library

IGetRelations Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRelations( _  
    ByVal Count As Long _  
) As SketchRelation
```

SOLIDWORKS Type Library

IGetSketchPaths Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPaths( _  
    ByVal Count As Long _  
) As SketchPath
```

SOLIDWORKS Type Library

IsBendLine Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBendLine() As Boolean
```

SOLIDWORKS Type Library

JogLine Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub JogLine( _  
    ByVal X0nLine As Double, _  
    ByVal Y0nLine As Double, _  
    ByVal Z0nLine As Double, _  
    ByVal X0nJog As Double, _  
    ByVal Y0nJog As Double, _  
    ByVal Z0nJog As Double _  
)
```

SOLIDWORKS Type Library

Layer Property (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Layer As String
```

SOLIDWORKS Type Library

LayerOverride Property (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Property LayerOverride As Integer
```

SOLIDWORKS Type Library

Select Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal AppendFlag As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

Select2 Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select2( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

Select3 Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select3( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long, _  
    ByVal Callout As Callout _  
) As Boolean
```

SOLIDWORKS Type Library

Select4 Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select4( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
) As Boolean
```

SOLIDWORKS Type Library

SelectByMark Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectByMark( _  
    ByVal AppendFlag As Boolean, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SelectChain Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectChain( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
) As Boolean
```

SOLIDWORKS Type Library

SplitEntity Method (SketchSegment)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SplitEntity( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal ClosedX As Double, _  
    ByVal ClosedY As Double, _  
    ByVal ClosedZ As Double _  
)
```

SOLIDWORKS Type Library

Status Property (SketchSegment)



Visual Basic for Applications (VBA)

```
Public Property Status As Long
```

SOLIDWORKS Type Library

Style Property (SketchSegment)



Visual Basic for Applications (VBA)

```
Public Property Style As Long
```

SOLIDWORKS Type Library

Width Property (SketchSegment)



Visual Basic for Applications (VBA)


```
Public Property Width As Long
```

SketchSlot (Type)

SOLIDWORKS Type Library

SketchSlot Object

Object Model



SOLIDWORKS Type Library

SketchSlot Object Members

Public Methods

-  [GetCenterPoint](#)
-  [GetCenterPointHandle](#)
-  [GetSlotPoints](#)

Public Properties

-  [CenterArcDirection](#)
-  [CreationType](#)
-  [Length](#)
-  [LengthType](#)
-  [Width](#)

SOLIDWORKS Type Library

CenterArcDirection Property (SketchSlot)

Syntax

Visual Basic for Applications (VBA)

Public Property CenterArcDirection As Long

SOLIDWORKS Type Library

CreationType Property (SketchSlot)

Syntax

Visual Basic for Applications (VBA)

Public Property CreationType As Long

SOLIDWORKS Type Library

GetCenterPoint Method (SketchSlot)

Syntax

Visual Basic for Applications (VBA)

Public Function GetCenterPoint() As [MathPoint](#)

SOLIDWORKS Type Library

GetCenterPointHandle Method (SketchSlot)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCenterPointHandle() As SketchPoint
```

SOLIDWORKS Type Library

GetSlotPoints Method (SketchSlot)



Visual Basic for Applications (VBA)

```
Public Function GetSlotPoints() As Variant
```

SOLIDWORKS Type Library

Length Property (SketchSlot)



Visual Basic for Applications (VBA)

```
Public Property Length As Double
```

SOLIDWORKS Type Library

LengthType Property (SketchSlot)



Visual Basic for Applications (VBA)

```
Public Property LengthType As Long
```

SOLIDWORKS Type Library

Width Property (SketchSlot)




Visual Basic for Applications (VBA)

```
Public Property Width As Double
```

SketchSpline (Type)

SOLIDWORKS Type Library
SketchSpline Object

Object Model



SOLIDWORKS Type Library
SketchSpline Object Members

Public Methods

	AddCurvatureControl
	AddTangencyControl
	DeletePoint
	GetControlVertexWeights
	GetEquationParameters
	GetEquationParameters2
	GetPointCount
	GetPoints
	GetPoints2
	GetSplineHandleCount
	GetSplineHandles
	IEnumPoints
	IGetPoints
	IGetSplineHandles
	InsertPoint
	MakeRational
	ModifyControlPoint
	ModifyKnot
	RelaxSpline
	ResetAllHandles
	SetControlVertexWeights
	SetEquationParameters
	SetEquationParameters2
	Simplify

Public Properties

	CurveDegree
--	-----------------------------

 CurveType
 DisplayControlPolygon
 IsRationalCurve
 IsStyleSpline
 Proportional
 ShowCurvatureCombs
 ShowInflectionPoints
 ShowMinimumRadius
 ShowSplineHandles

SOLIDWORKS Type Library

AddCurvatureControl Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCurvatureControl( _
    ByVal XPos As Double, _
    ByVal YPos As Double, _
    ByVal ZPos As Double _
) As SplineHandle
```

SOLIDWORKS Type Library

AddTangencyControl Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddTangencyControl( _
    ByVal XPos As Double, _
    ByVal YPos As Double, _
    ByVal ZPos As Double _
) As SplineHandle
```

SOLIDWORKS Type Library

CurveDegree Property (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CurveDegree As Long
```

SOLIDWORKS Type Library

CurveType Property (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CurveType As Long
```

SOLIDWORKS Type Library

DeletePoint Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeletePoint( _
    ByVal Point As SketchPoint _
) As Boolean
```

SOLIDWORKS Type Library

DisplayControlPolygon Property (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayControlPolygon As Boolean
```

SOLIDWORKS Type Library

GetControlVertexWeights Method (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetControlVertexWeights() As Variant
```

SOLIDWORKS Type Library

GetEquationParameters Method (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEquationParameters( _  
    ByRef YExpression As String, _  
    ByRef RangeStart As Double, _  
    ByRef RangeEnd As Double, _  
    ByRef IsAngleRange As Boolean, _  
    ByRef RotationAngle As Double, _  
    ByRef XOffset As Double, _  
    ByRef YOffset As Double, _  
    ByRef LockStart As Boolean, _  
    ByRef LockEnd As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

GetEquationParameters2 Method (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEquationParameters2( _  
    ByRef XExpression As String, _  
    ByRef YExpression As String, _  
    ByRef ZExpression As String, _  
    ByRef RangeStart As Double, _  
    ByRef RangeEnd As Double, _  
    ByRef IsAngleRange As Boolean, _  
    ByRef RotationAngle As Double, _  
    ByRef XOffset As Double, _  
    ByRef YOffset As Double, _  
    ByRef LockStart As Boolean, _  
    ByRef LockEnd As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

GetPointCount Method (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPointCount() As Long
```

SOLIDWORKS Type Library

GetPoints Method (SketchSpline)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPoints() As Variant
```

SOLIDWORKS Type Library

GetPoints2 Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function GetPoints2() As Variant
```

SOLIDWORKS Type Library

GetSplineHandleCount Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function GetSplineHandleCount() As Long
```

SOLIDWORKS Type Library

GetSplineHandles Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function GetSplineHandles() As Variant
```

SOLIDWORKS Type Library

IEnumPoints Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function IEnumPoints() As EnumSketchPoints
```

SOLIDWORKS Type Library

IGetPoints Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function IGetPoints() As Double
```

SOLIDWORKS Type Library

IGetSplineHandles Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function IGetSplineHandles( _  
    ByVal Count As Long _  
) As SplineHandle
```

SOLIDWORKS Type Library

InsertPoint Method (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Function InsertPoint( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IsRationalCurve Property (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IsRationalCurve As Boolean
```

SOLIDWORKS Type Library

IsStyleSpline Property (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IsStyleSpline As Boolean
```

SOLIDWORKS Type Library

MakeRational Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MakeRational( _  
    ByVal Val As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

ModifyControlPoint Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ModifyControlPoint( _  
    ByVal Index As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

ModifyKnot Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ModifyKnot( _  
    ByVal Index As Long, _  
    ByVal DKnot As Double _  
) As Boolean
```

SOLIDWORKS Type Library

Proportional Property (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Proportional As Boolean
```

SOLIDWORKS Type Library

RelaxSpline Method (SketchSpline)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RelaxSpline()
```

ResetAllHandles Method (SketchSpline) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ResetAllHandles()
```

SetControlVertexWeights Method (SketchSpline) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetControlVertexWeights( _  
    ByVal ControlWeightValues As Variant _  
) As Boolean
```

SetEquationParameters Method (SketchSpline) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetEquationParameters( _  
    ByVal YExpression As String, _  
    ByVal RangeStart As Double, _  
    ByVal RangeEnd As Double, _  
    ByVal IsAngleRange As Boolean, _  
    ByVal RotationAngle As Double, _  
    ByVal XOffset As Double, _  
    ByVal YOffset As Double, _  
    ByVal LockStart As Boolean, _  
    ByVal LockEnd As Boolean _  
) As Boolean
```

SetEquationParameters2 Method (SketchSpline) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetEquationParameters2( _  
    ByVal XExpression As String, _  
    ByVal YExpression As String, _  
    ByVal ZExpression As String, _  
    ByVal RangeStart As Double, _  
    ByVal RangeEnd As Double, _  
    ByVal IsAngleRange As Boolean, _  
    ByVal RotationAngle As Double, _  
    ByVal XOffset As Double, _  
    ByVal YOffset As Double, _  
    ByVal LockStart As Boolean, _  
    ByVal LockEnd As Boolean _  
) As Boolean
```

ShowCurvatureCombs Property (SketchSpline) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ShowCurvatureCombs As Boolean
```

ShowInflectionPoints Property (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Property ShowInflectionPoints As Boolean
```

SOLIDWORKS Type Library

ShowMinimumRadius Property (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Property ShowMinimumRadius As Boolean
```

SOLIDWORKS Type Library

ShowSplineHandles Property (SketchSpline)



Visual Basic for Applications (VBA)

```
Public Property ShowSplineHandles As Boolean
```

SOLIDWORKS Type Library

Simplify Method (SketchSpline)




Visual Basic for Applications (VBA)

```
Public Sub Simplify( _  
    ByVal ToleranceIn As Double _  
)
```

SketchText (Type)

SOLIDWORKS Type Library
SketchText Object

Object Model



SOLIDWORKS Type Library
SketchText Object Members

Public Methods

 EnumEdges
 GetCoordinates
 GetEdges
 GetEdges2
 GetTextFormat
 GetUseDocTextFormat
 IGetCoordinates
 IGetTextFormat
 ISetTextFormat
 SetCoordinates
 SetTextFormat

Public Properties

 Text
--

SOLIDWORKS Type Library
EnumEdges Method (SketchText)

Syntax

```
Visual Basic for Applications (VBA)

Public Function EnumEdges() As EnumEdges
```

SOLIDWORKS Type Library
GetCoordinates Method (SketchText)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetCoordinates() As Variant
```

SOLIDWORKS Type Library
GetEdges Method (SketchText)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetEdges() As Variant
```

SOLIDWORKS Type Library

GetEdges2 Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdges2() As Variant
```

SOLIDWORKS Type Library

GetTextFormat Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextFormat() As Object
```

SOLIDWORKS Type Library

GetUseDocTextFormat Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseDocTextFormat() As Boolean
```

SOLIDWORKS Type Library

IGetCoordinates Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetCoordinates() As Double
```

SOLIDWORKS Type Library

IGetTextFormat Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTextFormat() As TextFormat
```

SOLIDWORKS Type Library

ISetTextFormat Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetTextFormat( _  
    ByVal UseDoc As Boolean, _  
    ByVal TextFormat As TextFormat _  
) As Boolean
```

SOLIDWORKS Type Library

SetCoordinates Method (SketchText)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetCoordinates( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetTextFormat Method (SketchText)



Visual Basic for Applications (VBA)

```
Public Function SetTextFormat( _  
    ByVal UseDoc As Boolean, _  
    ByVal TextFormat As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

Text Property (SketchText)



Visual Basic for Applications (VBA)

```
Public Property Text As String
```

SldHotfix (Type)

SOLIDWORKS Type Library

SldHotfix Object

Object Model

SldHotfix

SOLIDWORKS Type Library

SldHotfix Object Members

Public Methods

[Command](#)

[IsSupported](#)

SOLIDWORKS Type Library

Command Method (SldHotfix)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Command( _  
    ByVal CmdID As Long, _  
    ByVal Args As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

IsSupported Method (SldHotfix)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSupported( _  
    ByVal IdStr As String _  
    ) As Long
```

SOLIDWORKS Type Library

IGetSelectionFiltersCount Method (SldWorks)



Visual Basic for Applications (VBA)

```
Public Function IGetSelectionFiltersCount() As Long
```

SldWorks (Namespace Overview)

SOLIDWORKS Type Library

LoadFile2 Method (SldWorks)



Visual Basic for Applications (VBA)

```
Public Function LoadFile2( _  
    ByVal FileName As String, _  
    ByVal ArgString As String _  
) As Boolean
```