

SOLIDWORKS API (VB6 COM) — Reference (92/102): Surface-SurfaceRadiateFeatureData

SOLIDWORKS API Documentation (converted from CHM)

Surface (Type)

SOLIDWORKS Type Library
Surface Object

Object Model

Surface

- GetBSurfParams3 (BSurfParamData)
- GetProjectedPointOn (MathPoint)
- ICopy (Surface)
- ICreateNewCurve (Curve)
- ICreateTrimmedSheet (Body)
- ICreateTrimmedSheet2 (Body2)
- ICreateTrimmedSheet3 (Body2)
- ICreateTrimmedSheet4 (Body)
- IGetProfileCurve (Curve)
- IMakeIsoCurve (Curve)
- MakeIsoCurve2 (Curve)
- Parameterization2 (SurfaceParameterizationData)

SOLIDWORKS Type Library
Surface Object Members

Public Methods

	AddTrimmingLoop
	AddTrimmingLoop2
	Copy
	CreateNewCurve
	CreateTrimmedSheet
	CreateTrimmedSheet4
	CreateTrimmedSheet5
	Evaluate
	EvaluateAtPoint
	FindMinimumRadius
	GetBSurfParams
	GetBSurfParams2
	GetBSurfParams3
	GetClosestPointOn
	GetExtrusionsurfParams
	GetIntersectCurveCount

	
	<u>GetIntersectCurveCount2</u>
	<u>GetIntersectSurfaceCount</u>
	<u>GetOffsetSurfParams</u>
	<u>GetOffsetSurfParams2</u>
	<u>GetProfileCurve</u>
	<u>GetProjectedPointOn</u>
	<u>GetRevsurfParams</u>
	<u>IAddTrimmingLoop</u>
	<u>IAddTrimmingLoop2</u>
	<u>ICopy</u>
	<u>ICreateNewCurve</u>
	<u>ICreateTrimmedSheet</u>
	<u>ICreateTrimmedSheet2</u>
	<u>ICreateTrimmedSheet3</u>
	<u>ICreateTrimmedSheet4</u>
	<u>Identity</u>
	<u>IEvaluate</u>
	<u>IEvaluateAtPoint</u>
	<u>IFindMinimumRadius</u>
	<u>IGetBSurfParams</u>
	<u>IGetBSurfParamsSize</u>
	<u>IGetBSurfParamsSize2</u>
	<u>IGetBSurfParamsSize3</u>
	<u>IGetClosestPointOn</u>
	<u>IGetExtrusionsurfParams</u>
	<u>IGetMaketsoCurvesCount</u>
	<u>IGetOffsetSurfParams2</u>
	<u>IGetProfileCurve</u>
	<u>IGetRevsurfParams</u>
	<u>IntersectCurve</u>
	<u>IntersectCurve2</u>
	<u>IntersectSurface</u>
	<u>IMaketsoCurve</u>
	<u>IMaketsoCurves</u>
	<u>IntersectCurve</u>
	<u>IntersectCurve2</u>
	<u>IntersectSurface</u>
	<u>IParameterization</u>
	<u>IReverseEvaluate</u>
	<u>IsBlending</u>
	<u>IsCone</u>
	<u>IsCylinder</u>
	<u>IsForeign</u>

	
	IsOffset
	IsParametric
	IsPlane
	IsRevolved
	IsSphere
	IsSwept
	IsTorus
	MakeIsoCurve
	MakeIsoCurve2
	MakeIsoCurves
	Parameterization
	Parameterization2
	ReverseEvaluate

Public Properties

	ConeParams
	ConeParams2
	CylinderParams
	IConeParams
	ICylinderParams
	IPlaneParams
	ISphereParams
	ITorusParams
	PlaneParams
	SphereParams
	TorusParams

SOLIDWORKS Type Library

AddTrimmingLoop Method (Surface)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AddTrimmingLoop(_ ByVal NCrvs As Long, _ ByVal VOrder As Variant, _ ByVal VDim As Variant, _ ByVal VPeriodic As Variant, _ ByVal VNumKnots As Variant, _ ByVal VNumCtrlPoints As Variant, _ ByVal VKnots As Variant, _ ByVal VCtrlPointDbls As Variant _) As Boolean</pre>

SOLIDWORKS Type Library

AddTrimmingLoop2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AddTrimmingLoop2(_ ByVal NCrvs As Long, _ ByVal VOrder As Variant, _</pre>

```
ByVal VDim As Variant, _  
ByVal VPeriodic As Variant, _  
ByVal VNumKnots As Variant, _  
ByVal VNumCtrlPoints As Variant, _  
ByVal VKnots As Variant, _  
ByVal VCtrlPointDbls As Variant, _  
ByVal UvRange As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

ConeParams Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ConeParams As Variant
```

SOLIDWORKS Type Library

ConeParams2 Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ConeParams2 As Variant
```

SOLIDWORKS Type Library

Copy Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Copy() As Object
```

SOLIDWORKS Type Library

CreateNewCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateNewCurve() As Object
```

SOLIDWORKS Type Library

CreateTrimmedSheet Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedSheet( _  
    ByVal Curves As Variant _  
) As Object
```

SOLIDWORKS Type Library

CreateTrimmedSheet4 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedSheet4( _  
    ByVal Curves As Variant, _  
    ByVal PreserveAnalyticCurves As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreateTrimmedSheet5 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedSheet5( _  
    ByVal Curves As Variant, _  
    ByVal PreserveAnalyticCurves As Boolean, _  
    ByVal Tolerance As Double _  
) As Object
```

SOLIDWORKS Type Library

CylinderParams Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CylinderParams As Variant
```

SOLIDWORKS Type Library

Evaluate Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Evaluate( _  
    ByVal UParam As Double, _  
    ByVal VParam As Double, _  
    ByVal NumUDeriv As Long, _  
    ByVal NumVDeriv As Long _  
) As Variant
```

SOLIDWORKS Type Library

EvaluateAtPoint Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EvaluateAtPoint( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
) As Variant
```

SOLIDWORKS Type Library

FindMinimumRadius Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function FindMinimumRadius( _  
    ByVal UBound As Variant, _  
    ByVal VBound As Variant, _  
    ByRef NumOfRadius As Long, _  
    ByRef Radius As Variant, _  
    ByRef Location As Variant, _  
    ByRef UVPParameter As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

GetBSurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBSurfParams( _  
    ByVal WantCubicRational As Boolean, _  
    ByVal VP0 As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetBSurfParams2 Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function GetBSurfParams2( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNonRational As Boolean, _  
    ByVal VP0 As Variant, _  
    ByVal Tolerance As Double, _  
    ByRef Sense As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetBSurfParams3 Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function GetBSurfParams3( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNonRational As Boolean, _  
    ByVal VP0 As Object, _  
    ByVal Tolerance As Double, _  
    ByRef Sense As Boolean _  
) As BSurfParamData
```

SOLIDWORKS Type Library

GetClosestPointOn Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function GetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetExtrusionsurfParams Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function GetExtrusionsurfParams() As Variant
```

SOLIDWORKS Type Library

GetIntersectCurveCount Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function GetIntersectCurveCount( _  
    ByVal OtherCurve As Curve, _  
    ByRef CurveBound As Double _  
) As Long
```

SOLIDWORKS Type Library

GetIntersectCurveCount2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectCurveCount2( _  
    ByVal OtherCurve As Curve, _  
    ByRef CurveBound As Double _  
) As Long
```

SOLIDWORKS Type Library

GetIntersectSurfaceCount Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectSurfaceCount( _  
    ByVal OtherSurface As Surface _  
) As Long
```

SOLIDWORKS Type Library

GetOffsetSurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOffsetSurfParams() As Double
```

SOLIDWORKS Type Library

GetOffsetSurfParams2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOffsetSurfParams2( _  
    ByRef BaseSurf As Object, _  
    ByRef Sense As Boolean _  
) As Double
```

SOLIDWORKS Type Library

GetProfileCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileCurve() As Object
```

SOLIDWORKS Type Library

GetProjectedPointOn Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProjectedPointOn( _  
    ByVal Point As MathPoint, _  
    ByVal Direction As MathVector _  
) As MathPoint
```

SOLIDWORKS Type Library

GetRevsurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRevsurfParams() As Variant
```

IAddTrimmingLoop Method (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Sub IAddTrimmingLoop( _  
    ByVal CurveCount As Long, _  
    ByRef Order As Long, _  
    ByRef Dim As Long, _  
    ByRef Periodic As Long, _  
    ByRef NumKnots As Long, _  
    ByRef NumCtrlPoints As Long, _  
    ByRef Knots As Double, _  
    ByRef CtrlPointDbls As Double _  
)
```

IAddTrimmingLoop2 Method (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Sub IAddTrimmingLoop2( _  
    ByVal CurveCount As Long, _  
    ByRef Order As Long, _  
    ByRef Dim As Long, _  
    ByRef Periodic As Long, _  
    ByRef NumKnots As Long, _  
    ByRef NumCtrlPoints As Long, _  
    ByRef Knots As Double, _  
    ByRef CtrlPointDbls As Double, _  
    ByRef UvRange As Double _  
)
```

IConeParams Property (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Property IConeParams As Double
```

ICopy Method (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function ICopy() As Surface
```

ICreateNewCurve Method (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function ICreateNewCurve() As Curve
```

ICreateTrimmedSheet Method (Surface)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function ICreateTrimmedSheet( _  
    ByVal NCurves As Long, _  
    ByVal Curves As Curve _  
    ) As Body
```

SOLIDWORKS Type Library

ICreateTrimmedSheet2 Method (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateTrimmedSheet2( _  
    ByVal NCurves As Long, _  
    ByVal Curves As Curve _  
    ) As Body2
```

SOLIDWORKS Type Library

ICreateTrimmedSheet3 Method (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateTrimmedSheet3( _  
    ByVal NCurves As Long, _  
    ByVal Curves As Curve _  
    ) As Body2
```

SOLIDWORKS Type Library

ICreateTrimmedSheet4 Method (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateTrimmedSheet4( _  
    ByVal NCurves As Long, _  
    ByVal Curves As Curve, _  
    ByVal PreserveAnalyticCurves As Boolean _  
    ) As Body
```

SOLIDWORKS Type Library

ICylinderParams Property (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ICylinderParams As Double
```

SOLIDWORKS Type Library

Identity Method (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Function Identity() As Long
```

SOLIDWORKS Type Library

IEvaluate Method (Surface)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IEvaluate( _  
    ByVal UParam As Double, _  
    ByVal VParam As Double, _  
    ByVal NumUDeriv As Long, _
```

```
    ByVal NumVDeriv As Long _  
  ) As Double
```

SOLIDWORKS Type Library

IEvaluateAtPoint Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IEvaluateAtPoint( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
  ) As Double
```

SOLIDWORKS Type Library

IFindMinimumRadius Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFindMinimumRadius( _  
    ByRef UBound As Double, _  
    ByRef VBound As Double, _  
    ByRef NumOfRadius As Long, _  
    ByRef Radius As Variant, _  
    ByRef Location As Variant, _  
    ByRef UVParameter As Variant _  
  ) As Boolean
```

SOLIDWORKS Type Library

IGetBSurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBSurfParams() As Double
```

SOLIDWORKS Type Library

IGetBSurfParamsSize Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBSurfParamsSize( _  
    ByVal WantCubicRational As Boolean, _  
    ByRef Range As Double _  
  ) As Long
```

SOLIDWORKS Type Library

IGetBSurfParamsSize2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBSurfParamsSize2( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNonRational As Boolean, _  
    ByRef Range As Double _  
  ) As Long
```

SOLIDWORKS Type Library

IGetBSurfParamsSize3 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBSurfParamsSize3( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNonRational As Boolean, _  
    ByRef Range As Double, _  
    ByVal Tolerance As Double, _  
    ByRef Sense As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

IGetClosestPointOn Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IGetExtrusionsurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetExtrusionsurfParams() As Double
```

SOLIDWORKS Type Library

IGetMakeIsoCurvesCount Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMakeIsoCurvesCount( _  
    ByRef UvRange As Double, _  
    ByRef Dir As Double, _  
    ByVal Angle As Double, _  
    ByVal Tol As Double _  
    ) As Long
```

SOLIDWORKS Type Library

IGetOffsetSurfParams2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetOffsetSurfParams2( _  
    ByRef BaseSurf As Surface, _  
    ByRef Sense As Boolean _  
    ) As Double
```

SOLIDWORKS Type Library

IGetProfileCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProfileCurve() As Curve
```

SOLIDWORKS Type Library

IGetRevsurfParams Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRevsurfParams() As Double
```

SOLIDWORKS Type Library

IntersectCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IIntersectCurve( _  
    ByVal OtherCurve As Curve, _  
    ByRef CurveBound As Double, _  
    ByVal PointCount As Long, _  
    ByRef PointArray As Double, _  
    ByRef TArray As Double, _  
    ByRef UvArray As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IntersectCurve2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IIntersectCurve2( _  
    ByVal OtherCurve As Curve, _  
    ByRef CurveBound As Double, _  
    ByVal PointCount As Long, _  
    ByRef PointArray As Double, _  
    ByRef TArray As Double, _  
    ByRef UvArray As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IntersectSurface Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IIntersectSurface( _  
    ByVal OtherSurf As Surface, _  
    ByVal CurveCount As Long, _  
    ByRef CurveArray As Curve, _  
    ByRef BoundsArray As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IMakeIsoCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMakeIsoCurve( _  
    ByVal UorV As Boolean, _  
    ByVal UvValue As Double _  
) As Curve
```

SOLIDWORKS Type Library

IMakeIsoCurves Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMakeIsoCurves( _  
    ByRef UvRange As Double, _  
    ByRef Dir As Double, _  
    ByVal Angle As Double, _
```

```
ByVal Tol As Double, _  
ByVal CurveCount As Long, _  
ByRef Curves As Curve, _  
ByRef CurveBounds As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IntersectCurve Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IntersectCurve( _  
    ByVal OtherCurve As Object, _  
    ByVal CurveBound As Variant, _  
    ByRef PointArray As Variant, _  
    ByRef TArray As Variant, _  
    ByRef UvArray As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

IntersectCurve2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IntersectCurve2( _  
    ByVal OtherCurve As Object, _  
    ByVal CurveBound As Variant, _  
    ByRef PointArray As Variant, _  
    ByRef TArray As Variant, _  
    ByRef UvArray As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

IntersectSurface Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IntersectSurface( _  
    ByVal OtherSurf As Object, _  
    ByRef CurveArray As Variant, _  
    ByRef BoundsArray As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

IParameterization Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IParameterization() As Double
```

SOLIDWORKS Type Library

IPlaneParams Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IPlaneParams As Double
```

SOLIDWORKS Type Library

IRverseEvaluate Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IReverseEvaluate( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IsBlending Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsBlending() As Boolean
```

SOLIDWORKS Type Library

IsCone Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsCone() As Boolean
```

SOLIDWORKS Type Library

IsCylinder Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsCylinder() As Boolean
```

SOLIDWORKS Type Library

IsForeign Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsForeign() As Boolean
```

SOLIDWORKS Type Library

IsOffset Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsOffset() As Boolean
```

SOLIDWORKS Type Library

IsParametric Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsParametric() As Boolean
```

SOLIDWORKS Type Library

ISphereParams Property (Surface)



Visual Basic for Applications (VBA)

```
Public Property ISphereParams As Double
```

SOLIDWORKS Type Library

IsPlane Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsPlane() As Boolean
```

SOLIDWORKS Type Library

IsRevolved Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsRevolved() As Boolean
```

SOLIDWORKS Type Library

IsSphere Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsSphere() As Boolean
```

SOLIDWORKS Type Library

IsSwept Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsSwept() As Boolean
```

SOLIDWORKS Type Library

IsTorus Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function IsTorus() As Boolean
```

SOLIDWORKS Type Library

ITorusParams Property (Surface)



Visual Basic for Applications (VBA)

```
Public Property ITorusParams As Double
```

SOLIDWORKS Type Library

MakeIsoCurve Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function MakeIsoCurve( _  
    ByVal UorV As Boolean, _  
    ByVal UvValue As Double _  
) As Object
```

SOLIDWORKS Type Library

MakeIsoCurve2 Method (Surface)



Visual Basic for Applications (VBA)

```
Public Function MakeIsoCurve2( _  
    ByVal UorV As Boolean, _  
    ByRef UvValue As Double _  
    ) As Curve
```

SOLIDWORKS Type Library

MakIsoCurves Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MakeIsoCurves( _  
    ByVal UvRange As Variant, _  
    ByVal Dir As Variant, _  
    ByVal Angle As Double, _  
    ByVal Tol As Double, _  
    ByRef Curves As Variant, _  
    ByRef CurveBounds As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

Parameterization Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Parameterization() As Variant
```

SOLIDWORKS Type Library

Parameterization2 Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Parameterization2() As SurfaceParameterizationData
```

SOLIDWORKS Type Library

PlaneParams Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PlaneParams As Variant
```

SOLIDWORKS Type Library

ReverseEvaluate Method (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReverseEvaluate( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
    ) As Variant
```

SOLIDWORKS Type Library

SphereParams Property (Surface)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SphereParams As Variant
```



Syntax


Visual Basic for Applications (VBA)

Public Property TorusParams As Variant

SurfaceExtendFeatureData (Type)

SOLIDWORKS Type Library
SurfaceExtendFeatureData Object

Object Model



SOLIDWORKS Type Library
SurfaceExtendFeatureData Object Members

Public Methods

	AccessSelections
	GetItemsCount
	GetPropagatingEdgesCount
	AccessSelections
	GetItems
	IGetPropagatingEdges
	SetItems
	SetPropagatingEdges
	ReleaseSelectionAccess

Public Properties

	Distance
	EndCondition
	Face
	IFace
	Items
	IVertex
	PropagatingEdges
	Type
	Vertex

SOLIDWORKS Type Library
AccessSelections Method (SurfaceExtendFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

Distance Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Distance As Double
```

SOLIDWORKS Type Library

EndCondition Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property EndCondition As Long
```

SOLIDWORKS Type Library

Face Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Face As Object
```

SOLIDWORKS Type Library

GetItemsCount Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetItemsCount() As Long
```

SOLIDWORKS Type Library

GetPropagatingEdgesCount Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPropagatingEdgesCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IFace Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IFace As Face2
```

SOLIDWORKS Type Library

IGetItems Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetItems( _  
    ByVal Count As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetPropagatingEdges Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPropagatingEdges( _  
    ByVal Count As Long _  
) As Edge
```

SOLIDWORKS Type Library

ISetItems Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetItems( _  
    ByVal Count As Long, _  
    ByRef ItemArr As Object _  
)
```

SOLIDWORKS Type Library

ISetPropagatingEdges Method (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetPropagatingEdges( _  
    ByVal Count As Long, _  
    ByVal EdgeArr As Edge _  
)
```

SOLIDWORKS Type Library

Items Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Items As Variant
```

SOLIDWORKS Type Library

IVertex Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IVertex As Vertex
```

SOLIDWORKS Type Library

PropagatingEdges Property (SurfaceExtendFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PropagatingEdges As Variant
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceExtendFeatureData)

Syntax

Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

Type Property (SurfaceExtendFeatureData)



Public Property Type As Long

SOLIDWORKS Type Library

Vertex Property (SurfaceExtendFeatureData)



Public Property Vertex As Object

SurfaceFlattenFeatureData (Type)

SOLIDWORKS Type Library
SurfaceFlattenFeatureData Object

Object Model

SurfaceFlattenFeatureData

SOLIDWORKS Type Library
SurfaceFlattenFeatureData Object Members

Public Methods

- AccessSelections
- ReleaseSelectionAccess

Public Properties

- AccuracyFactor
- Faces
- FixPointVertex
- GuideEdges
- KeepInternalControlCurves
- MapEdges
- ShouldMakeTears
- TearEdges

SOLIDWORKS Type Library
AccessSelections Method (SurfaceFlattenFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library
AccuracyFactor Property (SurfaceFlattenFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AccuracyFactor As Long
```

SOLIDWORKS Type Library
Faces Property (SurfaceFlattenFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Faces As Variant
```

SOLIDWORKS Type Library
FixPointVertex Property (SurfaceFlattenFeatureData)

Syntax

Public Property FixPointVertex As Object

SOLIDWORKS Type Library

GuideEdges Property (SurfaceFlattenFeatureData)



Public Property GuideEdges As Variant

SOLIDWORKS Type Library

KeepInternalControlCurves Property (SurfaceFlattenFeatureData)



Public Property KeepInternalControlCurves As Boolean

SOLIDWORKS Type Library

MapEdges Property (SurfaceFlattenFeatureData)



Public Property MapEdges As Variant

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceFlattenFeatureData)



Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

ShouldMakeTears Property (SurfaceFlattenFeatureData)



Public Property ShouldMakeTears As Boolean

SOLIDWORKS Type Library

TearEdges Property (SurfaceFlattenFeatureData)



Public Property TearEdges As Variant

SurfaceKnitFeatureData (Type)

SOLIDWORKS Type Library

SurfaceKnitFeatureData Object

Object Model

SurfaceKnitFeatureData

SOLIDWORKS Type Library

SurfaceKnitFeatureData Object Members

Public Methods

	AccessSelections
	GetEntitiesCount
	IAccessSelections
	IGetEntities
	ISetEntities
	ReleaseSelectionAccess

Public Properties

	Entities
	KnitTolerance
	MaxValueForGapRange
	MinValueForGapRange
	SeedFace
	UseGapFilters
	UseMergeEntities
	UseTryToFormSolid

SOLIDWORKS Type Library

AccessSelections Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AccessSelections(_ ByVal TopDoc As Object, _ ByVal Component As Object _) As Boolean</pre>

SOLIDWORKS Type Library

Entities Property (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Property Entities As Variant</pre>

SOLIDWORKS Type Library

GetEntitiesCount Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntitiesCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetEntities Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntities( _  
    ByVal Count As Long _  
    ) As Object
```

SOLIDWORKS Type Library

ISetEntities Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetEntities( _  
    ByVal Count As Long, _  
    ByRef FaceArr As Object _  
    )
```

SOLIDWORKS Type Library

KnitTolerance Property (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property KnitTolerance As Double
```

SOLIDWORKS Type Library

MaxValueForGapRange Property (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaxValueForGapRange As Double
```

SOLIDWORKS Type Library

MinValueForGapRange Property (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MinValueForGapRange As Double
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceKnitFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SeedFace Property (SurfaceKnitFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SeedFace As Object
```

SOLIDWORKS Type Library

UseGapFilters Property (SurfaceKnitFeatureData)



Visual Basic for Applications (VBA)

```
Public Property UseGapFilters As Boolean
```

SOLIDWORKS Type Library

UseMergeEntities Property (SurfaceKnitFeatureData)



Visual Basic for Applications (VBA)

```
Public Property UseMergeEntities As Boolean
```

SOLIDWORKS Type Library

UseTryToFormSolid Property (SurfaceKnitFeatureData)



Visual Basic for Applications (VBA)

```
Public Property UseTryToFormSolid As Boolean
```

SurfaceOffsetFeatureData (Type)

SOLIDWORKS Type Library

SurfaceOffsetFeatureData Object

Object Model

SurfaceOffsetFeatureData

IGetFaces (Face2)

SOLIDWORKS Type Library

SurfaceOffsetFeatureData Object Members

Public Methods

	AccessSelections
	GetEntitiesCount
	GetFacesCount
	IAccessSelections
	IGetEntities
	IGetFaces
	ISetEntities
	ISetFaces
	ReleaseSelectionAccess

Public Properties

	Distance
	Entities
	Faces
	Flip

SOLIDWORKS Type Library

AccessSelections Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AccessSelections(_ ByVal TopDoc As Object, _ ByVal Component As Object _) As Boolean</pre>

SOLIDWORKS Type Library

Distance Property (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Property Distance As Double</pre>

SOLIDWORKS Type Library

Entities Property (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Entities As Variant

SOLIDWORKS Type Library

Faces Property (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Faces As Variant

SOLIDWORKS Type Library

Flip Property (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Flip As Boolean

SOLIDWORKS Type Library

GetEntitiesCount Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Function GetEntitiesCount() As Long

SOLIDWORKS Type Library

GetFacesCount Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Function GetFacesCount() As Long

SOLIDWORKS Type Library

IAccessSelections Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetEntities Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntities( _  
    ByVal Count As Long _  
    ) As Object
```

SOLIDWORKS Type Library

IGetFaces Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFaces( _  
    ByVal Count As Long _  
    ) As Face2
```

SOLIDWORKS Type Library

ISetEntities Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetEntities( _  
    ByVal Count As Long, _  
    ByRef EntityArray As Object _  
    )
```

SOLIDWORKS Type Library

ISetFaces Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetFaces( _  
    ByVal Count As Long, _  
    ByVal FaceArr As Face2 _  
    )
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceOffsetFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SurfaceParameterizationData (Type)

SOLIDWORKS Type Library
SurfaceParameterizationData Object

Object Model

SurfaceParameterizationData

SOLIDWORKS Type Library
SurfaceParameterizationData Object Members

Public Properties

- UMax
- UMaxBoundType
- UMin
- UMinBoundType
- UProperties
- UPROPERTYNumber
- VMax
- VMaxBoundType
- VMin
- VMinBoundType
- VProperties
- VPROPERTYNumber

SOLIDWORKS Type Library
UMax Property (SurfaceParameterizationData)

Syntax

Visual Basic for Applications (VBA)

Public Property UMax As Double

SOLIDWORKS Type Library
UMaxBoundType Property (SurfaceParameterizationData)

Syntax

Visual Basic for Applications (VBA)

Public Property UMaxBoundType As Long

SOLIDWORKS Type Library
UMin Property (SurfaceParameterizationData)

Syntax

Visual Basic for Applications (VBA)

Public Property UMin As Double

SOLIDWORKS Type Library
UMinBoundType Property (SurfaceParameterizationData)

Syntax

Visual Basic for Applications (VBA)

Public Property UMinBoundType As Long

SOLIDWORKS Type Library

UProperties Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property UProperties As Variant

SOLIDWORKS Type Library

UPROPERTYNUMBER Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property UPROPERTYNUMBER As Long

SOLIDWORKS Type Library

VMax Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VMax As Double

SOLIDWORKS Type Library

VMaxBoundType Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VMaxBoundType As Long

SOLIDWORKS Type Library

VMin Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VMin As Double

SOLIDWORKS Type Library

VMinBoundType Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VMinBoundType As Long

SOLIDWORKS Type Library

VProperties Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VProperties As Variant

SOLIDWORKS Type Library

VPROPERTYNUMBER Property (SurfaceParameterizationData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property VPropertyNumber As Long

SurfacePlanarFeatureData (Type)

SOLIDWORKS Type Library
SurfacePlanarFeatureData Object

Object Model

SurfacePlanarFeatureData

SOLIDWORKS Type Library
SurfacePlanarFeatureData Object Members

Public Methods

 AccessSelections
 GetBoundingEntitiesCount
 IAccessSelections
 IGetBoundingEntities
 ISetBoundingEntities
 ReleaseSelectionAccess

Public Properties

 BoundingEntities
--

SOLIDWORKS Type Library
AccessSelections Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AccessSelections(_ ByVal TopDoc As Object, _ ByVal Component As Object _) As Boolean</pre>

SOLIDWORKS Type Library
BoundingEntities Property (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Property BoundingEntities As Variant</pre>

SOLIDWORKS Type Library
GetBoundingEntitiesCount Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetBoundingEntitiesCount() As Long</pre>

SOLIDWORKS Type Library
IAccessSelections Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function IAccessSelections(_ ByVal TopDoc As ModelDoc2, _</pre>

```
    ByVal Component As Component2 _  
  ) As Boolean
```

SOLIDWORKS Type Library

IGetBoundingEntities Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBoundingEntities( _  
    ByVal Count As Long _  
  ) As Object
```

SOLIDWORKS Type Library

ISetBoundingEntities Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetBoundingEntities( _  
    ByVal Count As Long _  
  ) As Object
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfacePlanarFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SurfaceRadiateFeatureData (Type)

SOLIDWORKS Type Library
SurfaceRadiateFeatureData Object

 Object Model

SurfaceRadiateFeatureData

SOLIDWORKS Type Library
SurfaceRadiateFeatureData Object Members

 Public Methods

 AccessSelections
 GetRadiatedEntitiesCount
 IAccessSelections
 IGetRadiatedEntities
 ISetRadiatedEntities
 ReleaseSelectionAccess

 Public Properties

 DirectionReference
 Distance
 Flip
 PropagateToTangentFaces
 RadiatedEntities

SOLIDWORKS Type Library
AccessSelections Method (SurfaceRadiateFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
DirectionReference Property (SurfaceRadiateFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Property DirectionReference As Object
```

SOLIDWORKS Type Library
Distance Property (SurfaceRadiateFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Property Distance As Double
```

SOLIDWORKS Type Library
Flip Property (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

Public Property Flip As Boolean

SOLIDWORKS Type Library

GetRadiatedEntitiesCount Method (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

Public Function GetRadiatedEntitiesCount() As Long

SOLIDWORKS Type Library

IAccessSelections Method (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetRadiatedEntities Method (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IGetRadiatedEntities( _  
    ByVal Count As Long _  
    ) As Object
```

SOLIDWORKS Type Library

ISetRadiatedEntities Method (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ISetRadiatedEntities( _  
    ByVal Count As Long, _  
    ByRef DispArr As Object _  
    )
```

SOLIDWORKS Type Library

PropagateToTangentFaces Property (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

Public Property PropagateToTangentFaces As Boolean

SOLIDWORKS Type Library

RadiatedEntities Property (SurfaceRadiateFeatureData)



Visual Basic for Applications (VBA)

Public Property RadiatedEntities As Variant

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceRadiateFeatureData)



```
Public Sub ReleaseSelectionAccess()
```