

# **SOLIDWORKS API (VB6 COM) — Reference (93/102): SurfaceTrimFeatureData- SWPropertySheet**

SOLIDWORKS API Documentation (converted from CHM)

# SurfaceTrimFeatureData (Type)

SOLIDWORKS Type Library  
SurfaceTrimFeatureData Object

## Object Model

SurfaceTrimFeatureData

IGetPiecesToKeep (Body2)

SOLIDWORKS Type Library  
SurfaceTrimFeatureData Object Members

## Public Methods

|                                                                                     |                                        |
|-------------------------------------------------------------------------------------|----------------------------------------|
|    | <a href="#">AccessSelections</a>       |
|    | <a href="#">GetPiecesToKeepCount</a>   |
|    | <a href="#">GetTrimToolsCount</a>      |
|    | <a href="#">GetType</a>                |
|    | <a href="#">IAccessSelections</a>      |
|    | <a href="#">IGetPiecesToKeep</a>       |
|    | <a href="#">IGetTrimTools</a>          |
|    | <a href="#">ISetPiecesToKeep</a>       |
|   | <a href="#">ISetTrimTools</a>          |
|  | <a href="#">ReleaseSelectionAccess</a> |

## Public Properties

|                                                                                     |                              |
|-------------------------------------------------------------------------------------|------------------------------|
|  | <a href="#">PiecesToKeep</a> |
|  | <a href="#">TrimTools</a>    |

SOLIDWORKS Type Library  
AccessSelections Method (SurfaceTrimFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library  
GetPiecesToKeepCount Method (SurfaceTrimFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)

Public Function GetPiecesToKeepCount() As Long
```

SOLIDWORKS Type Library  
GetTrimToolsCount Method (SurfaceTrimFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)
```

```
Public Function GetTrimToolsCount() As Long
```

SOLIDWORKS Type Library

**GetType Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

**IAccessSelections Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

**IGetPiecesToKeep Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPiecesToKeep( _  
    ByVal Count As Long _  
) As Body2
```

SOLIDWORKS Type Library

**IGetTrimTools Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimTools( _  
    ByVal Count As Long _  
) As Object
```

SOLIDWORKS Type Library

**ISetPiecesToKeep Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetPiecesToKeep( _  
    ByVal Count As Long, _  
    ByVal BodyArr As Body2 _  
)
```

SOLIDWORKS Type Library

**ISetTrimTools Method (SurfaceTrimFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetTrimTools( _  
    ByVal Count As Long, _  
    ByRef DispArr As Object _  
)
```

SOLIDWORKS Type Library

PiecesToKeep Property (SurfaceTrimFeatureData)



Visual Basic for Applications (VBA)

Public Property PiecesToKeep As Variant

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfaceTrimFeatureData)



Visual Basic for Applications (VBA)

Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

TrimTools Property (SurfaceTrimFeatureData)



Visual Basic for Applications (VBA)

Public Property TrimTools As Variant

# SurfCutFeatureData (Type)

SOLIDWORKS Type Library

SurfCutFeatureData Object

## Object Model

SurfCutFeatureData

IGetFeatureScopeBodies (Body2)

SOLIDWORKS Type Library

SurfCutFeatureData Object Members

## Public Methods

|                                                                                   |                                            |
|-----------------------------------------------------------------------------------|--------------------------------------------|
|  | <a href="#">AccessSelections</a>           |
|  | <a href="#">GetBodyIndexKept</a>           |
|  | <a href="#">GetFeatureScopeBodiesCount</a> |
|  | <a href="#">IAccessSelections</a>          |
|  | <a href="#">IGetFeatureScopeBodies</a>     |
|  | <a href="#">ISetFeatureScopeBodies</a>     |
|  | <a href="#">ReleaseSelectionAccess</a>     |

## Public Properties

|                                                                                     |                                    |
|-------------------------------------------------------------------------------------|------------------------------------|
|  | <a href="#">AutoSelect</a>         |
|  | <a href="#">FeatureScope</a>       |
|  | <a href="#">FeatureScopeBodies</a> |
|  | <a href="#">Flip</a>               |
|  | <a href="#">SurfaceForCut</a>      |

SOLIDWORKS Type Library

AccessSelections Method (SurfCutFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

AutoSelect Property (SurfCutFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)

Public Property AutoSelect As Boolean
```

SOLIDWORKS Type Library

FeatureScope Property (SurfCutFeatureData)

## Syntax

```
Visual Basic for Applications (VBA)
```

Public Property FeatureScope As Boolean

SOLIDWORKS Type Library

**FeatureScopeBodies Property (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

Public Property FeatureScopeBodies As Variant

SOLIDWORKS Type Library

**Flip Property (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

Public Property Flip As Boolean

SOLIDWORKS Type Library

**GetBodyIndexKept Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

Public Function GetBodyIndexKept() As Integer

SOLIDWORKS Type Library

**GetFeatureScopeBodiesCount Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

Public Function GetFeatureScopeBodiesCount() As Long

SOLIDWORKS Type Library

**IAccessSelections Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

**IGetFeatureScopeBodies Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

```
Public Function IGetFeatureScopeBodies( _  
    ByVal Count As Long _  
) As Body2
```

SOLIDWORKS Type Library

**ISetFeatureScopeBodies Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub ISetFeatureScopeBodies( _  
    ByVal Count As Long, _
```

```
ByVal BodyArr As Body2 _  
)
```

SOLIDWORKS Type Library

**ReleaseSelectionAccess Method (SurfCutFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

**SurfaceForCut Property (SurfCutFeatureData)**



Visual Basic for Applications (VBA)


```
Public Property SurfaceForCut As Object
```

# SurfExtrudeFeatureData (Type)

SOLIDWORKS Type Library

SurfExtrudeFeatureData Object

Object Model



SOLIDWORKS Type Library

SurfExtrudeFeatureData Object Members

Public Methods

|                                                                                     |                                        |
|-------------------------------------------------------------------------------------|----------------------------------------|
|    | <a href="#">AccessSelections</a>       |
|    | <a href="#">GetDepth</a>               |
|    | <a href="#">GetEndCondition</a>        |
|    | <a href="#">GetFace</a>                |
|    | <a href="#">GetReverseOffset</a>       |
|    | <a href="#">GetTranslateSurface</a>    |
|    | <a href="#">GetVertex</a>              |
|   | <a href="#">IAccessSelections</a>      |
|  | <a href="#">IGetFace</a>               |
|  | <a href="#">IGetVertex</a>             |
|  | <a href="#">ISetFace</a>               |
|  | <a href="#">ISetVertex</a>             |
|  | <a href="#">ReleaseSelectionAccess</a> |
|  | <a href="#">SetDepth</a>               |
|  | <a href="#">SetEndCondition</a>        |
|  | <a href="#">SetFace</a>                |
|  | <a href="#">SetReverseOffset</a>       |
|  | <a href="#">SetTranslateSurface</a>    |
|  | <a href="#">SetVertex</a>              |

Public Properties

|                                                                                     |                                |
|-------------------------------------------------------------------------------------|--------------------------------|
|  | <a href="#">BothDirections</a> |
|  | <a href="#">D1CapEnd</a>       |
|  | <a href="#">D1DraftAngle</a>   |
|  | <a href="#">D1DraftOn</a>      |
|  | <a href="#">D1DraftOutward</a> |
|  | <a href="#">D2CapEnd</a>       |
|  | <a href="#">D2DraftAngle</a>   |
|  | <a href="#">D2DraftOn</a>      |
|  | <a href="#">D2DraftOutward</a> |



 [DeleteOriginalFace](#)

 [KnitResult](#)

 [ReverseDirection](#)

SOLIDWORKS Type Library

### AccessSelections Method (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

### BothDirections Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property BothDirections As Boolean
```

SOLIDWORKS Type Library

### D1CapEnd Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property D1CapEnd As Boolean
```

SOLIDWORKS Type Library

### D1DraftAngle Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property D1DraftAngle As Double
```

SOLIDWORKS Type Library

### D1DraftOn Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property D1DraftOn As Boolean
```

SOLIDWORKS Type Library

### D1DraftOutward Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property D1DraftOutward As Boolean
```

SOLIDWORKS Type Library

### D2CapEnd Property (SurfExtrudeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property D2CapEnd As Boolean
```

SOLIDWORKS Type Library

## D2DraftAngle Property (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2DraftAngle As Double
```

SOLIDWORKS Type Library

## D2DraftOn Property (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2DraftOn As Boolean
```

SOLIDWORKS Type Library

## D2DraftOutward Property (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2DraftOutward As Boolean
```

SOLIDWORKS Type Library

## DeleteOriginalFace Property (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Property DeleteOriginalFace As Boolean
```

SOLIDWORKS Type Library

## GetDepth Method (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetDepth( _  
    ByVal Forward As Boolean _  
) As Double
```

SOLIDWORKS Type Library

## GetEndCondition Method (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetEndCondition( _  
    ByVal Forward As Boolean _  
) As Integer
```

SOLIDWORKS Type Library

## GetFace Method (SurfExtrudeFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetFace( _  
    ByVal Forward As Boolean _  
) As Object
```

SOLIDWORKS Type Library

## GetReverseOffset Method (SurfExtrudeFeatureData)

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReverseOffset( _  
    ByVal Fwd As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

**GetTranslateSurface Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTranslateSurface( _  
    ByVal Fwd As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

**GetVertex Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function GetVertex( _  
    ByVal Forward As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

**IAccessSelections Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

**IGetFace Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFace( _  
    ByVal Forward As Boolean _  
    ) As Face2
```

SOLIDWORKS Type Library

**IGetVertex Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetVertex( _  
    ByVal Forward As Boolean _  
    ) As Vertex
```

SOLIDWORKS Type Library

**ISetFace Method (SurfExtrudeFeatureData)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetFace( _  
    ByVal Forward As Boolean, _
```

```
    ByVal Face As Face2 _  
)
```

SOLIDWORKS Type Library

#### ISetVertex Method (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetVertex(  
    ByVal Forward As Boolean, _  
    ByVal Vtx As Vertex _  
)
```

SOLIDWORKS Type Library

#### KnitResult Property (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Property KnitResult As Boolean
```

SOLIDWORKS Type Library

#### ReleaseSelectionAccess Method (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

#### ReverseDirection Property (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

#### SetDepth Method (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDepth( _  
    ByVal Forward As Boolean, _  
    ByVal Depth As Double _  
)
```

SOLIDWORKS Type Library

#### SetEndCondition Method (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetEndCondition( _  
    ByVal Forward As Boolean, _  
    ByVal EndCondition As Integer _  
)
```

SOLIDWORKS Type Library

#### SetFace Method (SurfExtrudeFeatureData)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetFace( _  
    ByVal Forward As Boolean, _  
    ByVal Face As Object _  
)
```

SOLIDWORKS Type Library

**SetReverseOffset Method (SurfExtrudeFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetReverseOffset( _  
    ByVal Fwd As Boolean, _  
    ByVal RevOffset As Boolean _  
)
```

SOLIDWORKS Type Library

**SetTranslateSurface Method (SurfExtrudeFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetTranslateSurface( _  
    ByVal Fwd As Boolean, _  
    ByVal Trans As Boolean _  
)
```

SOLIDWORKS Type Library

**SetVertex Method (SurfExtrudeFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetVertex( _  
    ByVal Forward As Boolean, _  
    ByVal Vtx As Object _  
)
```

# SurfRevolveFeatureData (Type)

SOLIDWORKS Type Library

SurfRevolveFeatureData Object

Object Model

SurfRevolveFeatureData

SOLIDWORKS Type Library

SurfRevolveFeatureData Object Members

Public Methods

-  [AccessSelections](#)
-  [GetRevolutionAngle](#)
-  [IAccessSelections](#)
-  [ReleaseSelectionAccess](#)
-  [SetRevolutionAngle](#)

Public Properties

-  [ReverseDirection](#)
-  [Type](#)

SOLIDWORKS Type Library

AccessSelections Method (SurfRevolveFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

GetRevolutionAngle Method (SurfRevolveFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetRevolutionAngle( _
    ByVal Forward As Boolean _
) As Double
```

SOLIDWORKS Type Library

IAccessSelections Method (SurfRevolveFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (SurfRevolveFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

**ReverseDirection Property (SurfRevolveFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

**SetRevolutionAngle Method (SurfRevolveFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub SetRevolutionAngle( _  
    ByVal Forward As Boolean, _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

**Type Property (SurfRevolveFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property Type As Integer
```

# SweepFeatureData (Type)

SOLIDWORKS Type Library  
SweepFeatureData Object

Object Model

SweepFeatureData

IGetFeatureScopeBodies (Body2)

SOLIDWORKS Type Library  
SweepFeatureData Object Members

Public Methods

|                                                                                     |                                                 |
|-------------------------------------------------------------------------------------|-------------------------------------------------|
|    | <a href="#">AccessSelections</a>                |
|    | <a href="#">GetCutSweepOption</a>               |
|    | <a href="#">GetD2TwistAngle</a>                 |
|    | <a href="#">GetFeatureScopeBodiesCount</a>      |
|    | <a href="#">GetGuideCurvesCount</a>             |
|    | <a href="#">GetGuideCurvesType</a>              |
|    | <a href="#">GetPathAlignmentDirectionVector</a> |
|    | <a href="#">GetPathType</a>                     |
|   | <a href="#">GetProfileType</a>                  |
|  | <a href="#">GetTwistAngle</a>                   |
|  | <a href="#">GetWallThickness</a>                |
|  | <a href="#">IAccessSelections</a>               |
|  | <a href="#">IGetFeatureScopeBodies</a>          |
|  | <a href="#">IGetGuideCurves</a>                 |
|  | <a href="#">IGetGuideCurvesType</a>             |
|  | <a href="#">IsBossFeature</a>                   |
|  | <a href="#">ISetFeatureScopeBodies</a>          |
|  | <a href="#">ISetGuideCurves</a>                 |
|  | <a href="#">IsThinFeature</a>                   |
|  | <a href="#">ReleaseSelectionAccess</a>          |
|  | <a href="#">SetD2TwistAngle</a>                 |
|  | <a href="#">SetPathAlignmentDirectionVector</a> |
|  | <a href="#">SetTwistAngle</a>                   |
|  | <a href="#">SetWallThickness</a>                |

Public Properties

|                                                                                     |                                      |
|-------------------------------------------------------------------------------------|--------------------------------------|
|  | <a href="#">AdvancedSmoothing</a>    |
|  | <a href="#">AlignWithEndFaces</a>    |
|  | <a href="#">AssemblyFeatureScope</a> |
|  | <a href="#">AutoSelect</a>           |
|  | <a href="#">AutoSelectComponents</a> |
|                                                                                     | <a href="#">CircularProfile</a>      |



|                                                                                                                           |  |
|---------------------------------------------------------------------------------------------------------------------------|--|
|                                           |  |
|  <a href="#">CircularProfileDiameter</a> |  |
|  <a href="#">D1ReverseTwistDir</a>       |  |
|  <a href="#">D2ReverseTwistDir</a>       |  |
|  <a href="#">Direction</a>               |  |
|  <a href="#">EndDirectionVector</a>      |  |
|  <a href="#">EndTangencyType</a>         |  |
|  <a href="#">FeatureScope</a>            |  |
|  <a href="#">FeatureScopeBodies</a>      |  |
|  <a href="#">GuideCurves</a>             |  |
|  <a href="#">MaintainTangency</a>        |  |
|  <a href="#">Merge</a>                   |  |
|  <a href="#">MergeSmoothFaces</a>        |  |
|  <a href="#">Path</a>                    |  |
|  <a href="#">PathAlignmentType</a>       |  |
|  <a href="#">Profile</a>                 |  |
|  <a href="#">PropagateFeatureToParts</a> |  |
|  <a href="#">StartDirectionVector</a>    |  |
|  <a href="#">StartTangencyType</a>       |  |
|  <a href="#">SweepType</a>               |  |
|  <a href="#">TangentPropagation</a>      |  |
|  <a href="#">ThinFeature</a>            |  |
|  <a href="#">ThinWallType</a>          |  |
|  <a href="#">TwistControlType</a>      |  |

SOLIDWORKS Type Library

AccessSelections Method (SweepFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

AdvancedSmoothing Property (SweepFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AdvancedSmoothing As Boolean
```

SOLIDWORKS Type Library

AlignWithEndFaces Property (SweepFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AlignWithEndFaces As Boolean
```

SOLIDWORKS Type Library

SOLIDWORKS Type Library

**AssemblyFeatureScope Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property AssemblyFeatureScope As Boolean
```

SOLIDWORKS Type Library

**AutoSelect Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoSelect As Boolean
```

SOLIDWORKS Type Library

**AutoSelectComponents Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoSelectComponents As Boolean
```

SOLIDWORKS Type Library

**CircularProfile Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property CircularProfile As Boolean
```

SOLIDWORKS Type Library

**CircularProfileDiameter Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property CircularProfileDiameter As Double
```

SOLIDWORKS Type Library

**D1ReverseTwistDir Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1ReverseTwistDir As Boolean
```

SOLIDWORKS Type Library

**D2ReverseTwistDir Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2ReverseTwistDir As Boolean
```

SOLIDWORKS Type Library

**Direction Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property Direction As Long
```

SOLIDWORKS Type Library

SOLIDWORKS Type Library

**EndDirectionVector Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property EndDirectionVector As Object
```

SOLIDWORKS Type Library

**EndTangencyType Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property EndTangencyType As Integer
```

SOLIDWORKS Type Library

**FeatureScope Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property FeatureScope As Boolean
```

SOLIDWORKS Type Library

**FeatureScopeBodies Property (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Property FeatureScopeBodies As Variant
```

SOLIDWORKS Type Library

**GetCutSweepOption Method (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCutSweepOption() As Long
```

SOLIDWORKS Type Library

**GetD2TwistAngle Method (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetD2TwistAngle() As Double
```

SOLIDWORKS Type Library

**GetFeatureScopeBodiesCount Method (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatureScopeBodiesCount() As Long
```

SOLIDWORKS Type Library

**GetGuideCurvesCount Method (SweepFeatureData)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGuideCurvesCount() As Integer
```

SOLIDWORKS Type Library

## GetGuideCurvesType Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGuideCurvesType() As Variant
```

SOLIDWORKS Type Library

## GetPathAlignmentDirectionVector Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathAlignmentDirectionVector( _  
    ByRef Type As Long _  
    ) As Object
```

SOLIDWORKS Type Library

## GetPathType Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathType() As Long
```

SOLIDWORKS Type Library

## GetProfileType Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileType() As Long
```

SOLIDWORKS Type Library

## GetTwistAngle Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTwistAngle() As Double
```

SOLIDWORKS Type Library

## GetWallThickness Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetWallThickness( _  
    ByVal Forward As Boolean _  
    ) As Double
```

SOLIDWORKS Type Library

## GuideCurves Property (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property GuideCurves As Variant
```

SOLIDWORKS Type Library

## IAccessSelections Method (SweepFeatureData)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

**IGetFeatureScopeBodies Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeatureScopeBodies( _  
    ByVal Count As Long _  
    ) As Body2
```

SOLIDWORKS Type Library

**IGetGuideCurves Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetGuideCurves( _  
    ByVal Count As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

**IGetGuideCurvesType Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetGuideCurvesType( _  
    ByVal Count As Long _  
    ) As Long
```

SOLIDWORKS Type Library

**IsBossFeature Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBossFeature() As Boolean
```

SOLIDWORKS Type Library

**ISetFeatureScopeBodies Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetFeatureScopeBodies( _  
    ByVal Count As Long, _  
    ByVal BodyArr As Body2 _  
    )
```

SOLIDWORKS Type Library

**ISetGuideCurves Method (SweepFeatureData)**

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetGuideCurves( _  
    ByVal Count As Integer, _  
    ByRef PDisp As Object _  
    )
```

SOLIDWORKS Type Library

### IsThinFeature Method (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IsThinFeature() As Boolean
```

SOLIDWORKS Type Library

### MaintainTangency Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property MaintainTangency As Boolean
```

SOLIDWORKS Type Library

### Merge Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Merge As Boolean
```

SOLIDWORKS Type Library

### MergeSmoothFaces Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property MergeSmoothFaces As Boolean
```

SOLIDWORKS Type Library

### Path Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Path As Object
```

SOLIDWORKS Type Library

### PathAlignmentType Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property PathAlignmentType As Long
```

SOLIDWORKS Type Library

### Profile Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Profile As Object
```

SOLIDWORKS Type Library

### PropagateFeatureToParts Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property PropagateFeatureToParts As Boolean
```

SOLIDWORKS Type Library

### ReleaseSelectionAccess Method (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

### SetD2TwistAngle Method (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetD2TwistAngle( _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

### SetPathAlignmentDirectionVector Method (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetPathAlignmentDirectionVector( _  
    ByVal Dir As Object _  
)
```

SOLIDWORKS Type Library

### SetTwistAngle Method (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetTwistAngle( _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

### SetWallThickness Method (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetWallThickness( _  
    ByVal Forward As Boolean, _  
    ByVal WallThickness As Double _  
)
```

SOLIDWORKS Type Library

### StartDirectionVector Property (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property StartDirectionVector As Object
```

SOLIDWORKS Type Library

### StartTangencyType Property (SweepFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property StartTangencyType As Integer
```

SOLIDWORKS Type Library

## SweepType Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SweepType As Long
```

SOLIDWORKS Type Library

## TangentPropagation Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property TangentPropagation As Boolean
```

SOLIDWORKS Type Library

## ThinFeature Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ThinFeature As Boolean
```

SOLIDWORKS Type Library

## ThinWallType Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ThinWallType As Integer
```

SOLIDWORKS Type Library

## TwistControlType Property (SweepFeatureData)



Visual Basic for Applications (VBA)

```
Public Property TwistControlType As Integer
```



# SweptFlangeFeatureData (Type)

SOLIDWORKS Type Library

SweptFlangeFeatureData Object

## Object Model

SweptFlangeFeatureData

SOLIDWORKS Type Library

SweptFlangeFeatureData Object Members

## Public Methods

|                                                                                   |                                         |
|-----------------------------------------------------------------------------------|-----------------------------------------|
|  | <a href="#">AccessSelections</a>        |
|  | <a href="#">GetCustomBendAllowance</a>  |
|  | <a href="#">GetErrorCodes</a>           |
|  | <a href="#">GetGaugeTableParameters</a> |
|  | <a href="#">GetPathType</a>             |
|  | <a href="#">ReleaseSelectionAccess</a>  |
|  | <a href="#">SetCustomBendAllowance</a>  |
|  | <a href="#">SetGaugeTableParameters</a> |

## Public Properties

|                                                                                     |                                                     |
|-------------------------------------------------------------------------------------|-----------------------------------------------------|
|   | <a href="#">BendRadius</a>                          |
|  | <a href="#">CylindricalOrConicalEdge</a>            |
|  | <a href="#">EndOffset</a>                           |
|  | <a href="#">FlangePosition</a>                      |
|  | <a href="#">FlattenAlongPath</a>                    |
|  | <a href="#">MaterialInside</a>                      |
|  | <a href="#">OverrideDefaultSheetMetalParameters</a> |
|  | <a href="#">Path</a>                                |
|  | <a href="#">Profile</a>                             |
|  | <a href="#">ReliefDepth</a>                         |
|  | <a href="#">ReliefRatio</a>                         |
|  | <a href="#">ReliefType</a>                          |
|  | <a href="#">ReliefWidth</a>                         |
|  | <a href="#">ReverseDirection</a>                    |
|  | <a href="#">StartOffset</a>                         |
|  | <a href="#">Thickness</a>                           |
|  | <a href="#">TrimSideBends</a>                       |
|  | <a href="#">UseDefaultBendAllowance</a>             |
|  | <a href="#">UseDefaultBendRelief</a>                |
|  | <a href="#">UseDefaultRadius</a>                    |
|  | <a href="#">UseGaugeTable</a>                       |
|  | <a href="#">UseMaterialSheetMetalParameters</a>     |



SOLIDWORKS Type Library

### AccessSelections Method (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

### BendRadius Property (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property BendRadius As Double
```

SOLIDWORKS Type Library

### CylindricalOrConicalEdge Property (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property CylindricalOrConicalEdge As Object
```

SOLIDWORKS Type Library

### EndOffset Property (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property EndOffset As Double
```

SOLIDWORKS Type Library

### FlangePosition Property (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property FlangePosition As Long
```

SOLIDWORKS Type Library

### FlattenAlongPath Property (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Property FlattenAlongPath As Boolean
```

SOLIDWORKS Type Library

### GetCustomBendAllowance Method (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCustomBendAllowance() As Object
```

SOLIDWORKS Type Library

### GetErrorCodes Method (SweptFlangeFeatureData)

#### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetErrorCodes() As Long
```

SOLIDWORKS Type Library

**GetGaugeTableParameters Method (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Function GetGaugeTableParameters() As Object
```

SOLIDWORKS Type Library

**GetPathType Method (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Function GetPathType() As Long
```

SOLIDWORKS Type Library

**MaterialInside Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property MaterialInside As Boolean
```

SOLIDWORKS Type Library

**OverrideDefaultSheetMetalParameters Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property OverrideDefaultSheetMetalParameters As Boolean
```

SOLIDWORKS Type Library

**Path Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property Path As Variant
```

SOLIDWORKS Type Library

**Profile Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Property Profile As Object
```

SOLIDWORKS Type Library

**ReleaseSelectionAccess Method (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

**ReliefDepth Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReliefDepth As Double

SOLIDWORKS Type Library

**ReliefRatio Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReliefRatio As Double

SOLIDWORKS Type Library

**ReliefType Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReliefType As Long

SOLIDWORKS Type Library

**ReliefWidth Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReliefWidth As Double

SOLIDWORKS Type Library

**ReverseDirection Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property ReverseDirection As Boolean

SOLIDWORKS Type Library

**SetCustomBendAllowance Method (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub SetCustomBendAllowance( _  
    ByVal PBendData As Object _  
)
```

SOLIDWORKS Type Library

**SetGaugeTableParameters Method (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

```
Public Sub SetGaugeTableParameters( _  
    ByVal DispIn As Object _  
)
```

SOLIDWORKS Type Library

**StartOffset Property (SweptFlangeFeatureData)**



Visual Basic for Applications (VBA)

Public Property StartOffset As Double

SOLIDWORKS Type Library

## Thickness Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property Thickness As Double

SOLIDWORKS Type Library

## TrimSideBends Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property TrimSideBends As Boolean

SOLIDWORKS Type Library

## UseDefaultBendAllowance Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseDefaultBendAllowance As Boolean

SOLIDWORKS Type Library

## UseDefaultBendRelief Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseDefaultBendRelief As Boolean

SOLIDWORKS Type Library

## UseDefaultRadius Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseDefaultRadius As Boolean

SOLIDWORKS Type Library

## UseGaugeTable Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseGaugeTable As Boolean

SOLIDWORKS Type Library

## UseMaterialSheetMetalParameters Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseMaterialSheetMetalParameters As Boolean

SOLIDWORKS Type Library

## UseReliefRatio Property (SweptFlangeFeatureData)



Visual Basic for Applications (VBA)

Public Property UseReliefRatio As Boolean

# SwOLEObject (Type)

SOLIDWORKS Type Library  
SwOLEObject Object

Object Model

SwOLEObject

SOLIDWORKS Type Library  
SwOLEObject Object Members

Public Methods

|                                                                                                                  |
|------------------------------------------------------------------------------------------------------------------|
|  <a href="#">IGetBoundaries</a> |
|  <a href="#">IGetBuffer</a>     |
|  <a href="#">ISetBoundaries</a> |
|  <a href="#">Refresh</a>        |
|  <a href="#">Select</a>         |
|  <a href="#">SetActive</a>      |

Public Properties

|                                                                                                                |
|----------------------------------------------------------------------------------------------------------------|
|  <a href="#">Aspect</a>       |
|  <a href="#">Boundaries</a>   |
|  <a href="#">Buffer</a>      |
|  <a href="#">BufferSize</a> |
|  <a href="#">Clsid</a>      |
|  <a href="#">FileName</a>   |
|  <a href="#">IsLinked</a>   |

SOLIDWORKS Type Library  
Aspect Property (SwOLEObject)

Syntax

|                                     |
|-------------------------------------|
| Visual Basic for Applications (VBA) |
| Public Property Aspect As Long      |

SOLIDWORKS Type Library  
Boundaries Property (SwOLEObject)

Syntax

|                                       |
|---------------------------------------|
| Visual Basic for Applications (VBA)   |
| Public Property Boundaries As Variant |

SOLIDWORKS Type Library  
Buffer Property (SwOLEObject)

Syntax

|                                     |
|-------------------------------------|
| Visual Basic for Applications (VBA) |
| Public Property Buffer As Variant   |

SOLIDWORKS Type Library  
BufferSize Property (SwOLEObject)



## Syntax

Visual Basic for Applications (VBA)

```
Public Property BufferSize As Long
```

SOLIDWORKS Type Library

**Clsid Property (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Property Clsid As String
```

SOLIDWORKS Type Library

**FileName Property (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Property FileName As String
```

SOLIDWORKS Type Library

**IGetBoundaries Method (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetBoundaries( _  
    ByRef Boundary As Double _  
)
```

SOLIDWORKS Type Library

**IGetBuffer Method (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetBuffer( _  
    ByVal OleBufferSize As Long, _  
    ByRef BOldData As Byte _  
)
```

SOLIDWORKS Type Library

**ISetBoundaries Method (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetBoundaries( _  
    ByRef Boundary As Double _  
)
```

SOLIDWORKS Type Library

**IsLinked Property (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

```
Public Property IsLinked As Boolean
```

SOLIDWORKS Type Library

**Refresh Method (SwOLEObject)**



## Syntax

Visual Basic for Applications (VBA)

Public Sub Refresh()

SOLIDWORKS Type Library

Select Method (SwOLEObject)



Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal Append As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetActive Method (SwOLEObject)



Visual Basic for Applications (VBA)

```
Public Function SetActive( _  
    ByVal Active As Boolean _  
    ) As Object
```



# SwPEClassFactory (Type)

SOLIDWORKS Type Library  
SwPEClassFactory Object

Object Model

SwPEClassFactory

SOLIDWORKS Type Library  
SwPEClassFactory Object Members



Public Methods

SetPartnerKey

SOLIDWORKS Type Library  
SetPartnerKey Method (SwPEClassFactory)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPartnerKey( _  
    ByVal StrPartnerEntitlement As String, _  
    ByRef TokenObject As Object _  
) As Long
```

# SwPEToken (Type)

SOLIDWORKS Type Library

SwPEToken Object

 Object Model

SwPEToken

SOLIDWORKS Type Library

SwPEToken Object Members



# SWPropertySheet (Type)

SOLIDWORKS Type Library  
SWPropertySheet Object

Object Model

SWPropertySheet

SOLIDWORKS Type Library  
SWPropertySheet Object Members

Public Methods

- AddActivePage
- AddPage
- AddPagex64
- GetControl
- RemovePage

Events

- CreateControlNotify
- DestroyNotify
- HelpNotify
- OnCancelNotify
- OnOKNotify

SOLIDWORKS Type Library  
AddActivePage Method (SWPropertySheet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddActivePage( _  
    ByVal Title As String, _  
    ByVal ProgId As String, _  
    ByVal LicenseKey As String _  
    ) As Long
```

SOLIDWORKS Type Library  
AddPage Method (SWPropertySheet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPage( _  
    ByVal Page As Long _  
    ) As Long
```

SOLIDWORKS Type Library  
AddPagex64 Method (SWPropertySheet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPagex64( _  
    ByVal Page As Unknown _  
    ) As Long
```

**CreateControlNotify Event (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Event CreateControlNotify( _  
    ByVal PageIndex As Long, _  
    ByVal ControlDispatch As Object _  
)
```

**DestroyNotify Event (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Event DestroyNotify()
```

**GetControl Method (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetControl( _  
    ByVal PageIndex As Long _  
) As Unknown
```

**HelpNotify Event (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Event HelpNotify( _  
    ByVal PageIndex As Long _  
)
```

**OnCancelNotify Event (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Event OnCancelNotify()
```

**OnOKNotify Event (SWPropertySheet)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Event OnOKNotify()
```

**RemovePage Method (SWPropertySheet)**

```
Public Function RemovePage( _  
    ByVal Page As Long _  
) As Long
```