

SOLIDWORKS Enumerations (swconst) — Reference (5/17): swDatumTag, TextParts_e, swDistanceMateArcConditions_e

SOLIDWORKS API Documentation (converted from CHM)

swDatumTagTextParts_e (Type)

 

SolidWorks.Interop.swconst Namespace : swDatumTagTextParts_e Enumeration

Text parts of datum tags.

 Syntax

Visual Basic (Declaration)

Public Enum swDatumTagTextParts_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDatumTagTextParts_e](#)

C#

public enum swDatumTagTextParts_e : System.Enum

C++/CLI

public enum class swDatumTagTextParts_e : public System.Enum

 Members

Member	Description
swDatumTagTextCalloutAbove	3
swDatumTagTextCalloutBelow	4
swDatumTagTextPrefix	1
swDatumTagTextSuffix	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDatumTargetAreaShape_e (Type)

SOLIDWORKS API Enumerations

swDatumTargetAreaShape_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swDatumTargetAreaShape_e Enumeration

Target area shapes for datum target symbols.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDatumTargetAreaShape_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDatumTargetAreaShape\_e
```

C#

```
public enum swDatumTargetAreaShape_e : System.Enum
```

C++/CLI

```
public enum class swDatumTargetAreaShape_e : public System.Enum
```

Members

Member	Description
swDatumTargetAreaCircle	2
swDatumTargetAreaNone	0
swDatumTargetAreaPoint	1
swDatumTargetAreaRectangle	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDefaultBOMPartNumberSource_e (Type)

SOLIDWORKS API Enumerations

swDefaultBOMPartNumberSource_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDefaultBOMPartNumberSource_e Enumeration

Sources of bill of materials part numbers for new configurations.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swDefaultBOMPartNumberSource_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDefaultBOMPartNumberSource\_e
```

C#

```
public enum swDefaultBOMPartNumberSource_e : System.Enum
```

C++/CLI

```
public enum class swDefaultBOMPartNumberSource_e : public System.Enum
```

 Members

Member	Description
swDefaultBOMPartNumberSource_ConfigurationName	1
swDefaultBOMPartNumberSource_DocumentName	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDeleteSelectionOptions_e (Type)

SOLIDWORKS API Enumerations

swDeleteSelectionOptions_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDeleteSelectionOptions_e Enumeration

Options for deleting features. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDeleteSelectionOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDeleteSelectionOptions\_e
```

C#

```
public enum swDeleteSelectionOptions_e : System.Enum
```

C++/CLI

```
public enum class swDeleteSelectionOptions_e : public System.Enum
```

Members

Member	Description
swDelete_Absorbed	2 or 0x2
swDelete_Advanced	4 or 0x4
swDelete_Children	1 or 0x1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDesignTableErrors_e (Type)

SOLIDWORKS API Enumerations

swDesignTableErrors_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

▼

SolidWorks.Interop.swconst Namespace : swDesignTableErrors_e Enumeration

Design table errors.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDesignTableErrors_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDesignTableErrors\_e
```

C#

```
public enum swDesignTableErrors_e : System.Enum
```

C++/CLI

```
public enum class swDesignTableErrors_e : public System.Enum
```

 Members

Member	Description
swDTbCannotOpen	27
swDTbCfigInvalid	1
swDTbCorrupt	2
swDTbCurrentlyEditing	5
swDTbDataInvalidComponetState	15
swDTbDataInvalidFeatureState	16
swDTbDisplayStateError	18
swDTbExiting	3
swDTbFileNotFound	8
swDTbInvalidColCustomProp	10
swDTbInvalidColumnDimName	11
swDTbInvalidColumnFeatName	12
swDTbInvalidColumnKeyWord	13
swDTbInvalidColumnValue	9
swDTbInvalidConfigName	14
swDTbInvalidRowNameKeyword	21
swDTbInvalidYesNoData	17
swDTbLinkChanged	7
swDTbModelFeatRequired	19
swDTbNegativeDimension	25
swDTbNoError	0
swDTbNoFileName	4
swDTbNotSuppressible	23
swDTbParentConfigInvalid	20
swDTbTablesEmpty	24
swDTbTotTypeInvalid	22
swDTbTooManyColumns	6
swDTbUnusedConfiguration	26
swDTConfigCircularDefinition	33
swDTDimAngleValueRangeError	31
swDTDimValueRangeError	30
swDTInvalidComponentName	28
swDTInvalidEquation	32
swDTInvalidUserSpecifiedConfigName	34
swDTNeedsComponent	29

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDesignTableSourceTypes_e (Type)

SOLIDWORKS API Enumerations

swDesignTableSourceTypes_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDesignTableSourceTypes_e Enumeration

Types of source files for design tables.

 Syntax

Visual Basic (Declaration)

Public Enum swDesignTableSourceTypes_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDesignTableSourceTypes_e](#)

C#

public enum swDesignTableSourceTypes_e : System.Enum

C++/CLI

public enum class swDesignTableSourceTypes_e : public System.Enum

 Members

Member	Description
swDesignTableSourceFromFile	2
swDesignTableSourceLinked	3
swDesignTableSourceNone	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDesignTableUpdateOptions_e (Type)

SOLIDWORKS API Enumerations

swDesignTableUpdateOptions_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDesignTableUpdateOptions_e Enumeration

Options for updating design tables.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDesignTableUpdateOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDesignTableUpdateOptions\_e
```

C#

```
public enum swDesignTableUpdateOptions_e : System.Enum
```

C++/CLI

```
public enum class swDesignTableUpdateOptions_e : public System.Enum
```

Members

Member	Description
swUpdateDesignTableAll	2
swUpdateDesignTableNone	3
swUpdateDesignTableSelected	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDestroyNotifyType_e (Type)

SOLIDWORKS API Enumerations

swDestroyNotifyType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDestroyNotifyType_e Enumeration

Options for when destroying model views.

 Syntax

Visual Basic (Declaration)

Public Enum swDestroyNotifyType_e
Inherits System.Enum

Visual Basic (Usage) 

Dim instance As [swDestroyNotifyType_e](#)

C#

public enum swDestroyNotifyType_e : System.Enum

C++/CLI

public enum class swDestroyNotifyType_e : public System.Enum

 Members

Member	Description
swDestroyNotifyDestroy	0 = View is being destroyed
swDestroyNotifyHidden	1 = View is being hidden, not destroyed

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingBalloonAutoBalloons_e (Type)

SOLIDWORKS API Enumerations

swDetailingBalloonAutoBalloons_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingBalloonAutoBalloons_e Enumeration

Types of autoballoons.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingBalloonAutoBalloons_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingBalloonAutoBalloons\_e
```

C#

```
public enum swDetailingBalloonAutoBalloons_e : System.Enum
```

C++/CLI

```
public enum class swDetailingBalloonAutoBalloons_e : public System.Enum
```

Members

Member	Description
swBentAutoBalloonLeader	1
swStraightAutoBalloonLeader	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingChamferDimLeaderStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingChamferDimLeaderStyle_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingChamferDimLeaderStyle_e Enumeration

Detailing chamfer dimension leader style.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingChamferDimLeaderStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingChamferDimLeaderStyle\_e
```

C#

```
public enum swDetailingChamferDimLeaderStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingChamferDimLeaderStyle_e : public System.Enum
```

Members

Member	Description
swDetailChamferDimLeaderAlongEdge	5
swDetailChamferDimLeaderAngAbove	4
swDetailChamferDimLeaderAngBeside	3
swDetailChamferDimLeaderHorizAbove	2
swDetailChamferDimLeaderHorizBeside	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingChamferDimLeaderTextStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingChamferDimLeaderTextStyle_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingChamferDimLeaderTextStyle_e Enumeration

Detailing chamfer dimension leader text style.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingChamferDimLeaderTextStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingChamferDimLeaderTextStyle\_e
```

C#

```
public enum swDetailingChamferDimLeaderTextStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingChamferDimLeaderTextStyle_e : public System.Enum
```

Members

Member	Description
swDetailChamferDimAngDist	3
swDetailChamferDimCDist	4
swDetailChamferDimDistAng	2
swDetailChamferDimDistDist	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingChamferDimXStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingChamferDimXStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingChamferDimXStyle_e Enumeration

Detailing chamfer DimXpert style.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swDetailingChamferDimXStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetailingChamferDimXStyle_e](#)



C#

public enum swDetailingChamferDimXStyle_e : System.Enum

C++/CLI

public enum class swDetailingChamferDimXStyle_e : public System.Enum

 Members

Member	Description
swDetailingChamferDimXStyleLowerCaseX	2
swDetailingChamferDimXStyleUpperCaseX	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimFractionScaleIndex_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimFractionScaleIndex_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDimFractionScaleIndex_e Enumeration

Sizes of stacked dimensions in fractional dimensions.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimFractionScaleIndex_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swDetailingDimFractionScaleIndex\_e
```

C#

```
public enum swDetailingDimFractionScaleIndex_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimFractionScaleIndex_e : public System.Enum
```

 Members

Member	Description
swDetailingDimFractionScale_100Percent	0
swDetailingDimFractionScale_10Percent	9
swDetailingDimFractionScale_20Percent	8
swDetailingDimFractionScale_30Percent	7
swDetailingDimFractionScale_40Percent	6
swDetailingDimFractionScale_50Percent	5
swDetailingDimFractionScale_60Percent	4
swDetailingDimFractionScale_70Percent	3
swDetailingDimFractionScale_80Percent	2
swDetailingDimFractionScale_90Percent	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimFractionStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimFractionStyle_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDetailingDimFractionStyle_e Enumeration

Detailing dimension fraction styles.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimFractionStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimFractionStyle\_e
```

C#

```
public enum swDetailingDimFractionStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimFractionStyle_e : public System.Enum
```

Members

Member	Description
swDetailingDimFractionStyle_Dash	3
swDetailingDimFractionStyle_DiagonalStack	2
swDetailingDimFractionStyle_Slash	0
swDetailingDimFractionStyle_Stack	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimTrailingZero_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimTrailingZero_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDimTrailingZero_e Enumeration

Detailing dimension trailing zero styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimTrailingZero_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimTrailingZero\_e
```

C#

```
public enum swDetailingDimTrailingZero_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimTrailingZero_e : public System.Enum
```

Members

Member	Description
swDimRemoveOnlyOnZero	4 = Remove only on zero
swDimRemoveTrailingZeroes	2 = Trailing zeroes do not appear
swDimSameAsDimension	8 = Use the dimension's trailing zeroes setting
swDimSameAsDocumentDimension	6 = Use the document dimension's trailing zeroes setting
swDimSameAsDocumentTolerance	7 = Use the document tolerance's trailing zeroes setting
swDimSameAsSource	5 = Use the source's trailing zeroes setting
swDimShowTrailingZeroes	1 = Trailing zeroes appear
swDimSmartTrailingZeroes	0 = OBSOLETE; do not use to set document properties
swDimStandardTrailingZeroes	3 = OBSOLETE; do not use to set document properties

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimXpertChamferInstanceStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimXpertChamferInstanceStyle_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDimXpertChamferInstanceStyle_e Enumeration

DimXpert chamfer options.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimXpertChamferInstanceStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimXpertChamferInstanceStyle\_e
```

C#

```
public enum swDetailingDimXpertChamferInstanceStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimXpertChamferInstanceStyle_e : public System.Enum
```

Members

Member	Description
swDetailingDimXpertChamferInstance	3
swDetailingDimXpertChamferNone	1
swDetailingDimXpertChamferTyp	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimXpertChamferStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimXpertChamferStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDimXpertChamferStyle_e Enumeration

DimXpert chamfer options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimXpertChamferStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimXpertChamferStyle\_e
```

C#

```
public enum swDetailingDimXpertChamferStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimXpertChamferStyle_e : public System.Enum
```

Members

Member	Description
swDetailingDimXpertChamferDistAngle	2
swDetailingDimXpertChamferDistDist	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimXpertFilletInstanceStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingDimXpertFilletInstanceStyle_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDetailingDimXpertFilletInstanceStyle_e Enumeration

DimXpert fillet options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimXpertFilletInstanceStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimXpertFilletInstanceStyle\_e
```

C#

```
public enum swDetailingDimXpertFilletInstanceStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimXpertFilletInstanceStyle_e : public System.Enum
```

Members

Member	Description
swDetailingDimXpertFilletInstance	3
swDetailingDimXpertFilletNone	1
swDetailingDimXpertFilletType	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDimXpertSlotStyle_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swDetailingDimXpertSlotStyle_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDimXpertSlotStyle_e Enumeration

DimXpert slot options.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDimXpertSlotStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDimXpertSlotStyle\_e
```

C#

```
public enum swDetailingDimXpertSlotStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDimXpertSlotStyle_e : public System.Enum
```

Members

Member	Description
swDetailingDimXpertSlotCenter	1
swDetailingDimXpertSlotOverall	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingDualDimPosition_e (Type)

SOLIDWORKS API Enumerations

swDetailingDualDimPosition_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingDualDimPosition_e Enumeration

Detailing dual dimension positions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingDualDimPosition_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingDualDimPosition\_e
```

C#

```
public enum swDetailingDualDimPosition_e : System.Enum
```

C++/CLI

```
public enum class swDetailingDualDimPosition_e : public System.Enum
```

Members

Member	Description
swDualDimensionsAboveAndBelow	Obsolete
swDualDimensionsOnBottom	4
swDualDimensionsOnLeft	3
swDualDimensionsOnRight	1
swDualDimensionsOnTop	2
swDualDimensionsSideBySide	Obsolete

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingForeshortenedDiameterStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingForeshortenedDiameterStyle_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

SolidWorks.Interop.swconst Namespace : swDetailingForeshortenedDiameterStyle_e Enumeration

Detailing foreshortened diameter styles.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingForeshortenedDiameterStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingForeshortenedDiameterStyle\_e
```

C#

```
public enum swDetailingForeshortenedDiameterStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingForeshortenedDiameterStyle_e : public System.Enum
```

Members

Member	Description
swForeshortenedStyleDoubleArrowhead	1
swForeshortenedStyleZigZagLeader	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingGtolMaterialConditionSymbolPlacement_e (Type)

SOLIDWORKS API Enumerations

swDetailingGtolMaterialConditionSymbolPlacement_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDetailingGtolMaterialConditionSymbolPlacement_e Enumeration

Tools > System Options > Document properties > Annotations > Geometric Tolerances > Material Condition Symbol Placement.

 Syntax

Visual Basic (Declaration)

Public Enum swDetailingGtolMaterialConditionSymbolPlacement_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetailingGtolMaterialConditionSymbolPlacement_e](#)



C#

public enum swDetailingGtolMaterialConditionSymbolPlacement_e : System.Enum

C++/CLI

public enum class swDetailingGtolMaterialConditionSymbolPlacement_e : public System.Enum

 Members

Member	Description
swDetailingGtolMaterialConditionSymbolPlacement_ASME	0
swDetailingGtolMaterialConditionSymbolPlacement_ISO	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingHalfSectionArrow_e (Type)

SOLIDWORKS API Enumerations

swDetailingHalfSectionArrow_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swDetailingHalfSectionArrow_e Enumeration

Half section arrow displays.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingHalfSectionArrow_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swDetailingHalfSectionArrow\_e
```

C#

```
public enum swDetailingHalfSectionArrow_e : System.Enum
```

C++/CLI

```
public enum class swDetailingHalfSectionArrow_e : public System.Enum
```

Members

Member	Description
swDetailingHalfSectionArrow_AlternativeDisplay	0
swDetailingHalfSectionArrow_StandardDisplay	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingLeadingZero_e (Type)

SOLIDWORKS API Enumerations

swDetailingLeadingZero_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingLeadingZero_e Enumeration

Detailing leading zero options.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingLeadingZero_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingLeadingZero\_e
```

C#

```
public enum swDetailingLeadingZero_e : System.Enum
```

C++/CLI

```
public enum class swDetailingLeadingZero_e : public System.Enum
```

Members

Member	Description
swLeadingZero_DoNotShow	3
swLeadingZero_FollowStandard	1
swLeadingZero_Show	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingLinearForeshortened_e (Type)

SOLIDWORKS API Enumerations

swDetailingLinearForeshortened_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingLinearForeshortened_e Enumeration

Linear dimensions foreshortened types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swDetailingLinearForeshortened_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetailingLinearForeshortened_e](#)

 [Copy Code](#)

C#

public enum swDetailingLinearForeshortened_e : System.Enum

C++/CLI

public enum class swDetailingLinearForeshortened_e : public System.Enum

 Members

Member	Description
swDetailingLinearForeshortened_DoubleArrow	0
swDetailingLinearForeshortened_Line	2
swDetailingLinearForeshortened_SingleArrow	3
swDetailingLinearForeshortened_Zigzag	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingNoteTextContent_e (Type)

SOLIDWORKS API Enumerations

swDetailingNoteTextContent_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingNoteTextContent_e Enumeration

BOM balloon note text styles.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingNoteTextContent_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingNoteTextContent\_e
```

C#

```
public enum swDetailingNoteTextContent_e : System.Enum
```

C++/CLI

```
public enum class swDetailingNoteTextContent_e : public System.Enum
```

Members

Member	Description
swDetailingNoteTextCustom	1
swDetailingNoteTextCustomProperty	4
swDetailingNoteTextItemNumber	2
swDetailingNoteTextQuantity	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingSectionViewLineStyle_e (Type)

SOLIDWORKS API Enumerations

swDetailingSectionViewLineStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingSectionViewLineStyle_e Enumeration

Display section view line styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingSectionViewLineStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingSectionViewLineStyle\_e
```

C#

```
public enum swDetailingSectionViewLineStyle_e : System.Enum
```

C++/CLI

```
public enum class swDetailingSectionViewLineStyle_e : public System.Enum
```

Members

Member	Description
swDetailingSectionViewLineStyleDisplay_AlternateWithoutConnector	2
swDetailingSectionViewLineStyleDisplay_StandardWithConnector	0
swDetailingSectionViewLineStyleDisplay_StandardWithoutConnector	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingSFSymbolStandard_e (Type)

SOLIDWORKS API Enumerations

swDetailingSFSymbolStandard_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingSFSymbolStandard_e Enumeration

Detailing surface finish symbol standards.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingSFSymbolStandard_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingSFSymbolStandard\_e
```

C#

```
public enum swDetailingSFSymbolStandard_e : System.Enum
```

C++/CLI

```
public enum class swDetailingSFSymbolStandard_e : public System.Enum
```

Members

Member	Description
swDetailingSFSymbolStandard_1302_1992	0
swDetailingSFSymbolStandard_1302_2002	1
swDetailingSFSymbolStandard_21920_1	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingStandard_e (Type)

SOLIDWORKS API Enumerations

swDetailingStandard_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingStandard_e Enumeration

Detailing standards.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingStandard_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDetailingStandard\_e
```

C#

```
public enum swDetailingStandard_e : System.Enum
```

C++/CLI

```
public enum class swDetailingStandard_e : public System.Enum
```

 Members

Member	Description
swDetailingStandardANSI	1
swDetailingStandardBS	5
swDetailingStandardDIN	3
swDetailingStandardGB	7
swDetailingStandardGOST	6
swDetailingStandardISO	2
swDetailingStandardJIS	4
swDetailingStandardUserDefined	8

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingToleranceTextSizing_e (Type)

SOLIDWORKS API Enumerations

swDetailingToleranceTextSizing_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingToleranceTextSizing_e Enumeration

Detailing tolerance text sizes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingToleranceTextSizing_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingToleranceTextSizing\_e
```

C#

```
public enum swDetailingToleranceTextSizing_e : System.Enum
```

C++/CLI

```
public enum class swDetailingToleranceTextSizing_e : public System.Enum
```

Members

Member	Description
swToleranceTextSizeUsingHeightValue	2
swToleranceTextSizeUsingScaleValue	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingViewLabelsDelimiter_e (Type)

SOLIDWORKS API Enumerations

swDetailingViewLabelsDelimiter_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDetailingViewLabelsDelimiter_e Enumeration

Formats for the auxiliary view scale labels.

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingViewLabelsDelimiter_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingViewLabelsDelimiter\_e
```

C#

```
public enum swDetailingViewLabelsDelimiter_e : System.Enum
```

C++/CLI

```
public enum class swDetailingViewLabelsDelimiter_e : public System.Enum
```

Members

Member	Description
swDetailingViewLabelsDelimiter_none	0 = No format
swDetailingViewLabelsDelimiter_numberX	5 = 2X
swDetailingViewLabelsDelimiter_XcolonX	1 = 2:1
swDetailingViewLabelsDelimiter_XcolonXparen	3 = (2:1)
swDetailingViewLabelsDelimiter_XslashX	2 = 2/1
swDetailingViewLabelsDelimiter_XslashXparen	4 = (2/1)

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingViewLabelsLabel_e (Type)

SOLIDWORKS API Enumerations

swDetailingViewLabelsLabel_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingViewLabelsLabel_e Enumeration

Formats of the auxiliary view labels.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingViewLabelsLabel_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingViewLabelsLabel\_e
```

C#

```
public enum swDetailingViewLabelsLabel_e : System.Enum
```

C++/CLI

```
public enum class swDetailingViewLabelsLabel_e : public System.Enum
```

Members

Member	Description
swDetailingViewLabelsLabel_none	0 = No format
swDetailingViewLabelsLabel_X	1 = A
swDetailingViewLabelsLabel_XdashX	2 = A-A; however, not valid for swDetailingDetailViewLabels_Label
swDetailingViewLabelsLabel_XspaceX	3 = A A; however, not valid for swDetailingDetailViewLabels_Label

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingViewLabelsName_e (Type)

SOLIDWORKS API Enumerations

swDetailingViewLabelsName_e Enumeration

See Also

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swDetailingViewLabelsName_e Enumeration

Format of the titles to use in front of the auxiliary view labels.

Syntax

Visual Basic (Declaration)

Public Enum swDetailingViewLabelsName_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetailingViewLabelsName_e](#)

C#

public enum swDetailingViewLabelsName_e : System.Enum

C++/CLI

public enum class swDetailingViewLabelsName_e : public System.Enum

Members

Member	Description
swDetailingViewLabelsName_custom	3
swDetailingViewLabelsName_DrawingTree	4
swDetailingViewLabelsName_none	0
swDetailingViewLabelsName_VIEW	1
swDetailingViewLabelsName_viewtype	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingViewLabelsScale_e (Type)

SOLIDWORKS API Enumerations

swDetailingViewLabelsScale_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDetailingViewLabelsScale_e Enumeration

Format of the titles to use in front of the auxiliary view scales.

 Syntax

Visual Basic (Declaration)

Public Enum swDetailingViewLabelsScale_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetailingViewLabelsScale_e](#)



C#

public enum swDetailingViewLabelsScale_e : System.Enum

C++/CLI

public enum class swDetailingViewLabelsScale_e : public System.Enum

 Members

Member	Description
swDetailingViewLabelsScale_none	0
swDetailingViewLabelsScale_SCALE	1
swDetailingViewLabelsScale_SCALEcolon	2
swDetailingViewLabelsScale_SCALEcustom	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingViewRotation_e (Type)

SOLIDWORKS API Enumerations

swDetailingViewRotation_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingViewRotation_e Enumeration

View rotation options.

 Syntax

Visual Basic (Declaration)

Public Enum swDetailingViewRotation_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDetailingViewRotation_e](#)

C#

public enum swDetailingViewRotation_e : System.Enum

C++/CLI

public enum class swDetailingViewRotation_e : public System.Enum

 Members

Member	Description
swDetailingViewRotation_DisplayAngle	4 = Display the rotation angle only
swDetailingViewRotation_DisplayROTATEDAngleCWCCW	3 = Display the word ROTATED, the rotation angle, and either CW (clockwise) or CCW (counterclockwise)
swDetailingViewRotation_DisplaySymbol	2 = Display the rotation symbol only
swDetailingViewRotation_DisplaySymbolAngle	1 = Display both the rotation symbol and the rotation angle
swDetailingViewRotation_None	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetailingVirtualSharp_e (Type)

SOLIDWORKS API Enumerations

swDetailingVirtualSharp_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetailingVirtualSharp_e Enumeration

Display options for virtual sharps.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDetailingVirtualSharp_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDetailingVirtualSharp\_e
```

C#

```
public enum swDetailingVirtualSharp_e : System.Enum
```

C++/CLI

```
public enum class swDetailingVirtualSharp_e : public System.Enum
```

Members

Member	Description
swDetailingVirtualSharpDot	4
swDetailingVirtualSharpNone	0
swDetailingVirtualSharpPlus	1
swDetailingVirtualSharpStar	2
swDetailingVirtualSharpWitness	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetCircleShowType_e (Type)

SOLIDWORKS API Enumerations

swDetCircleShowType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetCircleShowType_e Enumeration

Types of circles or profiles to use for detail views.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDetCircleShowType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDetCircleShowType\_e
```

C#

```
public enum swDetCircleShowType_e : System.Enum
```

C++/CLI

```
public enum class swDetCircleShowType_e : public System.Enum
```

 Members

Member	Description
swDetCircleCIRCLE	1 = Use sketch circle to create detail view
swDetCircleDONTSHOW	2 = Do not show a sketch profile
swDetCirclePROFILE	0 = Use sketch profile to create detail view

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDetViewStyle_e (Type)

SOLIDWORKS API Enumerations

swDetViewStyle_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDetViewStyle_e Enumeration

Detail view styles.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swDetViewStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDetViewStyle_e](#)

 [Copy Code](#)

C#

public enum swDetViewStyle_e : System.Enum

C++/CLI

public enum class swDetViewStyle_e : public System.Enum

 Members

Member	Description
swDetViewBROKEN	1 = Use broken detail view style
swDetViewCONNECTED	4 = Use connected detail view style
swDetViewLEADER	2 = Use leader detail view style
swDetViewNOLEADER	3 = Use no leader detail view style
swDetViewSTANDARD	0 = Use standard detail view style

 See Also

[SolidWorks.Interop.swconst Namespace](#)

[SolidWorks.Interop.swconst Namespace](#)

swDimensionArrowsSide_e (Type)

SOLIDWORKS API Enumerations

swDimensionArrowsSide_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDimensionArrowsSide_e Enumeration

Dimension arrow directions.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionArrowsSide_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDimensionArrowsSide\_e
```

C#

```
public enum swDimensionArrowsSide_e : System.Enum
```

C++/CLI

```
public enum class swDimensionArrowsSide_e : public System.Enum
```

 Members

Member	Description
swDimArrowsFollowDoc	3 = As per the document's default setting
swDimArrowsInside	0 = Always positioned on the inside
swDimArrowsOutside	1 = Always positioned on the outside
swDimArrowsSmart	2 = Positioned on the inside, if there is room; otherwise, positioned on the outside

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionDrivenState_e (Type)

SOLIDWORKS API Enumerations

swDimensionDrivenState_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDimensionDrivenState_e Enumeration

Driven or driving state of dimensions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionDrivenState_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimensionDrivenState\_e
```

C#

```
public enum swDimensionDrivenState_e : System.Enum
```

C++/CLI

```
public enum class swDimensionDrivenState_e : public System.Enum
```

Members

Member	Description
swDimensionDriven	1 = Dimension is a driven dimension
swDimensionDrivenUnknown	0 = Driven or driving state is unknown
swDimensionDriving	2 = Dimension is a driving dimension

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionParamType_e (Type)

SOLIDWORKS API Enumerations

swDimensionParamType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimensionParamType_e Enumeration

Dimension types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionParamType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDimensionParamType\_e
```

C#

```
public enum swDimensionParamType_e : System.Enum
```

C++/CLI

```
public enum class swDimensionParamType_e : public System.Enum
```

 Members

Member	Description
swDimensionParamTypeDoubleAngular	1
swDimensionParamTypeDoubleLinear	0
swDimensionParamTypeInteger	2
swDimensionParamTypeUnknown	-1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionPrecisionSettings_e (Type)

SOLIDWORKS API Enumerations

swDimensionPrecisionSettings_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDimensionPrecisionSettings_e Enumeration

Precision settings for dimensions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swDimensionPrecisionSettings_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDimensionPrecisionSettings_e](#)

C#

public enum swDimensionPrecisionSettings_e : System.Enum

C++/CLI

public enum class swDimensionPrecisionSettings_e : public System.Enum

Members

Member	Description
swDoNotChangePrecisionSetting	-1 = Used by IDisplayDimension::SetPrecision2 only
swPrecisionFollowsDocumentSetting	-2 = Precision equals the document default precision value
swTolerancePrecisionFollowsNominal	-3 = Tolerance precision equals the dimension precision value

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionPrefix_e (Type)

SOLIDWORKS API Enumerations

swDimensionPrefix_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDimensionPrefix_e Enumeration

Prefixes for PMI dimension annotations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionPrefix_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimensionPrefix\_e
```

C#

```
public enum swDimensionPrefix_e : System.Enum
```

C++/CLI

```
public enum class swDimensionPrefix_e : public System.Enum
```

Members

Member	Description
swDimensionPrefix_2X	1
swDimensionPrefix_3X	2
swDimensionPrefix_4X	3
swDimensionPrefix_5X	4
swDimensionPrefix_6X	5
swDimensionPrefix_None	0
swDimensionPrefix_Unknown	6

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionSymbol_e (Type)

SOLIDWORKS API Enumerations

swDimensionSymbol_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDimensionSymbol_e Enumeration

Symbols for PMI dimension annotations.

Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionSymbol_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimensionSymbol\_e
```

C#

```
public enum swDimensionSymbol_e : System.Enum
```

C++/CLI

```
public enum class swDimensionSymbol_e : public System.Enum
```

Members

Member	Description
swDimensionSymbol_Angle	37
swDimensionSymbol_CalloutText	40
swDimensionSymbol_Centerline	5
swDimensionSymbol_CenterOfMass	6
swDimensionSymbol_ConicalTaper	9
swDimensionSymbol_Continuous	10
swDimensionSymbol_ControlledRadius	11
swDimensionSymbol_Counterbore	7
swDimensionSymbol_Countersink	8
swDimensionSymbol_Degree	4
swDimensionSymbol_Delta	12
swDimensionSymbol_Depth	3
swDimensionSymbol_Diameter	2
swDimensionSymbol_Encircling	13
swDimensionSymbol_FlattenedLength	14
swDimensionSymbol_FreeState	15
swDimensionSymbol_Independency	16
swDimensionSymbol_LeastMaterialCondition	17
swDimensionSymbol_MaximumMaterialCondition	18
swDimensionSymbol_None	0
swDimensionSymbol_PartingLine	19
swDimensionSymbol_PlusMinus	20
swDimensionSymbol_ProjectToleranceZone	21
swDimensionSymbol_Radius	36
swDimensionSymbol_RegardlessOfFeatureSize	22
swDimensionSymbol_Rho	23
swDimensionSymbol_SlopeDown	25
swDimensionSymbol_SlopeInvertedDown	27
swDimensionSymbol_SlopeInvertedUp	26
swDimensionSymbol_SlopeUp	24
swDimensionSymbol_SlotLength	38
swDimensionSymbol_SlotWidth	39
swDimensionSymbol_SphericalDiameter	29
swDimensionSymbol_SphericalRadius	28
swDimensionSymbol_Square	30
swDimensionSymbol_SquareBS	31
swDimensionSymbol_Statistical	32
swDimensionSymbol_TangentPlane	33
swDimensionSymbol_Translation	34
swDimensionSymbol_UnequallyDisposedProfile	35
swDimensionSymbol_Unknown	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionTextParts_e (Type)

SOLIDWORKS API Enumerations

swDimensionTextParts_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDimensionTextParts_e Enumeration

Options for getting and setting display dimension text.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionTextParts_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swDimensionTextParts\_e
```

C#

```
public enum swDimensionTextParts_e : System.Enum
```

C++/CLI

```
public enum class swDimensionTextParts_e : public System.Enum
```

 Members

Member	Description
swDimensionTextAll	0 = Entire dimension text string (IDisplayDimension.SetText only)
swDimensionTextCalloutAbove	3 = Callout-above portion of the text
swDimensionTextCalloutAboveDefinition	7 = Definition of the callout portion of the text above the dimension
swDimensionTextCalloutBelow	4 = Callout-below portion of the text
swDimensionTextCalloutBelowDefinition	8 = Definition of the callout portion of the text below the dimension
swDimensionTextPrefix	1 = Prefix portion of the text
swDimensionTextPrefixDefinition	5 = Definition of the prefix portion of the text
swDimensionTextSuffix	2 = Suffix portion of the text
swDimensionTextSuffixDefinition	6 = Definition of the suffix portion of the text

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionToleranceWarning_e (Type)

SOLIDWORKS API Enumerations

swDimensionToleranceWarning_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimensionToleranceWarning_e Enumeration

Dimension tolerance warnings.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionToleranceWarning_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDimensionToleranceWarning\_e
```

C#

```
public enum swDimensionToleranceWarning_e : System.Enum
```

C++/CLI

```
public enum class swDimensionToleranceWarning_e : public System.Enum
```

 Members

Member	Description
swDimensionTolerance_InvalidForType	1
swDimensionTolerance_ValidForType	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimensionType_e (Type)

SOLIDWORKS API Enumerations

swDimensionType_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swDimensionType_e Enumeration

Types of dimensions.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimensionType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDimensionType\_e
```

C#

```
public enum swDimensionType_e : System.Enum
```

C++/CLI

```
public enum class swDimensionType_e : public System.Enum
```

 Members

Member	Description
swAngularDimension	3 = Angular dimension type
swAngularOrdinateDimension	16 = Angular ordinate dimension
swArcLengthDimension	4 = Arc length dimension type
swChamferDimension	10
swDiameterDimension	6 = Diameter dimension
swDiametricLinearDimension	15 = Doubled distance linear dimension
swDimensionTypeUnknown	0 = Dimension type could not be determined
swHorLinearDimension	11 = Horizontal linear dimension
swHorOrdinateDimension	7 = Horizontal ordinate dimension
swLinearDimension	2 = Linear dimension type
swOrdinateDimension	1 = Base ordinate and its subordinates are of this type
swRadialDimension	5 = Radial dimension
swRadialLinearDimension	14 = Doubled distance radial dimension
swScalarDimension	13
swVertLinearDimension	12 = Vertical linear dimension
swVertOrdinateDimension	8 = Vertical ordinate dimension
swZAxisDimension	9

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertBlockPrecision_e (Type)

SOLIDWORKS API Enumerations

swDimXpertBlockPrecision_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertBlockPrecision_e Enumeration

DimXpert block tolerance precisions.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swDimXpertBlockPrecision_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDimXpertBlockPrecision_e](#)



C#

public enum swDimXpertBlockPrecision_e : System.Enum

C++/CLI

public enum class swDimXpertBlockPrecision_e : public System.Enum

 Members

Member	Description
swDimXpertBlockPrecisionFourDecimals	2
swDimXpertBlockPrecisionThreeDecimals	1
swDimXpertBlockPrecisionTwoDecimals	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertDisplayDatumGtolLinearDimAttachmentType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertDisplayDatumGtolLinearDimAttachmentType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertDisplayDatumGtolLinearDimAttachmentType_e Enumeration

Attachment types for DimXpert datum geometric tolerance linear dimensions.

Syntax

Visual Basic (Declaration)

Public Enum swDimXpertDisplayDatumGtolLinearDimAttachmentType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDimXpertDisplayDatumGtolLinearDimAttachmentType_e](#)

C#

public enum swDimXpertDisplayDatumGtolLinearDimAttachmentType_e : System.Enum

C++/CLI

public enum class swDimXpertDisplayDatumGtolLinearDimAttachmentType_e : public System.Enum

Members

Member	Description
swDimXpertDisplayDatumGtolLinearDimAttachmentType_ValueSide	0
swDimXpertDisplayDatumGtolLinearDimAttachmentType_ValueTop	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertDisplayDatumGtolSurfaceAttachmentType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertDisplayDatumGtolSurfaceAttachmentType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertDisplayDatumGtolSurfaceAttachmentType_e Enumeration

Attachment types for DimXpert datum geometric tolerance surfaces.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDimXpertDisplayDatumGtolSurfaceAttachmentType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimXpertDisplayDatumGtolSurfaceAttachmentType\_e
```

C#

```
public enum swDimXpertDisplayDatumGtolSurfaceAttachmentType_e : System.Enum
```

C++/CLI

```
public enum class swDimXpertDisplayDatumGtolSurfaceAttachmentType_e : public System.Enum
```

Members

Member	Description
swDimXpertDisplayDatumGtolSurfaceAttachmentType_ValueSide	0
swDimXpertDisplayDatumGtolSurfaceAttachmentType_ValueTop	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertDisplayGtolLinearDimAttachmentType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertDisplayGtolLinearDimAttachmentType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDimXpertDisplayGtolLinearDimAttachmentType_e Enumeration

Attachment types for DimXpert geometric tolerance linear dimensions.

Syntax

Visual Basic (Declaration)

```
Public Enum swDimXpertDisplayGtolLinearDimAttachmentType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimXpertDisplayGtolLinearDimAttachmentType\_e
```

C#

```
public enum swDimXpertDisplayGtolLinearDimAttachmentType_e : System.Enum
```

C++/CLI

```
public enum class swDimXpertDisplayGtolLinearDimAttachmentType_e : public System.Enum
```

Members

Member	Description
swDimXpertDisplayGtolLinearDimAttachmentType_ValueSide	0
swDimXpertDisplayGtolLinearDimAttachmentType_ValueTop	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertDisplayHoleDimensionType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertDisplayHoleDimensionType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertDisplayHoleDimensionType_e Enumeration

Dimension types for DimXpert holes.

Syntax

Visual Basic (Declaration)

```
Public Enum swDimXpertDisplayHoleDimensionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDimXpertDisplayHoleDimensionType\_e
```

C#

```
public enum swDimXpertDisplayHoleDimensionType_e : System.Enum
```

C++/CLI

```
public enum class swDimXpertDisplayHoleDimensionType_e : public System.Enum
```

Members

Member	Description
swDimXpertDisplayHoleDimensionType_DiameterDepth	1
swDimXpertDisplayHoleDimensionType_Diameters	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertDisplaySlotDimensionType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertDisplaySlotDimensionType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertDisplaySlotDimensionType_e Enumeration

Dimension types for DimXpert slots.

 Syntax

Visual Basic (Declaration)

Public Enum swDimXpertDisplaySlotDimensionType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDimXpertDisplaySlotDimensionType_e](#)

C#

public enum swDimXpertDisplaySlotDimensionType_e : System.Enum

C++/CLI

public enum class swDimXpertDisplaySlotDimensionType_e : public System.Enum

 Members

Member	Description
swDimXpertDisplaySlotDimensionType_LengthRadius	0
swDimXpertDisplaySlotDimensionType_LengthWidth	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertGeneralTolClass_e (Type)

SOLIDWORKS API Enumerations

swDimXpertGeneralTolClass_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertGeneralTolClass_e Enumeration

DimXpert tolerance classes.

Syntax

Visual Basic (Declaration)

```
Public Enum swDimXpertGeneralTolClass_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swDimXpertGeneralTolClass\_e
```

C#

```
public enum swDimXpertGeneralTolClass_e : System.Enum
```

C++/CLI

```
public enum class swDimXpertGeneralTolClass_e : public System.Enum
```

Members

Member	Description
swDimXpertGeneralTolClass_Coarse	2
swDimXpertGeneralTolClass_Custom1	4
swDimXpertGeneralTolClass_Custom2	5
swDimXpertGeneralTolClass_Fine	0
swDimXpertGeneralTolClass_Medium	1
swDimXpertGeneralTolClass_VeryCoarse	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertTolType_e (Type)

SOLIDWORKS API Enumerations

swDimXpertTolType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertTolType_e Enumeration

DimXpert tolerance types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDimXpertTolType_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swDimXpertTolType\_e
```

C#

```
public enum swDimXpertTolType_e : System.Enum
```

C++/CLI

```
public enum class swDimXpertTolType_e : public System.Enum
```

 Members

Member	Description
swDimXpertTolType_Bilateral	0
swDimXpertTolType_GeneralOrBlock	2
swDimXpertTolType_Symmetric	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDimXpertTreeDisplay_e (Type)

SOLIDWORKS API Enumerations

swDimXpertTreeDisplay_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDimXpertTreeDisplay_e Enumeration

Types of tree display on the DimXpert tab.

 Syntax

Visual Basic (Declaration)

Public Enum swDimXpertTreeDisplay_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDimXpertTreeDisplay_e](#)

C#

public enum swDimXpertTreeDisplay_e : System.Enum

C++/CLI

public enum class swDimXpertTreeDisplay_e : public System.Enum

 Members

Member	Description
swDimXpertTreeDisplay_Annotation	2 = Show annotation-based tree.
swDimXpertTreeDisplay_Feature	3 = Show feature-based tree.
swDimXpertTreeDisplay_Flat	1 = Show flat tree

 Remarks

The members of this enumeration correspond to the Tree Display options that are available in the right-mouse button menu for a DimXpert schema.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayCircularReferencesInEquations_e (Type)

SOLIDWORKS API Enumerations

swDisplayCircularReferencesInEquations_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDisplayCircularReferencesInEquations_e Enumeration

Display options for circular references in equations.

 Syntax

Visual Basic (Declaration)

Public Enum swDisplayCircularReferencesInEquations_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDisplayCircularReferencesInEquations_e](#)

C#

public enum swDisplayCircularReferencesInEquations_e : System.Enum

C++/CLI

public enum class swDisplayCircularReferencesInEquations_e : public System.Enum

 Members

Member	Description
swDisplayCircularReferencesInEquationsEverywhere	0
swDisplayCircularReferencesInEquationsInEquationDialogOnly	1
swDisplayCircularReferencesInEquationsNever	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayDimensionLeaderText_e (Type)

SOLIDWORKS API Enumerations

swDisplayDimensionLeaderText_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDisplayDimensionLeaderText_e Enumeration

Display dimension leaders and text placement.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swDisplayDimensionLeaderText_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDisplayDimensionLeaderText_e](#)



C#

public enum swDisplayDimensionLeaderText_e : System.Enum

C++/CLI

public enum class swDisplayDimensionLeaderText_e : public System.Enum

 Members

Member	Description
swBrokenLeaderAlignedText	3 = Leader is broken and the text is aligned with the leader
swBrokenLeaderHorizontalText	2 = Leader is broken and the text is horizontal
swSolidLeaderAlignedText	1 = Leader is solid (not broken) and the text is aligned with the leader
swSolidLeaderHorizontalText	4 = The leader is solid and the text is horizontal; although this value can be applied to any type of dimension where the dimension text is not between the extension lines, it is currently only implemented by SOLIDWORKS for chamfer dimensions

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayMode_e (Type)

SOLIDWORKS API Enumerations

swDisplayMode_e Enumeration

See Also

[Send comments on this topic.](#)

 SolidWorks.Interop.swconst Namespace : swDisplayMode_e Enumeration

Display modes of drawing views.

 Syntax

Visual Basic (Declaration)

Public Enum swDisplayMode_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDisplayMode_e](#)

C#

public enum swDisplayMode_e : System.Enum

C++/CLI

public enum class swDisplayMode_e : public System.Enum

 Members

Member	Description
swDisplayModeDEFAULT	8
swDisplayModeUNKNOWN	-1
swFACETED_HIDDEN	6
swFACETED_HIDDEN_GREYED	5
swFACETED_WIREFRAME	4
swHIDDEN	2; Hidden Lines Removed (HLR)
swHIDDEN_GREYED	1; Hidden Lines Visible (HLV)
swSHADED	3
swSHADED_EDGES	7
swWIREFRAME	0

 Remarks

A faceted display mode is draft quality.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayPaneIndex_e (Type)

SOLIDWORKS API Enumerations

swDisplayPaneIndex_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDisplayPaneIndex_e Enumeration

Active display panes.

Syntax

Visual Basic (Declaration)

Public Enum swDisplayPaneIndex_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDisplayPaneIndex_e](#)

C#

public enum swDisplayPaneIndex_e : System.Enum

C++/CLI

public enum class swDisplayPaneIndex_e : public System.Enum

Members

Member	Description
swDisplayPaneAllContentTab	3
swDisplayPaneLifeCycleTab	1
swDisplayPaneNone	0 = Display pane is hidden
swDisplayPaneTab	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayPotentialCircularReferencesInEquations_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swDisplayPotentialCircularReferencesInEquations_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDisplayPotentialCircularReferencesInEquations_e Enumeration

Display options for potential circular references in equations.

Syntax

Visual Basic (Declaration)

```
Public Enum swDisplayPotentialCircularReferencesInEquations_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDisplayPotentialCircularReferencesInEquations\_e
```

C#

```
public enum swDisplayPotentialCircularReferencesInEquations_e : System.Enum
```

C++/CLI

```
public enum class swDisplayPotentialCircularReferencesInEquations_e : public System.Enum
```

Members

Member	Description
swDisplayPotentialCircularReferencesInEquationsEverywhere	0
swDisplayPotentialCircularReferencesInEquationsInEquationDialogOnly	1
swDisplayPotentialCircularReferencesInEquationsNever	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayStateCreationChoices_e (Type)

SOLIDWORKS API Enumerations

swDisplayStateCreationChoices_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDisplayStateCreationChoices_e Enumeration

Display-state preserve options.

Syntax

Visual Basic (Declaration)

```
Public Enum swDisplayStateCreationChoices_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDisplayStateCreationChoices\_e
```

C#

```
public enum swDisplayStateCreationChoices_e : System.Enum
```

C++/CLI

```
public enum class swDisplayStateCreationChoices_e : public System.Enum
```

Members

Member	Description
swDisplayStateCreation_AskUser	-1; Display the dialog where the user can select the display states (PhotoWorks material and SOLIDWORKS colors) he or she wants to preserve; however, if swDisplayStateCreation_AskUser is set and the user opens the file using ISldWorks::OpenDocn (where <i>n</i> is the version number of the method), then both display states are preserved and the dialog is not displayed; valid in documents created in SOLIDWORKS 2009 and earlier
swDisplayStateCreation_BothPWSW	3; Preserve both PhotoWorks and SOLIDWORKS display states; valid in documents created in SOLIDWORKS 2009 and earlier
swDisplayStateCreation_PW	1; Preserve PhotoWorks material display state only; valid in documents created in SOLIDWORKS 2009 and earlier
swDisplayStateCreation_SW	2; Preserve SOLIDWORKS color display state only; valid in documents created in SOLIDWORKS 2009 and earlier

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayStateOpts_e (Type)

SOLIDWORKS API Enumerations

swDisplayStateOpts_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDisplayStateOpts_e Enumeration

Display state options.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swDisplayStateOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)

 [Copy Code](#)

```
Dim instance As swDisplayStateOpts\_e
```

C#

```
public enum swDisplayStateOpts_e : System.Enum
```

C++/CLI

```
public enum class swDisplayStateOpts_e : public System.Enum
```

 Members

Member	Description
swAllDisplayState	2 = All display states
swSpecifyDisplayState	3 = Specific display state
swThisDisplayState	1 = This display state

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDisplayTangentEdges_e (Type)

SOLIDWORKS API Enumerations

swDisplayTangentEdges_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDisplayTangentEdges_e Enumeration

Tangent edge display modes.

 Syntax

Visual Basic (Declaration)

Public Enum swDisplayTangentEdges_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDisplayTangentEdges_e](#)

C#

public enum swDisplayTangentEdges_e : System.Enum

C++/CLI

public enum class swDisplayTangentEdges_e : public System.Enum

 Members

Member	Description
swTangentEdgesHidden	0
swTangentEdgesVisible	2
swTangentEdgesVisibleAndFonted	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swDistanceMateArcConditions_e (Type)

SOLIDWORKS API Enumerations

swDistanceMateArcConditions_e Enumeration

See Also

[Send comments on this topic.](#)

  SolidWorks.Interop.swconst Namespace : swDistanceMateArcConditions_e Enumeration

Arc conditions for cylindrical distance mates.

 Syntax

Visual Basic (Declaration)

Public Enum swDistanceMateArcConditions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDistanceMateArcConditions_e](#)

C#

public enum swDistanceMateArcConditions_e : System.Enum

C++/CLI

public enum class swDistanceMateArcConditions_e : public System.Enum

 Members

Member	Description
swArcCondition_Center	1; Cylindrical axis
swArcCondition_Maximum	3; Furthest arc
swArcCondition_Minimum	2; Nearest arc
swArcCondition_NotSet	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)