

SOLIDWORKS Enumerations (swconst) — Reference (11/17): swPointInferenceBrokerOption_e swRemoveCommandGroupErrors

SOLIDWORKS API Documentation (converted from CHM)

swPointInferenceBrokerOption_e (Type)

SOLIDWORKS API Enumerations

swPointInferenceBrokerOption_e Enumeration

See Also

 [SolidWorks.Interop.swconst Namespace](#) : swPointInferenceBrokerOption_e Enumeration

[Send comments on this topic.](#)

Inference points options from add-ins. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swPointInferenceBrokerOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPointInferenceBrokerOption\_e
```

C#

```
public enum swPointInferenceBrokerOption_e : System.Enum
```

C++/CLI

```
public enum class swPointInferenceBrokerOption_e : public System.Enum
```

Members

Member	Description
swPointInferenceBrokerOption_IncludeHidden	1 or 0x1; Include hidden inference points

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPointSize_e (Type)

SOLIDWORKS API Enumerations

swPointSize_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPointSize_e Enumeration

Point styles.

 Syntax

Visual Basic (Declaration)

Public Enum swPointSize_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPointSize_e](#)

C#

public enum swPointSize_e : System.Enum

C++/CLI

public enum class swPointSize_e : public System.Enum

 Members

Member	Description
swPointSize_Circle	4 = Point represented by a circle
swPointSize_Plus	2 = Point represented by a plus sign (+)
swPointSize_X	1 = Point represented by the x character
swPointSize_XPlus	3 = Point represented by a symbol that looks like the x character and the plus sign, e.g., a symbol similar to an asterisk (*)

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPresentationOpts_e (Type)

SOLIDWORKS API Enumerations

swPresentationOpts_e Enumeration

See Also

 [SolidWorks.Interop.swconst Namespace](#) : swPresentationOpts_e Enumeration

SOLIDWORKS Presentation options. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swPresentationOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPresentationOpts\_e
```

C#

```
public enum swPresentationOpts_e : System.Enum
```

C++/CLI

```
public enum class swPresentationOpts_e : public System.Enum
```

 Members

Member	Description
swPresentationOpts_ActiveView	32 or 0x20
swPresentationOpts_Animations	4 or 0x4
swPresentationOpts_BackView	2048 or 0x800
swPresentationOpts_BottomView	128 or 0x80
swPresentationOpts_CameraMovement	16 or 0x10
swPresentationOpts_ChkOpenPassword3DPDF	1073741824 or 0x40000000;
swPresentationOpts_CompressTessellation	8388608 or 0x800000
swPresentationOpts_CreateAttachSTEP242	262144 or 0x40000
swPresentationOpts_DimetricView	32768 or 0x8000
swPresentationOpts_DisableCopying3DPDF	67108864 or 0x4000000
swPresentationOpts_DisableEditing3DPDF	33554432 or 0x2000000
swPresentationOpts_DisablePrinting3DPDF	16777216 or 0x1000000
swPresentationOpts_ExcludeFromAnnoView	131072 or 0x20000
swPresentationOpts_Explodes	8 or 0x8
swPresentationOpts_FrontView	1024 or 0x400
swPresentationOpts_HighAccuracy	1048576 or 0x100000
swPresentationOpts_IsometricView	8192 or 0x2000
swPresentationOpts_LeftView	256 or 0x100
swPresentationOpts_LowAccuracy	524288 or 0x80000
swPresentationOpts_MaxAccuracy	4194304 or 0x400000
swPresentationOpts_MedAccuracy	2097152 or 0x200000
swPresentationOpts_None	0 or 0x0
swPresentationOpts_NormalView	4096 or 0x1000
swPresentationOpts_OpenPDF	65536 or 0x10000
swPresentationOpts_PDFPreview	268435456 or 0x10000000
swPresentationOpts_Pres	1 or 0x1
swPresentationOpts_RightView	512 or 0x200
swPresentationOpts_ShowOnlyGraphicalData	134217728 or 0x8000000
swPresentationOpts_SingleHTML	536870912 or 0x20000000; Option to export HTML from 3DPDF
swPresentationOpts_TopView	64 or 0x40
swPresentationOpts_TrimetricView	16384 or 0x4000
swPresentationOpts_USD	2 or 0x2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPrimaryMemberPointLengthEndCondition_e (Type)

SOLIDWORKS API Enumerations

swPrimaryMemberPointLengthEndCondition_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPrimaryMemberPointLengthEndCondition_e Enumeration

Structure system primary member point length end conditions.

 Syntax

Visual Basic (Declaration)

Public Enum swPrimaryMemberPointLengthEndCondition_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPrimaryMemberPointLengthEndCondition_e](#)



C#

public enum swPrimaryMemberPointLengthEndCondition_e : System.Enum

C++/CLI

public enum class swPrimaryMemberPointLengthEndCondition_e : public System.Enum

 Members

Member	Description
swPrimaryMemberPointLengthEndCondition_Length	0
swPrimaryMemberPointLengthEndCondition_Point	1
swPrimaryMemberPointLengthEndCondition_UpToPlane	3
swPrimaryMemberPointLengthEndCondition_UpToPoint	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPrintProperties_e (Type)

SOLIDWORKS API Enumerations

swPrintProperties_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPrintProperties_e Enumeration

Print properties.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPrintProperties_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPrintProperties_e](#)

C#

public enum swPrintProperties_e : System.Enum

C++/CLI

public enum class swPrintProperties_e : public System.Enum

 Members

Member	Description
swPrintOrientation	1
swPrintPaperLength	2
swPrintPaperSize	0
swPrintPaperWidth	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPrintSelectionScaleFactor_e (Type)

SOLIDWORKS API Enumerations

swPrintSelectionScaleFactor_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPrintSelectionScaleFactor_e Enumeration

Drawing print selection scale options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swPrintSelectionScaleFactor_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swPrintSelectionScaleFactor\_e
```

C#

```
public enum swPrintSelectionScaleFactor_e : System.Enum
```

C++/CLI

```
public enum class swPrintSelectionScaleFactor_e : public System.Enum
```

 Members

Member	Description
swPrintAll	0
swPrintCurrentSheet	1; Print the current drawing sheet with a 1:1 scale
swPrintScreenImage	2
swPrintSelection	3; Specify custom scale factors for the current drawing sheet

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPrompForFilenameCause_e (Type)

SOLIDWORKS API Enumerations

swPrompForFilenameCause_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swPrompForFilenameCause_e Enumeration

Reasons for opening or saving missing dependent documents.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPrompForFilenameCause_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPrompForFilenameCause\_e
```

C#

```
public enum swPrompForFilenameCause_e : System.Enum
```

C++/CLI

```
public enum class swPrompForFilenameCause_e : public System.Enum
```

Members

Member	Description
swAddComponent	15
swAddVirtualComponent	24
swComponentPropsReplace	10
swCreateNamedViewFromFile	9
swDerivedPart	4
swDrawingAddViewFromFile	13
swDrawingInsert3ViewFromFile	14
swEditReadOnlyComponent	19 = User attempted to edit a read-only component document in context.
swFileReloadReplace	12
swFormNewSubAssembly	23 = For use with ISldWorks PromptForFileNameNotify event handler, which fires the event when an interactive user wants to form a new sub-assembly.
swGeneric	1
swInsertBlock	20 = For use with ISldWorks PromptForFileNameNotify event handler, which fires the event when an interactive user clicks the Browse button on the Insert Block PropertyManager page.
swInsertEnvelopeFromFile	7
swMakeComponentIndependent	25
swMirrorComponent	2
swMirrorComponentBrowse	8
swOpenAssociatedDrawing	11
swPromptForFilename_Cancelled	26
swSaveDefeaturedModel	22 = For use with ISldWorks PromptForFileNameNotify event handler, which fires the event when an interactive user wants to save a de-featured model as a separate file.
swSaveRoutePart	17
swSaveVirtualComponentExternally	18 = For use with the ISldWorks PromptForMultipleFileNamesNotify event handler and ISldWorks::SetMultipleFileNamesPrompt to: 1. Supply path names for virtual components to be saved externally. 2. Suppress dialogs prompting user to select paths for virtual components.
swSketchBlock	21 = For use with ISldWorks PromptForFileNameNotify event handler, which fires the event when an interactive user clicks the Browse button on the Insert Block PropertyManager page.
swSplitAssembly	5
swSplitPart	6
swStartRouteAssembly	16
swUnused	0
swWeldBead	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPromptAlwaysNever_e (Type)

SOLIDWORKS API Enumerations

swPromptAlwaysNever_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPromptAlwaysNever_e Enumeration

Responses to being prompted by SOLIDWORKS.

 Syntax

Visual Basic (Declaration)

Public Enum swPromptAlwaysNever_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPromptAlwaysNever_e](#)

 Copy Code

C#

public enum swPromptAlwaysNever_e : System.Enum

C++/CLI

public enum class swPromptAlwaysNever_e : public System.Enum

 Members

Member	Description
swResponseAlways	1
swResponseNever	2
swResponsePrompt	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerButtonTypes_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerButtonTypes_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerButtonTypes_e Enumeration

PropertyManager button types. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerButtonTypes_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropertyManagerButtonTypes_e](#)



C#

public enum swPropertyManagerButtonTypes_e : System.Enum

C++/CLI

public enum class swPropertyManagerButtonTypes_e : public System.Enum

 Members

Member	Description
swPropertyManager_CancelButton	2 or 0x2
swPropertyManager_HelpButton	4 or 0x4
swPropertyManager_OkayButton	1 or 0x1
swPropertyManager_PreviewButton	8 or 0x8
swPropertyManager_PushpinButton	16 or 0x10

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerCheckboxState_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerCheckboxState_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerCheckboxState_e Enumeration

PropertyManager page check box states.

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerCheckboxState_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swPropertyManagerCheckboxState_e](#)

C#

public enum swPropertyManagerCheckboxState_e : System.Enum

C++/CLI

public enum class swPropertyManagerCheckboxState_e : public System.Enum

 Members

Member	Description
Checked	1
Indeterminate	2
Unchecked	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerColorScheme_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerColorScheme_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerColorScheme_e Enumeration

Color schemes for PropertyManager pages.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerColorScheme_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerColorScheme\_e
```

C#

```
public enum swPropertyManagerColorScheme_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerColorScheme_e : public System.Enum
```

Members

Member	Description
swPropertyManagerColorScheme_Blue	1
swPropertyManagerColorScheme_Default	7
swPropertyManagerColorScheme_Gray	2
swPropertyManagerColorScheme_Mustard	3
swPropertyManagerColorScheme_Olive	4
swPropertyManagerColorScheme_Sand	5
swPropertyManagerColorScheme_SeaGreen	6
swPropertyManagerColorScheme_Windows	8

Remarks

These enumerators describe themes for the various colors used in the PropertyManager pages, not a specific color. When a scheme is changed, any open PropertyManager pages are immediately updated to the new color scheme.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageBitmapButtons_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageBitmapButtons_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageBitmapButtons_e Enumeration

PropertyManager page bitmap buttons.

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageBitmapButtons_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerPageBitmapButtons\_e
```

C#

```
public enum swPropertyManagerPageBitmapButtons_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageBitmapButtons_e : public System.Enum
```

Members

Member	Description
swBitmapButtonImage_alongz	1
swBitmapButtonImage_angle	2
swBitmapButtonImage_auto_bal_circular	3
swBitmapButtonImage_auto_bal_left	4
swBitmapButtonImage_auto_bal_right	5
swBitmapButtonImage_auto_bal_square	6
swBitmapButtonImage_auto_bal_top	7
swBitmapButtonImage_diameter	8
swBitmapButtonImage_dimension_set_default_attributes	38
swBitmapButtonImage_distance1	9
swBitmapButtonImage_distance2	10
swBitmapButtonImage_draft	11
swBitmapButtonImage_dve_but_cmark_bolt	12
swBitmapButtonImage_dve_but_cmark_linear	13
swBitmapButtonImage_dve_but_cmark_single	14
swBitmapButtonImage_favorite_add	34
swBitmapButtonImage_favorite_delete	35
swBitmapButtonImage_favorite_load	37
swBitmapButtonImage_favorite_save	36
swBitmapButtonImage_leader_ang_above	15
swBitmapButtonImage_leader_ang_beside	16
swBitmapButtonImage_leader_hor_above	17
swBitmapButtonImage_leader_hor_beside	18
swBitmapButtonImage_leader_left	19
swBitmapButtonImage_leader_no	20
swBitmapButtonImage_leader_right	21
swBitmapButtonImage_leader_yes	22
swBitmapButtonImage_parallel	23
swBitmapButtonImage_perpendicular	24
swBitmapButtonImage_reverse_direction	25
swBitmapButtonImage_revision_circle	26
swBitmapButtonImage_revision_hexagon	27
swBitmapButtonImage_revision_square	28
swBitmapButtonImage_revision_triangle	29
swBitmapButtonImage_stack	33
swBitmapButtonImage_stackleft	30
swBitmapButtonImage_stackright	31
swBitmapButtonImage_stackup	32

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageButtons_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageButtons_e Enumeration

See Also

 SolidWorks.Interop.swconst Namespace : swPropertyManagerPageButtons_e Enumeration

PropertyManager page buttons.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageButtons_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerPageButtons\_e
```

C#

```
public enum swPropertyManagerPageButtons_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageButtons_e : public System.Enum
```

Members

Member	Description
swPropertyManagerPageButton_Back	5
swPropertyManagerPageButton_Cancel	2
swPropertyManagerPageButton_Help	3
swPropertyManagerPageButton_Next	4
swPropertyManagerPageButton_Ok	1
swPropertyManagerPageButton_Preview	7
swPropertyManagerPageButton_Pushpin	8
swPropertyManagerPageButton_Redo	9
swPropertyManagerPageButton_Undo	6
swPropertyManagerPageButton_WhatsNew	10

Remarks

Enable or disable a button on a PropertyManager page using [IPropertyManagerPage2::EnableButton](#).

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageCloseReasons_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageCloseReasons_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageCloseReasons_e Enumeration

Reasons why a PropertyManager page closes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageCloseReasons_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swPropertyManagerPageCloseReasons\_e
```

C#

```
public enum swPropertyManagerPageCloseReasons_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageCloseReasons_e : public System.Enum
```

 Members

Member	Description
swPropertyManagerPageClose_Apply	6
swPropertyManagerPageClose_Cancel	2
swPropertyManagerPageClose_Closed	4
swPropertyManagerPageClose_Okay	1
swPropertyManagerPageClose_ParentClosed	3
swPropertyManagerPageClose_Preview	7
swPropertyManagerPageClose_UnknownReason	0
swPropertyManagerPageClose_UserEscape	5

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageControlLeftAlign_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageControlLeftAlign_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageControlLeftAlign_e Enumeration

Left alignments for controls on PropertyManager pages.

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageControlLeftAlign_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerPageControlLeftAlign\_e
```

C#

```
public enum swPropertyManagerPageControlLeftAlign_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageControlLeftAlign_e : public System.Enum
```

Members

Member	Description
swControlAlign_DoubleIndent	3
swControlAlign_Indent	2
swControlAlign_LeftEdge	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageControlType_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageControlType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageControlType_e Enumeration

Controls for PropertyManager pages.

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageControlType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerPageControlType\_e
```

C#

```
public enum swPropertyManagerPageControlType_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageControlType_e : public System.Enum
```

Members

Member	Description
swControlType_ActiveX	10
swControlType_Bitmap	14
swControlType_BitmapButton	11
swControlType_Button	3
swControlType_CheckableBitmapButton	12
swControlType_Checkbox	2
swControlType_Combobox	7
swControlType_Label	1
swControlType_Listbox	6
swControlType_Numberbox	8
swControlType_Option	4
swControlType_Selectionbox	9
swControlType_Slider	13
swControlType_Textbox	5
swControlType_WindowFromHandle	15

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageCursors_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageCursors_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageCursors_e Enumeration

PropertyManager page's cursor after a user makes a selection in the SOLIDWORKS graphics area.

Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerPageCursors_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropertyManagerPageCursors_e](#)

C#

public enum swPropertyManagerPageCursors_e : System.Enum

C++/CLI

public enum class swPropertyManagerPageCursors_e : public System.Enum

Members

Member	Description
swPropertyManagerPageCursors_Advance	2 = Move to the next selection box on the PropertyManager page
swPropertyManagerPageCursors_None	0 = None
swPropertyManagerPageCursors_Okay	1 = Okay and close the PropertyManager page

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageMessageExpanded (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageMessageExpanded Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageMessageExpanded Enumeration

Expand, compress, or leave the state of the PropertyManage page's message as is.

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerPageMessageExpanded
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swPropertyManagerPageMessageExpanded](#)

C#

public enum swPropertyManagerPageMessageExpanded : System.Enum

C++/CLI

public enum class swPropertyManagerPageMessageExpanded : public System.Enum

 Members

Member	Description
swMessageBoxCompress	2
swMessageBoxExpand	1
swMessageBoxMaintainExpandState	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageMessageVisibility (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageMessageVisibility Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageMessageVisibility Enumeration

Visibility states for messages for PropertyManager pages.

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerPageMessageVisibility
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropertyManagerPageMessageVisibility](#)



C#

public enum swPropertyManagerPageMessageVisibility : System.Enum

C++/CLI

public enum class swPropertyManagerPageMessageVisibility : public System.Enum

 Members

Member	Description
swImportantMessageBox	1
swMessageBoxHidden	2
swMessageBoxVisible	3
swNoMessageBox	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageOptions_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageOptions_e Enumeration

See Also

 [SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageOptions_e Enumeration

Options for PropertyManager pages. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerPageOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropertyManagerPageOptions_e](#)

C#

public enum swPropertyManagerPageOptions_e : System.Enum

C++/CLI

public enum class swPropertyManagerPageOptions_e : public System.Enum

 Members

Member	Description
swPropertyManagerOptions_AbortCommands	1024 or 0x400; Abort active command when PropertyManager page is displayed
swPropertyManagerOptions_AllowHorizontalResize	<i>Obsolete; as of SOLIDWORKS 2006 and later, all PropertyManager pages can be resized horizontally</i>
swPropertyManagerOptions_CancelButton	2 or 0x2
swPropertyManagerOptions_CanEscapeCancel	4096 or 0x1000; When a user presses the Esc key, the PropertyManager page will close the page; this enumerator only applies to pages that do not contain selection boxes
swPropertyManagerOptions_CloseDialogButton	8 or 0x8
swPropertyManagerOptions_DisablePageBuildDuringHandlers	32768 or 0x8000; Paint the PropertyManager page after control returns to SOLIDWORKS from the add-in's handler; may help eliminate any flickering of the PropertyManager page of the add-in changes the visibility of numerous controls on the PropertyManager page
swPropertyManagerOptions_DisableSelection	256 or 0x100
swPropertyManagerOptions_GrayOutDisabledSelectionListboxes	65536 or 0x10000; Controls whether a PropertyManager page should show its disabled selection list boxes so that they appear grayed out by coloring their backgrounds the same color as the divider box background. NOTE: Disabled selection list boxes should be hidden; graying them out is an exception to SOLIDWORKS standard practice.
swPropertyManagerOptions_HandleKeystrokes	8192 or 0x2000; Enables processing of keystrokes while the PropertyManager page is displayed; disabled by default
swPropertyManagerOptions_LockedPage	4 or 0x4
swPropertyManagerOptions_MultiplePages	16 or 0x10
swPropertyManagerOptions_OkayButton	1 or 0x1
swPropertyManagerOptions_PreviewButton	128 or 0x80
swPropertyManagerOptions_PushpinButton	32 or 0x20
swPropertyManagerOptions_RedoButton	16384 or 0x4000;
swPropertyManagerOptions_SupportsChainSelection	131072 or 0x20000; If set, then show Select Chain: - on the shortcut menu if a sketch entity is currently selected. - or - - if nothing is selected, but the cursor is over a sketch entity when the right-mouse button was clicked.
swPropertyManagerOptions_SupportsIsolate	262144 or 0x40000; If set, then show Isolate item in right-mouse button menu of assembly components. This option must be used with swPropertyManagerOptions_LockedPage.
swPropertyManagerOptions_UndoButton	2048 or 0x800
swPropertyManagerOptions_WhatsNew	512 or 0x200; Indicates that you want a What's New button to appear on your PropertyManager page

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageShowOptions_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerPageShowOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageShowOptions_e Enumeration

Options for showing PropertyManager pages. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum swPropertyManagerPageShowOptions_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swPropertyManagerPageShowOptions_e](#)

C#

public enum swPropertyManagerPageShowOptions_e : System.Enum

C++/CLI

public enum class swPropertyManagerPageShowOptions_e : public System.Enum

 Members

Member	Description
swPropertyManagerShowOptions_StackPage	1 or 0x1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerPageStatus_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swPropertyManagerPageStatus_e Enumeration

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerPageStatus_e Enumeration

PropertyManager page statuses.

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerPageStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerPageStatus\_e
```

C#

```
public enum swPropertyManagerPageStatus_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerPageStatus_e : public System.Enum
```

Members

Member	Description
swPropertyManagerPage_CreationFailure	-1
swPropertyManagerPage_NoDocument	-2 = A PropertyManager page can only be shown in a SOLIDWORKS document window; you can create and set up the page without a document being active, but there must be a document active when you try to show the page; if there is no active document window, then swPropertyManagerPage_NoDocument is returned
swPropertyManagerPage_Okay	0
swPropertyManagerPage_UnsupportedHandler	1 = The PropertyManager page is created and shown; however, a problem exists; for example, you must specify the handler when you create the PropertyManager page; your add-in must implement IPropertyManagerPage2Handler4 so that SOLIDWORKS can call back certain methods when operations, such as clicking a button, occur on the PropertyManager page;if the interface that is passed in does not support PropertyManagerPage2Handler4 , then swPropertyManagerPage_UnsupportedHandler is returned

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertyManagerStatus_e (Type)

SOLIDWORKS API Enumerations

swPropertyManagerStatus_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropertyManagerStatus_e Enumeration

Return values for various PropertyManager APIs.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertyManagerStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropertyManagerStatus\_e
```

C#

```
public enum swPropertyManagerStatus_e : System.Enum
```

C++/CLI

```
public enum class swPropertyManagerStatus_e : public System.Enum
```

Members

Member	Description
swPropertyManagerStatus_Disconnected	-2
swPropertyManagerStatus_Failed	-1
swPropertyManagerStatus_Okay	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropertySheetNotify_e (Type)

SOLIDWORKS API Enumerations

swPropertySheetNotify_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swPropertySheetNotify_e Enumeration

Property sheet notifications.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPropertySheetNotify_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swPropertySheetNotify_e
```

C#

```
public enum swPropertySheetNotify_e : System.Enum
```

C++/CLI

```
public enum class swPropertySheetNotify_e : public System.Enum
```

Members

Member	Description
swPropertySheetCreateControlNotify	5 = CreateControlNotify
swPropertySheetDestroyNotify	1 = DestroyNotify
swPropertySheetHelpNotify	2 = HelpNotify
swPropertySheetOnCancelNotify	4 = OnCancelNotify
swPropertySheetOnOKNotify	3 = OnOKNotify

Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports property sheet events (e.g., SwPropertySheet.h), include:

```
BEGIN_SINK_MAP(CSwPropertySheet)

    SINK_ENTRY_EX(ID_SWPROPERTYSHEET_EVENTS, DIID_DSwPropertySheetEvents,
        swPropertySheetCreateControlNotify, CreateControlNotify)

    SINK_ENTRY_EX(ID_SWPROPERTYSHEET_EVENTS, DIID_DSwPropertySheetEvents,
        swPropertySheetDestroyNotify, DestroyNotify)

END_SINK_MAP( )
```

If developing a C++ application, use these enumerators to [register for notifications](#) for [ISWPropertySheet](#) events.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageComboBoxStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageComboBoxStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageComboBoxStyle_e Enumeration

PropertyManager page combobox styles.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageComboBoxStyle_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swPropMgrPageComboBoxStyle_e](#)

C#

public enum swPropMgrPageComboBoxStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageComboBoxStyle_e : public System.Enum

 Members

Member	Description
swPropMgrPageComboBoxStyle_AvoidSelectionText	8 or 0x8; The item the user selects in the attached drop-down list does not appear in the combo box. Instead, the user's selection causes the add-in to get a callback via IPropertyManagerPage2Handler4::OnComboboxSelectionChanged . The Id argument is the combo box
swPropMgrPageComboBoxStyle_EditableText	2 or 0x2; Allows editing of the text in the combo box
swPropMgrPageComboBoxStyle_EditBoxReadOnly	4 or 0x4; User can only select a value from the attached drop-down list for the combo box
NOTE: You can set swPropMgrPageComboBoxStyle_EditBoxReadOnly either before or after the PropertyManager page is displayed. If set after the PropertyManager page is displayed and the box contains editable text, then that text cannot be edited by the user. However, you can use IPropertyManagerPageCombobox::EditText to edit the text in the combo box.	
swPropMgrPageComboBoxStyle_Sorted	1 or 0x1; Sort the items in the attached drop-down list of the combo box in alphabetical order

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageControlOnResizeOptions_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageControlOnResizeOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageControlOnResizeOptions_e Enumeration

PropertyManager page control resize options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swPropMgrPageControlOnResizeOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropMgrPageControlOnResizeOptions\_e
```

C#

```
public enum swPropMgrPageControlOnResizeOptions_e : System.Enum
```

C++/CLI

```
public enum class swPropMgrPageControlOnResizeOptions_e : public System.Enum
```

Members

Member	Description
swControlOptionsOnResize_LockLeft	1 or 0x1
swControlOptionsOnResize_LockRight	2 or 0x2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageLabelStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageLabelStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageLabelStyle_e Enumeration

PropertyManager page control label styles. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPropMgrPageLabelStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropMgrPageLabelStyle\_e
```

C#

```
public enum swPropMgrPageLabelStyle_e : System.Enum
```

C++/CLI

```
public enum class swPropMgrPageLabelStyle_e : public System.Enum
```

Members

Member	Description
swPropMgrPageLabelStyle_CenterText	2 or 0x2
swPropMgrPageLabelStyle_LeftText	1 or 0x1
swPropMgrPageLabelStyle_RightText	4 or 0x4
swPropMgrPageLabelStyle_Sunken	8 or 0x8

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageLabelUnderlineStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageLabelUnderlineStyle_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageLabelUnderlineStyle_e Enumeration

Underline style of PropertyManager page label.

 Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageLabelUnderlineStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageLabelUnderlineStyle_e](#)

 [Copy Code](#)

C#

public enum swPropMgrPageLabelUnderlineStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageLabelUnderlineStyle_e : public System.Enum

 Members

Member	Description
swPropMgrPageLabel_DashedUnderline	2
swPropMgrPageLabel_NoUnderline	0
swPropMgrPageLabel_SolidUnderline	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageListBoxStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageListBoxStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageListBoxStyle_e Enumeration

PropertyManager page list box styles. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageListBoxStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageListBoxStyle_e](#)

C#

public enum swPropMgrPageListBoxStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageListBoxStyle_e : public System.Enum

 Members

Member	Description
swPropMgrPageListBoxStyle_MultiItemSelect	4 or 0x4; Enable multi-select style listbox
swPropMgrPageListBoxStyle_NoIntegralHeight	2 or 0x2
swPropMgrPageListBoxStyle_Sorted	1 or 0x1; Sort the list in alphabetically

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageNumberBoxStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageNumberBoxStyle_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swPropMgrPageNumberBoxStyle_e Enumeration

PropertyManager page number box styles. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swPropMgrPageNumberBoxStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropMgrPageNumberBoxStyle\_e
```

C#

```
public enum swPropMgrPageNumberBoxStyle_e : System.Enum
```

C++/CLI

```
public enum class swPropMgrPageNumberBoxStyle_e : public System.Enum
```

 Members

Member	Description
swPropMgrPageNumberBoxStyle_AvoidSelectionText	4 or 0x4; The item the user selects in the attached drop-down list does not appear in the number box. Instead, the user's selection causes the add-in to get a callback via IPropertyManagerPage2Handler9::OnComboboxSelectionChanged ; the Id argument will be the number box; the add-in is expected to respond by setting the value for the number box using IPropertyManagerPageNumberbox::Value .
swPropMgrPageNumberBoxStyle_ComboEditBox	1 or 0x1; Enables the attached drop-down list for the number box; user can type a value or select a value from the attached drop-down list for the number box
swPropMgrPageNumberBoxStyle_EditBoxReadOnly	2 or 0x2; User can only select a value from the attached drop-down list for the number box NOTE: You can set swPropMgrPageNumberBoxStyle_EditBoxReadOnly either before or after the PropertyManager page is displayed. If set after the PropertyManager page is displayed and the number box contains editable text, then that text cannot be edited by the user
swPropMgrPageNumberBoxStyle_NoScrollArrows	8 or 0x8; Do not show the up and down arrows in the number box, thus, disallowing incrementing or decrementing the value in the number box
swPropMgrPageNumberBoxStyle_Slider	16 or 0x10; Slider
swPropMgrPageNumberBoxStyle_SuppressNotifyWhileTracking	64 or 0x40; Suppress sending multiple notifications when a user is dragging or spinning the slider of a number box on a PropertyManager page; instead, send only one notification; see IPropertyManagerPage2Handler9::OnNumberboxChanged for details
swPropMgrPageNumberBoxStyle_Thumbwheel	32 or 0x20; Thumbwheel

 Remarks

When the user selects an item in the attached drop-down list, SOLIDWORKS attempts to use that item as a value in the number box. Thus, the items in the attached drop-down list should be numeric values and optionally include their units. The add-in then gets a callback via [IPropertyManagerPage2Handler9::OnNumberboxChanged](#) as if the user had typed a value in the number box or clicked the up-arrow or down-arrow buttons to increment or decrement the value.

If you do not want your add-in to directly use items in the attached drop-down list in the number box, but instead want it to react to the user selecting a computed or linked value in the number box, then use [swPropMgrPageNumberBoxStyle_AvoidSelectionText](#).

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageOptionStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageOptionStyle_e Enumeration

See Also

 [SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageOptionStyle_e Enumeration

PropertyManage page group option styles. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageOptionStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageOptionStyle_e](#)

C#

public enum swPropMgrPageOptionStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageOptionStyle_e : public System.Enum

 Members

Member	Description
swPropMgrPageOptionStyle_FirstInGroup	1 or 0x1; This is the beginning of a group of option items; any following option items without this value set are considered part of the group; the next option with this value set indicates the start of a new option group

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageSelectionBoxStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageSelectionBoxStyle_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageSelectionBoxStyle_e Enumeration

PropertyManager page selection box styles. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageSelectionBoxStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageSelectionBoxStyle_e](#)

 [Copy Code](#)

C#

public enum swPropMgrPageSelectionBoxStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageSelectionBoxStyle_e : public System.Enum

 Members

Member	Description
swPropMgrPageSelectionBoxStyle_HScroll	1 or 0x1; Specifies that the selection box has a scroll bar so that interactive users can scroll through the list of items
swPropMgrPageSelectionBoxStyle_MultipleItemSelect	4 or 0x4; Specifies that you can select multiple items in the selection box
swPropMgrPageSelectionBoxStyle_UpAndDownButtons	2 or 0x2; Specifies that selection listbox has up and down arrows so that interactive users can move items in the list up or down
swPropMgrPageSelectionBoxStyle_WantListBoxSelectionChanged	8 or 0x8; Specifies that you want a notification sent when a user changes the selected item in a listbox or selection listbox

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropMgrPageSliderStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageSliderStyle_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageSliderStyle_e Enumeration

PropertyManager page slider styles. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageSliderStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageSliderStyle_e](#)

C#

public enum swPropMgrPageSliderStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageSliderStyle_e : public System.Enum

Members

Member	Description
swPropMgrPageSliderStyle_AutoTicks	2 or 0x2; If set, then tick marks are created based on swPropMgrPageSliderStyle_BottomLeftTicks and swPropMgrPageSliderStyle_TopRightTicks
swPropMgrPageSliderStyle_BottomLeftTicks	4 or 0x4; If set, then tick marks appear at the bottom (horizontal) or left (vertical) of the slider
swPropMgrPageSliderStyle_NotifyWhileTracking	16 or 0x10; If set, then your application is notified when the user is dragging the slider, each time the value changes; if not set, then your application is not notified when the user is dragging the slider, only when the user is done dragging the slider; setting this bit allows your application to react immediately to changes, but it does generate many more callbacks, so it is less efficient
swPropMgrPageSliderStyle_TopRightTicks	8 or 0x8; If set, then tick marks appear at the top (horizontal) or right (vertical) of the slider
swPropMgrPageSliderStyle_Vertical	1 or 0x1; If set, then the slider is oriented vertically; if not set, then the slider is oriented horizontally

See Also

[SolidWorks.Interop.swconst Namespace](#)



swPropMgrPageTextBoxStyle_e (Type)

SOLIDWORKS API Enumerations

swPropMgrPageTextBoxStyle_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swPropMgrPageTextBoxStyle_e Enumeration

PropertyManager page textbox styles. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swPropMgrPageTextBoxStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPropMgrPageTextBoxStyle_e](#)



C#

public enum swPropMgrPageTextBoxStyle_e : System.Enum

C++/CLI

public enum class swPropMgrPageTextBoxStyle_e : public System.Enum

Members

Member	Description
swPropMgrPageTextBoxStyle_Multiline	8 or 0x8
swPropMgrPageTextBoxStyle_NoBorder	4 or 0x4
swPropMgrPageTextBoxStyle_NotifyOnlyWhenFocusLost	1 or 0x1; Do not send notification every time a character in the text box changes; instead, only send notification when text box loses focus after the user has made all changes
swPropMgrPageTextBoxStyle_ReadOnly	2 or 0x2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPropSheetType_e (Type)

SOLIDWORKS API Enumerations

swPropSheetType_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPropSheetType_e Enumeration

Property sheet types.

Syntax

Visual Basic (Declaration)

```
Public Enum swPropSheetType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPropSheetType\_e
```

C#

```
public enum swPropSheetType_e : System.Enum
```

C++/CLI

```
public enum class swPropSheetType_e : public System.Enum
```

Members

Member	Description
swPropSheetAmbientLight	3 = Property sheet ambient light
swPropSheetDirectionalLight	4 = Property sheet directional light
swPropSheetLighting	1 = Property sheet lighting
swPropSheetNotValid	0 = Invalid property sheet
swPropSheetPositionLight	5 = Property sheet position light
swPropSheetSpotLight	6 = Property sheet spot light
swPropSheetToolsOptions	2 = Property sheet tools options

Remarks

This enumerator specifies possible values for the types of [ISWPPropertySheets](#) exported by SOLIDWORKS when a SldWorks notification of type [swAppPropertySheetCreateNotify](#) is sent.

An example of a property sheet is the dialog that is displayed when you click **Tools, Options**. This dialog consists of a base property sheet and property pages stacked on top of it. To display a specific property page, click its tab.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPublishStepOpts_e (Type)

SOLIDWORKS API Enumerations

swPublishStepOpts_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swPublishStepOpts_e Enumeration

Options for publishing to Step 242.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPublishStepOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPublishStepOpts\_e
```

C#

```
public enum swPublishStepOpts_e : System.Enum
```

C++/CLI

```
public enum class swPublishStepOpts_e : public System.Enum
```

Members

Member	Description
swPublishStepOpts_FaceEdgeSTEP242	2 = Export face/edge properties/IDs
swPublishStepOpts_None	0
swPublishStepOpts_SplitFacesSTEP242	1 = Split features with 360 degree faces (holes, cylinders, cones) into two

See Also

[SolidWorks.Interop.swconst Namespace](#)

swPublishTo3DPDFError_e (Type)

SOLIDWORKS API Enumerations

swPublishTo3DPDFError_e Enumeration

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swPublishTo3DPDFError_e Enumeration

Status codes for publishing SOLIDWORKS MBD 3D PDF files.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swPublishTo3DPDFError_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swPublishTo3DPDFError_e](#)

C#

public enum swPublishTo3DPDFError_e : System.Enum

C++/CLI

public enum class swPublishTo3DPDFError_e : public System.Enum

 Members

Member	Description
swPublishTo3DPDF.InvalidPath	1
swPublishTo3DPDF.InvalidTheme	2
swPublishTo3DPDF.MBDLicenseNotAvailable	4
swPublishTo3DPDF.NothingToPublish	5
swPublishTo3DPDF.Step242EditionError	6
swPublishTo3DPDF.Success	0
swPublishTo3DPDF.UnknownError	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swPunchTableTagStyle_e (Type)

SOLIDWORKS API Enumerations

swPunchTableTagStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swPunchTableTagStyle_e Enumeration

Punch table datum tag styles

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swPunchTableTagStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swPunchTableTagStyle\_e
```

C#

```
public enum swPunchTableTagStyle_e : System.Enum
```

C++/CLI

```
public enum class swPunchTableTagStyle_e : public System.Enum
```

Members

Member	Description
swPunchTable.AlphaNumericTags	1
swPunchTable.NumericTags	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swQuadant_e (Type)

SOLIDWORKS API Enumerations

swQuadant_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swQuadant_e Enumeration

Angular dimension types

Syntax

Visual Basic (Declaration)

Public Enum swQuadant_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swQuadant_e](#)

C#

public enum swQuadant_e : System.Enum

C++/CLI

public enum class swQuadant_e : public System.Enum

Members

Member	Description
swQuadNegQ1	2
swQuadNegQ2	4
swQuadPosQ1	1
swQuadPosQ2	3
swQuadUnknown	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRackPinionMateDistanceOptions_e (Type)

SOLIDWORKS API Enumerations

swRackPinionMateDistanceOptions_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swRackPinionMateDistanceOptions_e Enumeration

Rack and pinion mate distance options.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swRackPinionMateDistanceOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRackPinionMateDistanceOptions_e](#)



C#

public enum swRackPinionMateDistanceOptions_e : System.Enum

C++/CLI

public enum class swRackPinionMateDistanceOptions_e : public System.Enum

 Members

Member	Description
swPinionPitchDiameter	0 = Specify the pinion pitch diameter
swRackTravelPerRevolution	1 = Specify the distance the rack travels for each full rotation of the pinion

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRackPinionMateEntityType_e (Type)

SOLIDWORKS API Enumerations

swRackPinionMateEntityType_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swRackPinionMateEntityType_e Enumeration

Rack and pinion mate entity types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRackPinionMateEntityType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRackPinionMateEntityType\_e
```

C#

```
public enum swRackPinionMateEntityType_e : System.Enum
```

C++/CLI

```
public enum class swRackPinionMateEntityType_e : public System.Enum
```

Members

Member	Description
swRackPinionMateEntityType_Pinion	1 = Select a cylindrical face , arc or circular edge, sketch circle or arc, axis , or revolved surface
swRackPinionMateEntityType_Rack	0 = Select a linear edge , sketch line , centerline , axis, or cylindrical face

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRayPtsOpts_e (Type)

SOLIDWORKS API Enumerations

swRayPtsOpts_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swRayPtsOpts_e Enumeration

Ray points options. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum swRayPtsOpts_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRayPtsOpts_e](#)

C#

public enum swRayPtsOpts_e : System.Enum

C++/CLI

public enum class swRayPtsOpts_e : public System.Enum

 Members

Member	Description
swRayPtsOptsENTRY_EXIT	4 or 0x4; Output requested of whether ray was entering or exiting body when it hit
swRayPtsOptsNORMALS	1 or 0x1; Output of normals requested
swRayPtsOptsTOPOLS	2 or 0x2; Output of entities hit requested
swRayPtsOptsUNBLOCK	8 or 0x8; Allow the system to respond while waiting

 See Also

[SolidWorks.Interop.swconst Namespace](#)

[SolidWorks.Interop.swconst Namespace](#)

swRayPtsResults_e (Type)

SOLIDWORKS API Enumerations

swRayPtsResults_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRayPtsResults_e Enumeration

Types of intersections and whether the rays are entering or exiting the body when they hit. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swRayPtsResults_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swRayPtsResults\_e
```

C#

```
public enum swRayPtsResults_e : System.Enum
```

C++/CLI

```
public enum class swRayPtsResults_e : public System.Enum
```

 Members

Member	Description
swRayPtsResultsEDGE	4 or 0x4; Edge hit
swRayPtsResultsENTER	16 or 0x10; Ray was entering body when it hit (optionally appears when swRayPtsOptsENTRY_EXIT is specified in the options argument to IModelDoc2-RayIntersections)
swRayPtsResultsEXIT	32 or 0x20; Ray was exiting body when it hit (optionally appears when swRayPtsOptsENTRY_EXIT is specified in the options argument to IModelDoc2-RayIntersections)
swRayPtsResultsFACE	1 or 0x1; Simple face hit
swRayPtsResultsSILHOUETTE	2 or 0x2; Grazing face hit
swRayPtsResultsUnknown	0 or 0x0; Unknown
swRayPtsResultsVERTEX	8 or 0x8; Vertex hit

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRayTraceRenderImageFormat_e (Type)

SOLIDWORKS API Enumerations

swRayTraceRenderImageFormat_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swRayTraceRenderImageFormat_e Enumeration

Image formats.

 Syntax

Visual Basic (Declaration)

Public Enum swRayTraceRenderImageFormat_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swRayTraceRenderImageFormat_e](#)

C#

public enum swRayTraceRenderImageFormat_e : System.Enum

C++/CLI

public enum class swRayTraceRenderImageFormat_e : public System.Enum

 Members

Member	Description
swImageFormat_FlexiblePrecision	0 = Flexible Precision (*.flx)
swImageFormat_HDR	3 = Radiance High Dynamic Range (*.hdr)
swImageFormat_JPEG	7 = JPEG (*.jpg)
swImageFormat_JPEG2000	4 = JPEG 2000 (*.jp2)
swImageFormat_JPEG2000_16bit	5 = JPEG 2000 16-bit (*.jp2)
swImageFormat_JPEG2000_16bit_Lossless	6 = JPEG 2000 16-bit Lossless (*.jp2)
swImageFormat_OpenEXR	14 = OpenEXR Half 16-bit (*.exr)
swImageFormat_OpenEXR_32bit	15 = OpenEXR Flat 32-bit (*.exr)
swImageFormat_OpenEXR_TILED16bit	16 = OpenEXR Tiled Half 16-bit (*.exr)
swImageFormat_OpenEXR_TILED32bit	17 = OpenEXR Tiled Flat 32-bit (*.exr)
swImageFormat_PNG	8 = Portable Network Graphic (*.png)
swImageFormat_PNG_16bit	9 = 16-bit Portable Network Graphic (*.png)
swImageFormat_SGI_RGB	10 = SGI RGB (*.sgi)
swImageFormat_Targa	1 = Targa (*.tga)
swImageFormat_TIF	11 = Tagged Image File Format (*.tif)
swImageFormat_TIF_16bit	12 = 16-bit Tagged Image File Format (*.tif)
swImageFormat_TIF_16bit_uncompr	13 = 16-bit uncompressed Tagged Image File Format (*.tif)
swImageFormat_WindowsBmp	2 = Windows Bitmap (*.bmp)

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRayTraceRenderingType_e (Type)

SOLIDWORKS API Enumerations

swRayTraceRenderingType_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swRayTraceRenderingType_e Enumeration

Ray trace rendering types.

Syntax

Visual Basic (Declaration)

```
Public Enum swRayTraceRenderingType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRayTraceRenderingType\_e
```

C#

```
public enum swRayTraceRenderingType_e : System.Enum
```

C++/CLI

```
public enum class swRayTraceRenderingType_e : public System.Enum
```

Members

Member	Description
swRayTraceCartoon	0
swRayTraceContour	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRayTraceRenderQuality_e (Type)

SOLIDWORKS API Enumerations

swRayTraceRenderQuality_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swRayTraceRenderQuality_e Enumeration

Ray-trace render quality.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swRayTraceRenderQuality_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRayTraceRenderQuality_e](#)

C#

public enum swRayTraceRenderQuality_e : System.Enum

C++/CLI

public enum class swRayTraceRenderQuality_e : public System.Enum

Members

Member	Description
swRenderQuality_Best	2 = Best
swRenderQuality_Better	1 = Better
swRenderQuality_Good	0 = Good
swRenderQuality_Maximum	3 = Maximum

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRayTraceRenderType_e (Type)

SOLIDWORKS API Enumerations

swRayTraceRenderType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swRayTraceRenderType_e Enumeration

Ray trace rendering methods.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swRayTraceRenderType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRayTraceRenderType_e](#)

C#

public enum swRayTraceRenderType_e : System.Enum

C++/CLI

public enum class swRayTraceRenderType_e : public System.Enum

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRebuildOnActivation_e (Type)

SOLIDWORKS API Enumerations

swRebuildOnActivation_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swRebuildOnActivation_e Enumeration

Rebuild options during document activation.

 Syntax

Visual Basic (Declaration)

```
Public Enum swRebuildOnActivation_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swRebuildOnActivation\_e
```

C#

```
public enum swRebuildOnActivation_e : System.Enum
```

C++/CLI

```
public enum class swRebuildOnActivation_e : public System.Enum
```

 Members

Member	Description
swDontRebuildActiveDoc	1 = do not rebuild the activated document
swRebuildActiveDoc	2 = rebuild the activated document
swUserDecision	0 = prompt the user whether to rebuild the activated document

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRebuildOptions_e (Type)

SOLIDWORKS API Enumerations

swRebuildOptions_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swRebuildOptions_e Enumeration

Rebuild options. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRebuildOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRebuildOptions\_e
```

C#

```
public enum swRebuildOptions_e : System.Enum
```

C++/CLI

```
public enum class swRebuildOptions_e : public System.Enum
```

Members

Member	Description
swCurrentSheetDisp	8 or 0x8; Drawing only; only rebuilds the display of the views on the current drawing sheet
swForceRebuildAll	2 or 0x2; Assembly or drawing; Forces a rebuild of all geometry
swRebuildAll	1 or 0x1; Assembly or drawing; rebuilds geometry that has not been regenerated
swUpdateDirtyOnly	16 or 0x10; Drawing only; only rebuilds drawing views that are dirty when OR'd with swCurrentSheetDisp option
swUpdateMates	4 or 0x4; Assembly only; only rebuilds mates, which is much faster than rebuilding the geometry. Especially useful for IComponent2::Transform2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefAxisType_e (Type)

SOLIDWORKS API Enumerations

swRefAxisType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRefAxisType_e Enumeration

Reference axis types.

Syntax

Visual Basic (Declaration)

Public Enum swRefAxisType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRefAxisType_e](#)

C#

public enum swRefAxisType_e : System.Enum

C++/CLI

public enum class swRefAxisType_e : public System.Enum

Members

Member	Description
swAxisTypeCylOrConeFace	3
swAxisTypeOneLine	0
swAxisTypePtAndPlane	4
swAxisTypeTwoPlanes	1
swAxisTypeTwoPoints	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swReferencedFileStatus_e (Type)

SOLIDWORKS API Enumerations

swReferencedFileStatus_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swReferencedFileStatus_e Enumeration

Reference file open error codes.

Syntax

Visual Basic (Declaration)

```
Public Enum swReferencedFileStatus_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swReferencedFileStatus\_e
```

C#

```
public enum swReferencedFileStatus_e : System.Enum
```

C++/CLI

```
public enum class swReferencedFileStatus_e : public System.Enum
```

Members

Member	Description
swReferencedFileStatus_FileOk	0
swReferencedFileStatus_InternalIdMismatch	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefGeometryError_e (Type)

SOLIDWORKS API Enumerations

swRefGeometryError_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swRefGeometryError_e Enumeration

Errors when setting geometry of moveable rotational datum target symbols.

 Syntax

Visual Basic (Declaration)

Public Enum swRefGeometryError_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swRefGeometryError_e](#)



C#

public enum swRefGeometryError_e : System.Enum

C++/CLI

public enum class swRefGeometryError_e : public System.Enum

 Members

Member	Description
swEdgeNotFound	-1
swInvalidEdgeSelection	2
swNonlinearEdgeSelection	1
swValidEdge	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefPlaneReferenceConstraints_e (Type)

SOLIDWORKS API Enumerations

swRefPlaneReferenceConstraints_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swRefPlaneReferenceConstraints_e Enumeration

Reference plane constraints. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRefPlaneReferenceConstraints_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRefPlaneReferenceConstraints\_e
```

C#

```
public enum swRefPlaneReferenceConstraints_e : System.Enum
```

C++/CLI

```
public enum class swRefPlaneReferenceConstraints_e : public System.Enum
```

Members

Member	Description
swRefPlaneReferenceConstraint_Angle	16 or 0x10
swRefPlaneReferenceConstraint_Coincident	4 or 0x4
swRefPlaneReferenceConstraint_Distance	8 or 0x8
swRefPlaneReferenceConstraint_MidPlane	128 or 0x80
swRefPlaneReferenceConstraint_OptionFlip	256 or 0x100
swRefPlaneReferenceConstraint_OptionOriginOnCurve	512 or 0x200
swRefPlaneReferenceConstraint_OptionProjectAlongSketchNormal	2056 or 0x800
swRefPlaneReferenceConstraint_OptionProjectToNearestLocation	1028 or 0x400
swRefPlaneReferenceConstraint_OptionReferenceFlip	8192 or 0x2000
swRefPlaneReferenceConstraint_Parallel	1 or 0x1
swRefPlaneReferenceConstraint_ParallelToScreen	4096 or 0x1000
swRefPlaneReferenceConstraint_Perpendicular	2 or 0x2
swRefPlaneReferenceConstraint_Project	64 or 0x40
swRefPlaneReferenceConstraint_Tangent	32 or 0x20

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefPlaneReferenceIndex_e (Type)

SOLIDWORKS API Enumerations

swRefPlaneReferenceIndex_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRefPlaneReferenceIndex_e Enumeration

Reference plane entities.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRefPlaneReferenceIndex_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRefPlaneReferenceIndex\_e
```

C#

```
public enum swRefPlaneReferenceIndex_e : System.Enum
```

C++/CLI

```
public enum class swRefPlaneReferenceIndex_e : public System.Enum
```

Members

Member	Description
swRefPlaneReference_First	0
swRefPlaneReference_Second	1
swRefPlaneReference_Third	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefPlaneType_e (Type)

SOLIDWORKS API Enumerations

swRefPlaneType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swRefPlaneType_e Enumeration

Reference plane types.

Syntax

Visual Basic (Declaration)

```
Public Enum swRefPlaneType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRefPlaneType\_e
```

C#

```
public enum swRefPlaneType_e : System.Enum
```

C++/CLI

```
public enum class swRefPlaneType_e : public System.Enum
```

Members

Member	Description
swRefPlaneAngle	7
swRefPlaneConstraintBase	11
swRefPlaneDistance	5
swRefPlaneInvalid	0
swRefPlaneLineLine	4
swRefPlaneLinePoint	2
swRefPlaneNormal	8
swRefPlaneOnSurface	9
swRefPlaneParallel	6
swRefPlaneSWStandard	10
swRefPlaneThreePoint	3
swRefPlaneUndefined	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefPointAlongCurveType_e (Type)

SOLIDWORKS API Enumerations

swRefPointAlongCurveType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRefPointAlongCurveType_e Enumeration

Reference point along curve types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRefPointAlongCurveType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRefPointAlongCurveType\_e
```

C#

```
public enum swRefPointAlongCurveType_e : System.Enum
```

C++/CLI

```
public enum class swRefPointAlongCurveType_e : public System.Enum
```

Members

Member	Description
swRefPointAlongCurveDistance	0
swRefPointAlongCurveEvenlyDistributed	2
swRefPointAlongCurvePercentage	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRefPointType_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swRefPointType_e Enumeration

Reference point type.

 Syntax

Visual Basic (Declaration)

Public Enum swRefPointType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swRefPointType_e](#)

C#

public enum swRefPointType_e : System.Enum

C++/CLI

public enum class swRefPointType_e : public System.Enum

 Members

Member	Description
swRefPointAlongCurve	2
swRefPointCenterEdge	3
swRefPointFaceCenter	4
swRefPointFaceVertexProjection	5
swRefPointIntersection	6
swRefPointInvalid	0
swRefPointSketchPoint	7
swRefPointUndefined	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRegionType_e (Type)

SOLIDWORKS API Enumerations

swRegionType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRegionType_e Enumeration

Drawing zone region types.

Syntax

Visual Basic (Declaration)

```
Public Enum swRegionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRegionType\_e
```

C#

```
public enum swRegionType_e : System.Enum
```

C++/CLI

```
public enum class swRegionType_e : public System.Enum
```

Members

Member	Description
swRegionTypeMargins	0
swRegionTypeSheet	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRelativeViewCreationDirection_e (Type)

SOLIDWORKS API Enumerations

swRelativeViewCreationDirection_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRelativeViewCreationDirection_e Enumeration

Relative view creation directions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swRelativeViewCreationDirection_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swRelativeViewCreationDirection\_e
```

C#

```
public enum swRelativeViewCreationDirection_e : System.Enum
```

C++/CLI

```
public enum class swRelativeViewCreationDirection_e : public System.Enum
```

Members

Member	Description
swRelativeViewCreationDirection_AUXILIARY	6
swRelativeViewCreationDirection_BACK	3
swRelativeViewCreationDirection_BOTTOM	5
swRelativeViewCreationDirection_FRONT	0
swRelativeViewCreationDirection_LEFT	4
swRelativeViewCreationDirection_RIGHT	1
swRelativeViewCreationDirection_TOP	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swReliefTearTypes_e (Type)

SOLIDWORKS API Enumerations

swReliefTearTypes_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swReliefTearTypes_e Enumeration

Sheet metal tear-drop relief types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swReliefTearTypes_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swReliefTearTypes_e](#)

C#

public enum swReliefTearTypes_e : System.Enum

C++/CLI

public enum class swReliefTearTypes_e : public System.Enum

Members

Member	Description
swReliefTearTypeExtend	2
swReliefTearTypeRip	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swReloadTemplateResult_e (Type)

SOLIDWORKS API Enumerations

swReloadTemplateResult_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swReloadTemplateResult_e Enumeration

Reload template results.

Syntax

Visual Basic (Declaration)

Public Enum swReloadTemplateResult_e
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swReloadTemplateResult_e](#)

C#

public enum swReloadTemplateResult_e : System.Enum

C++/CLI

public enum class swReloadTemplateResult_e : public System.Enum

Members

Member	Description
swReloadTemplate_CustomSheet	3
swReloadTemplate_FileNotFound	2
swReloadTemplate_Success	0
swReloadTemplate_UnknownError	1
swReloadTemplate_ViewOnly	4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swRemainingDofs_e (Type)

SOLIDWORKS API Enumerations

swRemainingDofs_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRemainingDofs_e Enumeration

Remaining Dofs types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swRemainingDofs_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swRemainingDofs\_e
```

C#

```
public enum swRemainingDofs_e : System.Enum
```

C++/CLI

```
public enum class swRemainingDofs_e : public System.Enum
```

 Members

Member	Description
swRemainingDofs_Failed	3
swRemainingDofs_Restricted	0
swRemainingDofs_RootComponent	4
swRemainingDofs_Unavailable	2
swRemainingDofs_Unrestricted	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swRemoveCommandGroupErrors (Type)

SOLIDWORKS API Enumerations

swRemoveCommandGroupErrors Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swRemoveCommandGroupErrors Enumeration

Error codes for removing CommandGroups.

 Syntax

Visual Basic (Declaration)

```
Public Enum swRemoveCommandGroupErrors
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swRemoveCommandGroupErrors
```

C#

```
public enum swRemoveCommandGroupErrors : System.Enum
```

C++/CLI

```
public enum class swRemoveCommandGroupErrors : public System.Enum
```

 Members

Member	Description
swRemoveCommandGroup_Failed	0
swRemoveCommandGroup_Success	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)