

SOLIDWORKS Enumerations (swconst) — Reference (13/17). swSetRouteFixedLengthError_e swSolidworksWeldmentEndCondOptions_e

SOLIDWORKS API Documentation (converted from CHM)

swSetRouteFixedLengthError_e (Type)

SOLIDWORKS API Enumerations

swSetRouteFixedLengthError_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSetRouteFixedLengthError_e Enumeration

Routing fixed-length errors.

Syntax

Visual Basic (Declaration)

```
Public Enum swSetRouteFixedLengthError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSetRouteFixedLengthError\_e
```

C#

```
public enum swSetRouteFixedLengthError_e : System.Enum
```

C++/CLI

```
public enum class swSetRouteFixedLengthError_e : public System.Enum
```

Members

Member	Description
swSetRouteFixedLengthError_FailedMinBendRadius	6
swSetRouteFixedLengthError_NoError	0
swSetRouteFixedLengthError_NoProperty	3
swSetRouteFixedLengthError_NotFixedLengthSegment	1
swSetRouteFixedLengthError_NotFlexible	2
swSetRouteFixedLengthError_SelectionFailed	5
swSetRouteFixedLengthError_SetLengthFailed	4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSetSectionLabelStatus_e (Type)

SOLIDWORKS API Enumerations

swSetSectionLabelStatus_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swSetSectionLabelStatus_e Enumeration

Section label statuses.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSetSectionLabelStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSetSectionLabelStatus\_e
```

C#

```
public enum swSetSectionLabelStatus_e : System.Enum
```

C++/CLI

```
public enum class swSetSectionLabelStatus_e : public System.Enum
```

 Members

Member	Description
swSetSectionLabel_DuplicateLabelFailure	-2
swSetSectionLabel_DuplicateLabelWarning	1
swSetSectionLabel_Failure	-1
swSetSectionLabel_Okay	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSetValueInConfiguration_e (Type)

SOLIDWORKS API Enumerations

swSetValueInConfiguration_e Enumeration

See Also

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swSetValueInConfiguration_e Enumeration

Values for indicating in which configurations the value should be set.

Syntax

Visual Basic (Declaration)

```
Public Enum swSetValueInConfiguration_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSetValueInConfiguration\_e
```

C#

```
public enum swSetValueInConfiguration_e : System.Enum
```

C++/CLI

```
public enum class swSetValueInConfiguration_e : public System.Enum
```

Members

Member	Description
swSetValue_InAllConfigurations	2 = Set the value in all configurations
swSetValue_InSpecificConfigurations	3 = Set the value in the specific configuration
swSetValue_InThisConfiguration	1 = Set the value in the current configuration only
swSetValue_NoConfiguration	-1 = Ignore configurations in drawing sketches
swSetValue_UseCurrentSetting	0 = Use whatever setting this parameter currently has

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSetValueReturnStatus_e (Type)

SOLIDWORKS API Enumerations

swSetValueReturnStatus_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSetValueReturnStatus_e Enumeration

Return values for attempting to set the value of a parameter.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSetValueReturnStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSetValueReturnStatus\_e
```

C#

```
public enum swSetValueReturnStatus_e : System.Enum
```

C++/CLI

```
public enum class swSetValueReturnStatus_e : public System.Enum
```

Members

Member	Description
swSetValue_DrivenDimension	3 = Cannot be done on a dimension driven by geometry
swSetValue_Failure	1 = Failed for an unknown reason
swSetValue_FrozenFeatureOwner	5 = Owner of the dimension is frozen
swSetValue_InvalidValue	2 = Not a valid value for change parameter
swSetValue_ModelNotLoaded	4 = Model must be loaded in order to set this value
swSetValue_Successful	0 = Successful

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSFLaySym_e (Type)

SOLIDWORKS API Enumerations

swSFLaySym_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swSFLaySym_e Enumeration

Values for direction of lay types.

Syntax

Visual Basic (Declaration)

Public Enum swSFLaySym_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSFLaySym_e](#)

C#

public enum swSFLaySym_e : System.Enum

C++/CLI

public enum class swSFLaySym_e : public System.Enum

Members

Member	Description
swSFCircular	1
swSFCross	2
swSFMultiDir	3
swSFNone	0
swSFParallel	4
swSFParticulate	7
swSFPerp	5
swSFRadial	6

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSFProfileDirection_e (Type)

SOLIDWORKS API Enumerations

swSFProfileDirection_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSFProfileDirection_e Enumeration

Surface finish profile directions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swSFProfileDirection_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSFProfileDirection_e](#)

C#

public enum swSFProfileDirection_e : System.Enum

C++/CLI

public enum class swSFProfileDirection_e : public System.Enum

Members

Member	Description
swSFProfileDirectionCircular	3
swSFProfileDirectionDefinedAngle	4
swSFProfileDirectionNone	0
swSFProfileDirectionParallel	2
swSFProfileDirectionPerp	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSFSymType_e (Type)

SOLIDWORKS API Enumerations

swSFSymType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swSFSymType_e Enumeration

Values for surface finish symbol types and options.

Syntax

Visual Basic (Declaration)

```
Public Enum swSFSymType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSFSymType\_e
```

C#

```
public enum swSFSymType_e : System.Enum
```

C++/CLI

```
public enum class swSFSymType_e : public System.Enum
```

Members

Member	Description
swSFBasic	0
swSFDont_Machine	2
swSFJIS_Basic	8
swSFJIS_Machining_Req	1
swSFJIS_No_Machining	7
swSFJIS_Surface_Texture_1	3
swSFJIS_Surface_Texture_2	4
swSFJIS_Surface_Texture_3	5
swSFJIS_Surface_Texture_4	6
swSFMachining_Req	9

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalAutoReliefTypes_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalAutoReliefTypes_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalAutoReliefTypes_e Enumeration

Sheet metal auto relief types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSheetMetalAutoReliefTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSheetMetalAutoReliefTypes\_e
```

C#

```
public enum swSheetMetalAutoReliefTypes_e : System.Enum
```

C++/CLI

```
public enum class swSheetMetalAutoReliefTypes_e : public System.Enum
```

Members

Member	Description
swSheetMetalAutoReliefTypes_e_Obround	2
swSheetMetalAutoReliefTypes_e_Rectangular	1
swSheetMetalAutoReliefTypes_e_Tear	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalBendNotesBorderSize_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalBendNotesBorderSize_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalBendNotesBorderSize_e Enumeration

Sheet metal bend notes border sizes.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalBendNotesBorderSize_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSheetMetalBendNotesBorderSize_e](#)

C#

public enum swSheetMetalBendNotesBorderSize_e : System.Enum

C++/CLI

public enum class swSheetMetalBendNotesBorderSize_e : public System.Enum



 Members

Member	Description
swSheetMetalBendNotesBorderSizeFiveCharacters	5
swSheetMetalBendNotesBorderSizeFourCharacters	4
swSheetMetalBendNotesBorderSizeOneCharacter	1
swSheetMetalBendNotesBorderSizeThreeCharacters	3
swSheetMetalBendNotesBorderSizeTightFit	0
swSheetMetalBendNotesBorderSizeTwoCharacters	2
swSheetMetalBendNotesBorderSizeUserDefined	6

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalGussetProfileDimType_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalGussetProfileDimType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalGussetProfileDimType_e Enumeration

Sheet metal gusset profile dimensioning schemes.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalGussetProfileDimType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSheetMetalGussetProfileDimType_e](#)



C#

public enum swSheetMetalGussetProfileDimType_e : System.Enum

C++/CLI

public enum class swSheetMetalGussetProfileDimType_e : public System.Enum

 Members

Member	Description
swSheetMetalGussetProfileDimType_IndentDepth	0
swSheetMetalGussetProfileDimType_ProfileDimensions	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalGussetProfileType_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalGussetProfileType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swSheetMetalGussetProfileType_e Enumeration

Sheet metal gusset profile types.

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalGussetProfileType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swSheetMetalGussetProfileType_e](#)

C#

public enum swSheetMetalGussetProfileType_e : System.Enum

C++/CLI

public enum class swSheetMetalGussetProfileType_e : public System.Enum

 Members

Member	Description
swSheetMetalGussetProfileType_Custom	1
swSheetMetalGussetProfileType_Rib	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalMBDBendNotesStyle_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalMBDBendNotesStyle_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalMBDBendNotesStyle_e Enumeration

Sheet metal MBD bend note styles.

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalMBDBendNotesStyle_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSheetMetalMBDBendNotesStyle_e](#)

 [Copy Code](#)

C#

public enum swSheetMetalMBDBendNotesStyle_e : System.Enum

C++/CLI

public enum class swSheetMetalMBDBendNotesStyle_e : public System.Enum

 Members

Member	Description
swSheetMetalMBDBendNotesStyle_AboveBendLine	0
swSheetMetalMBDBendNotesStyle_BelowBendLine	1
swSheetMetalMBDBendNotesStyle_WithLeader	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalModifierError_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalModifierError_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalModifierError_e Enumeration

Sheet metal feature data errors.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSheetMetalModifierError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSheetMetalModifierError\_e
```

C#

```
public enum swSheetMetalModifierError_e : System.Enum
```

C++/CLI

```
public enum class swSheetMetalModifierError_e : public System.Enum
```

Members

Member	Description
swSheetMetalModifierError_GaugeTablePathNotEmpty	5 = ISheetMetalFeatureData.SetUseGaugeTable's GaugeTableFile parameter must be an empty string for derived sheet-metal features
swSheetMetalModifierError_InvalidProperty	3
swSheetMetalModifierError_NoError	0
swSheetMetalModifierError_NotEnabledOnTemplate	2
swSheetMetalModifierError_OldArchitecture	1
swSheetMetalModifierError_UnspecifiedError	4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalOverlapTypes_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalOverlapTypes_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalOverlapTypes_e Enumeration

Sheet metal overlap types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalOverlapTypes_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSheetMetalOverlapTypes_e](#)



C#

public enum swSheetMetalOverlapTypes_e : System.Enum

C++/CLI

public enum class swSheetMetalOverlapTypes_e : public System.Enum

 Members

Member	Description
swSheetMetalOverlapTypes_OpenButt	0
swSheetMetalOverlapTypes_Overlap	1
swSheetMetalOverlapTypes_Underlap	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalOverrideDefaultParameters_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalOverrideDefaultParameters_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalOverrideDefaultParameters_e Enumeration

Types of default parameters to override in a sheet metal feature in a multibody sheet metal part.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSheetMetalOverrideDefaultParameters_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSheetMetalOverrideDefaultParameters\_e
```

C#

```
public enum swSheetMetalOverrideDefaultParameters_e : System.Enum
```

C++/CLI

```
public enum class swSheetMetalOverrideDefaultParameters_e : public System.Enum
```

 Members

Member	Description
swSheetMetalOverrideDefaultParameters.AutoRelief	2
swSheetMetalOverrideDefaultParameters.BendAllowance	1
swSheetMetalOverrideDefaultParameters.BendParameters	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalReliefTypes_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalReliefTypes_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalReliefTypes_e Enumeration

Sheet metal relief types.

 Syntax

Visual Basic (Declaration)

Public Enum swSheetMetalReliefTypes_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swSheetMetalReliefTypes_e](#)

C#

public enum swSheetMetalReliefTypes_e : System.Enum

C++/CLI

public enum class swSheetMetalReliefTypes_e : public System.Enum

 Members

Member	Description
swSheetMetalReliefNone	4
swSheetMetalReliefObround	3
swSheetMetalReliefRectangular	1
swSheetMetalReliefTear	2
swSheetMetalReliefTearBend	5

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetMetalRibGussetType_e (Type)

SOLIDWORKS API Enumerations

swSheetMetalRibGussetType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetMetalRibGussetType_e Enumeration

Sheet metal gusset rib types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swSheetMetalRibGussetType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSheetMetalRibGussetType\_e
```

C#

```
public enum swSheetMetalRibGussetType_e : System.Enum
```

C++/CLI

```
public enum class swSheetMetalRibGussetType_e : public System.Enum
```

 Members

Member	Description
swSheetMetalRibGussetType_Flat	1
swSheetMetalRibGussetType_Rounded	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetPrintQuadrant_e (Type)

SOLIDWORKS API Enumerations

swSheetPrintQuadrant_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSheetPrintQuadrant_e Enumeration

Quadrant options to print in TIFF format a high quality (zoomed) image of a drawing sheet. Used for machine learning and pixel compare tests.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSheetPrintQuadrant_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSheetPrintQuadrant\_e
```

C#

```
public enum swSheetPrintQuadrant_e : System.Enum
```

C++/CLI

```
public enum class swSheetPrintQuadrant_e : public System.Enum
```

 Members

Member	Description
swSheetPrintQuadNotSet	0
swSheetPrintQuadQ1	1
swSheetPrintQuadQ2	2
swSheetPrintQuadQ3	3
swSheetPrintQuadQ4	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetSewingError_e (Type)

SOLIDWORKS API Enumerations

swSheetSewingError_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swSheetSewingError_e Enumeration

Sheet sewing errors.

Syntax

Visual Basic (Declaration)

```
Public Enum swSheetSewingError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSheetSewingError\_e
```

C#

```
public enum swSheetSewingError_e : System.Enum
```

C++/CLI

```
public enum class swSheetSewingError_e : public System.Enum
```

Members

Member	Description
swBadArgument	1
swSewingFailed	3
swSewingIncomplete	4
swSewingOk	0
swUnspecifiedError	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSheetSewingOption_e (Type)

SOLIDWORKS API Enumerations

swSheetSewingOption_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSheetSewingOption_e Enumeration

Sheet sewing options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSheetSewingOption_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swSheetSewingOption\_e
```

C#

```
public enum swSheetSewingOption_e : System.Enum
```

C++/CLI

```
public enum class swSheetSewingOption_e : public System.Enum
```

Members

Member	Description
swSewToSheets	1
swSewToSolid	0
swSewToSolidOrSheets	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swShowMessageBarResult_e (Type)

SOLIDWORKS API Enumerations

swShowMessageBarResult_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swShowMessageBarResult_e Enumeration

Message bar display result codes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swShowMessageBarResult_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swShowMessageBarResult\_e
```

C#

```
public enum swShowMessageBarResult_e : System.Enum
```

C++/CLI

```
public enum class swShowMessageBarResult_e : public System.Enum
```

 Members

Member	Description
swShowMessageBarResult_DontShowAgain	1 = The message bar is not shown when "Don't show again" is selected
swShowMessageBarResult_FailedInvalidDefinition	2 = The message bar could not be displayed due to an invalid definition (e.g., empty title/description)
swShowMessageBarResult_FailedInvalidHandler	3 = The message bar could not be displayed because the Handler argument is NULL or does not support the expected interface
swShowMessageBarResult_Shown	0 = The modeless message bar is shown

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swShowNotificationResult_e (Type)

SOLIDWORKS API Enumerations

swShowNotificationResult_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swShowNotificationResult_e Enumeration

User notification display return values.

Syntax

Visual Basic (Declaration)

```
Public Enum swShowNotificationResult_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swShowNotificationResult\_e
```

C#

```
public enum swShowNotificationResult_e : System.Enum
```

C++/CLI

```
public enum class swShowNotificationResult_e : public System.Enum
```

Members

Member	Description
swShowNotificationResult_DontShowAgain	1 = The user notification is not shown when "Don't show again" is selected
swShowNotificationResult_FailedInvalidDefinition	2 = The user notification could not be displayed due to an invalid definition (e.g., empty title/description)
swShowNotificationResult_FailedInvalidHandler	3 = The user notification could not be displayed because the Handler argument is NULL or does not support the expected interface
swShowNotificationResult_Shown	0 = The user notification is shown

See Also

[SolidWorks.Interop.swconst Namespace](#)

swShutOffSurfaceFeatureStatus_e (Type)

SOLIDWORKS API Enumerations

swShutOffSurfaceFeatureStatus_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swShutOffSurfaceFeatureStatus_e Enumeration

Shut-off surface features statuses.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swShutOffSurfaceFeatureStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swShutOffSurfaceFeatureStatus\_e
```

C#

```
public enum swShutOffSurfaceFeatureStatus_e : System.Enum
```

C++/CLI

```
public enum class swShutOffSurfaceFeatureStatus_e : public System.Enum
```

Members

Member	Description
STATUS_SHUTOFF_COMPLETE	2
STATUS_SHUTOFF_INCOMPLETE	3
STATUS_SHUTOFF_REDUNDANT	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swShutOffSurfacePatchType_e (Type)

SOLIDWORKS API Enumerations

swShutOffSurfacePatchType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swShutOffSurfacePatchType_e Enumeration

Shut-off surface patch types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swShutOffSurfacePatchType_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swShutOffSurfacePatchType\_e
```

C#

```
public enum swShutOffSurfacePatchType_e : System.Enum
```

C++/CLI

```
public enum class swShutOffSurfacePatchType_e : public System.Enum
```

Members

Member	Description
swPatchTypeContact	1
swPatchTypeNoFill	0
swPatchTypeTangent	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimpleFilletPartialEdgeCondition_e (Type)

SOLIDWORKS API Enumerations

swSimpleFilletPartialEdgeCondition_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSimpleFilletPartialEdgeCondition_e Enumeration

Partial fillet edge condition options.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swSimpleFilletPartialEdgeCondition_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSimpleFilletPartialEdgeCondition_e](#)



C#

public enum swSimpleFilletPartialEdgeCondition_e : System.Enum

C++/CLI

public enum class swSimpleFilletPartialEdgeCondition_e : public System.Enum

 Members

Member	Description
swPartialEdgeDistanceOffset	1
swPartialEdgeNone	0
swPartialEdgePercentOffset	2
swPartialEdgeReferenceOffset	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimpleFilletType_e (Type)

SOLIDWORKS API Enumerations

swSimpleFilletType_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swSimpleFilletType_e Enumeration

Simple fillet types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimpleFilletType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimpleFilletType\_e
```

C#

```
public enum swSimpleFilletType_e : System.Enum
```

C++/CLI

```
public enum class swSimpleFilletType_e : public System.Enum
```

Members

Member	Description
swConstRadiusFillet	0
swFaceFillet	2
swFullRoundFillet	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimpleFilletWhichFaces_e (Type)

SOLIDWORKS API Enumerations

swSimpleFilletWhichFaces_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swSimpleFilletWhichFaces_e Enumeration

Faces for simple-fillet features.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimpleFilletWhichFaces_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimpleFilletWhichFaces\_e
```

C#

```
public enum swSimpleFilletWhichFaces_e : System.Enum
```

C++/CLI

```
public enum class swSimpleFilletWhichFaces_e : public System.Enum
```

Members

Member	Description
swFaceFilletSet1	1
swFaceFilletSet2	2
swFullRoundFilletCenterSet	4
swFullRoundFilletSet1	3
swFullRoundFilletSet2	5
swSimpleFilletSingleRadius	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationDamperType_e (Type)

SOLIDWORKS API Enumerations

swSimulationDamperType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationDamperType_e Enumeration

Simulation damper types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationDamperType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSimulationDamperType\_e
```

C#

```
public enum swSimulationDamperType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationDamperType_e : public System.Enum
```

 Members

Member	Description
swSimulationDamper_Linear	0
swSimulationDamper_Torsional	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationForceActionType_e (Type)

SOLIDWORKS API Enumerations

swSimulationForceActionType_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swSimulationForceActionType_e Enumeration

Simulation force action types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationForceActionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationForceActionType\_e
```

C#

```
public enum swSimulationForceActionType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationForceActionType_e : public System.Enum
```

Members

Member	Description
swSimulationForceAction_ActionAndRecation	1
swSimulationForceAction_ActionOnly	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationForceFunctionType_e (Type)

SOLIDWORKS API Enumerations

swSimulationForceFunctionType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationForceFunctionType_e Enumeration

Simulation force function types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationForceFunctionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationForceFunctionType\_e
```

C#

```
public enum swSimulationForceFunctionType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationForceFunctionType_e : public System.Enum
```

Members

Member	Description
swSimulationForceFunction_Constant	0
swSimulationForceFunction_Function	3
swSimulationForceFunction_Harmonic	2
swSimulationForceFunction_Spline	4
swSimulationForceFunction_Step	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationForceType_e (Type)

SOLIDWORKS API Enumerations

swSimulationForceType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationForceType_e Enumeration

Simulation force types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationForceType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationForceType\_e
```

C#

```
public enum swSimulationForceType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationForceType_e : public System.Enum
```

Members

Member	Description
swSimulationForce_LinearForce	0
swSimulationForce_Torque	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationGravityAxisName_e (Type)

SOLIDWORKS API Enumerations

swSimulationGravityAxisName_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swSimulationGravityAxisName_e Enumeration

Simulation gravity axis names.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swSimulationGravityAxisName_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSimulationGravityAxisName_e](#)

C#

public enum swSimulationGravityAxisName_e : System.Enum

C++/CLI

public enum class swSimulationGravityAxisName_e : public System.Enum

Members

Member	Description
swSimulationGravityAxis_Invalid	-1
swSimulationGravityAxis_X	0
swSimulationGravityAxis_Y	1
swSimulationGravityAxis_Z	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationMotorDriveType_e (Type)

SOLIDWORKS API Enumerations

swSimulationMotorDriveType_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swSimulationMotorDriveType_e Enumeration

Simulation motor drive types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationMotorDriveType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationMotorDriveType\_e
```

C#

```
public enum swSimulationMotorDriveType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationMotorDriveType_e : public System.Enum
```

Members

Member	Description
swSimulationMotorDrive_Acceleration	2
swSimulationMotorDrive_Displacement	0
swSimulationMotorDrive_Velocity	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationMotorMotionType_e (Type)

SOLIDWORKS API Enumerations

swSimulationMotorMotionType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationMotorMotionType_e Enumeration

Simulation motor motion types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationMotorMotionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationMotorMotionType\_e
```

C#

```
public enum swSimulationMotorMotionType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationMotorMotionType_e : public System.Enum
```

Members

Member	Description
swSimulationMotorMotion_Constant	0
swSimulationMotorMotion_Function	3
swSimulationMotorMotion_Harmonic	2
swSimulationMotorMotion_Spline	4
swSimulationMotorMotion_Step	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationMotorType_e (Type)

SOLIDWORKS API Enumerations

swSimulationMotorType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationMotorType_e Enumeration

Simulation motor types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationMotorType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSimulationMotorType\_e
```

C#

```
public enum swSimulationMotorType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationMotorType_e : public System.Enum
```

Members

Member	Description
swSimulationLinearMotor	0
swSimulationRotaryMotor	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSimulationSpringType_e (Type)

SOLIDWORKS API Enumerations

swSimulationSpringType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSimulationSpringType_e Enumeration

Simulation spring types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSimulationSpringType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSimulationSpringType\_e
```

C#

```
public enum swSimulationSpringType_e : System.Enum
```

C++/CLI

```
public enum class swSimulationSpringType_e : public System.Enum
```

 Members

Member	Description
swSimulationSpring_Linear	0
swSimulationSpring_Torsional	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchChamferType_e (Type)

SOLIDWORKS API Enumerations

swSketchChamferType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchChamferType_e Enumeration

Chamfer types.

 Syntax

Visual Basic (Declaration)

Public Enum swSketchChamferType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swSketchChamferType_e](#)

C#

public enum swSketchChamferType_e : System.Enum

C++/CLI

public enum class swSketchChamferType_e : public System.Enum

 Members

Member	Description
swSketchChamfer_DistanceAngle	0
swSketchChamfer_DistanceDistance	-1
swSketchChamfer_DistanceEqual	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchCheckFeatureProfileUsage_e (Type)

SOLIDWORKS API Enumerations

swSketchCheckFeatureProfileUsage_e Enumeration

See Also

Send comments on this topic.

 [SolidWorks.Interop.swconst Namespace](#) : swSketchCheckFeatureProfileUsage_e Enumeration

Types of features to check to see if this sketch is valid for use in creating the specified feature.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSketchCheckFeatureProfileUsage_e
    Inherits System.Enum
```

Visual Basic (Usage) 

```
Dim instance As swSketchCheckFeatureProfileUsage\_e
```

C#

```
public enum swSketchCheckFeatureProfileUsage_e : System.Enum
```

C++/CLI

```
public enum class swSketchCheckFeatureProfileUsage_e : public System.Enum
```

 Members

Member	Description
swSketchCheckFeature_BASEEXTRUDE	1
swSketchCheckFeature_BASEEXTRUDETHIN	2
swSketchCheckFeature_BASEREVOLVE	6
swSketchCheckFeature_BASEREVOLVE_THIN	7
swSketchCheckFeature_BOSSEXTRUDE	3
swSketchCheckFeature_BOSSEXTRUDETHIN	4
swSketchCheckFeature_BOSSREVOLVE	8
swSketchCheckFeature_BOSSREVOLVE_THIN	9
swSketchCheckFeature_CUTEXTRUDE	11
swSketchCheckFeature_CUTEXTRUDETHIN	12
swSketchCheckFeature_CUTREVOLVE	13
swSketchCheckFeature_CUTREVOLVE_THIN	14
swSketchCheckFeature_LOFTGUIDE	20
swSketchCheckFeature_LOFTSECTION	18
swSketchCheckFeature_MOLD_PARTINGSURFACES	23
swSketchCheckFeature_RIBSECTION	21
swSketchCheckFeature_SHEETMETAL_BASEFLANGE	22
swSketchCheckFeature_SURFACEEXTRUDE	5
swSketchCheckFeature_SURFACELOFTSECTION	19
swSketchCheckFeature_SURFACEREVOLVE	10
swSketchCheckFeature_SURFACESWEEPSECTION	16
swSketchCheckFeature_SWEEP_PATH_OR_GUIDE	17
swSketchCheckFeature_SWEEPSECTION	15
swSketchCheckFeature_UNSET	0 = Check for things that are wrong in any feature usage

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchCheckFeatureStatus_e (Type)

SOLIDWORKS API Enumerations

swSketchCheckFeatureStatus_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swSketchCheckFeatureStatus_e Enumeration

Statuses after checking to see if this sketch is valid for use in creating the specified feature

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchCheckFeatureStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchCheckFeatureStatus\_e
```

C#

```
public enum swSketchCheckFeatureStatus_e : System.Enum
```

C++/CLI

```
public enum class swSketchCheckFeatureStatus_e : public System.Enum
```

Members

Member	Description
swSketchCheckFeatureStatus_ClosedWantOpen	15 = The contour is closed
swSketchCheckFeatureStatus_ContourIntersectsCenterLine	23 = The revolution contour cannot cross the centerline or touch it in an isolated point
swSketchCheckFeatureStatus_CturXCur	12 = The sketch has intersecting contours
swSketchCheckFeatureStatus_DisjCturs	13 = The sketch contains disjoint contours
swSketchCheckFeatureStatus_DoubleContainment	16 = The sketch contains a doubly nested contour
swSketchCheckFeatureStatus_EmptySketch	5
swSketchCheckFeatureStatus_EntUnspecBad	3 = The sketch contains a self-intersecting entity
swSketchCheckFeatureStatus_EntXEnt	1 = The sketch contains a self-intersecting contour
swSketchCheckFeatureStatus_EntXSelf	2 = The sketch contains a self-intersecting entity
swSketchCheckFeatureStatus_ManyOpen	9 = The sketch has more than one open contour
swSketchCheckFeatureStatus_MixedContours	11 = The sketch has both open and closed contours
swSketchCheckFeatureStatus_MoreThanOneContour	17 = The sketch contains more than one contour
swSketchCheckFeatureStatus_NeedsAxis	21 = The sketch should contain a centerline
swSketchCheckFeatureStatus_NoOpen	10 = The sketch has no more open contours
swSketchCheckFeatureStatus_OK	0 = No problems found, the sketch can be used to create the specified feature.
swSketchCheckFeatureStatus_OneClosedContourExpected	19 = The sketch should contain a single closed contour
swSketchCheckFeatureStatus_OneOpenContourExpected	18 = The sketch should contain a single open contour
swSketchCheckFeatureStatus_OpenOrUnclear	22 = Selected contours are open or ambiguous
swSketchCheckFeatureStatus_OpenWantClosed	14 = The contour is open
swSketchCheckFeatureStatus_ThreeEnts	4 = The sketch cannot be used for a feature because an endpoint is wrongly shared by multiple entities
swSketchCheckFeatureStatus_UnknownError	-1 = Unknown error
swSketchCheckFeatureStatus_WantSingleOpenOrMultiClosedDisjoint	20 = The sketch should contain either one open contour or multiple closed disjoint contours
swSketchCheckFeatureStatus_WrongManyContours	7 = The sketch has more than one contour
swSketchCheckFeatureStatus_WrongOpen	6 = The sketch contains an open contour
swSketchCheckFeatureStatus_ZeroLengthEnt	8 = The sketch contains a zero-length entity

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchEntityType_e (Type)

SOLIDWORKS API Enumerations

swSketchEntityType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSketchEntityType_e Enumeration

Sketch entity types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchEntityType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchEntityType\_e
```

C#

```
public enum swSketchEntityType_e : System.Enum
```

C++/CLI

```
public enum class swSketchEntityType_e : public System.Enum
```

Members

Member	Description
swSketchEntityArc	3
swSketchEntityEllipse	4
swSketchEntityLine	2
swSketchEntityParabola	5
swSketchEntityPoint	1
swSketchEntitySpline	6

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchFullyDefineRelationType_e (Type)

SOLIDWORKS API Enumerations

swSketchFullyDefineRelationType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchFullyDefineRelationType_e Enumeration

Fully defined sketch relations. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchFullyDefineRelationType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchFullyDefineRelationType\_e
```

C#

```
public enum swSketchFullyDefineRelationType_e : System.Enum
```

C++/CLI

```
public enum class swSketchFullyDefineRelationType_e : public System.Enum
```

Members

Member	Description
swSketchFullyDefineRelationType_Coincident	512 or 0x200
swSketchFullyDefineRelationType_Colinear	32 or 0x20
swSketchFullyDefineRelationType_Concentric	64 or 0x40
swSketchFullyDefineRelationType_Equal	1 or 0x1
swSketchFullyDefineRelationType_Horizontal	2 or 0x2
swSketchFullyDefineRelationType_Midpoint	256 or 0x100
swSketchFullyDefineRelationType_Parallel	128 or 0x80
swSketchFullyDefineRelationType_Perpendicular	16 or 0x10
swSketchFullyDefineRelationType_Tangent	8 or 0x8
swSketchFullyDefineRelationType_Vertical	4 or 0x4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchPictureTransparencyStyle_e (Type)

SOLIDWORKS API Enumerations

swSketchPictureTransparencyStyle_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchPictureTransparencyStyle_e Enumeration

Transparency styles for sketch pictures.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchPictureTransparencyStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchPictureTransparencyStyle\_e
```

C#

```
public enum swSketchPictureTransparencyStyle_e : System.Enum
```

C++/CLI

```
public enum class swSketchPictureTransparencyStyle_e : public System.Enum
```

Members

Member	Description
swSketchPictureTransparencyFromFile	1
swSketchPictureTransparencyFullImage	2
swSketchPictureTransparencyNone	0
swSketchPictureTransparencyUserDefined	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchPointType_e (Type)

SOLIDWORKS API Enumerations

swSketchPointType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchPointType_e Enumeration

Sketch point types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSketchPointType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchPointType\_e
```

C#

```
public enum swSketchPointType_e : System.Enum
```

C++/CLI

```
public enum class swSketchPointType_e : public System.Enum
```

 Members

Member	Description
swSketchPointType_Datum	3
swSketchPointType_Ellipse	9
swSketchPointType_External	10
swSketchPointType_FramePoint	7
swSketchPointType_Internal	0
swSketchPointType_MidPoint	6
swSketchPointType-Origin	8
swSketchPointType_Parabola	5
swSketchPointType_Spline	2
swSketchPointType_Unknown	-1
swSketchPointType_User	1
swSketchPointType_VirtualSharp	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchRelationEntityTypes_e (Type)

SOLIDWORKS API Enumerations

swSketchRelationEntityTypes_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSketchRelationEntityTypes_e Enumeration

Sketch relation entity types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchRelationEntityTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchRelationEntityTypes\_e
```

C#

```
public enum swSketchRelationEntityTypes_e : System.Enum
```

C++/CLI

```
public enum class swSketchRelationEntityTypes_e : public System.Enum
```

Members

Member	Description
swSketchRelationEntityType_Arc	4
swSketchRelationEntityType_Cylinder	11
swSketchRelationEntityType_Dimension	14
swSketchRelationEntityType_Ellipse	5
swSketchRelationEntityType_Hatch	8
swSketchRelationEntityType_Line	3
swSketchRelationEntityType_Parabola	6
swSketchRelationEntityType_Plane	10
swSketchRelationEntityType_Point	2
swSketchRelationEntityType_Sphere	12
swSketchRelationEntityType_Spline	7
swSketchRelationEntityType_SubSketch	1
swSketchRelationEntityType_Surface	13
swSketchRelationEntityType_Text	9
swSketchRelationEntityType_Unknown	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchRelationFilterType_e (Type)

SOLIDWORKS API Enumerations

swSketchRelationFilterType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchRelationFilterType_e Enumeration

Sketch relation filter types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSketchRelationFilterType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSketchRelationFilterType\_e
```

C#

```
public enum swSketchRelationFilterType_e : System.Enum
```

C++/CLI

```
public enum class swSketchRelationFilterType_e : public System.Enum
```

 Members

Member	Description
swAll	0
swBroken	6
swDangling	1
swDefinedInContext	4
swExternal	3
swLocked	5
swOverDefining	2
swSelectedEntities	7

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchSegments_e (Type)

SOLIDWORKS API Enumerations

swSketchSegments_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSketchSegments_e Enumeration

Types of [ISketchSegment](#) objects.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchSegments_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swSketchSegments\_e
```

C#

```
public enum swSketchSegments_e : System.Enum
```

C++/CLI

```
public enum class swSketchSegments_e : public System.Enum
```

Members

Member	Description
swSketchARC	1
swSketchELLIPSE	2
swSketchLINE	0
swSketchPARABOLA	5
swSketchSPLINE	3
swSketchTEXT	4

Remarks

Based on these types, you can obtain the appropriate derived class (that is, [ISketchLine](#), [ISketchArc](#), and so on) and call the appropriate derived class functions.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchSegmentType_e (Type)

SOLIDWORKS API Enumerations

swSketchSegmentType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSketchSegmentType_e Enumeration

[ISketchSegment::EqualSegment](#) divide types.

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchSegmentType_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swSketchSegmentType\_e
```

C#

```
public enum swSketchSegmentType_e : System.Enum
```

C++/CLI

```
public enum class swSketchSegmentType_e : public System.Enum
```

Members

Member	Description
swSketchSegmentType_sketchpoints	1
swSketchSegmentType_sketchsegments	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchSlotCreationType_e (Type)

SOLIDWORKS API Enumerations

swSketchSlotCreationType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchSlotCreationType_e Enumeration

Sketch slot creation types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSketchSlotCreationType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSketchSlotCreationType\_e
```

C#

```
public enum swSketchSlotCreationType_e : System.Enum
```

C++/CLI

```
public enum class swSketchSlotCreationType_e : public System.Enum
```

 Members

Member	Description
swSketchSlotCreationType_3pointarc	3 = 3-point arc
swSketchSlotCreationType_arc	2 = Centerpoint arc
swSketchSlotCreationType_center_line	1 = Centerpoint straight
swSketchSlotCreationType_line	0 = Straight

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchSlotLengthType_e (Type)

SOLIDWORKS API Enumerations

swSketchSlotLengthType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSketchSlotLengthType_e Enumeration

Sketch slot length types.

 Syntax

Visual Basic (Declaration)

Public Enum swSketchSlotLengthType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swSketchSlotLengthType_e](#)

C#

public enum swSketchSlotLengthType_e : System.Enum

C++/CLI

public enum class swSketchSlotLengthType_e : public System.Enum

 Members

Member	Description
swSketchSlotLengthType_CenterCenter	0
swSketchSlotLengthType_FullLength	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSketchTrimChoice_e (Type)

SOLIDWORKS API Enumerations

swSketchTrimChoice_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swSketchTrimChoice_e Enumeration

Sketch trim options.

Syntax

Visual Basic (Declaration)

```
Public Enum swSketchTrimChoice_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSketchTrimChoice_e
```

C#

```
public enum swSketchTrimChoice_e : System.Enum
```

C++/CLI

```
public enum class swSketchTrimChoice_e : public System.Enum
```

Members

Member	Description
swSketchTrimClosest	0 = Trim to closest. One and only one sketch segment must be selected before calling ISketchManager::SketchTrim using this option.
swSketchTrimCorner	1 = Corner. Two and only two sketch segments must be selected before calling ISketchManager::SketchTrim using this option.
swSketchTrimEntities	4 = Power trim. Before calling ISketchManager::SketchTrim using this option, use IModelDocExtension::SelectByID2 with Mark = 2 to select 1 or more sketch segments (up to total number of sketch segments in the model), specifying their pick points. The sketch segments are trimmed to the sketch segments nearest their pick points. When you trim sketch segments using Power trim in the user interface, you drag your cursor across sketch segments, and the point at which the cursor crosses a sketch segment is where that sketch segment is trimmed. The API simulates this functionality by requiring you to select sketch segments by pick points, which are used as references when trimming the selected sketch segments.
swSketchTrimEntityPoint	3 = Power trim. One and only one sketch segment must be selected before calling ISketchManager::SketchTrim using this option. Trims to a specific point on the sketch segment. Call this method, specifying non-zero X, Y, and Z, the point at which to trim the selected sketch segment. The specified point must lie on the sketch segment.
swSketchTrimInside	6 = Trim away inside. Before calling ISketchManager::SketchTrim using this option, select at least three sketch segments: two to create the boundary, and one or more that intersect both sketch segments in the boundary. All selected sketch segments that intersect the boundary are trimmed inside the boundary segments.
swSketchTrimOutside	5 = Trim away outside. Before calling ISketchManager::SketchTrim using this option, select at least three sketch segments: two to create the trim boundary, and one or more that intersect both sketch segments in the boundary. All selected sketch segments that intersect the boundary are trimmed outside the boundary segments.
swSketchTrimTwoEntities	2 = Power trim. Before calling ISketchManager::SketchTrim using this option, use IModelDocExtension::SelectByID2 with Mark = 0 to select two intersecting sketch segments, specifying their pick points. Trims the first selected sketch segment to the second intersecting sketch segment. The order in which the sketch segments are selected determines which one is trimmed. The first selected sketch segment will be trimmed on its pick point side to the second selected sketch segment.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSkInternalPntOpts_e (Type)

SOLIDWORKS API Enumerations

swSkInternalPntOpts_e Enumeration

See Also

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swSkInternalPntOpts_e Enumeration

Values to control the display of internal sketch points.

Syntax

Visual Basic (Declaration)

Public Enum swSkInternalPntOpts_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSkInternalPntOpts_e](#)

C#

public enum swSkInternalPntOpts_e : System.Enum

C++/CLI

public enum class swSkInternalPntOpts_e : public System.Enum

Members

Member	Description
swSkPntsDefault	2
swSkPntsOff	0
swSkPntsOn	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSkOffsetCapEndType_e (Type)

SOLIDWORKS API Enumerations

swSkOffsetCapEndType_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swSkOffsetCapEndType_e Enumeration

Offset sketch cap end types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swSkOffsetCapEndType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSkOffsetCapEndType_e](#)



C#

public enum swSkOffsetCapEndType_e : System.Enum

C++/CLI

public enum class swSkOffsetCapEndType_e : public System.Enum

Members

Member	Description
swSkOffsetArcCaps	1
swSkOffsetLineCaps	2
swSkOffsetNoCaps	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

[SolidWorks.Interop.swconst Namespace](#)

swSkOffsetMakeConstructionType_e (Type)

SOLIDWORKS API Enumerations

swSkOffsetMakeConstructionType_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swSkOffsetMakeConstructionType_e Enumeration

Convert original and offset sketch entities to construction sketch entities.

 Syntax

Visual Basic (Declaration)

Public Enum swSkOffsetMakeConstructionType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swSkOffsetMakeConstructionType_e](#)

C#

public enum swSkOffsetMakeConstructionType_e : System.Enum

C++/CLI

public enum class swSkOffsetMakeConstructionType_e : public System.Enum

 Members

Member	Description
swSkOffsetDontMakeConstruction	0 = Do not the convert original or offset sketch entities to construction sketch entities
swSkOffsetMakeBothConstruction	3 = Convert the original and offset sketch entities to construction sketch entities
swSkOffsetMakeOffsConstruction	2 = Convert only the offset sketch entities to construction sketch entities
swSkOffsetMakeOrigConstruction	1 = Convert only the original sketch entities to construction sketch entities

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSlicingTypes_e (Type)

SOLIDWORKS API Enumerations

swSlicingTypes_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swSlicingTypes_e Enumeration

Types of slicing. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSlicingTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSlicingTypes\_e
```

C#

```
public enum swSlicingTypes_e : System.Enum
```

C++/CLI

```
public enum class swSlicingTypes_e : public System.Enum
```

Members

Member	Description
swSlicingTypes_Circle	4 = Creates a circle whose diameter equals the average of the length and width of the rectangle that encloses all the sketch entities; circle is located at the intersection of the source geometry and the slicing plane
swSlicingTypes_Exact	2 = Creates an exact intersection of the mesh BREP body and graphics body resulting in a polyline; set only if swSlicingTypes_Intersection is also set; not valid with swSlicingTypes_Circle and swSlicingTypes_Rectangle
swSlicingTypes_Intersection	1 = For SOLIDWORKS BREP geometry, the slicing is identical to what is generated using the Intersection Curve tool; for mesh BREP and graphics bodies, sketches generated cannot be modified
swSlicingTypes_None	0
swSlicingTypes_Rectangle	8 = Creates a rectangle that encloses all the sketch entities and is located at the intersection of the source geometry and the slicing plane

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSlotMateConstraintOptions_e (Type)

SOLIDWORKS API Enumerations

swSlotMateConstraintOptions_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSlotMateConstraintOptions_e Enumeration

Slot mate constraint options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swSlotMateConstraintOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSlotMateConstraintOptions_e](#)

C#

public enum swSlotMateConstraintOptions_e : System.Enum

C++/CLI

public enum class swSlotMateConstraintOptions_e : public System.Enum

Members

Member	Description
swSlotMateConstraintOption_Centered	1 = Center the component in the slot
swSlotMateConstraintOption_Distance	2 = Place the component axis at a specified distance from the end of the slot
swSlotMateConstraintOption_Free	0 = Allow the component to move freely in the slot
swSlotMateConstraintOption_Percent	3 = Place the component axis at a specified percent of slot length distance from the end of the slot

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSmartComponentSelectionTypes_e (Type)

SOLIDWORKS API Enumerations

swSmartComponentSelectionTypes_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSmartComponentSelectionTypes_e Enumeration

Smart component selection types.

 Syntax

Visual Basic (Declaration)

Public Enum swSmartComponentSelectionTypes_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swSmartComponentSelectionTypes_e](#)

C#

public enum swSmartComponentSelectionTypes_e : System.Enum

C++/CLI

public enum class swSmartComponentSelectionTypes_e : public System.Enum

 Members

Member	Description
swSmartComponentComponents	2
swSmartComponentFeatures	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSmartDimensionDirection_e (Type)

SOLIDWORKS API Enumerations

swSmartDimensionDirection_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSmartDimensionDirection_e Enumeration

Smart dimension extension line directions or rapid dimensioning selector quadrants.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSmartDimensionDirection_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSmartDimensionDirection\_e
```

C#

```
public enum swSmartDimensionDirection_e : System.Enum
```

C++/CLI

```
public enum class swSmartDimensionDirection_e : public System.Enum
```

Members

Member	Description
swSmartDimensionDirection_Down	3
swSmartDimensionDirection_Left	2
swSmartDimensionDirection_Right	0
swSmartDimensionDirection_Up	1

Remarks

In parts, this enumerator is used to specify the extension line that is needed to unambiguously define the angle to dimension. In the user interface, a direction manipulator appears during dimensioning if selected entities do not fully specify the angle to dimension. This enumerator specifies the directions of that manipulator.

In drawings that have **Rapid dimensioning** turned on, this enumerator may be used to specify the quadrant or side of the entities to which to add the display dimension.

See [IModelDocExtension::AddDimension](#).

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMBendState_e (Type)

SOLIDWORKS API Enumerations

swSMBendState_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swSMBendState_e Enumeration

Bend state values for a sheet metal part.

Syntax

Visual Basic (Declaration)

Public Enum swSMBendState_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swSMBendState_e](#)

C#

public enum swSMBendState_e : System.Enum

C++/CLI

public enum class swSMBendState_e : public System.Enum

Members

Member	Description
swSMBendStateFlattened	2 = The bends are flattened; the model is rolled back to just after a FlattenBends feature, but just before the corresponding ProcessBends feature
swSMBendStateFolded	3 = The bends are folded; the model is rolled back to just after a FlattenBends ProcessBends feature pair
swSMBendStateNone	0 = Not a sheet metal part; no SheetMetal features present
swSMBendStateSharps	1 = The bends are in their sharp state, the part is rolled back to just before the first FlattenBends feature

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMCommandStatus_e (Type)

SOLIDWORKS API Enumerations

swSMCommandStatus_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swSMCommandStatus_e Enumeration

Return conditions for various sheet metal APIs that attempt to do set operations.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSMCommandStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSMCommandStatus\_e
```

C#

```
public enum swSMCommandStatus_e : System.Enum
```

C++/CLI

```
public enum class swSMCommandStatus_e : public System.Enum
```

 Members

Member	Description
swSMErrorInvalidBendState	4 = Failed, an invalid bend state was specified
swSMErrorNone	0 = Successful, operation completed
swSMErrorNotAPart	2 = Failed, sheet metal commands only apply to SOLIDWORKS parts
swSMErrorNotASheetMetalPart	3 = Failed, the part contains no sheet metal features
swSMErrorUnknown	1 = Failed, for an unknown reason

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMGExportProfiles_e (Type)

SOLIDWORKS API Enumerations

swSMGExportProfiles_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swSMGExportProfiles_e Enumeration

SMG export profiles.

Syntax

Visual Basic (Declaration)

```
Public Enum swSMGExportProfiles_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSMGExportProfiles\_e
```

C#

```
public enum swSMGExportProfiles_e : System.Enum
```

C++/CLI

```
public enum class swSMGExportProfiles_e : public System.Enum
```

Members

Member	Description
swSMGExportProfiles_Custom	0
swSMGExportProfiles_swDefault	1
swSMGExportProfiles_swWithSurfaceParts	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMGRefinementType_e (Type)

SOLIDWORKS API Enumerations

swSMGRefinementType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSMGRefinementType_e Enumeration

SMG export refinement types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swSMGRefinementType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swSMGRefinementType\_e
```

C#

```
public enum swSMGRefinementType_e : System.Enum
```

C++/CLI

```
public enum class swSMGRefinementType_e : public System.Enum
```

 Members

Member	Description
swSMGRefinementType_Absolute	1
swSMGRefinementType_Relative	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMGRefineRelativeType_e (Type)

SOLIDWORKS API Enumerations

swSMGRefineRelativeType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swSMGRefineRelativeType_e Enumeration

SMG export relative refinement types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swSMGRefineRelativeType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSMGRefineRelativeType\_e
```

C#

```
public enum swSMGRefineRelativeType_e : System.Enum
```

C++/CLI

```
public enum class swSMGRefineRelativeType_e : public System.Enum
```

Members

Member	Description
swSMGRefineRelativeType_ChordalError	0
swSMGRefineRelativeType_NormalDeviation	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSMNormalCutError_e (Type)

SOLIDWORKS API Enumerations

swSMNormalCutError_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSMNormalCutError_e Enumeration

Status codes when creating a Normal Cut feature.

 Syntax

Visual Basic (Declaration)

Public Enum swSMNormalCutError_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swSMNormalCutError_e](#)

C#

public enum swSMNormalCutError_e : System.Enum

C++/CLI

public enum class swSMNormalCutError_e : public System.Enum

 Members

Member	Description
swSMNormalCutError_FaceAlreadyExists	1
swSMNormalCutError_FaceNotPresent	3
swSMNormalCutError_InvalidFace	2
swSMNormalCutError_InvalidFaceArray	4
swSMNormalCutError_NoError	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swSolidBodiesDescriptionPropertyIndex (Type)

SOLIDWORKS API Enumerations

swSolidBodiesDescriptionPropertyIndex Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swSolidBodiesDescriptionPropertyIndex Enumeration

Arguments in the text expression of the Description bounding box property.

Syntax

Visual Basic (Declaration)

```
Public Enum swSolidBodiesDescriptionPropertyIndex
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSolidBodiesDescriptionPropertyIndex
```

C#

```
public enum swSolidBodiesDescriptionPropertyIndex : System.Enum
```

C++/CLI

```
public enum class swSolidBodiesDescriptionPropertyIndex : public System.Enum
```

Members

Member	Description
swSolidBodiesDescriptionProp_Length	1
swSolidBodiesDescriptionProp_None	0
swSolidBodiesDescriptionProp_Thickness	2
swSolidBodiesDescriptionProp_Width	3

Remarks

This enumerator corresponds to dropdowns displayed under **Tools > Options > Document Properties > Weldments > Bounding Box Properties > Solid Bodies Description**.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swSolidworksWeldmentEndCondOptions_e (Type)

SOLIDWORKS API Enumerations

swSolidworksWeldmentEndCondOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swSolidworksWeldmentEndCondOptions_e Enumeration

Weldment end condition options.

Syntax

Visual Basic (Declaration)

```
Public Enum swSolidworksWeldmentEndCondOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swSolidworksWeldmentEndCondOptions\_e
```

C#

```
public enum swSolidworksWeldmentEndCondOptions_e : System.Enum
```

C++/CLI

```
public enum class swSolidworksWeldmentEndCondOptions_e : public System.Enum
```

Members

Member	Description
swEndConditionButt1	2
swEndConditionButt2	3
swEndConditionMiter	1
swEndConditionNone	0
swEndConditionTrim	4
swEndConditionUseDefault	5

See Also

[SolidWorks.Interop.swconst Namespace](#)