

SOLIDWORKS Enumerations (swconst) — Reference (16/17). swUserPreferenceIntegerValue_e- swWeldBeadType_e

SOLIDWORKS API Documentation (converted from CHM)

swUserPreferenceIntegerValue_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swUserPreferenceIntegerValue_e Enumeration

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swUserPreferenceIntegerValue_e Enumeration
User-preference enumerators for system options and document properties.

Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferenceIntegerValue_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferenceIntegerValue\_e
```

C#

```
public enum swUserPreferenceIntegerValue_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferenceIntegerValue_e : public System.Enum
```

Members

Member	Description
sw3DPDFAccuracy	See System Options and Document Properties .
swAcisOutputGeometryPreference	See System Options and Document Properties .
swAcisOutputUnits	See System Options and Document Properties .
swAcisOutputVersion	See System Options and Document Properties .
swAssemblyLoadComponents	See System Options and Document Properties .
swAssemblyOpenMessagesDismissTime	See System Options and Document Properties .
swAssemblyVisualizationComponentColor1	See System Options and Document Properties .
swAssemblyVisualizationComponentColor2	See System Options and Document Properties .
swAssemblyVisualizationComponentColor3	See System Options and Document Properties .
swAssemblyVisualizationComponentColor4	See System Options and Document Properties .
swAssemblyVisualizationComponentColor5	See System Options and Document Properties .
swAssemblyVisualizationComponentColor6	See System Options and Document Properties .
swAutoSaveInterval	See System Options and Document Properties .
swAutoSaveIntervalMode	See System Options and Document Properties .
swBackupCopiesPerDocument	See System Options and Document Properties .
swBackupRemoveInterval	See System Options and Document Properties .
swBasicDimType	See System Options and Document Properties .
swBBoxDescriptionApplyMethod	See System Options and Document Properties .
swBendAllowancePrecision	See System Options and Document Properties .
swBendAngularPrecision	See System Options and Document Properties .
swBendInnerRadiusPrecision	See System Options and Document Properties .
swBendLeadingZero	See System Options and Document Properties .
swBendNoteStyle	See System Options and Document Properties .
swBendTableTagStyle	See System Options and Document Properties .
swBendTableZeroQuantityDisplay	See System Options and Document Properties .
swBOMConfigurationAnchorType	See System Options and Document Properties .
swBOMConfigurationWhatToShow	See System Options and Document Properties .
swBOMControlMissingRowDisplay	See System Options and Document Properties .
swBOMControlSplitDirection	See System Options and Document Properties .
swBomOverriddenCellValueColor	See System Options and Document Properties .
swBomTableZeroQuantityDisplay	See System Options and Document Properties .
swButtonSize	See System Options and Document Properties .
swCartoonEdgeThickness	See System Options and Document Properties .
swCenterLineMarkOrient	See System Options and Document Properties .
swCheckForOutOfDateLightweightComponents	See System Options and Document Properties .
swCollabCheckReadOnlyModifiedInterval	See System Options and Document Properties .
swCollinearChainDimensionArrowHeadTerminationStyle	See System Options and Document Properties .
swColorsBackgroundAppearance	See System Options and Document Properties .
swConfigurationViewForFeatureManagerTree	See System Options and Document Properties .
swCreateBodyFromSurfacesOption	See System Options and Document Properties .
swDefaultBOMPartNumberForNewConfig	See System Options and Document Properties .
swDefaultConfigSortOrder	See System Options and Document Properties .
swDetailingAltLinearDimPrecision	See System Options and Document Properties .
swDetailingAltLinearTolPrecision	See System Options and Document Properties .
swDetailingAngleTrailingZero	See System Options and Document Properties .
swDetailingAngleTrailingZeroTolerance	See System Options and Document Properties .
swDetailingAngularDimLeaderStyle	See System Options and Document Properties .
swDetailingAngularDimPrecision	See System Options and Document Properties .
swDetailingAngularRunningTrailingZero	See System Options and Document Properties .
swDetailingAngularRunningTrailingZeroTolerance	See System Options and Document Properties .
swDetailingAngularToleranceStyle	See System Options and Document Properties .
swDetailingAngularTolPrecision	See System Options and Document Properties .
swDetailingArrowStyleForDimensions	See System Options and Document Properties .
swDetailingArrowStyleForEdgeVertexAttachment	See System Options and Document Properties .
swDetailingArrowStyleForFaceAttachment	See System Options and Document Properties .
swDetailingArrowStyleForUnattached	See System Options and Document Properties .
swDetailingAutoBalloonLayout	See System Options and Document Properties .

swDetailingAuxView_Rotation	See System Options and Document Properties .
swDetailingAuxView_ViewIndication	See System Options and Document Properties .
swDetailingAuxViewLabels_Delimiter	See System Options and Document Properties .
swDetailingAuxViewLabels_Label	See System Options and Document Properties .
swDetailingAuxViewLabels_Name	See System Options and Document Properties .
swDetailingAuxViewLabels_Scale	See System Options and Document Properties .
swDetailingBalloonAutoBalloons	See System Options and Document Properties .
swDetailingBalloonFit	See System Options and Document Properties .
swDetailingBalloonFrameLineStyle	See System Options and Document Properties .
swDetailingBalloonFrameLineThickness	See System Options and Document Properties .
swDetailingBalloonLeaderLineStyle	See System Options and Document Properties .
swDetailingBalloonLeaderLineThickness	See System Options and Document Properties .
swDetailingBalloonLeaderStyle	See System Options and Document Properties .
swDetailingBalloonStyle	See System Options and Document Properties .
swDetailingBendTableBorderLineWeight	See System Options and Document Properties .
swDetailingBendTableGridLineWeight	See System Options and Document Properties .
swDetailingBillOfMaterialBorderLineWeight	See System Options and Document Properties .
swDetailingBillOfMaterialGridLineWeight	See System Options and Document Properties .
swDetailingBOMBalloonFit	See System Options and Document Properties .
swDetailingBOMBalloonStyle	See System Options and Document Properties .
swDetailingBOMLowerText	See System Options and Document Properties .
swDetailingBOMStackedBalloonFit	See System Options and Document Properties .
swDetailingBOMStackedBalloonStyle	See System Options and Document Properties .
swDetailingBOMUpperText	See System Options and Document Properties .
swDetailingBorderLeaderLineStyle	See System Options and Document Properties .
swDetailingBorderLeaderLineThickness	See System Options and Document Properties .
swDetailingBorderZoneDividerLineStyle	See System Options and Document Properties .
swDetailingBorderZoneDividerLineThickness	See System Options and Document Properties .
swDetailingChamferDimLeaderStyle	See System Options and Document Properties .
swDetailingChamferDimTextStyle	See System Options and Document Properties .
swDetailingChamferDimXStyle	See System Options and Document Properties .
swDetailingDatumDisplayType	See System Options and Document Properties .
swDetailingDatumFrameLineStyle	See System Options and Document Properties .
swDetailingDatumFrameLineThickness	See System Options and Document Properties .
swDetailingDatumGbLeaderStyle	See System Options and Document Properties .
swDetailingDatumLeaderLineStyle	See System Options and Document Properties .
swDetailingDatumLeaderLineThickness	See System Options and Document Properties .
swDetailingDetailViewLabels_Delimiter	See System Options and Document Properties .
swDetailingDetailViewLabels_Label	See System Options and Document Properties .
swDetailingDetailViewLabels_Name	See System Options and Document Properties .
swDetailingDetailViewLabels_Scale	See System Options and Document Properties .
swDetailingDimensionArrowPosition	See System Options and Document Properties .
swDetailingDimensionStandard	See System Options and Document Properties .
swDetailingDimensionTextAlignmentHorizontal	See System Options and Document Properties .
swDetailingDimensionTextAlignmentVertical	See System Options and Document Properties .
swDetailingDimensionTextAndLeaderStyle	See System Options and Document Properties .
swDetailingDimFractionScaleIndex	See System Options and Document Properties .
swDetailingDimFractionStyle	See System Options and Document Properties .
swDetailingDimTrailingZero	See System Options and Document Properties .
swDetailingDimXpertChamferOptions	See System Options and Document Properties .
swDetailingDimXpertChamferScheme	See System Options and Document Properties .
swDetailingDimXpertFilletOptions	See System Options and Document Properties .
swDetailingDimXpertSlotScheme	See System Options and Document Properties .
swDetailingDualDimPosition	See System Options and Document Properties .
swDetailingFamilyTableBorderLineWeight	See System Options and Document Properties .
swDetailingFamilyTableGridLineWeight	See System Options and Document Properties .
swDetailingForeshortenedDiameterStyle	See System Options and Document Properties .
swDetailingGeneralTableBorderLineWeight	See System Options and Document Properties .
swDetailingGeneralTableGridLineWeight	See System Options and Document Properties .
swDetailingGtolFrameLineStyle	See System Options and Document Properties .
swDetailingGtolFrameLineThickness	See System Options and Document Properties .
swDetailingGtolLeaderLineStyle	See System Options and Document Properties .
swDetailingGtolLeaderLineThickness	See System Options and Document Properties .
swDetailingGtolLeaderSide	See System Options and Document Properties .
swDetailingGtolLeaderStyle	See System Options and Document Properties .
swDetailingGtolMaterialConditionSymbolPlacement	See System Options and Document Properties .
swDetailingHalfSectionArrow	See System Options and Document Properties .
swDetailingHoleTableBorderLineWeight	See System Options and Document Properties .
swDetailingHoleTableGridLineWeight	See System Options and Document Properties .
swDetailingLeadingZero	See System Options and Document Properties .
swDetailingLinearDimLeaderStyle	See System Options and Document Properties .
swDetailingLinearDimPrecision	See System Options and Document Properties .
swDetailingLinearForeshortened	See System Options and Document Properties .
swDetailingLinearToleranceStyle	See System Options and Document Properties .
swDetailingLinearTolPrecision	See System Options and Document Properties .
swDetailingLocationLabelFit	See System Options and Document Properties .
swDetailingLocationLabelFrameLineStyle	See System Options and Document Properties .
swDetailingLocationLabelFrameLineThickness	See System Options and Document Properties .
swDetailingLocationLabelLowerText	See System Options and Document Properties .
swDetailingLocationLabelStyle	See System Options and Document Properties .
swDetailingLocationLabelUpperText	See System Options and Document Properties .
swDetailingMiscView_Delimiter	See System Options and Document Properties .
swDetailingMiscView_Name	See System Options and Document Properties .
swDetailingMiscView_Scale	See System Options and Document Properties .
swDetailingNoteLeaderLineStyle	See System Options and Document Properties .
swDetailingNoteLeaderLineThickness	See System Options and Document Properties .
swDetailingNoteLeaderSide	See System Options and Document Properties .
swDetailingNotesLeaderStyle	See System Options and Document Properties .
swDetailingNoteTextAlignment	See System Options and Document Properties .
swDetailingOrthoView_Name	See System Options and Document Properties .
swDetailingOrthoViewLabels_Delimiter	See System Options and Document Properties .
swDetailingOrthoViewLabels_Scale	See System Options and Document Properties .
swDetailingPunchTableBorderLineWeight	See System Options and Document Properties .
swDetailingPunchTableGridLineWeight	See System Options and Document Properties .
swDetailingRadialDimLeaderStyle	See System Options and Document Properties .
swDetailingRadialDimsArrowPlacement	See System Options and Document Properties .
swDetailingRevisionCloudLineStyle	See System Options and Document Properties .
swDetailingRevisionCloudLineThickness	See System Options and Document Properties .
swDetailingRevisionTableBorderLineWeight	See System Options and Document Properties .
swDetailingRevisionTableGridLineWeight	See System Options and Document Properties .
swDetailingSectionArrowStyle	See System Options and Document Properties .
swDetailingSectionView_Rotation	See System Options and Document Properties .
swDetailingSectionViewLabels_Delimiter	See System Options and Document Properties .
swDetailingSectionViewLabels_Label	See System Options and Document Properties .
swDetailingSectionViewLabels_Name	See System Options and Document Properties .
swDetailingSectionViewLabels_Scale	See System Options and Document Properties .
swDetailingSectionViewLineStyleDisplay	See System Options and Document Properties .
swDetailingSFSymbolLeaderLineStyle	See System Options and Document Properties .

swDetailingSFSymbolLeaderLineThickness	See System Options and Document Properties .
swDetailingSFSymbolLeaderStyle	See System Options and Document Properties .
swDetailingSFSymbolStandard	See System Options and Document Properties .
swDetailingTitleBlockTableBorderLineWeight	See System Options and Document Properties .
swDetailingTitleBlockTableGridLineWeight	See System Options and Document Properties .
swDetailingToleranceFitTolDisplay	See System Options and Document Properties .
swDetailingToleranceFitTolDisplayAngular	See System Options and Document Properties .
swDetailingToleranceFitTolDisplayLinear	See System Options and Document Properties .
swDetailingToleranceFitTolTextSizing	See System Options and Document Properties .
swDetailingToleranceStyle	See System Options and Document Properties .
swDetailingToleranceTextSizing	See System Options and Document Properties .
swDetailingTrailingZeroProperties	See System Options and Document Properties .
swDetailingTrailingZeroTolerance	See System Options and Document Properties .
swDetailingVirtualSharpStyle	See System Options and Document Properties .
swDetailingWeldSymbolLeaderLineStyle	See System Options and Document Properties .
swDetailingWeldSymbolLeaderLineThickness	See System Options and Document Properties .
swDetailingWeldSymbolLeaderSide	See System Options and Document Properties .
swDetailingWeldTableBorderLineWeight	See System Options and Document Properties .
swDetailingWeldTableGridLineWeight	See System Options and Document Properties .
swDimensionsExtensionLineStyle	See System Options and Document Properties .
swDimensionsExtensionLineStyleThickness	See System Options and Document Properties .
swDimOverrideCellValueColor	See System Options and Document Properties .
swDisplayStateCreationChoice	See System Options and Document Properties .
swDocumentColorFeatBend	See System Options and Document Properties .
swDocumentColorFeatBoss	See System Options and Document Properties .
swDocumentColorFeatCavity	See System Options and Document Properties .
swDocumentColorFeatChamfer	See System Options and Document Properties .
swDocumentColorFeatCut	See System Options and Document Properties .
swDocumentColorFeatDerivedPart	See System Options and Document Properties .
swDocumentColorFeatDome	See System Options and Document Properties .
swDocumentColorFeatEndCap	See System Options and Document Properties .
swDocumentColorFeatExtrude	See System Options and Document Properties .
swDocumentColorFeatFilllet	See System Options and Document Properties .
swDocumentColorFeatForm	See System Options and Document Properties .
swDocumentColorFeatGusset	See System Options and Document Properties .
swDocumentColorFeatHole	See System Options and Document Properties .
swDocumentColorFeatLibrary	See System Options and Document Properties .
swDocumentColorFeatLoft	See System Options and Document Properties .
swDocumentColorFeatLoftCut	See System Options and Document Properties .
swDocumentColorFeatMidSurface	See System Options and Document Properties .
swDocumentColorFeatPattern	See System Options and Document Properties .
swDocumentColorFeatRefSurface	See System Options and Document Properties .
swDocumentColorFeatReplaceFace	See System Options and Document Properties .
swDocumentColorFeatRevolution	See System Options and Document Properties .
swDocumentColorFeatRib	See System Options and Document Properties .
swDocumentColorFeatShape	See System Options and Document Properties .
swDocumentColorFeatShell	See System Options and Document Properties .
swDocumentColorFeatStructuralMember	See System Options and Document Properties .
swDocumentColorFeatSurfCut	See System Options and Document Properties .
swDocumentColorFeatSweep	See System Options and Document Properties .
swDocumentColorFeatSweepCut	See System Options and Document Properties .
swDocumentColorFeatThicken	See System Options and Document Properties .
swDocumentColorFeatWeldBead	See System Options and Document Properties .
swDocumentColorFeatWrap	See System Options and Document Properties .
swDocumentColorHidden	See System Options and Document Properties .
swDocumentColorShading	See System Options and Document Properties .
swDocumentColorWireFrame	See System Options and Document Properties .
swDrawing_Auto_Solve_Threshold	See System Options and Document Properties .
swDrawingAreaHatchFillStyle	See System Options and Document Properties .
swDrawingPrintCrosshatchOutOfDateViews	See System Options and Document Properties .
swDrawingProjectionType	See System Options and Document Properties .
swDrawingSheetCustomPropSheetNo	See System Options and Document Properties .
swDrawingSheetsZonesLetterLayout	See System Options and Document Properties .
swDrawingSheetsZonesOrigin	See System Options and Document Properties .
swDxfGeomExportOption	See System Options and Document Properties .
swDxfMappingFileIndex	See System Options and Document Properties .
swDxfMultiSheetOption	See System Options and Document Properties .
swDxfOutputFonts	See System Options and Document Properties .
swDxfOutputLineStyle	See System Options and Document Properties .
swDxfOutputNoScale	See System Options and Document Properties .
swDxfVersion	See System Options and Document Properties .
swEdgesHiddenEdgeDisplay	See System Options and Document Properties .
swEdgesInContextEditTransparency	See System Options and Document Properties .
swEdgesInContextEditTransparencyType	See System Options and Document Properties .
swEdgesShadedModeDisplay	See System Options and Document Properties .
swEdgesTangentEdgeDisplay	See System Options and Document Properties .
swEdrawingsAttachmentOption	See System Options and Document Properties .
swEdrawingsAttachmentType	See System Options and Document Properties .
swEdrawingsSaveAsSelectionOption	See System Options and Document Properties .
swEnableAutoMateFlip	See System Options and Document Properties .
swEnvelopeComponentColor	See System Options and Document Properties .
swExportIFCUnits	See System Options and Document Properties .
swExportJpegCompression	See System Options and Document Properties .
swExportPlyUnits	See System Options and Document Properties .
swExportStlUnits	See System Options and Document Properties .
swExportSVPJFileFormatGroupType	See System Options and Document Properties .
swExportVrmUnits	See System Options and Document Properties .
swExportVrmVersion	See System Options and Document Properties .
swExternalReferencesUpdateOutOfDateLinkedDesignTable	See System Options and Document Properties .
swFeatureManagerAnnotationsVisibility	See System Options and Document Properties .
swFeatureManagerBlocksVisibility	See System Options and Document Properties .
swFeatureManagerConfigTableFolderVisibility	See System Options and Document Properties .
swFeatureManagerDefaultPlanesVisibility	See System Options and Document Properties .
swFeatureManagerDesignBinderVisibility	See System Options and Document Properties .
swFeatureManagerDesignTableVisibility	See System Options and Document Properties .
swFeatureManagerDisplayWarnings	See System Options and Document Properties .
swFeatureManagerEDrawingMarkups	See System Options and Document Properties .
swFeatureManagerEquationsVisibility	See System Options and Document Properties .
swFeatureManagerFavorites	See System Options and Document Properties .
swFeatureManagerHistory	See System Options and Document Properties .
swFeatureManagerLightsVisibility	See System Options and Document Properties .
swFeatureManagerMarkupsVisibility	See System Options and Document Properties .
swFeatureManagerMateReferencesVisibility	See System Options and Document Properties .
swFeatureManagerMaterialVisibility	See System Options and Document Properties .
swFeatureManagerMeshBodiesVisibility	See System Options and Document Properties .
swFeatureManagerOriginVisibility	See System Options and Document Properties .
swFeatureManagerSelectionSetsVisibility	See System Options and Document Properties .
swFeatureManagerSensorVisibility	See System Options and Document Properties .

swFeatureManagerSolidBodiesVisibility	See System Options and Document Properties .
swFeatureManagerSurfaceBodiesVisibility	See System Options and Document Properties .
swFeatureManagerTableFolderVisibility	See System Options and Document Properties .
swFeatureManagerTranslatedLanguage	See System Options and Document Properties .
swFlatPatternColorsBendLinesDownDirection	See System Options and Document Properties .
swFlatPatternColorsBendLinesHems	See System Options and Document Properties .
swFlatPatternColorsBendLinesUpDirection	See System Options and Document Properties .
swFlatPatternColorsBoundingBox	See System Options and Document Properties .
swFlatPatternColorsFlatPatternSketchColor	See System Options and Document Properties .
swFlatPatternColorsFromFeature	See System Options and Document Properties .
swFlatPatternColorsModelEdges	See System Options and Document Properties .
swGraphicalAnnotationsColor	See System Options and Document Properties .
swGraphicsTreeItemNormalColor	See System Options and Document Properties .
swGridMinorLinesPerMajor	See System Options and Document Properties .
swGtoDecimalSeparatorType	See System Options and Document Properties .
swHiddenEdgeDisplayDefault	See System Options and Document Properties .
swHoleTableHoleLocationPrecision	See System Options and Document Properties .
swHoleTableOriginStandard	See System Options and Document Properties .
swHoleTableTagStyle	See System Options and Document Properties .
swIFCExportSaveType	See System Options and Document Properties .
swIGESCurveRepresentation	See System Options and Document Properties .
swIGESRepresentation	See System Options and Document Properties .
swIGESSystem	See System Options and Document Properties .
swImageQualityShaded	See System Options and Document Properties .
swImageQualityWireframe	See System Options and Document Properties .
swImageQualityWireframeValue	See System Options and Document Properties .
swImportCheckAndRepair	See System Options and Document Properties .
swImportCurvePreference	See System Options and Document Properties .
swImportNeutral_CurvesAndPointsOption	See System Options and Document Properties .
swImportNeutral_KnitOption	See System Options and Document Properties .
swImportNeutralAssemblyStructureMapping	See System Options and Document Properties .
swImportNeutralUnits	See System Options and Document Properties .
swImportStlVrmModelType	See System Options and Document Properties .
swImportStlVrmUnits	See System Options and Document Properties .
swImportUnitPreference	See System Options and Document Properties .
swImportUseBrep	See System Options and Document Properties .
swLargeAsmLevelOfDetail	See System Options and Document Properties .
swLargeAsmModeAutoActivate	Obsolete.
swLargeAsmModeAutoRecoverCount	See System Options and Document Properties .
swLargeAsmModeCheckOutOfDateLightweight	See System Options and Document Properties .
swLargeAsmModeDisplayModeForNewDrawViews	See System Options and Document Properties .
swLargeAsmModeLargeDesignReviewThreshold	See System Options and Document Properties .
swLargeAsmModeThreshold	See System Options and Document Properties .
swLevelOfDetail	See System Options and Document Properties .
swLineFontAdjoiningComponent	See System Options and Document Properties .
swLineFontAdjoiningComponentStyle	See System Options and Document Properties .
swLineFontBendLineDownStyle	See System Options and Document Properties .
swLineFontBendLineDownThickness	See System Options and Document Properties .
swLineFontBendLineUpStyle	See System Options and Document Properties .
swLineFontBendLineUpThickness	See System Options and Document Properties .
swLineFontBreakLineStyle	See System Options and Document Properties .
swLineFontBreakLineThickness	See System Options and Document Properties .
swLineFontConstructionCurvesStyle	See System Options and Document Properties .
swLineFontConstructionCurvesThickness	See System Options and Document Properties .
swLineFontCosmeticThreadStyle	See System Options and Document Properties .
swLineFontCosmeticThreadThickness	See System Options and Document Properties .
swLineFontCrosshatchStyle	See System Options and Document Properties .
swLineFontCrosshatchThickness	See System Options and Document Properties .
swLineFontDetailBorderStyle	See System Options and Document Properties .
swLineFontDetailBorderThickness	See System Options and Document Properties .
swLineFontDetailCircleStyle	See System Options and Document Properties .
swLineFontDetailCircleThickness	See System Options and Document Properties .
swLineFontDimensionsStyle	See System Options and Document Properties .
swLineFontDimensionsThickness	See System Options and Document Properties .
swLineFontEmphasizedSectionEndCapStyle	See System Options and Document Properties .
swLineFontEmphasizedSectionOutlineStyle	See System Options and Document Properties .
swLineFontEmphasizedSectionThickness	See System Options and Document Properties .
swLineFontEnvelopeComponentStyle	See System Options and Document Properties .
swLineFontEnvelopeComponentThickness	See System Options and Document Properties .
swLineFontExplodedLineStyle	See System Options and Document Properties .
swLineFontExplodedLinesThickness	See System Options and Document Properties .
swLineFontHiddenEdgesEndCap	See System Options and Document Properties .
swLineFontHiddenEdgesStyle	See System Options and Document Properties .
swLineFontHiddenEdgesThickness	See System Options and Document Properties .
swLineFontHideTangentEdgeStyle	See System Options and Document Properties .
swLineFontHideTangentEdgeThickness	See System Options and Document Properties .
swLineFontSectionLineStyle	See System Options and Document Properties .
swLineFontSectionLineThickness	See System Options and Document Properties .
swLineFontSketchCurvesEndCap	See System Options and Document Properties .
swLineFontSketchCurvesStyle	See System Options and Document Properties .
swLineFontSketchCurvesThickness	See System Options and Document Properties .
swLineFontSpeedPakDrawingsModelEdgesStyle	See System Options and Document Properties .
swLineFontSpeedPakDrawingsModelEdgesThickness	See System Options and Document Properties .
swLineFontTangentEdgesStyle	See System Options and Document Properties .
swLineFontTangentEdgesThickness	See System Options and Document Properties .
swLineFontViewArrowStyle	See System Options and Document Properties .
swLineFontViewArrowThickness	See System Options and Document Properties .
swLineFontVisibleEdgesEndCap	See System Options and Document Properties .
swLineFontVisibleEdgesStyle	See System Options and Document Properties .
swLineFontVisibleEdgesThickness	See System Options and Document Properties .
swLoadExternalReferences	See System Options and Document Properties .
swManipConnectionPointColor	See System Options and Document Properties .
swMarkAssyAsModifiedWhenCosmeticChangesToRefDocs	See System Options and Document Properties .
swMaterialPropertyAreaHatchFillStyle	See System Options and Document Properties .
swMatesDefaultMisalignedType	See System Options and Document Properties .
swMaximumRecentDocuments	See System Options and Document Properties .
swOppHandMirrorComp	See System Options and Document Properties .
swPageSetupPrinterDrawingColor	See System Options and Document Properties .
swPageSetupPrinterOrientation	See System Options and Document Properties .
swParasolidOutputVersion	See System Options and Document Properties .
swPartDimXpertChainDistanceBwtnFeatBlockPrecision	See System Options and Document Properties .
swPartDimXpertChainInnerToType	See System Options and Document Properties .
swPartDimXpertChainPatternLocBlockPrecision	See System Options and Document Properties .
swPartDimXpertChainPatternLocToType	See System Options and Document Properties .
swPartDimXpertChamferAngleBlockPrecision	See System Options and Document Properties .
swPartDimXpertChamferAngleToType	See System Options and Document Properties .
swPartDimXpertChamferDistanceBlockPrecision	See System Options and Document Properties .
swPartDimXpertChamferDistanceToType	See System Options and Document Properties .

swPartDimXpertDisplayDatumGtolLinearDimAttachment	See System Options and Document Properties .
swPartDimXpertDisplayDatumGtolSurfaceAttachment	See System Options and Document Properties .
swPartDimXpertDisplayGtolLinearDimAttachment	See System Options and Document Properties .
swPartDimXpertDisplayHoleDimensionType	See System Options and Document Properties .
swPartDimXpertDisplaySlotDimensionType	See System Options and Document Properties .
swPartDimXpertGeneralToleranceClass	See System Options and Document Properties .
swPartDimXpertLengthUnitTo1Decimals	See System Options and Document Properties .
swPartDimXpertLengthUnitTo2Decimals	See System Options and Document Properties .
swPartDimXpertLengthUnitTo3Decimals	See System Options and Document Properties .
swPartDimXpertLocationAngleBlockPrecision	See System Options and Document Properties .
swPartDimXpertLocationAngleToType	See System Options and Document Properties .
swPartDimXpertLocationDistanceBlockPrecision	See System Options and Document Properties .
swPartDimXpertLocationDistanceToType	See System Options and Document Properties .
swPartDimXpertSizeCounterboreDiameterBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeCounterboreDiameterToType	See System Options and Document Properties .
swPartDimXpertSizeCountersinkAngleBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeCountersinkAngleToType	See System Options and Document Properties .
swPartDimXpertSizeCountersinkDiameterBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeCountersinkDiameterToType	See System Options and Document Properties .
swPartDimXpertSizeDepthBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeDepthToType	See System Options and Document Properties .
swPartDimXpertSizeDiameterBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeDiameterToType	See System Options and Document Properties .
swPartDimXpertSizeFilletRadiusBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeFilletRadiusToType	See System Options and Document Properties .
swPartDimXpertSizeLengthSlotBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeLengthSlotToType	See System Options and Document Properties .
swPartDimXpertSizeWidthSlotBlockPrecision	See System Options and Document Properties .
swPartDimXpertSizeWidthSlotToType	See System Options and Document Properties .
swPartDimXpertToleranceMethod	See System Options and Document Properties .
swPDFExportOLE DPI	See System Options and Document Properties .
swPDFExportShadedDraftDPI	See System Options and Document Properties .
swPenSketchStrokeColor	See System Options and Document Properties .
swPenSketchStrokeThickness	See System Options and Document Properties .
swPerformanceAssemRebuildOnLoad	See System Options and Document Properties .
swPerformanceFeedback	See System Options and Document Properties .
swPerformanceViewsToDraftQuality	See System Options and Document Properties .
swPlaneDisplayBackFaceColor	See System Options and Document Properties .
swPlaneDisplayFrontFaceColor	See System Options and Document Properties .
swPlaneDisplayIntersectionLineColor	See System Options and Document Properties .
swPlaneDisplayTransparency	See System Options and Document Properties .
swPLYQuality	See System Options and Document Properties .
swPMEditColor	See System Options and Document Properties .
swPolarMinHoles	See System Options and Document Properties .
swPrimaryComponentIdentifier	See System Options and Document Properties .
swPropertyManagerColorActiveClosedDivider	See System Options and Document Properties .
swPropertyManagerColorBackground	See System Options and Document Properties .
swPropertyManagerColorDivider	See System Options and Document Properties .
swPropertyManagerColorEditBox	See System Options and Document Properties .
swPropertyManagerColorEditText	See System Options and Document Properties .
swPropertyManagerColorImportantMessage	See System Options and Document Properties .
swPropertyManagerColorInnerBorder	See System Options and Document Properties .
swPropertyManagerColorLabelAndIcon	See System Options and Document Properties .
swPropertyManagerColorOuterBorder	See System Options and Document Properties .
swPropertyManagerColorTitle	See System Options and Document Properties .
swPropertyManagerColorTopBorder	See System Options and Document Properties .
swPropertyMgrDockingState	See System Options and Document Properties .
swPunchTableLocationPrecision	See System Options and Document Properties .
swPunchTableOriginStandard	See System Options and Document Properties .
swPunchTableTagStyle	See System Options and Document Properties .
swRebuildErrorAction	See System Options and Document Properties .
swRebuildOnActivation	See System Options and Document Properties .
swRecognizedMeshFaceColor	See System Options and Document Properties .
swRefVisualizationChildrenColor	See System Options and Document Properties .
swRefVisualizationParentColor	See System Options and Document Properties .
swResolveLightweight	See System Options and Document Properties .
swRevisionTableMultipleSheetStyle	See System Options and Document Properties .
swRevisionTableSymbolShape	See System Options and Document Properties .
swRevisionTableTagStyle	See System Options and Document Properties .
swSaveAssemblyAsPartOptions	See System Options and Document Properties .
swSaveIFCFormat	See System Options and Document Properties .
swSaveReminderAutoDismissInterval	See System Options and Document Properties .
swSaveReminderInterval	See System Options and Document Properties .
swSaveReminderIntervalMode	See System Options and Document Properties .
swSaveToVersion	See System Options and Document Properties .
swSearchDissectionDailyStartTime	See System Options and Document Properties .
swSearchDissectionDailyStopTime	See System Options and Document Properties .
swSearchIndexingPerformance	See System Options and Document Properties .
swSearchMaxResultsPerDataSource	See System Options and Document Properties .
swSearchResultsPerPage	See System Options and Document Properties .
swShadedSketchContourColor	See System Options and Document Properties .
swSheetMetalBendNotesBorderSize	See System Options and Document Properties .
swSheetMetalBendNotesBorderStyle	See System Options and Document Properties .
swSheetMetalBendNotesLeaderAnchor	See System Options and Document Properties .
swSheetMetalBendNotesLeaderDisplay	See System Options and Document Properties .
swSheetMetalBendNotesLeaderLineStyle	See System Options and Document Properties .
swSheetMetalBendNotesLeaderLineThickness	See System Options and Document Properties .
swSheetMetalBendNotesTextAlignment	See System Options and Document Properties .
swSheetMetalColorBendLinesDown	See System Options and Document Properties .
swSheetMetalColorBendLinesHems	See System Options and Document Properties .
swSheetMetalColorBendLinesUp	See System Options and Document Properties .
swSheetMetalColorBoundingBox	See System Options and Document Properties .
swSheetMetalColorFlatPatternSketch	See System Options and Document Properties .
swSheetMetalColorFormFeature	See System Options and Document Properties .
swSheetMetalColorModelEdges	See System Options and Document Properties .
swSheetMetalMBDBalloonStyle	See System Options and Document Properties .
swSheetMetalMBDBendNotesStyle	See System Options and Document Properties .
swSheetMetalMBDFit	See System Options and Document Properties .
swSheetMetalMBDLeaderAnchor	See System Options and Document Properties .
swSheetMetalMBDLeaderDisplay	See System Options and Document Properties .
swSheetMetalMBDLeaderLineThickness	See System Options and Document Properties .
swSheetMetalMBDLeaderStyle	See System Options and Document Properties .
swSheetMetalMBDLineStyle_BendLinesDown	See System Options and Document Properties .
swSheetMetalMBDLineStyle_BendLinesUp	See System Options and Document Properties .
swSheetMetalMBDTextAlignment	See System Options and Document Properties .
swSheetPrintQuadrant	(Internal) Specifies the quadrant to print a high quality (zoomed) image of a drawing sheet to a TIFF format. Use specifically for machine learning and pixel compare tests.
swShowEquationCircularReferencesMessage	See System Options and Document Properties .
swShowEquationPotentialCircularReferencesMessage	See System Options and Document Properties .

swSketch_Auto_Solve_Threshold	See System Options and Document Properties .
swSketchExplodedColor	See System Options and Document Properties .
swSMGExportProfile	See System Options and Document Properties .
swSMGRefinementRelativeQuality	See System Options and Document Properties .
swSMGRefinementType	See System Options and Document Properties .
swSMGRefineRelativeType	See System Options and Document Properties .
swSnapPointsPerMinor	See System Options and Document Properties .
swSolidBodiesDescriptionFirstPropertyIndex	See System Options and Document Properties .
swSolidBodiesDescriptionSecondPropertyIndex	See System Options and Document Properties .
swSolidBodiesDescriptionThirdPropertyIndex	See System Options and Document Properties .
swStepAP	See System Options and Document Properties .
swStepExportPreference	See System Options and Document Properties .
swSTLQuality	See System Options and Document Properties .
swSystemColorsActiveSelectionListBox	See System Options and Document Properties .
swSystemColorsAsmInterferenceVolume	See System Options and Document Properties .
swSystemColorsAssemblyEditPart	See System Options and Document Properties .
swSystemColorsAssemblyEditPartHiddenLines	See System Options and Document Properties .
swSystemColorsAssemblyNonEditPart	See System Options and Document Properties .
swSystemColorsBackground	See System Options and Document Properties .
swSystemColorsBottomGradientColor	See System Options and Document Properties .
swSystemColorsConstructionGeometry	See System Options and Document Properties .
swSystemColorsCrossHair	See System Options and Document Properties .
swSystemColorsCurrentColorScheme	See System Options and Document Properties .
swSystemColorsDanglingDimension	See System Options and Document Properties .
swSystemColorsDimsNotMarkedForDrawing	See System Options and Document Properties .
swSystemColorsDrawingsBackground	See System Options and Document Properties .
swSystemColorsDrawingsChangedDimensions	See System Options and Document Properties .
swSystemColorsDrawingsHiddenModelEdge	See System Options and Document Properties .
swSystemColorsDrawingsLockedFocus	See System Options and Document Properties .
swSystemColorsDrawingsModelTangentEdges	See System Options and Document Properties .
swSystemColorsDrawingsPaper	See System Options and Document Properties .
swSystemColorsDrawingsPaperBorder	See System Options and Document Properties .
swSystemColorsDrawingsPaperShadow	See System Options and Document Properties .
swSystemColorsDrawingsSheetBorder	See System Options and Document Properties .
swSystemColorsDrawingsSpeedPakModelEdge	See System Options and Document Properties .
swSystemColorsDrawingsViewBorder	See System Options and Document Properties .
swSystemColorsDrawingsVisibleModelEdge	See System Options and Document Properties .
swSystemColorsDTDim	See System Options and Document Properties .
swSystemColorsDynamicHighlight	See System Options and Document Properties .
swSystemColorsEnvelopes	See System Options and Document Properties .
swSystemColorsGhostSelColor	See System Options and Document Properties .
swSystemColorsGridLinesMajor	See System Options and Document Properties .
swSystemColorsGridLinesMinor	See System Options and Document Properties .
swSystemColorsHiddenEdgeSelectionShow	See System Options and Document Properties .
swSystemColorsHighlight	See System Options and Document Properties .
swSystemColorsIconColor	See System Options and Document Properties .
swSystemColorsImportedAnnotation	See System Options and Document Properties .
swSystemColorsImportedDrivenAnnotation	See System Options and Document Properties .
swSystemColorsImportedDrivingAnnotation	See System Options and Document Properties .
swSystemColorsInactiveEntity	See System Options and Document Properties .
swSystemColorsInactiveHandles	See System Options and Document Properties .
swSystemColorsMateCalloutError	See System Options and Document Properties .
swSystemColorsMateCalloutHealthy	See System Options and Document Properties .
swSystemColorsMateCalloutWarning	See System Options and Document Properties .
swSystemColorsMeasureSelection	See System Options and Document Properties .
swSystemColorsNonImportedAnnotation	See System Options and Document Properties .
swSystemColorsNoteEditHandle	See System Options and Document Properties .
swSystemColorsNoteHandle	See System Options and Document Properties .
swSystemColorsPropertyManagerColor	See System Options and Document Properties .
swSystemColorsRefTriadX	See System Options and Document Properties .
swSystemColorsRefTriadY	See System Options and Document Properties .
swSystemColorsRefTriadZ	See System Options and Document Properties .
swSystemColorsSelectedFaceShaded	See System Options and Document Properties .
swSystemColorsSelectedItem1	See System Options and Document Properties .
swSystemColorsSelectedItem2	See System Options and Document Properties .
swSystemColorsSelectedItem3	See System Options and Document Properties .
swSystemColorsSelectedItem4	See System Options and Document Properties .
swSystemColorsSelectedItem5	See System Options and Document Properties .
swSystemColorsSelectedItem6	See System Options and Document Properties .
swSystemColorsShadedEdge	See System Options and Document Properties .
swSystemColorsSheetMetalTemporaryGraphics	See System Options and Document Properties .
swSystemColorsSketchFullyDefined	See System Options and Document Properties .
swSystemColorsSketchInactive	See System Options and Document Properties .
swSystemColorsSketchInvalidGeometry	See System Options and Document Properties .
swSystemColorsSketchNotSolved	See System Options and Document Properties .
swSystemColorsSketchOverDefined	See System Options and Document Properties .
swSystemColorsSketchUnderDefined	See System Options and Document Properties .
swSystemColorsSurfacesOpenEdge	See System Options and Document Properties .
swSystemColorsSwiftAnnotations	See System Options and Document Properties .
swSystemColorsSwiftFullyConstrained	See System Options and Document Properties .
swSystemColorsSwiftOverConstrained	See System Options and Document Properties .
swSystemColorsSwiftUnderConstrained	See System Options and Document Properties .
swSystemColorsTemporaryGraphics	See System Options and Document Properties .
swSystemColorsTemporaryGraphicsShaded	See System Options and Document Properties .
swSystemColorsTemporarySketchDragging	See System Options and Document Properties .
swSystemColorsText	See System Options and Document Properties .
swSystemColorsToleranceAnalysisDim	See System Options and Document Properties .
swSystemColorsTopGradientColor	See System Options and Document Properties .
swSystemColorsTreeItemNormal	See System Options and Document Properties .
swSystemColorsTreeItemSelected	See System Options and Document Properties .
swSystemColorsTreeViewBackground	See System Options and Document Properties .
swSystemColorsViewportBackground	See System Options and Document Properties .
swSystemColorsWeldPathSelection	See System Options and Document Properties .
swSystemOptionDisplayAntiAliasing	See System Options and Document Properties .
swTableHoleDualDimensionPos	See System Options and Document Properties .
swTablePunchDualDimensionPos	See System Options and Document Properties .
swTangentEdgeDisplayDefault	See System Options and Document Properties .
swTempGraphicsAddMaterialColor	See System Options and Document Properties .
swTempGraphicsRemoveMaterialColor	See System Options and Document Properties .
swTextSize	See System Options and Document Properties .
swTiffCompressionScheme	See System Options and Document Properties .
swTiffImageType	See System Options and Document Properties .
swTiffPrintDPI	See System Options and Document Properties .
swTiffPrintPaperSize	See System Options and Document Properties .
swTiffPrintScaleFactor	See System Options and Document Properties .
swTiffScreenOrPrintCapture	See System Options and Document Properties .
swTwistCountValue	See System Options and Document Properties .
swUndoStepsMaximum	See System Options and Document Properties .

swUnitsAngular	See System Options and Document Properties .
swUnitsAngularDecimalPlaces	See System Options and Document Properties .
swUnitsDecimalRounding	See System Options and Document Properties .
swUnitsDualLinear	See System Options and Document Properties .
swUnitsDualLinearDecimalDisplay	See System Options and Document Properties .
swUnitsDualLinearDecimalPlaces	See System Options and Document Properties .
swUnitsDualLinearFractionDenominator	See System Options and Document Properties .
swUnitsEnergyDecimalPlaces	See System Options and Document Properties .
swUnitsEnergyUnits	See System Options and Document Properties .
swUnitsForce	See System Options and Document Properties .
swUnitsForceDecimalPlaces	See System Options and Document Properties .
swUnitsLinear	See System Options and Document Properties .
swUnitsLinearDecimalDisplay	See System Options and Document Properties .
swUnitsLinearDecimalPlaces	See System Options and Document Properties .
swUnitsLinearFractionDenominator	See System Options and Document Properties .
swUnitsMassPropDecimalPlaces	See System Options and Document Properties .
swUnitsMassPropLength	See System Options and Document Properties .
swUnitsMassPropMass	See System Options and Document Properties .
swUnitsMassPropVolume	See System Options and Document Properties .
swUnitsPowerDecimalPlaces	See System Options and Document Properties .
swUnitsPowerUnits	See System Options and Document Properties .
swUnitsTimeDecimalPlaces	See System Options and Document Properties .
swUnitsTimeUnits	See System Options and Document Properties .
swUnitSystem	See System Options and Document Properties .
swUnrecognizedMeshFaceColor	See System Options and Document Properties .
swUpdateOutOfDateSpeedPakConfigOnSave	See System Options and Document Properties .
swUseCustomizedImportTolerance	See System Options and Document Properties .
swViewRotationMouseSpeed	See System Options and Document Properties .
swZoneLineColor	See System Options and Document Properties .
swZoomLevelOnOpen	See System Options and Document Properties .

See Also

[SolidWorks.Interop.swconst Namespace](#)
[swUserPreferenceDoubleValue e Enumeration](#)
[swUserPreferenceStringListValue e Enumeration](#)
[swUserPreferenceStringValue e Enumeration](#)
[swUserPreferenceTextFormat e Enumeration](#)
[swUserPreferenceToggle e Enumeration](#)

swUserPreferenceOption_e (Type)

SOLIDWORKS API Enumerations

swUserPreferenceOption_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swUserPreferenceOption_e Enumeration

User-preference enumerators for customizing document-level annotation, dimension, table, and view-label drafting standards.

Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferenceOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferenceOption\_e
```

C#

```
public enum swUserPreferenceOption_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferenceOption_e : public System.Enum
```

Members

Member	Description
swDetailingAngleDimension	See System Options and Document Properties .
swDetailingAngularRunningDimension	See System Options and Document Properties .
swDetailingAnnotation	See System Options and Document Properties .
swDetailingArcLengthDimension	See System Options and Document Properties .
swDetailingAuxiliaryView	See System Options and Document Properties .
swDetailingBalloon	See System Options and Document Properties .
swDetailingBendTable	See System Options and Document Properties .
swDetailingBillOfMaterial	See System Options and Document Properties .
swDetailingChamferDimension	See System Options and Document Properties .
swDetailingDatum	See System Options and Document Properties .
swDetailingDetailView	See System Options and Document Properties .
swDetailingDiameterDimension	See System Options and Document Properties .
swDetailingDimension	See System Options and Document Properties .
swDetailingDrawingView	See System Options and Document Properties .
swDetailingFamilyTable	See System Options and Document Properties .
swDetailingGeneralTable	See System Options and Document Properties .
swDetailingGeometricTolerance	See System Options and Document Properties .
swDetailingHoleDimension	See System Options and Document Properties .
swDetailingHoleTable	See System Options and Document Properties .
swDetailingLinearDimension	See System Options and Document Properties .
swDetailingLocationLabel	See System Options and Document Properties .
swDetailingMiscView	See System Options and Document Properties .
swDetailingNoOptionSpecified	See System Options and Document Properties .
swDetailingNote	See System Options and Document Properties .
swDetailingOrdinateDimension	See System Options and Document Properties .
swDetailingOrthoView	See System Options and Document Properties .
swDetailingPunchTable	See System Options and Document Properties .
swDetailingRadiusDimension	See System Options and Document Properties .
swDetailingRevisionCloud	See System Options and Document Properties .
swDetailingRevisionTable	See System Options and Document Properties .
swDetailingSectionView	See System Options and Document Properties .
swDetailingSurfaceFinishSymbol	See System Options and Document Properties .
swDetailingTableAnnotation	See System Options and Document Properties .
swDetailingWeldSymbol	See System Options and Document Properties .
swDetailingWeldTable	See System Options and Document Properties .

Remarks

Use with:

- [IModelDocExtension::GetUserPreferenceDouble](#) and [IModelDocExtension::SetUserPreferenceDouble](#)
- [IModelDocExtension::GetUserPreferenceInteger](#) and [IModelDocExtension::SetUserPreferenceInteger](#)
- [IModelDocExtension::GetUserPreferenceString](#) and [IModelDocExtension::SetUserPreferenceString](#)
- [IModelDocExtension::GetUserPreferenceTextFormat](#) and [IModelDocExtension::SetUserPreferenceTextFormat](#)
- [IModelDocExtension::GetUserPreferenceToggle](#) and [IModelDocExtension::SetUserPreferenceToggle](#)

See Also

[SolidWorks.Interop.swconst Namespace](#)

swUserPreferencesLanguages_e (Type)

SOLIDWORKS API Enumerations

swUserPreferencesLanguages_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swUserPreferencesLanguages_e Enumeration

Supported FeatureManager design tree language translations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferencesLanguages_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferencesLanguages\_e
```

C#

```
public enum swUserPreferencesLanguages_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferencesLanguages_e : public System.Enum
```

Members

Member	Description
swLang_Chinese	0
swLang_Chinese_Simplified	1
swLang_Czech	2
swLang_English	3
swLang_French	4
swLang_German	5
swLang_Italian	6
swLang_Japanese	7
swLang_Korean	8
swLang_Polish	9
swLang_Portuguese_Brazilian	10
swLang_Russian	11
swLang_Spanish	12
swLang_Turkish	13

See Also

[SolidWorks.Interop.swconst Namespace](#)

swUserPreferenceStringListValue_e (Type)

SOLIDWORKS API Enumerations

swUserPreferenceStringListValue_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swUserPreferenceStringListValue_e Enumeration

User-preference enumerators for system options and document properties.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferenceStringListValue_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferenceStringListValue\_e
```

C#

```
public enum swUserPreferenceStringListValue_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferenceStringListValue_e : public System.Enum
```

Members

Member	Description
swDxfMappingFiles	0 = This setting is persistent across SOLIDWORKS sessions; you can also interactively get or set the custom map file setting by clicking File, Save As, .dxf or .dwg as Save as type , and Options ; separate each string in the list by a line feed (e.g., the vbLf constant in Visual Basic).
swModelAttachmentList	2 = Sets which configurations for which to generate and attach STEP files
swModelSelectionList	1 = Sets which configurations or sheets to save when publishing an eDrawings

Remarks

Use this enumeration with [ISldWorks::GetUserPreferenceStringListValue](#) and [ISldWorks::SetUserPreferenceStringListValue](#).

See Also

- [SolidWorks.Interop.swconst Namespace](#)
- [swUserPreferenceDoubleValue_e Enumeration](#)
- [swUserPreferenceIntegerValue_e Enumeration](#)
- [swUserPreferenceStringValue_e Enumeration](#)
- [swUserPreferenceTextFormat_e Enumeration](#)
- [swUserPreferenceToggle_e Enumeration](#)

swUserPreferenceStringValue_e (Type)

SOLIDWORKS API Enumerations

swUserPreferenceStringValue_e Enumeration

See Also

 [SolidWorks.Interop.swconst Namespace](#) : swUserPreferenceStringValue_e Enumeration

User-preference enumerators for system options and document properties.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swUserPreferenceStringValue_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swUserPreferenceStringValue_e](#)

C#

public enum swUserPreferenceStringValue_e : System.Enum

C++/CLI

public enum class swUserPreferenceStringValue_e : public System.Enum

Member	Description
swAutoSaveDirectory	See System Options and Document Properties .
swBackupDirectory	See System Options and Document Properties .
swBomTableBOMHeaderCustomText_ForIndentedBOM	See System Options and Document Properties .
swBomTableBOMHeaderCustomText_ForPartOnlyBOM	See System Options and Document Properties .
swBomTableBOMHeaderCustomText_ForTopLevelOnlyBOM	See System Options and Document Properties .
swBorderLayer	See System Options and Document Properties .
swCenterLineLayer	See System Options and Document Properties .
swCenterMarkLayer	See System Options and Document Properties .
swColorsBackgroundImageFile	See System Options and Document Properties .
swCustomPropertyUsedAsComponentDescription	See System Options and Document Properties .
swDefaultTemplateAssembly	See System Options and Document Properties .
swDefaultTemplateDrawing	See System Options and Document Properties .
swDefaultTemplatePart	See System Options and Document Properties .
swDetailingAuxViewLabels_CustomName	See System Options and Document Properties .
swDetailingAuxViewLabels_CustomScale	See System Options and Document Properties .
swDetailingBOMLowerCustomProperty	See System Options and Document Properties .
swDetailingBOMUpperCustomProperty	See System Options and Document Properties .
swDetailingDetailViewLabels_CustomName	See System Options and Document Properties .
swDetailingDetailViewLabels_CustomScale	See System Options and Document Properties .
swDetailingDimensionStandardName	See System Options and Document Properties .
swDetailingLayer	See System Options and Document Properties .
swDetailingMiscView_CustomName	See System Options and Document Properties .
swDetailingMiscView_CustomScale	See System Options and Document Properties .
swDetailingNextDatumFeatureLabel	See System Options and Document Properties .
swDetailingOrthoView_CustomName	See System Options and Document Properties .
swDetailingOrthoView_CustomScale	See System Options and Document Properties .
swDetailingSectionViewLabels_CustomName	See System Options and Document Properties .
swDetailingSectionViewLabels_CustomScale	See System Options and Document Properties .
swDimXpertGeneralToleranceCustomTable	See System Options and Document Properties .
swDraftStandardExclusionList	See System Options and Document Properties .
swDrawingAreaHatchPattern	See System Options and Document Properties .
swDrawingCustomPropertyUsedAsRevision	See System Options and Document Properties .
swElecCableTrayDuctName	See System Options and Document Properties .
swElecCableTrayElbowName	See System Options and Document Properties .
swElecDuctingDuctName	See System Options and Document Properties .
swElecDuctingElbowName	See System Options and Document Properties .
swExportIFCType	See System Options and Document Properties .
swExportOutputCoordinateSystem	See System Options and Document Properties .
swFileLocations3DCCModelFolder	See System Options and Document Properties .
swFileLocationsAppearances	See System Options and Document Properties .
swFileLocationsBendNoteFormatFile	See System Options and Document Properties .
swFileLocationsBendTable	See System Options and Document Properties .
swFileLocationsBendTableTemplate	See System Options and Document Properties .
swFileLocationsBlocks	See System Options and Document Properties .
swFileLocationsBOMTemplates	See System Options and Document Properties .
swFileLocationsColorSwatches	See System Options and Document Properties .
swFileLocationsConnectedLibrary	See System Options and Document Properties .
swFileLocationsCostingReportTemplateFolder	See System Options and Document Properties .
swFileLocationsCostingTemplates	See System Options and Document Properties .
swFileLocationsCustomAppearances	See System Options and Document Properties .
swFileLocationsCustomDecals	See System Options and Document Properties .
swFileLocationsCustomPropertyFile	See System Options and Document Properties .
swFileLocationsCustomScenes	See System Options and Document Properties .
swFileLocationsDefaultSave	See System Options and Document Properties .
swFileLocationsDefeatureRuleSets	See System Options and Document Properties .
swFileLocationsDesignCheckerFile	See System Options and Document Properties .
swFileLocationsDesignJournalTemplate	See System Options and Document Properties .

swFileLocationsDesignLibrary	See System Options and Document Properties .
swFileLocationsDimensionFavorites	See System Options and Document Properties .
swFileLocationsDocuments	See System Options and Document Properties .
swFileLocationsDocumentTemplates	See System Options and Document Properties .
swFileLocationsDraftingStandard	See System Options and Document Properties .
swFileLocationsDrawingScaleStandard	See System Options and Document Properties .
swFileLocationsFamilyTableTemplates	See System Options and Document Properties .
swFileLocationsFuncBlDrSegTypeDefinitions	See System Options and Document Properties .
swFileLocationsGeneralTablesTemplate	See System Options and Document Properties .
swFileLocationsHatchPatternFile	See System Options and Document Properties .
swFileLocationsHoleCalloutFormatFile	See System Options and Document Properties .
swFileLocationsHoleTableTemplates	See System Options and Document Properties .
swFileLocationsHoleWizardFavoritesDB	See System Options and Document Properties .
swFileLocationsInspectionExports	See System Options and Document Properties .
swFileLocationsInspectionProjects	See System Options and Document Properties .
swFileLocationsInspectionReports	See System Options and Document Properties .
swFileLocationsJournalFile	See System Options and Document Properties .
swFileLocationsLibraryFeatures	See System Options and Document Properties .
swFileLocationsLights	See System Options and Document Properties .
swFileLocationsLineStyleDefinitions	See System Options and Document Properties .
swFileLocationsMacroFeatures	See System Options and Document Properties .
swFileLocationsMacros	See System Options and Document Properties .
swFileLocationsMaterialDatabases	See System Options and Document Properties .
swFileLocationsNewSheetFormat	See System Options and Document Properties .
swFileLocationsPaletteAssemblies	See System Options and Document Properties .
swFileLocationsPaletteFeatures	See System Options and Document Properties .
swFileLocationsPaletteFormTools	See System Options and Document Properties .
swFileLocationsPaletteParts	See System Options and Document Properties .
swFileLocationsPunchTableTemplate	See System Options and Document Properties .
swFileLocationsRevisionTableTemplates	See System Options and Document Properties .
swFileLocationsRouteCableLibrary	See System Options and Document Properties .
swFileLocationsRouteComponentLibrary	See System Options and Document Properties .
swFileLocationsRouteCoveringLibrary	See System Options and Document Properties .
swFileLocationsScenes	See System Options and Document Properties .
swFileLocationsSearchPaths	See System Options and Document Properties .
swFileLocationsSheetFormat	See System Options and Document Properties .
swFileLocationsSheetMetalGaugeTable	See System Options and Document Properties .
swFileLocationsSpellingFolders	See System Options and Document Properties .
swFileLocationsStructureSystemsConnectionElements	See System Options and Document Properties .
swFileLocationsSustainabilityReportTemplateFolder	See System Options and Document Properties .
swFileLocationsSymbolLibraryFolder	See System Options and Document Properties .
swFileLocationsTextures	See System Options and Document Properties .
swFileLocationsThemeFolder	See System Options and Document Properties .
swFileLocationsThreadProfiles	See System Options and Document Properties .
swFileLocationsTitleBlockTableTemplate	See System Options and Document Properties .
swFileLocationsTxCalloutFormatFile	See System Options and Document Properties .
swFileLocationsTxGeneralFileLocation	See System Options and Document Properties .
swFileLocationsWebFolders	See System Options and Document Properties .
swFileLocationsWeldmentCutListTemplates	See System Options and Document Properties .
swFileLocationsWeldmentProfiles	See System Options and Document Properties .
swFileLocationsWeldmentPropertyFile	See System Options and Document Properties .
swFileLocationsWeldTableTemplate	See System Options and Document Properties .
swFileSaveAsCoordinateSystem	See System Options and Document Properties .
swHoleTagsList	See System Options and Document Properties .
swHoleWizardToolBoxFolder	See System Options and Document Properties .
swHvacCirDuctName	See System Options and Document Properties .
swHvacCirElbowName	See System Options and Document Properties .
swHvacRectDuctName	See System Options and Document Properties .
swHvacRectElbowName	See System Options and Document Properties .
swIFCExportPropertySetMappingFile	See System Options and Document Properties .
swLastSynchronizationTimeStamp	See System Options and Document Properties .
swMaterialPropertyCrosshatchPattern	See System Options and Document Properties .
swMultiCAD_ImportQueuePath	See System Options and Document Properties .
swMySldSettings	See System Options and Document Properties .
swOppPrefixSuffixText	See System Options and Document Properties .
swOverriddenQuantityColumnName	See System Options and Document Properties .
swReferenceTriadXLabel	See System Options and Document Properties .
swReferenceTriadYLabel	See System Options and Document Properties .
swReferenceTriadZLabel	See System Options and Document Properties .
swSearchDissectionLocation	See System Options and Document Properties .
swSeparatorCharacterForDims	See System Options and Document Properties .
swSheetMetalBendNotesLayer	See System Options and Document Properties .
swSheetMetalDescription	See System Options and Document Properties .
swSMGMetaPropertyName	See System Options and Document Properties .
swSolidBodiesBBoxDescriptionFirstSeparator	See System Options and Document Properties .
swSolidBodiesBBoxDescriptionPrefix	See System Options and Document Properties .
swSolidBodiesBBoxDescriptionSecondSeparator	See System Options and Document Properties .
swSolidBodiesBBoxDescriptionSuffix	See System Options and Document Properties .
swStructureSystemsFolder	See System Options and Document Properties .
swVirtualComponentPrefixedit	See System Options and Document Properties .
swWeldmentGenericCutlistID	See System Options and Document Properties .
swWeldmentSheetmetalCutlistID	See System Options and Document Properties .
swWeldmentStructureCutlistID	See System Options and Document Properties .

See Also

[SolidWorks.Interop.swconst Namespace](#)
[swUserPreferenceDoubleValue e Enumeration](#)
[swUserPreferenceIntegerValue e Enumeration](#)
[swUserPreferenceStringListValue e Enumeration](#)
[swUserPreferenceTextFormat e Enumeration](#)
[swUserPreferenceToggle e Enumeration](#)

swUserPreferenceTextFormat_e (Type)

SOLIDWORKS API Enumerations

swUserPreferenceTextFormat_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swUserPreferenceTextFormat_e Enumeration

User-preference enumerators for system options and document properties.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferenceTextFormat_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferenceTextFormat\_e
```

C#

```
public enum swUserPreferenceTextFormat_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferenceTextFormat_e : public System.Enum
```

 Members

Member	Description
swDetailingAnnotationTextFormat	See System Options and Document Properties .
swDetailingAuxView_DelimiterTextFormat	See System Options and Document Properties .
swDetailingAuxView_LabelTextFormat	See System Options and Document Properties .
swDetailingAuxView_NameTextFormat	See System Options and Document Properties .
swDetailingAuxView_RotationTextFormat	See System Options and Document Properties .
swDetailingAuxView_ScaleTextFormat	See System Options and Document Properties .
swDetailingBalloonTextFormat	See System Options and Document Properties .
swDetailingBendTextFormat	See System Options and Document Properties .
swDetailingBillOfMaterialTextFormat	See System Options and Document Properties .
swDetailingDatumTextFormat	See System Options and Document Properties .
swDetailingDetailLabelTextFormat	See System Options and Document Properties .
swDetailingDetailTextFormat	See System Options and Document Properties .
swDetailingDetailView_DelimiterTextFormat	See System Options and Document Properties .
swDetailingDetailView_LabelTextFormat	See System Options and Document Properties .
swDetailingDetailView_NameTextFormat	See System Options and Document Properties .
swDetailingDetailView_ScaleTextFormat	See System Options and Document Properties .
swDetailingDimensionTextFormat	See System Options and Document Properties .
swDetailingFamilyTableTextFormat	See System Options and Document Properties .
swDetailingGeneralTableTextFormat	See System Options and Document Properties .
swDetailingGeometricToleranceTextFormat	See System Options and Document Properties .
swDetailingHoleTableTextFormat	See System Options and Document Properties .
swDetailingLocationLabelTextFormat	See System Options and Document Properties .
swDetailingMiscView_DelimiterTextFormat	See System Options and Document Properties .
swDetailingMiscView_NameTextFormat	See System Options and Document Properties .
swDetailingMiscView_ScaleTextFormat	See System Options and Document Properties .
swDetailingNoteTextFormat	See System Options and Document Properties .
swDetailingOrthoView_DelimiterTextFormat	See System Options and Document Properties .
swDetailingOrthoView_NameTextFormat	See System Options and Document Properties .
swDetailingOrthoView_ScaleTextFormat	See System Options and Document Properties .
swDetailingPunchTextFormat	See System Options and Document Properties .
swDetailingRevisionTableTextFormat	See System Options and Document Properties .
swDetailingSectionLabelDelimiterTextFormat	See System Options and Document Properties .
swDetailingSectionLabelLabelTextFormat	See System Options and Document Properties .
swDetailingSectionLabelNameTextFormat	See System Options and Document Properties .
swDetailingSectionLabelScaleTextFormat	See System Options and Document Properties .
swDetailingSectionLabelTextFormat	See System Options and Document Properties .
swDetailingSectionTextFormat	See System Options and Document Properties .
swDetailingSectionView_RotationTextFormat	See System Options and Document Properties .
swDetailingSurfaceFinishTextFormat	See System Options and Document Properties .
swDetailingTableTextFormat	See System Options and Document Properties .
swDetailingTitleBlockTableTextFormat	See System Options and Document Properties .
swDetailingViewArrowTextFormat	See System Options and Document Properties .
swDetailingViewTextFormat	See System Options and Document Properties .
swDetailingWeldSymbolTextFormat	See System Options and Document Properties .
swDetailingWeldSymbolTextRootInsideFont	See System Options and Document Properties .
swPointAxisCoordSystemLabelTextFormat	See System Options and Document Properties .
swPointAxisCoordSystemNameTextFormat	See System Options and Document Properties .
swSheetMetalBendNotesTextFormat	See System Options and Document Properties .
swSheetMetalIMBDTextFormat	See System Options and Document Properties .

 Remarks

Use these user-preference enumerations with [IModelDocExtension::GetUserPreferenceTextFormat](#) and [IModelDocExtension::SetUserPreferenceTextFormat](#) to get and set detailing text formats at the document level.

See Also

[SolidWorks.Interop.swconst Namespace](#)
[swUserPreferenceDoubleValue e Enumeration](#)
[swUserPreferenceIntegerValue e Enumeration](#)
[swUserPreferenceStringListValue e Enumeration](#)
[swUserPreferenceStringValue e Enumeration](#)
[swUserPreferenceToggle e Enumeration](#)

swUserPreferenceToggle_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swUserPreferenceToggle_e Enumeration

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swUserPreferenceToggle_e Enumeration

User-preference enumerators for system options and document properties.



Syntax

Visual Basic (Declaration)

```
Public Enum swUserPreferenceToggle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserPreferenceToggle\_e
```

C#

```
public enum swUserPreferenceToggle_e : System.Enum
```

C++/CLI

```
public enum class swUserPreferenceToggle_e : public System.Enum
```



Members

Member	Description
sw3DPDFCompressLossyTessellation	See System Options and Document Properties .
sw3MFAppearances	See System Options and Document Properties .
sw3MFDecals	See System Options and Document Properties .
sw3MFMaterials	See System Options and Document Properties .
sw3MFShowInfoOnSave	See System Options and Document Properties .
swAbsChordalError	See System Options and Document Properties .
swAbsEdgeLength	See System Options and Document Properties .
swAbsNormalDeviation	See System Options and Document Properties .
swAddDimensionsToArcEntity	See System Options and Document Properties .
swAddDimensionsToCircleEntity	See System Options and Document Properties .
swAddDimensionsToLineEntity	See System Options and Document Properties .
swAddDimensionsToRectangleEntity	See System Options and Document Properties .
swAddDimensionsToSketchEntity	See System Options and Document Properties .
swAddDimensionsToSlotEntity	See System Options and Document Properties .
swAddDrivenDimensions	See System Options and Document Properties .
swAllowCreationOfReferencesExternalToModel	See System Options and Document Properties .
swAlwaysUseDefaultTemplates	See System Options and Document Properties .
swAMFColors	See System Options and Document Properties .
swAMFCompression	See System Options and Document Properties .
swAMFMaterials	See System Options and Document Properties .
swAnnotationDisplayHideDanglingDim	See System Options and Document Properties .
swASMSLDPRT_ExcludeComponentsByBBoxVolume	See System Options and Document Properties .
swASMSLDPRT_ExcludeComponentsByVisibility	See System Options and Document Properties .
swASMSLDPRT_ExcludeIfToolboxComponents	See System Options and Document Properties .
swASMSLDPRT_IncludeMassProperties	See System Options and Document Properties .
swAssemblyAllowComponentMoveByDragging	See System Options and Document Properties .
swAssemblyAllowCreationOfMisalignedMates	See System Options and Document Properties .
swAssemblyAllowGraphicsComponent	See System Options and Document Properties .
swAssemblyEnableCreationOfMatesUsingAI	See System Options and Document Properties .
swAssemblyUpdateModelGraphicsWhenSavingFiles	See System Options and Document Properties .
swAutoLoadPartsLightweight	See System Options and Document Properties .
swAutomaticallyPopUpSelectionToolForPreciseLocation	See System Options and Document Properties .
swAutomaticDrawingViewUpdate	See System Options and Document Properties .
swAutomaticDrawingViewUpdateDefault	See System Options and Document Properties .
swAutomaticDrawingViewUpdateForceOff	See System Options and Document Properties .
swAutomaticScaling3ViewDrawings	See System Options and Document Properties .
swAutomaticSyncSettings	See System Options and Document Properties .
swAutoNormalToSketchMode	See System Options and Document Properties .
swAutoResolveLightweightCompUponExplnFMTTree	See System Options and Document Properties .
swAutoSaveEnable	See System Options and Document Properties .
swAutoScaleTextureSFDecalsToModelSize	See System Options and Document Properties .
swAutoShowPropertyManager	See System Options and Document Properties .
swAutoSizePropertyManager	See System Options and Document Properties .
swAutoSyncSettingsToInclude_Customizations	See System Options and Document Properties .
swAutoSyncSettingsToInclude_FileLocations	See System Options and Document Properties .
swAutoSyncSettingsToInclude_SystemOptions	See System Options and Document Properties .
swBackupAfterMeshOrRunSimulationStudy	See System Options and Document Properties .
swBackupEnable	See System Options and Document Properties .
swBackupRemoveEnable	See System Options and Document Properties .
swBOMConfigurationAlignBottom	See System Options and Document Properties .
swBOMConfigurationLocked	See System Options and Document Properties .
swBOMConfigurationUseDocumentFont	See System Options and Document Properties .
swBOMConfigurationUseSummaryInfo	See System Options and Document Properties .
swBOMContentsDisplayAtTop	See System Options and Document Properties .
swBOMControlIdFromAssembly	See System Options and Document Properties .
swBOMControlMissingRows	See System Options and Document Properties .
swBOMControlSplitTable	See System Options and Document Properties .

swBomTableDontAddQTYNextToConfigName	See System Options and Document Properties .
swBomTableKeepMissingItems	See System Options and Document Properties .
swBomTableShowConfigurationInBOMHeader_ForIndentedBOM	See System Options and Document Properties .
swBomTableShowConfigurationInBOMHeader_ForPartOnlyBOM	See System Options and Document Properties .
swBomTableShowConfigurationInBOMHeader_ForTopLevelOnlyBOM	See System Options and Document Properties .
swBomTableShowCustomTextInBOMHeader_ForIndentedBOM	See System Options and Document Properties .
swBomTableShowCustomTextInBOMHeader_ForPartOnlyBOM	See System Options and Document Properties .
swBomTableShowCustomTextInBOMHeader_ForTopLevelOnlyBOM	See System Options and Document Properties .
swBomTableStrikeThroughMissingItems	See System Options and Document Properties .
swBreakAlignWithParent	See System Options and Document Properties .
swCenterLineMarkCircular	See System Options and Document Properties .
swCenterLineMarkEndsOnlyCircular	See System Options and Document Properties .
swCenterLineMarkEndsOnlyLinear	See System Options and Document Properties .
swCenterLineMarkLinear	See System Options and Document Properties .
swCheckCrashSolutions	See System Options and Document Properties .
swClearanceCreateFasteners	See System Options and Document Properties .
swClearanceDisplayOption	See System Options and Document Properties .
swClearanceIgnoreEqual	See System Options and Document Properties .
swClearanceMakeTransparent	See System Options and Document Properties .
swClearanceShowIgnored	See System Options and Document Properties .
swClearanceSubAssyAsComp	See System Options and Document Properties .
swCollabAddShortcutMenuItems	See System Options and Document Properties .
swCollabAddTimeStampToComments	See System Options and Document Properties .
swCollabCheckReadOnlyModifiedByOthers	See System Options and Document Properties .
swCollabEnableMultiUser	See System Options and Document Properties .
swCollabShowCommentsInPropertyManager	See System Options and Document Properties .
swCollabTopDocsNoPromptOrSave	See System Options and Document Properties .
swCollinearChainDimensionArrowHeadTermination	See System Options and Document Properties .
swCollinearChainDimensionOffsetText	See System Options and Document Properties .
swColorsGradientPartBackground	See System Options and Document Properties .
swColorsMatchViewAndFeatureManagerBackground	See System Options and Document Properties .
swColorsUseShadedEdgeColor	See System Options and Document Properties .
swColorsUseSpecifiedEditColors	See System Options and Document Properties .
swColorsWireframeHLRShadedSame	See System Options and Document Properties .
swColorUseSelectedItemColorsSeedsPatterns	See System Options and Document Properties .
swCombineCutItItemsInBOM	See System Options and Document Properties .
swCreateConfigurationTableOnOpen	See System Options and Document Properties .
swDetachSegmentOnDragMode	See System Options and Document Properties .
swDetailingAllUpperCase	See System Options and Document Properties .
swDetailingAltLinearDimPrecisionLinkWithModel	See System Options and Document Properties .
swDetailingAngularDimensionsRemoveInsignificantZeros	See System Options and Document Properties .
swDetailingAngularRunningDisplayAsChain	See System Options and Document Properties .
swDetailingAngularRunningExtensionLineExtend	See System Options and Document Properties .
swDetailingAngularRunningRunBidirectionally	See System Options and Document Properties .
swDetailingAnnotationApplyNewCTDepthArchForToNewParts	See System Options and Document Properties .
swDetailingAnnotationShowTypeInThreadCallouts	See System Options and Document Properties .
swDetailingAnnotationUseBentLeaders	See System Options and Document Properties .
swDetailingAutoInsertBalloons	See System Options and Document Properties .
swDetailingAutoInsertCenterLines	See System Options and Document Properties .
swDetailingAutoInsertCenterMarks	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForFilletAsm	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForFilletAsm	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForHoles	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForHolesAsm	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForSlots	See System Options and Document Properties .
swDetailingAutoInsertCenterMarksForSlotsAsm	See System Options and Document Properties .
swDetailingAutoInsertCosmeticThreadForHolesAsm	See System Options and Document Properties .
swDetailingAutoInsertDimsMarkedForDrawing	See System Options and Document Properties .
swDetailingAutoInsertDowelSymbols	See System Options and Document Properties .
swDetailingAutoInsertDowelSymbolsAsm	See System Options and Document Properties .
swDetailingAutoInsertDowelSymForHolesAsm	See System Options and Document Properties .
swDetailingAutoInsertDowelSymForHolesPart	See System Options and Document Properties .
swDetailingAutoUpdateBOM	See System Options and Document Properties .
swDetailingAuxView_IncludeLocationLabelsForNewViews	See System Options and Document Properties .
swDetailingAuxView_RemoveSpaceInScale	See System Options and Document Properties .
swDetailingAuxView_RotateClockwiseCounterclockwise	See System Options and Document Properties .
swDetailingAuxView_RotateViewToHorizontalSheet	See System Options and Document Properties .
swDetailingAuxView_SimplifiedDetailed	See System Options and Document Properties .
swDetailingAuxViewLabels_AboveView	See System Options and Document Properties .
swDetailingAuxViewLabels_PerStandard	See System Options and Document Properties .
swDetailingAuxViewLabels_Stacked	See System Options and Document Properties .
swDetailingBalloonsDisplayWithBentLeader	See System Options and Document Properties .
swDetailingBalloonUseDocBentLeaderLength	See System Options and Document Properties .
swDetailingBorderDoubleLine	See System Options and Document Properties .
swDetailingBorderShowColumns	See System Options and Document Properties .
swDetailingBorderShowRows	See System Options and Document Properties .
swDetailingBorderShowZoneDividers	See System Options and Document Properties .
swDetailingCenterMarkScaleByViewScale	See System Options and Document Properties .
swDetailingCenterMarkShowLines	See System Options and Document Properties .
swDetailingCenterMarkUseCenterLine	See System Options and Document Properties .
swDetailingCenterOfMassScaleByView	See System Options and Document Properties .
swDetailingChainDimensionAddLastReferenceDimension	See System Options and Document Properties .
swDetailingChainDimensionAddOverallDimensions	See System Options and Document Properties .
swDetailingConnectionLinesHolePatternsCenterMarks	See System Options and Document Properties .
swDetailingCThreadDisplayHighQuality	See System Options and Document Properties .
swDetailingDatumsAnchorFilled	See System Options and Document Properties .
swDetailingDatumsAnchorShoulder	See System Options and Document Properties .
swDetailingDetailView_IncludeLocationLabelsForNewViews	See System Options and Document Properties .
swDetailingDetailView_RemoveSpaceInScale	See System Options and Document Properties .
swDetailingDetailViewLabels_AboveView	See System Options and Document Properties .
swDetailingDetailViewLabels_PerStandard	See System Options and Document Properties .
swDetailingDetailViewLabels_ScaleForJaggedOutline	See System Options and Document Properties .
swDetailingDetailViewLabels_Stacked	See System Options and Document Properties .
swDetailingDiameterForeshortenedAutomatic	See System Options and Document Properties .
swDetailingDimANSIBentLeader	See System Options and Document Properties .
swDetailingDimBreakAroundArrow	See System Options and Document Properties .
swDetailingDimensionsAngularToleranceUseParentheses	See System Options and Document Properties .
swDetailingDimensionsToleranceFitToUseDimensionFont	See System Options and Document Properties .
swDetailingDimensionsToleranceInwardRounding	See System Options and Document Properties .
swDetailingDimensionsToleranceUseDimensionFont	See System Options and Document Properties .
swDetailingDimensionsToleranceUseParentheses	See System Options and Document Properties .
swDetailingDimLeaderOverrideStandard	See System Options and Document Properties .
swDetailingDimOffsetText	See System Options and Document Properties .
swDetailingDimsApplyUpdatedRules	See System Options and Document Properties .
swDetailingDimsAutoJogAngularRunning	See System Options and Document Properties .
swDetailingDimsAutoJogOrdinates	See System Options and Document Properties .
swDetailingDimsCenterText	See System Options and Document Properties .
swDetailingDimsFollowDimXpertLayout	See System Options and Document Properties .

swDetailingDimsPrefixInsideBasicToIBox	See System Options and Document Properties .
swDetailingDimsShowBroken	See System Options and Document Properties .
swDetailingDimsShowLeadingZeros	See System Options and Document Properties .
swDetailingDimsShowParenthesisByDefault	See System Options and Document Properties .
swDetailingDimsSnapTextToGrid	See System Options and Document Properties .
swDetailingDisplayAlternateSection	See System Options and Document Properties .
swDetailingDisplayDatumsPer1982	See System Options and Document Properties .
swDetailingDisplayDualBasicDimensioninOneBox	See System Options and Document Properties .
swDetailingDisplayFSymbolsPer2002	See System Options and Document Properties .
swDetailingDisplayWithBrokenLeaders	See System Options and Document Properties .
swDetailingDualDimensions	See System Options and Document Properties .
swDetailingFixedSizeWeldSymbol	See System Options and Document Properties .
swDetailingGtoIUseDocBentLeaderLength	See System Options and Document Properties .
swDetailingHighlightElements	See System Options and Document Properties .
swDetailingImportEntireAssemblyAnnotations	See System Options and Document Properties .
swDetailingLinearDimPrecisionLinkWithModel	See System Options and Document Properties .
swDetailingLinearForeshortenedAutomatic	See System Options and Document Properties .
swDetailingLinkParentViewConfiguration	See System Options and Document Properties .
swDetailingLocationLabelAddSameSheetNumber	See System Options and Document Properties .
swDetailingMiscView_AboveView	See System Options and Document Properties .
swDetailingMiscView_AddViewLabelOnViewCreation	See System Options and Document Properties .
swDetailingMiscView_DisplayLabelAboveView	See System Options and Document Properties .
swDetailingMiscView_PerStandard	See System Options and Document Properties .
swDetailingMiscView_RemoveSpaceInScale	See System Options and Document Properties .
swDetailingModeIncludeStandardViewsInViewPalette	See System Options and Document Properties .
swDetailingModeSaveModelData	See System Options and Document Properties .
swDetailingNoDimSpecificOptionSpecified	See System Options and Document Properties .
swDetailingNotesDisplayWithBentLeader	See System Options and Document Properties .
swDetailingNotesLeaderJustificationSnapping	See System Options and Document Properties .
swDetailingNoteUseDocBentLeaderLength	See System Options and Document Properties .
swDetailingOrdinateDisplayAsChain	See System Options and Document Properties .
swDetailingOrthoView_AddViewLabelOnViewCreation	See System Options and Document Properties .
swDetailingOrthoView_DisplayLabelAboveView	See System Options and Document Properties .
swDetailingOrthoView_RemoveSpaceInScale	See System Options and Document Properties .
swDetailingOrthoViewLabels_AboveView	See System Options and Document Properties .
swDetailingOrthoViewLabels_PerStandard	See System Options and Document Properties .
swDetailingOrthoViewLabelsEnableShow	Not used.
swDetailingRadialDimsArrowsFollowText	Not used.
swDetailingRadialDimsDisplay2ndOutsideArrow	Not used.
swDetailingRadialDimsDisplayNearSideMessages	See System Options and Document Properties .
swDetailingRadialDimsDisplayWithSolidLeader	See System Options and Document Properties .
swDetailingScaleForJaggedStyle	See System Options and Document Properties .
swDetailingScaleWithDimHeight	See System Options and Document Properties .
swDetailingScaleWithSectionTextHeight	See System Options and Document Properties .
swDetailingSectionHideShoulders	See System Options and Document Properties .
swDetailingSectionView_IncludeLocationLabelsForNewViews	See System Options and Document Properties .
swDetailingSectionView_RemoveSpaceInScale	See System Options and Document Properties .
swDetailingSectionViewLabels_AboveView	See System Options and Document Properties .
swDetailingSectionViewLabels_PerStandard	See System Options and Document Properties .
swDetailingSectionViewLabels_Stacked	See System Options and Document Properties .
swDetailingSFSymbolUseDocBentLeaderLength	See System Options and Document Properties .
swDetailingShowDimensionUnits	See System Options and Document Properties .
swDetailingShowDualDimensionUnits	See System Options and Document Properties .
swDetailingShowHaloAroundAnnotation	See System Options and Document Properties .
swDetailingShowPeriodWithBorders	See System Options and Document Properties .
swDetailingShowUnitsForDualDisplay	See System Options and Document Properties .
swDetailingSplitDualDimensions	See System Options and Document Properties .
swDetailingSplitTextDualDimensions	See System Options and Document Properties .
swDetailingSplitWhenTextsSolidLeaderAligned	See System Options and Document Properties .
swDetailingTablesUseTemplateSettings	See System Options and Document Properties .
swDimensionsExtensionLineStyleSameAsLeader	See System Options and Document Properties .
swDimOverriddenHighlight	See System Options and Document Properties .
swDisableDerivedConfigurations	See System Options and Document Properties .
swDisableWeldmentConfigStrings	See System Options and Document Properties .
swDispDimXpertDimOnTopOfModel	See System Options and Document Properties .
swDisplayAllAnnotations	See System Options and Document Properties .
swDisplayAllSplineHandles	See System Options and Document Properties .
swDisplayAmbientOcclusionShadows	See System Options and Document Properties .
swDisplayAnnotations	See System Options and Document Properties .
swDisplayAnnotationsUseAssemblySettings	See System Options and Document Properties .
swDisplayArcCenterPoints	See System Options and Document Properties .
swDisplayAxes	See System Options and Document Properties .
swDisplayBendLines	See System Options and Document Properties .
swDisplayCameraFOVBox	See System Options and Document Properties .
swDisplayCameras	See System Options and Document Properties .
swDisplayCartoon	See System Options and Document Properties .
swDisplayCompAnnotations	See System Options and Document Properties .
swDisplayComponentDimXpertAnnotations	See System Options and Document Properties .
swDisplayComponentEnvelopes	See System Options and Document Properties .
swDisplayCoordSystems	See System Options and Document Properties .
swDisplayCosmeticThreads	See System Options and Document Properties .
swDisplayCounterpartLocationLabel	See System Options and Document Properties .
swDisplayCurves	See System Options and Document Properties .
swDisplayDataMarkNewConfig	See System Options and Document Properties .
swDisplayDatumCoordSystems	See System Options and Document Properties .
swDisplayDatums	See System Options and Document Properties .
swDisplayDatumTargets	See System Options and Document Properties .
swDisplayDecals	See System Options and Document Properties .
swDisplayDimensionsFlatToScreen	Not used.
swDisplayDimXpertDimensions	See System Options and Document Properties .
swDisplayDspbrAppearances	See System Options and Document Properties .
swDisplayEnableSelectionThroughTransparency	See System Options and Document Properties .
swDisplayEntityPoints	See System Options and Document Properties .
swDisplayEquationIds	See System Options and Document Properties .
swDisplayFeatureDimensions	See System Options and Document Properties .
swDisplayGeometricTolerances	See System Options and Document Properties .
swDisplayGraphicsComponents	See System Options and Document Properties .
swDisplayLights	See System Options and Document Properties .
swDisplayLiveSections	See System Options and Document Properties .
swDisplayMarkups	See System Options and Document Properties .
swDisplayMeshBREPFacetFins	See System Options and Document Properties .
swDisplayMissingRefsWhenEditFeature	See System Options and Document Properties .
swDisplayMotionSymbol	See System Options and Document Properties .
swDisplayNotes	See System Options and Document Properties .
swDisplayNotesFlatToScreen	Not used.
swDisplayOnlyInViewOfCreation	See System Options and Document Properties .
swDisplayOrigins	See System Options and Document Properties .
swDisplayPartingLines	See System Options and Document Properties .

swDisplayPatternInformationTooltips	See System Options and Document Properties .
swDisplayPlanes	See System Options and Document Properties .
swDisplayPlaneSections	Not used.
swDisplayRealViewGraphics	See System Options and Document Properties .
swDisplayReferenceDimensions	See System Options and Document Properties .
swDisplayReferencePoints	Obsolete.
swDisplayReferencePoints2	See System Options and Document Properties .
swDisplayReferenceTriad	See System Options and Document Properties .
swDisplayRelationsShowPropertyManager	See System Options and Document Properties .
swDisplayRoutePoints	See System Options and Document Properties .
swDisplayScrollbarsInGraphicsViewDrawings	See System Options and Document Properties .
swDisplayScrollbarsInGraphicsViewPartsAndAssemblies	See System Options and Document Properties .
swDisplayShadedCosmeticThreads	See System Options and Document Properties .
swDisplayShadowsInShadedMode	See System Options and Document Properties .
swDisplaySimulationSymbol	See System Options and Document Properties .
swDisplaySketches	See System Options and Document Properties .
swDisplaySketchPlanes	See System Options and Document Properties .
swDisplaySpeedpakGraphicsCircle	See System Options and Document Properties .
swDisplaySurfaceFinishSymbols	See System Options and Document Properties .
swDisplayTempAxesOnMouseHover	See System Options and Document Properties .
swDisplayTemporaryAxes	See System Options and Document Properties .
swDisplayTextAtSameSizeAlways	See System Options and Document Properties .
swDisplayTopLevelEnvelopes	See System Options and Document Properties .
swDisplayVirtualSharps	See System Options and Document Properties .
swDisplayWeldBead	See System Options and Document Properties .
swDisplayWeldSymbols	See System Options and Document Properties .
swDoNotShowConfigOrDisplayStyleName	See System Options and Document Properties .
swDontCopyQTYColumnNameFromTemplate	See System Options and Document Properties .
swDoublePrimeMark	See System Options and Document Properties .
swDraftingStandardAllUppercaseForDimensionsAndHoleCallouts	See System Options and Document Properties .
swDraftingStandardAllUppercaseForTable	See System Options and Document Properties .
swDraftingStandardUppercase	See System Options and Document Properties .
swDraftQualityAmbientOcclusion	See System Options and Document Properties .
swDrawingAutomaticBomUpdate	See System Options and Document Properties .
swDrawingAutomaticModelDimPlacement	See System Options and Document Properties .
swDrawingAutoSpaceDimsOnDelete	See System Options and Document Properties .
swDrawingCreateDetailAsCircle	See System Options and Document Properties .
swDrawingDetailInferCenter	See System Options and Document Properties .
swDrawingDetailInferCorner	See System Options and Document Properties .
swDrawingDisableNoteDimensionInference	See System Options and Document Properties .
swDrawingDisableNoteMergeWhenDragging	See System Options and Document Properties .
swDrawingDisallowCreationOfMirrorViews	See System Options and Document Properties .
swDrawingDisplayArcCenterPoints	See System Options and Document Properties .
swDrawingDisplayEntityPoints	See System Options and Document Properties .
swDrawingDisplaySketchHatchBehindGeometry	See System Options and Document Properties .
swDrawingDisplaySketchPicturesOnSheetBehindGeometry	See System Options and Document Properties .
swDrawingDisplayViewBorders	See System Options and Document Properties .
swDrawingEliminateDuplicateDimsOnInsert	See System Options and Document Properties .
swDrawingEliminateDuplicateModelNotesOnInsert	See System Options and Document Properties .
swDrawingEnableSymbolAddingNewRevision	See System Options and Document Properties .
swDrawingHideEnds	See System Options and Document Properties .
swDrawingMarkAllDimensionsForDrawing	See System Options and Document Properties .
swDrawingOpenInDetailingMode	See System Options and Document Properties .
swDrawingPrintBreaklinesInBrokenView	See System Options and Document Properties .
swDrawingReuseViewLettersFromDeletedAuxiliary	See System Options and Document Properties .
swDrawingSaveShadedData	See System Options and Document Properties .
swDrawingsDefaultDisplayTypeFastHLRLV	Not used.
swDrawingsDefaultDisplayTypeHLREdgeQualityWhenShaded	See System Options and Document Properties .
swDrawingsDefaultDisplayTypeHLREdgesWhenShaded	See System Options and Document Properties .
swDrawingSelectHiddenEntities	See System Options and Document Properties .
swDrawingSheetBackgroundAsPicture	Not used.
swDrawingSheetsContinueColumnIteration	See System Options and Document Properties .
swDrawingSheetsListNumFirstInZoneCallout	See System Options and Document Properties .
swDrawingSheetsMatchCustomPropVals	See System Options and Document Properties .
swDrawingSheetsUseDifferentSheetFormat	See System Options and Document Properties .
swDrawingShowSheetFormatDialog	See System Options and Document Properties .
swDrawingTurnOffAutomaticSolveModeAndUndo	See System Options and Document Properties .
swDrawingViewAutoHideComponents	See System Options and Document Properties .
swDrawingViewShowContentsWhileDragging	See System Options and Document Properties .
swDrawingViewSmoothDynamicMotion	See System Options and Document Properties .
swDxAllSheetsToPaperSpace	See System Options and Document Properties .
swDXF DontShowMap	See System Options and Document Properties .
swDXF EndPointMerge	See System Options and Document Properties .
swDXF ExportAllSheetsToPaperSpace	See System Options and Document Properties .
swDXF ExportHiddenLayersOn	See System Options and Document Properties .
swDXF ExportHiddenLayersWarnsOn	See System Options and Document Properties .
swDXF ExportSplinesAsSplines	See System Options and Document Properties .
swDXF ExportViewAsBlock	See System Options and Document Properties .
swDXF HighQualityExport	See System Options and Document Properties .
swDXF Mapping	See System Options and Document Properties .
swDXF UseSolidworksLayers	See System Options and Document Properties .
swDynamicDrawingViewActivation	See System Options and Document Properties .
swDynamicReferenceVisualization_Child	See System Options and Document Properties .
swDynamicReferenceVisualization_Parent	See System Options and Document Properties .
swEdgeQualityShadedEdgeViews	See System Options and Document Properties .
swEdgeQualityWireframeHiddenViews	See System Options and Document Properties .
swEdgesAntiAlias	See System Options and Document Properties .
swEdgesDefaultBulkSelection	Obsolete
swEdgesDefaultBulkSelection2	See System Options and Document Properties .
swEdgesDisplayShadedPlanes	See System Options and Document Properties .
swEdgesDynamicHighlight	See System Options and Document Properties .
swEdgesHiddenEdgeSelectionInHLR	See System Options and Document Properties .
swEdgesHiddenEdgeSelectionInWireframe	See System Options and Document Properties .
swEdgesHighlightFeatureEdges	See System Options and Document Properties .
swEdgesHighQualityDisplay	See System Options and Document Properties .
swEdgesOpenEdgesDifferentColor	See System Options and Document Properties .
swEdgesRepaintAfterSelectionInHLR	See System Options and Document Properties .
swEdgesShadedEdgesDifferentColor	See System Options and Document Properties .
swEdgesShadedModeDisplayOptimizeForThinParts	See System Options and Document Properties .
swEdit3DPDFTemplate	See System Options and Document Properties .
swEditDesignTableInSeparateWindow	See System Options and Document Properties .
swEditMacroAfterRecord	See System Options and Document Properties .
swEditNameWithSlowDoubleClick	See System Options and Document Properties .
swEDrawingsCompression	See System Options and Document Properties .
swEDrawingsExportSTLOkay	See System Options and Document Properties .
swEDrawingsIncludeLayersNotToPrint	See System Options and Document Properties .
swEDrawingsOkayToMeasure	See System Options and Document Properties .
swEDrawingsSaveAnimationOkay	See System Options and Document Properties .

swEDrawingsSaveAnimationRecalculate	See System Options and Document Properties .
swEDrawingsSaveAnimationToAllConfigs	See System Options and Document Properties .
swEDrawingsSaveBOM	See System Options and Document Properties .
swEDrawingsSaveShadedDataInDrawings	See System Options and Document Properties .
swEnable3DEXPERIENCEFileCompatibilityUpdate	See System Options and Document Properties .
swEnable3DEXPERIENCEIntegration	See System Options and Document Properties .
swEnableAllowCosmeticThreadsUpgrade	See System Options and Document Properties .
swEnableConfirmationCorner	See System Options and Document Properties .
swEnableInterfDetMultiThread	Registry setting to control whether to perform interference detection on a secondary thread; to set, call ISIdWorks:-SetUserPreferenceToggle swUserPreferenceToggle_e_swEnableInterfDetProgressDlg True/False
swEnableInterfDetProgressDlg	Registry setting to control whether to display the progress dialog during interference detection; to set, call ISIdWorks:-SetUserPreferenceToggle swUserPreferenceToggle_e_swEnableInterfDetProgressDlg True/False
swEnableMouseGestures	See System Options and Document Properties .
swEnablePerformanceEmail	See System Options and Document Properties .
swEnablePerformanceFeedback	See System Options and Document Properties .
swEnablePerformancePipeline	See System Options and Document Properties .
swEnablePropertyManager	See System Options and Document Properties .
swEnableSaveToVersion	See System Options and Document Properties .
swEnableSoundsForSolidWorksEvents	See System Options and Document Properties .
swEnableVSTAVersion3	See System Options and Document Properties .
swEnhanceSmallFaceSelectionPrecision	See System Options and Document Properties .
swExportVmlAllComponentsInSingleFile	See System Options and Document Properties .
swExternalReferencesDisable	Obsolete.
swExtRefAutoGenNames	See System Options and Document Properties .
swExtRefExcludeActiveFoldersAndRecentSaveLocations	See System Options and Document Properties .
swExtRefForceSaveToCurrentVersion	See System Options and Document Properties .
swExtRefIncludeSubFolders	See System Options and Document Properties .
swExtRefLoadRefDocsInMemory	See System Options and Document Properties .
swExtRefMultipleContexts	See System Options and Document Properties .
swExtRefNoPromptOrSave	See System Options and Document Properties .
swExtRefOpenReadOnly	See System Options and Document Properties .
swExtRefShowXInFeatureTree	See System Options and Document Properties .
swExtRefUpdateCompNames	See System Options and Document Properties .
swFamilyTableDimName	See System Options and Document Properties .
swFeatureManagerDynamicHighlight	See System Options and Document Properties .
swFeatureManagerEnablePreviewHiddenComponents	See System Options and Document Properties .
swFeatureManagerEnableRenamingComponent	See System Options and Document Properties .
swFeatureManagerEnableTreeFilter	See System Options and Document Properties .
swFeatureManagerEnsureVisible	See System Options and Document Properties .
swFeatureManagerKeyboardNavigation	See System Options and Document Properties .
swFeatureManagerNameFeatureWhenCreated	See System Options and Document Properties .
swFeatureManagerShowTranslatedNameInFMTTree	See System Options and Document Properties .
swFeatureManagerTransparentFlyout	See System Options and Document Properties .
swFileExplorerShowHiddenReferencedDocuments	See System Options and Document Properties .
swFileExplorerShowMyComputer	See System Options and Document Properties .
swFileExplorerShowMyDocuments	See System Options and Document Properties .
swFileExplorerShowMyNetworkPlaces	See System Options and Document Properties .
swFileExplorerShowRecentDocuments	See System Options and Document Properties .
swFileExplorerShowSamples	See System Options and Document Properties .
swFlatPatternOpt_CornerTreatment	See System Options and Document Properties .
swFlatPatternOpt_DisableSplitters	See System Options and Document Properties .
swFlatPatternOpt_ShowFixedFace	See System Options and Document Properties .
swFlatPatternOpt_ShowGrainDirection	See System Options and Document Properties .
swFlatPatternOpt_SimplifyBends	See System Options and Document Properties .
swFlatPatternOpt_WhenFlattenedShowCenters	See System Options and Document Properties .
swFlatPatternOpt_WhenFlattenedShowGussetCenters	See System Options and Document Properties .
swFlatPatternOpt_WhenFlattenedShowGussetProfiles	See System Options and Document Properties .
swFlatPatternOpt_WhenFlattenedShowProfiles	See System Options and Document Properties .
swFlatPatternOpt_WhenFlattenedShowPunches	See System Options and Document Properties .
swForceEnableImportDiagnosis	See System Options and Document Properties .
swFourViewportProjectionType	See System Options and Document Properties .
swFullyConstrainedSketchMode	See System Options and Document Properties .
swGenerateCutlistIDInDocUnits	See System Options and Document Properties .
swGridAutomaticScaling	See System Options and Document Properties .
swGridDisplay	See System Options and Document Properties .
swGridDisplayDashed	See System Options and Document Properties .
swHardwareAccSilhouetteEdges	See System Options and Document Properties .
swHideShowSketchDimensions	See System Options and Document Properties .
swHideUnitsOfLengthValues	See System Options and Document Properties .
swHoleTableAddNewAIEnd	See System Options and Document Properties .
swHoleTableAutomaticUpdate	See System Options and Document Properties .
swHoleTableCombineSameSize	See System Options and Document Properties .
swHoleTableCombineTags	See System Options and Document Properties .
swHoleTableHoleCentersVisible	See System Options and Document Properties .
swHoleTableReuseDeleted	See System Options and Document Properties .
swHoleTableShowAnsilnchSize	See System Options and Document Properties .
swIFCCustomPropsPreference	See System Options and Document Properties .
swIFCExportUsePropertySetMappingFile	See System Options and Document Properties .
swIFCMaterialsMassPropertiesPreference	See System Options and Document Properties .
swIFCOmniClassPreference	See System Options and Document Properties .
swIFCUniClass2Preference	See System Options and Document Properties .
swIGESComponentsIntoOneFile	See System Options and Document Properties .
swIGESDuplicateEntities	See System Options and Document Properties .
swIGESExportAsWireframe	See System Options and Document Properties .
swIGESExportFreeCurves	See System Options and Document Properties .
swIGESExportSketchEntities	See System Options and Document Properties .
swIGESExportSolidAndSurface	See System Options and Document Properties .
swIGESExportSplitPeriodic	See System Options and Document Properties .
swIGESFlattenAssemHierarchy	See System Options and Document Properties .
swIGESHHighTrimCurveAccuracy	See System Options and Document Properties .
swIGESImportShowLevel	See System Options and Document Properties .
swIGESNurbsSetting	See System Options and Document Properties .
swIGESStandardSetting	See System Options and Document Properties .
swIgnoreConstructionEntity	See System Options and Document Properties .
swIgnoreFeatureColors	See System Options and Document Properties .
swImageQualityApplyToAllReferencedPartDoc	See System Options and Document Properties .
swImageQualitySaveTessellationWithPartDoc	See System Options and Document Properties .
swImageQualityUseHighQualityEdgeSize	See System Options and Document Properties .
swImageQualityUseOldTangentEdgeDisplay	See System Options and Document Properties .
swImageQualityWireframeHighCurveQuality	See System Options and Document Properties .
swImageQualityZoomToFitForPreviewImages	See System Options and Document Properties .
swImport2dCurvesAs2dSketch	See System Options and Document Properties .
swImportAssemblyHybrid	See System Options and Document Properties .
swImportAutoRunImportDiagnostics	See System Options and Document Properties .
swImportAutoRunImportDiagnosticsPersist	See System Options and Document Properties .
swImportCustomProperties	See System Options and Document Properties .
swImportDissolveTopLevelAssemblyOnOpen	See System Options and Document Properties .
swImportDoclessModelInAssem	Not used.
swImportDxfDimsToPartSketch	See System Options and Document Properties .

swimportFreeCurves	See System Options and Document Properties .
swimportIDFAddDrilledHoles	See System Options and Document Properties .
swimportIDFReverseUndersideComponents	See System Options and Document Properties .
swimportIgnoreHiddenEntities	See System Options and Document Properties .
swimportMaterialProperties	See System Options and Document Properties .
swimportMultiBodyAsPartData	See System Options and Document Properties .
swimportNeutral_AttributesAndProperties	See System Options and Document Properties .
swimportNeutral_FreeCurvesAndPoints	See System Options and Document Properties .
swimportNeutral_SolidandSurface	See System Options and Document Properties .
swimportNeutralAnalyticalConversion	See System Options and Document Properties .
swimportNeutralReferencePlane	See System Options and Document Properties .
swimportNeutralRunDiagnostics	See System Options and Document Properties .
swimportPSEnableTemplates	See System Options and Document Properties .
swimportReferenceAxis	See System Options and Document Properties .
swimportReferencePlane	See System Options and Document Properties .
swimportSLDXMLImportAssemblyMatesData	See System Options and Document Properties .
swimportSLDXMLImportMechanismSketchObjectsAsBlocks	See System Options and Document Properties .
swimportSLDXMLImportSketchData	See System Options and Document Properties .
swimportSolidBody	See System Options and Document Properties .
swimportSolidSurface	See System Options and Document Properties .
swimportStepConfigData	See System Options and Document Properties .
swimportStlVmlTextureInformation	See System Options and Document Properties .
swimportSurfaceBody	See System Options and Document Properties .
swimportToolBodiesFromUGNX	See System Options and Document Properties .
swimportUGToolBodies	See System Options and Document Properties .
swimportUnconsumedSketchesAndCurves	See System Options and Document Properties .
swincludeDataForDelmia	See System Options and Document Properties .
swincludeDocumentsOpenedFromOtherDocuments	See System Options and Document Properties .
swincludePMI	See System Options and Document Properties .
swincludeSketchData	DO NOT USE; for internal use only
swincludeSubfoldersForDrawingsSearchInPackAndGo	See System Options and Document Properties .
swincontextFeatureHolderVisibility	See System Options and Document Properties .
swinputDimValOnCreate	See System Options and Document Properties .
swinsertComponentForNewAssembly	See System Options and Document Properties .
swinsertViewForNewDrawing	See System Options and Document Properties .
swLargeAsmModeAlwaysGenerateCurvature	See System Options and Document Properties .
swLargeAsmModeAntiAliasEdgesFastMode	See System Options and Document Properties .
swLargeAsmModeAutoCheckUpdateAllComponents	See System Options and Document Properties .
swLargeAsmModeAutoHideCompsDrawViewCreation	See System Options and Document Properties .
swLargeAsmModeAutoLoadLightweight	See System Options and Document Properties .
swLargeAsmModeAutoRecover	See System Options and Document Properties .
swLargeAsmModeDismissAutoUpdate	See System Options and Document Properties .
swLargeAsmModeDrawingAutoLoadModels	See System Options and Document Properties .
swLargeAsmModeDrawingHLREdgesWhenShaded	See System Options and Document Properties .
swLargeAsmModeDynHighlightFeatureMgr	See System Options and Document Properties .
swLargeAsmModeDynHighlightGraphicsView	See System Options and Document Properties .
swLargeAsmModeEnabled	See System Options and Document Properties .
swLargeAsmModeHideAllItems	See System Options and Document Properties .
swLargeAsmModeImageQualityPerformance	See System Options and Document Properties .
swLargeAsmModePreviewHiddenComponent	See System Options and Document Properties .
swLargeAsmModeRemoveDetail	See System Options and Document Properties .
swLargeAsmModeShadowsShadedMode	See System Options and Document Properties .
swLargeAsmModeShowContentsDragDrawView	See System Options and Document Properties .
swLargeAsmModeSmoothDynamicMotionDrawView	See System Options and Document Properties .
swLargeAsmModeSuspendAutoRebuild	See System Options and Document Properties .
swLargeAsmModeTransparencyDynamicViewMode	See System Options and Document Properties .
swLargeAsmModeTransparencyNormalViewMode	See System Options and Document Properties .
swLargeAsmModeUpdateMassPropsOnSave	See System Options and Document Properties .
swLargeAsmModeUseHLREdgesInShaded	See System Options and Document Properties .
swLargeAsmModeUseLargeDesignReview	See System Options and Document Properties .
swLargeAsmModeVerificationOnRebuild	See System Options and Document Properties .
swLoadEnvelopeLightweight	See System Options and Document Properties .
swLoadEnvelopeReadOnly	See System Options and Document Properties .
swLockRecentDocumentsList	See System Options and Document Properties .
swLockRotationConcentricMates	See System Options and Document Properties .
swMagMatePreAlign	See System Options and Document Properties .
swMakeFirstSelectionTransparentInMateDialog	See System Options and Document Properties .
swMakeTrimEntityConstruction	See System Options and Document Properties .
swMatchConfigurationNames	See System Options and Document Properties .
swMaterialPropertySolidFill	See System Options and Document Properties .
swMaximizeDocumentOnOpen	See System Options and Document Properties .
swMultiCAD_3DInterconnectLinksFlag	See System Options and Document Properties .
swMultiCAD_3DInterconnectMaintainLinks	See System Options and Document Properties .
swMultiCAD_3DInterconnectManualBreakLink	See System Options and Document Properties .
swMultiCAD_ApplyOnlyToParts	See System Options and Document Properties .
swMultiCAD_CreateNewComponentsAsExternalFiles	See System Options and Document Properties .
swMultiCAD_Enable3DInterconnect	See System Options and Document Properties .
swNoteParagraphAutoNumbering	See System Options and Document Properties .
swNoteZoomToFit	See System Options and Document Properties .
swNotifySNLNotObtainedForEDrawingsSave	See System Options and Document Properties .
swOneConfigOnlyTopLevelBom	See System Options and Document Properties .
swOpenLastUsedDocumentAtStart	See System Options and Document Properties .
swOptimizeMatePlacement	See System Options and Document Properties .
swOverrideQuantityColumnName	See System Options and Document Properties .
swOverrideTreeDisplaySysSettings	See System Options and Document Properties .
swPageSetupHighQuality	See System Options and Document Properties .
swPageSetupPrinterDrawingScaleToFit	See System Options and Document Properties .
swPageSetupPrinterPartAsmPrintWindow	See System Options and Document Properties .
swPageSetupPrinterUsePrinterMargin	See System Options and Document Properties .
swPageSetupScaleDraftEdges	See System Options and Document Properties .
swPartDimXpertBlockTolerance	See System Options and Document Properties .
swPartDimXpertChainHoleDimensionChain	See System Options and Document Properties .
swPartDimXpertChainPocketDimensionChain	See System Options and Document Properties .
swPartDimXpertDisplayEliminateDuplicates	See System Options and Document Properties .
swPartDimXpertDisplayShowInstanceCount	See System Options and Document Properties .
swPartDimXpertGeometricApplyMMC	See System Options and Document Properties .
swPartDimXpertGeometricCreateBasicDimension	See System Options and Document Properties .
swPartDimXpertGeometricPositionAtMMC	See System Options and Document Properties .
swPartDimXpertGeometricPositionComposite	See System Options and Document Properties .
swPartDimXpertGeometricSurfaceProfileComposite	See System Options and Document Properties .
swPartDimXpertLocationInclinedPlane	See System Options and Document Properties .
swPartExportFlatPattern	See System Options and Document Properties .
swPDFExportEmbeddedFonts	See System Options and Document Properties .
swPDFExportHighQuality	See System Options and Document Properties .
swPDFExportIncludeDrawingsPaperColor	See System Options and Document Properties .
swPDFExportIncludeLayersNotToPrint	See System Options and Document Properties .
swPDFExportInColor	See System Options and Document Properties .
swPDFExportPrintHeaderFooter	See System Options and Document Properties .

swPDFExportShadedEdgesHighQuality	See System Options and Document Properties .
swPDFExportUseCurrentPrintLineWeights	See System Options and Document Properties .
swPdfIncludeBookmarks	See System Options and Document Properties .
swPDFViewOnSave	See System Options and Document Properties .
swPerformanceAlwaysGenerateCurvature	See System Options and Document Properties .
swPerformanceAlwaysResolveSubassemblies	See System Options and Document Properties .
swPerformanceDynamicUpdateOnMove	See System Options and Document Properties .
swPerformancePreviewDuringOpen	See System Options and Document Properties .
swPerformanceRemoveDetailDuringZoomPanRotate	See System Options and Document Properties .
swPerformanceSave	See System Options and Document Properties .
swPerformanceSheetMetalIgnoreSelfIntersect	See System Options and Document Properties .
swPerformanceVerifyOnRebuild	See System Options and Document Properties .
swPerformanceWin9ZoomClipping	See System Options and Document Properties .
swPlaneDisplayShowEdges	See System Options and Document Properties .
swPlaneDisplayShowIntersections	See System Options and Document Properties .
swPLYBinaryFormat	See System Options and Document Properties .
swPLYIncludeColors	See System Options and Document Properties .
swPLYPreview	See System Options and Document Properties .
swPMIOverwriteColor	See System Options and Document Properties .
swPointAxisCoordSystemHideNames	See System Options and Document Properties .
swPreciseRenderingOfOverlappingGeometry	See System Options and Document Properties .
swPreserveRedundantGeometry	See System Options and Document Properties .
swPrintBackground	See System Options and Document Properties .
swPrintGrid	See System Options and Document Properties .
swPrintZoneLines	See System Options and Document Properties .
swPromptForAutoMateFlip	See System Options and Document Properties .
swPunchTableCombineSameSize	See System Options and Document Properties .
swPunchTableCombineTags	See System Options and Document Properties .
swPurgeAllBodiesForNonActiveConfigurations	See System Options and Document Properties .
swQuickTipsAssembly	See System Options and Document Properties .
swQuickTipsDrawing	See System Options and Document Properties .
swQuickTipsPart	See System Options and Document Properties .
swQuickViewTransparencyDynamic	See System Options and Document Properties .
swQuickViewTransparencyEnabled	See System Options and Document Properties .
swRapidDraftPrintOutOfSynchronWaterMark	See System Options and Document Properties .
swRebuildSaveNewConfig	See System Options and Document Properties .
swReferenceInContextOfTopLevelAssembly	See System Options and Document Properties .
swReferenceOnlyEnvelopeComponentType	See System Options and Document Properties .
swReferenceTriadUseAlternateLabels	See System Options and Document Properties .
swRevisionTableUpdateAllLabels	See System Options and Document Properties .
swSATExportFaceEdgeProps	See System Options and Document Properties .
swSATExportMultiLumpsToSingleBody	See System Options and Document Properties .
swSATExportSplitPeriodic	See System Options and Document Properties .
swSaveAsmAsPartPreserveIDs	See System Options and Document Properties .
swSaveBackupFilesInSameLocationAsOriginal	See System Options and Document Properties .
swSaveEModelData	See System Options and Document Properties .
swSaveFileProperties	See System Options and Document Properties .
swSaveFilePropertiesForEachComp	See System Options and Document Properties .
swSaveNewComponentsToExternalFile	See System Options and Document Properties .
swSaveReminderAutoDismissEnable	See System Options and Document Properties .
swSaveReminderEnable	See System Options and Document Properties .
swSaveWithoutCostingData	See System Options and Document Properties .
swScaleSketchOnFirstDimension	See System Options and Document Properties .
swSearchDissectionScheduleDaily	See System Options and Document Properties .
swSearchIncludeContentCentral	See System Options and Document Properties .
swSearchShowSolidWorksSearchBox	See System Options and Document Properties .
swSearchWhileTyping	See System Options and Document Properties .
swSecondaryComponentDescription	See System Options and Document Properties .
swSecondaryConfigurationDescription	See System Options and Document Properties .
swSecondaryConfigurationName	See System Options and Document Properties .
swSecondaryEnterpriseItemNumber	See System Options and Document Properties .
swSecondaryPhysicalProductDescription	See System Options and Document Properties .
swSeeThroughTransparentComponents	See System Options and Document Properties .
swShadedSketchContours	See System Options and Document Properties .
swSheetMetalBendNotesLeaderJustificationSnapping	See System Options and Document Properties .
swSheetMetalBendNotesUseDocLeaderLength	See System Options and Document Properties .
swSheetMetalBodiesDescriptionUseDefault	See System Options and Document Properties .
swSheetMetalDimensionFlangeSketch	See System Options and Document Properties .
swSheetMetalMBDDisplaySheetMetalBendNotes	See System Options and Document Properties .
swSheetMetalMBDFFormat	See System Options and Document Properties .
swSheetMetalMBDLeaderJustificationSnapping	See System Options and Document Properties .
swSheetMetalMBDShowFixedFace	See System Options and Document Properties .
swSheetMetalMBDShowGrainDirection	See System Options and Document Properties .
swSheetMetalMBDUseDocumentLeaderLength	See System Options and Document Properties .
swSheetMetalOverrideTemplateAllowance	See System Options and Document Properties .
swSheetMetalOverrideTemplateParam	See System Options and Document Properties .
swSheetMetalOverrideTemplateRelief	See System Options and Document Properties .
swSheetMetalUseMaterial	See System Options and Document Properties .
swShowAnnotationInAnnotationViews	See System Options and Document Properties .
swShowBreadcrumbsAtMousePointer	See System Options and Document Properties .
swShowBreadcrumbsOnSelection	See System Options and Document Properties .
swShowCADAndOtherConfig3dexpIntegration	See System Options and Document Properties .
swShowCADFamilyConfigOnly3dexpIntegration	See System Options and Document Properties .
swShowDimensionNames	See System Options and Document Properties .
swShowDismissedMessagesIconInStatusBar	See System Options and Document Properties .
swShowDrawingViewPalette	See System Options and Document Properties .
swShowErrorsEveryRebuild	See System Options and Document Properties .
swShowMateReferenceErrors	See System Options and Document Properties .
swShowNewsFeedsInTaskPane	See System Options and Document Properties .
swShowRefGeomName	See System Options and Document Properties .
swShowSheetMetalBendNotes	See System Options and Document Properties .
swShowToolboxFavoritesFolder	See System Options and Document Properties .
swShowZoneLines	See System Options and Document Properties .
swSingleCommandPerPick	See System Options and Document Properties .
swSketchAcceptNumericInput	See System Options and Document Properties .
swSketchAddConstLineDiagonalType	See System Options and Document Properties .
swSketchAddConstToRectEntity	See System Options and Document Properties .
swSketchAlternateSplineCreation	See System Options and Document Properties .
swSketchAutomaticRelations	See System Options and Document Properties .
swSketchCreateDimensionOnlyWhenEntered	See System Options and Document Properties .
swSketchCreateSketchOnNewPart	See System Options and Document Properties .
swSketchDisplayPlaneWhenShaded	See System Options and Document Properties .
swSketchInference	See System Options and Document Properties .
swSketchInferFromModel	See System Options and Document Properties .
swSketch.LineLengthVirtualSharp3d	See System Options and Document Properties .
swSketchNoSolveMove	See System Options and Document Properties .
swSketchOverdefiningDimsPromptToSetState	See System Options and Document Properties .
swSketchOverdefiningDimsSetDrivenByDefault	See System Options and Document Properties .

swSketchOverrideDimensionsOnDrag	See System Options and Document Properties .
swSketchPreviewDimensionOnSelect	See System Options and Document Properties .
swSketchPromptToCloseSketch	See System Options and Document Properties .
swSketchShadowDrag	See System Options and Document Properties .
swSketchShowSplineControlPolygon	See System Options and Document Properties .
swSketchShowSplineOuterComb	See System Options and Document Properties .
swSketchSnapsAngle	See System Options and Document Properties .
swSketchSnapsCenterPoints	See System Options and Document Properties .
swSketchSnapsGrid	See System Options and Document Properties .
swSketchSnapsHVLines	See System Options and Document Properties .
swSketchSnapsHVPoints	See System Options and Document Properties .
swSketchSnapsIntersections	See System Options and Document Properties .
swSketchSnapsLength	See System Options and Document Properties .
swSketchSnapsMidPoints	See System Options and Document Properties .
swSketchSnapsNearest	See System Options and Document Properties .
swSketchSnapsParallel	See System Options and Document Properties .
swSketchSnapsPerpendicular	See System Options and Document Properties .
swSketchSnapsPoints	See System Options and Document Properties .
swSketchSnapsQuadrantPoints	See System Options and Document Properties .
swSketchSnapsTangent	See System Options and Document Properties .
swSketchSnapToGridIfDisplayed	See System Options and Document Properties .
swSketchSuppressedDimProfileErrorOption	See System Options and Document Properties .
swSketchTurnOffAutomaticSolveModeAndUndo	See System Options and Document Properties .
swSMGEnableHealing	See System Options and Document Properties .
swSMGExportAsBodies	See System Options and Document Properties .
swSMGExportFreeFaces	See System Options and Document Properties .
swSMGExportHiddenCompNOSHOW	See System Options and Document Properties .
swSMGExportInstanceNames	See System Options and Document Properties .
swSMGExportMetaProps	See System Options and Document Properties .
swSMGExportSWAppearance	See System Options and Document Properties .
swSMGExportSWAssemEnvelope	See System Options and Document Properties .
swSMGExportSWBOM	See System Options and Document Properties .
swSMGExportSWDecals	See System Options and Document Properties .
swSMGExportSWExplodedAndSavedViews	See System Options and Document Properties .
swSMGExportSWPMI	See System Options and Document Properties .
swSMGMergeFileintoOneActorPerPart	See System Options and Document Properties .
swSMGOverloadAssemTreeNames	See System Options and Document Properties .
swSnapOnlyIfGridDisplayed	See System Options and Document Properties .
swSnapToAngle	See System Options and Document Properties .
swSnapToPoints	See System Options and Document Properties .
swSolidBBoxDescriptionUseDefault	c
swSpeedpakUpdateSlider	See System Options and Document Properties .
swStepExport3DCurveFeatures	See System Options and Document Properties .
swStepExportAppearances	See System Options and Document Properties .
swStepExportAtomicSave	See System Options and Document Properties .
swStepExportConfigurationData	See System Options and Document Properties .
swStepExportIFaceEdgeProps	See System Options and Document Properties .
swStepExportSplitPeriodic	See System Options and Document Properties .
swSTLBinaryFormat	See System Options and Document Properties .
swSTLCheckForInterference	See System Options and Document Properties .
swSTLComponentsIntoOneFile	See System Options and Document Properties .
swSTLDontTranslateToPositive	See System Options and Document Properties .
swSTLPreview	See System Options and Document Properties .
swSTLShowInfoOnSave	See System Options and Document Properties .
swStopDebuggingVstaOnExit	See System Options and Document Properties .
swStoreImagesWithModel	See System Options and Document Properties .
swStoreOLEImagesWithModel	See System Options and Document Properties .
swSystemNotificationHideGraphicsNotification	See System Options and Document Properties .
swTableHoleDualDimensionDisplay	See System Options and Document Properties .
swTableHoleShowUnitsForDualDisplay	See System Options and Document Properties .
swTablePunchDualDimensionsDisplay	See System Options and Document Properties .
swTablePunchShowUnitsForDualDisplay	See System Options and Document Properties .
swTertiaryDisplayStyleName	See System Options and Document Properties .
swTertiaryDialogTitle	See System Options and Document Properties .
swTertiaryRevision	See System Options and Document Properties .
swTextSizeUseOperatingSystemScale	See System Options and Document Properties .
swThumbnailGraphics	See System Options and Document Properties .
swTIFExportIncludeDrawingsPaperColor	See System Options and Document Properties .
swTiffPrintAllSheets	See System Options and Document Properties .
swTiffPrintPadText	See System Options and Document Properties .
swTiffPrintScaleToFit	See System Options and Document Properties .
swTiffPrintUseSheetSize	See System Options and Document Properties .
swTIFIncludeLayersNotToPrint	See System Options and Document Properties .
swTransferHoleWizardSizeComboBoxSettings	See System Options and Document Properties .
swTranslateNameAttribFromKernelBody	Not used.
swTransparencyHighQualityDynamic	See System Options and Document Properties .
swUnitsDualLinearFeetAndInchesFormat	See System Options and Document Properties .
swUnitsDualLinearRoundToNearestFraction	See System Options and Document Properties .
swUnitsLinearFeetAndInchesFormat	See System Options and Document Properties .
swUnitsLinearRoundToNearestFraction	See System Options and Document Properties .
swUpdateExternFilesDispList	See System Options and Document Properties .
swUpdateMassPropsDuringSave	See System Options and Document Properties .
swUseAlphaTransparency	See System Options and Document Properties .
swUseChangedDimensions	See System Options and Document Properties .
swUseEnglishLanguage	See System Options and Document Properties .
swUseEnglishLanguageFeatureNames	See System Options and Document Properties .
swUseFolderAsDefaultSearchLocation	See System Options and Document Properties .
swUseFolderSearchRules	See System Options and Document Properties .
swUseModelColorInDrawings	See System Options and Document Properties .
swUsePositiveInertiaTensorNotation	See System Options and Document Properties .
swUserEnableAutoFix	See System Options and Document Properties .
swUserEnableFreezeBar	See System Options and Document Properties .
swUserEnablePlasticsMode	See System Options and Document Properties .
swUserEnablePlasticsMode2	See System Options and Document Properties .
swUseShadedFaceHighlight	See System Options and Document Properties .
swUseShadedPreview	See System Options and Document Properties .
swUseSimpleOpenGL	See System Options and Document Properties .
swUseSpeedpakModelColorInDrawings	See System Options and Document Properties .
swUseSystemSeparatorForDims	See System Options and Document Properties .
swViewDispGlobalBBox	See System Options and Document Properties .
swViewDisplayHideAllTypes	See System Options and Document Properties .
swViewpintPreserveNormals	See System Options and Document Properties .
swViewReverseWheelZoomDirection	See System Options and Document Properties .
swViewShowAnnotationLinkErrors	See System Options and Document Properties .
swViewShowAnnotationLinkVariables	See System Options and Document Properties .
swViewShowAnnotationTextExpression	See System Options and Document Properties .
swViewSketchRelations	See System Options and Document Properties .
swViewZoomFitAndCenter	See System Options and Document Properties .

swVrmIStIImportAsPSMesh	See System Options and Document Properties .
swVrmIStIImportSegmented	See System Options and Document Properties .
swWarnOnDupCompRefsForDlg	849; right-click on the assembly in the FeatureManager design tree, select Edit Component References... In the Component References dialog, Warn if there are duplicate Component References check box corresponds to this user preference.
swWarnSaveUpdateErrors	See System Options and Document Properties .
swWarnSavingReferencedDoc	See System Options and Document Properties .
swWarnStartingSketchInContextAssembly	See System Options and Document Properties .
swWeldmentCollectIdenticalBodies	See System Options and Document Properties .
swWeldmentEnableAutomaticCutList	See System Options and Document Properties .
swWeldmentEnableAutomaticUpdate	See System Options and Document Properties .
swWeldmentGenerateCutlistIDs	See System Options and Document Properties .
swWeldmentRenameCutlistDescriptionPropertyValue	See System Options and Document Properties .
swWeldmentUseEnglishDescriptionNameInCutlist	See System Options and Document Properties .
swWhileOpeningAssembliesAutoDismissMessages	See System Options and Document Properties .
swXTAssemSaveFormat	See System Options and Document Properties .

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)
[swUserPreferenceIntegerValue e Enumeration](#)
[swUserPreferenceStringListValue e Enumeration](#)
[swUserPreferenceStringValue e Enumeration](#)
[swUserPreferenceTextFormat e Enumeration](#)

swUserUnitsType_e (Type)

SOLIDWORKS API Enumerations

swUserUnitsType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swUserUnitsType_e Enumeration

User unit types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swUserUnitsType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swUserUnitsType\_e
```

C#

```
public enum swUserUnitsType_e : System.Enum
```

C++/CLI

```
public enum class swUserUnitsType_e : public System.Enum
```

Members

Member	Description
swAngleUnit	1
swLengthUnit	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swVariablePitchHelixRegionParameter_e (Type)

SOLIDWORKS API Enumerations

swVariablePitchHelixRegionParameter_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swVariablePitchHelixRegionParameter_e Enumeration

Parameters to modify in a variable-pitch helix.

Syntax

Visual Basic (Declaration)

```
Public Enum swVariablePitchHelixRegionParameter_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swVariablePitchHelixRegionParameter\_e
```

C#

```
public enum swVariablePitchHelixRegionParameter_e : System.Enum
```

C++/CLI

```
public enum class swVariablePitchHelixRegionParameter_e : public System.Enum
```

Members

Member	Description
swVariablePitchHelixRegionParameter_Diameter	3
swVariablePitchHelixRegionParameter_Height	2
swVariablePitchHelixRegionParameter_Pitch	1
swVariablePitchHelixRegionParameter_Revolution	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swVariableRadiusFilletOptions_e (Type)

SOLIDWORKS API Enumerations

swVariableRadiusFilletOptions_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swVariableRadiusFilletOptions_e Enumeration

Variable radius fillet transition options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swVariableRadiusFilletOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swVariableRadiusFilletOptions_e](#)

C#

public enum swVariableRadiusFilletOptions_e : System.Enum

C++/CLI

public enum class swVariableRadiusFilletOptions_e : public System.Enum

Members

Member	Description
swSmoothTransition	0 = Fillet changes smoothly from one radius to another when matching a fillet edge to an adjacent face
swStraightTransition	1 = Fillet changes from one radius to another linearly without matching edge tangency with an adjacent fillet

See Also

[SolidWorks.Interop.swconst Namespace](#)

swVersionCompatibilityResult_e (Type)

SOLIDWORKS API Enumerations

swVersionCompatibilityResult_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swVersionCompatibilityResult_e Enumeration

Results for file version compatibility checks.

 Syntax

Visual Basic (Declaration)

Public Enum swVersionCompatibilityResult_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swVersionCompatibilityResult_e](#)



C#

public enum swVersionCompatibilityResult_e : System.Enum

C++/CLI

public enum class swVersionCompatibilityResult_e : public System.Enum

 Members

Member	Description
swVersionCompatibilityResult_Completed	0 = Success. No incompatibility found.
swVersionCompatibilityResult_FailFileNotResolved	2 = Failure. The file could not be resolved.
swVersionCompatibilityResult_FailInvalidVersion	3 = Failure. The requested version is not valid for compatibility checks. (See swSaveToVersion_e)
swVersionCompatibilityResult_FailUnknown	1 = Failure. The file contains features incompatible with the specified version, or could not be checked.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swVerticalJustification_e (Type)

SOLIDWORKS API Enumerations

swVerticalJustification_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swVerticalJustification_e Enumeration

Dimension text vertical justifications.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swVerticalJustification_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swVerticalJustification\_e
```

C#

```
public enum swVerticalJustification_e : System.Enum
```

C++/CLI

```
public enum class swVerticalJustification_e : public System.Enum
```

Members

Member	Description
swVerticalJustificationBottom	3
swVerticalJustificationMiddle	2
swVerticalJustificationNone	0
swVerticalJustificationTop	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewAlignment_e (Type)

SOLIDWORKS API Enumerations

swViewAlignment_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swViewAlignment_e Enumeration

Values for alignment of views.

Syntax

Visual Basic (Declaration)

```
Public Enum swViewAlignment_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swViewAlignment\_e
```

C#

```
public enum swViewAlignment_e : System.Enum
```

C++/CLI

```
public enum class swViewAlignment_e : public System.Enum
```

Members

Member	Description
swViewAlignBoth	3 = View is aligned and has aligned children
swViewAligned	2 = View is aligned with a parent view
swViewAlignedChildren	1 = View has children aligned with it
swViewAlignNone	0 = View has no alignment restrictions

See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewDisplayMode_e (Type)

SOLIDWORKS API Enumerations

swViewDisplayMode_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swViewDisplayMode_e Enumeration

View display modes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swViewDisplayMode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swViewDisplayMode\_e
```

C#

```
public enum swViewDisplayMode_e : System.Enum
```

C++/CLI

```
public enum class swViewDisplayMode_e : public System.Enum
```

Members

Member	Description
swViewDisplayMode_Faceted	12
swViewDisplayMode_HiddenLinesGrayed	3
swViewDisplayMode_HiddenLinesRemoved	2
swViewDisplayMode_IntegratedPreview	13
swViewDisplayMode_PerspectiveOff	11
swViewDisplayMode_PerspectiveOn	10
swViewDisplayMode_Shaded	4
swViewDisplayMode_ShadedCurvatureOFF	7
swViewDisplayMode_ShadedCurvatureOn	6
swViewDisplayMode_ShadedWithEdges	5
swViewDisplayMode_StripesOff	9
swViewDisplayMode_StripesOn	8
swViewDisplayMode_Wireframe	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewDisplayType_e (Type)

SOLIDWORKS API Enumerations

swViewDisplayType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swViewDisplayType_e Enumeration

View display states.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swViewDisplayType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swViewDisplayType_e](#)

C#

public enum swViewDisplayType_e : System.Enum

C++/CLI

public enum class swViewDisplayType_e : public System.Enum

 Members

Member	Description
swsViewCurvature	6
swsViewHiddenInGrey	5
swsViewHiddenLinesRemoved	4
swsViewPerspective	1
swsViewSectioned	0
swsViewShaded	2
swsViewStripe	7
swsViewWireFrame	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewEntityType_e (Type)

SOLIDWORKS API Enumerations

swViewEntityType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swViewEntityType_e Enumeration

View entity types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swViewEntityType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swViewEntityType\_e
```

C#

```
public enum swViewEntityType_e : System.Enum
```

C++/CLI

```
public enum class swViewEntityType_e : public System.Enum
```

 Members

Member	Description
swViewEntityType_Edge	1
swViewEntityType_Face	3
swViewEntityType_SilhouetteEdge	4
swViewEntityType_Vertex	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewIndication_e (Type)

SOLIDWORKS API Enumerations

swViewIndication_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swViewIndication_e Enumeration

View indicators.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swViewIndication_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swViewIndication\_e
```

C#

```
public enum swViewIndication_e : System.Enum
```

C++/CLI

```
public enum class swViewIndication_e : public System.Enum
```

Members

Member	Description
swViewIndication_ArrowMethod	0
swViewIndication_SameAsSection	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewNotify_e (Type)

SOLIDWORKS API Enumerations

swViewNotify_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swViewNotify_e Enumeration

Model view notifications.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swViewNotify_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swViewNotify_e
```

C#

```
public enum swViewNotify_e : System.Enum
```

C++/CLI

```
public enum class swViewNotify_e : public System.Enum
```

Members

Member	Description
swViewBufferSwapNotify	5 = BufferSwapNotify
swViewChangeNotify	2 = ViewChangeNotify
swViewDestroyNotify	Obsolete
swViewDestroyNotify2	6 = DestroyNotify2
swViewDisplayModeChangePostNotify	13 = DisplayModeChangePostNotify
swViewDisplayModeChangePreNotify	12 = DisplayModeChangePreNotify
swViewGraphicsRenderPostNotify	11 = GraphicsRenderPostNotify
swViewPerspectiveViewNotify	7 = PerspectiveViewNotify
swViewPrintNotify	Obsolete
swViewPrintNotify2	14 = PrintNotify2
swViewRenderLayer0Notify	8 = RenderLayerNotify
swViewRepaintNotify	1 = RepaintNotify
swViewRepaintPostNotify	4 = RepaintPostNotify
swViewUserClearSelectionsNotify	9 = UserClearSelectionsNotify

Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports model view events (e.g., DocView.h), include:

```
BEGIN_SINK_MAP(CDocView)
    SINK_ENTRY_EX(ID_MODELVIEW_EVENTS, DIID_DModelViewEvents, swViewDestroyNotify, DestroyNotify)
    SINK_ENTRY_EX(ID_MODELVIEW_EVENTS, DIID_DModelViewEvents, swViewRepaintNotify, RepaintNotify)
END_SINK_MAP()
```

If developing a C++ application, use these enumerators to [register for notifications](#) for the [IModelView](#) events.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewOrientationUpAxisFlyout_e (Type)

SOLIDWORKS API Enumerations

swViewOrientationUpAxisFlyout_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swViewOrientationUpAxisFlyout_e Enumeration

View orientation up axis flyout options.

 Syntax

Visual Basic (Declaration)

Public Enum swViewOrientationUpAxisFlyout_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swViewOrientationUpAxisFlyout_e](#)

C#

public enum swViewOrientationUpAxisFlyout_e : System.Enum

C++/CLI

public enum class swViewOrientationUpAxisFlyout_e : public System.Enum

 Members

Member	Description
swViewOrientationUpAxisFlyout_Y_Up	0
swViewOrientationUpAxisFlyout_Z_Up	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swViewportDisplay_e (Type)

SOLIDWORKS API Enumerations

swViewportDisplay_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swViewportDisplay_e Enumeration

Viewport arrangements.

Syntax

Visual Basic (Declaration)

```
Public Enum swViewportDisplay_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swViewportDisplay\_e
```

C#

```
public enum swViewportDisplay_e : System.Enum
```

C++/CLI

```
public enum class swViewportDisplay_e : public System.Enum
```

Members

Member	Description
swViewPortFourView	4
swViewPortSingle	1
swViewPortTwoViewHorizontal	2
swViewPortTwoViewVertical	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swVisibilityState_e (Type)

SOLIDWORKS API Enumerations

swVisibilityState_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swVisibilityState_e Enumeration

Visibility states.

 Syntax

Visual Basic (Declaration)

```
Public Enum swVisibilityState_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swVisibilityState\_e
```

C#

```
public enum swVisibilityState_e : System.Enum
```

C++/CLI

```
public enum class swVisibilityState_e : public System.Enum
```

 Members

Member	Description
swVisibilityStateHide	1
swVisibilityStateShown	2
swVisibilityStateUnknown	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swVrmlOutputVersion_e (Type)

SOLIDWORKS API Enumerations

swVrmlOutputVersion_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swVrmlOutputVersion_e Enumeration

[Send comments on this topic.](#)

VRML output versions.

Syntax

Visual Basic (Declaration)

```
Public Enum swVrmlOutputVersion_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swVrmlOutputVersion\_e
```

C#

```
public enum swVrmlOutputVersion_e : System.Enum
```

C++/CLI

```
public enum class swVrmlOutputVersion_e : public System.Enum
```

Members

Member	Description
swVrmlOutputVersion_01	2
swVrmlOutputVersion_97	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swWeldBeadSide_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swWeldBeadSide_e Enumeration

Weld bead sides.

 Syntax

Visual Basic (Declaration)

Public Enum swWeldBeadSide_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swWeldBeadSide_e](#)

C#

public enum swWeldBeadSide_e : System.Enum

C++/CLI

public enum class swWeldBeadSide_e : public System.Enum

 Members

Member	Description
swWeldBeadArrowSide	0
swWeldBeadOtherSide	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swWeldBeadType_e (Type)

SOLIDWORKS API Enumerations

swWeldBeadType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swWeldBeadType_e Enumeration

Weld bead types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swWeldBeadType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swWeldBeadType_e](#)

C#

public enum swWeldBeadType_e : System.Enum

C++/CLI

public enum class swWeldBeadType_e : public System.Enum

Members

Member	Description
swWeldBeadTypeFull	0
swWeldBeadTypeIntermittent	1
swWeldBeadTypeStaggered	2

See Also

[SolidWorks.Interop.swconst Namespace](#)