

SOLIDWORKS DimXpert API (.NET) — Reference

(5/8): IDimXpertExtrudeFeature- IDimXpertIntersectPlaneFeature

SOLIDWORKS API Documentation (converted from CHM)

IDimXpertExtrudeFeature (Type)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertExtrudeFeature Interface

See Also [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertExtrudeFeature Interface

Allows you to access specific information about DimXpert extrudes on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertExtrudeFeature

Visual Basic (Usage)



Dim instance As [IDimXpertExtrudeFeature](#)

C#

public interface IDimXpertExtrudeFeature

C++/CLI

public interface class IDimXpertExtrudeFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature](#).

Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertExtrudeFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertExtrudeFeature Interface Methods

See Also

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertExtrudeFeature Interface

For a list of all members of this type, see [IDimXpertExtrudeFeature members](#).

Public Methods

Name	Description
 GetBottomBlends	Gets the bottom blend DimXpert feature for this DimXpert extrude.
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert extrude.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert extrude.

	GetSubFeatureCount	Gets the number of sub-features in this DimXpert extrude.
	GetSubFeatures	Gets all of the sub-features of this DimXpert extrude.
	GetTopBlends	Gets the top blend DimXpert feature for this DimXpert extrude.
	IGetSubFeatures	Gets all of the sub-features of this DimXpert extrude.

[Top](#)

 See Also

[IDimXpertExtrudeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertExtrudeFeature Interface Members
[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertExtrudeFeature Interface

The following tables list the members exposed by [IDimXpertExtrudeFeature](#).

 Public Properties

Name	Description
 Blind	Gets whether the DimXpert extrude is blind or through all.

[Top](#)

 Public Methods

Name	Description
 GetBottomBlends	Gets the bottom blend DimXpert feature for this DimXpert extrude.
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert extrude.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert extrude.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert extrude.
 GetSubFeatures	Gets all of the sub-features of this DimXpert extrude.
 GetTopBlends	Gets the top blend DimXpert feature for this DimXpert extrude.
 IGetSubFeatures	Gets all of the sub-features of this DimXpert extrude.

[Top](#)

 See Also

[IDimXpertExtrudeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertExtrudeFeature Interface Properties
[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertExtrudeFeature Interface

For a list of all members of this type, see [IDimXpertExtrudeFeature members](#).

 Public Properties

Name	Description
 Blind	Gets whether the DimXpert extrude is blind or through all.

[Top](#)

 See Also

[IDimXpertExtrudeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

Blind Property (IDimXpertExtrudeFeature)
[See Also](#) [Example](#)

 

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : Blind Property (IDimXpertExtrudeFeature)

Gets whether the DimXpert extrude is blind or through all.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As System.Boolean  
  
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::Blind](#).

Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetBottomBlends Method (IDimXpertExtrudeFeature)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetBottomBlends Method (IDimXpertExtrudeFeature)

Gets the bottom blend DimXpert feature for this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

Function GetBottomBlends() As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As DimXpertFeature  
  
value = instance.GetBottomBlends()
```

C#

```
DimXpertFeature GetBottomBlends()
```

C++/CLI

DimXpertFeature^ GetBottomBlends();

Return Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetBottomBlends](#).

 Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

 Remarks

The bottom blend is typically an [IDimXpertFilletFeature](#).

 See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetBottomFeature Method (IDimXpertExtrudeFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetBottomFeature Method (IDimXpertExtrudeFeature)

Gets the bottom DimXpert feature for this DimXpert extrude.

 .NET Syntax

Visual Basic (Declaration)

Function GetBottomFeature() As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As DimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

DimXpertFeature GetBottomFeature()

C++/CLI

DimXpertFeature^ GetBottomFeature();

Return Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetBottomFeature](#).

 Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

Remarks

Only blind extrudes have bottom features. The bottom feature of a blind extrude is usually a [DimXpert plane feature](#).

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

GetReferenceFeature Method (IDimXpertExtrudeFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetReferenceFeature Method (IDimXpertExtrudeFeature)

Gets the reference DimXpert feature for this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferenceFeature() As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As DimXpertFeature  
  
value = instance.GetReferenceFeature()
```

C#

```
DimXpertFeature GetReferenceFeature()
```

C++/CLI

```
DimXpertFeature^ GetReferenceFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetReferenceFeature](#).

Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

Remarks

The reference feature is used to dimension the depth of a blind extrude. This method currently returns a plane feature but could return another feature type. Cast the object returned by this method to [IDimXpertPlaneFeature](#).

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetSubFeatureCount Method (IDimXpertExtrudeFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetSubFeatureCount Method (IDimXpertExtrudeFeature)

Gets the number of sub-features in this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As System.Integer  
  
value = instance.GetSubFeatureCount()
```

C#

```
System.int GetSubFeatureCount()
```

C++/CLI

```
System.int GetSubFeatureCount();
```

Return Value

Number of sub-features in this DimXpert extrude

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetSubFeatureCount](#).

Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)

[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

See Also

[IDimXpertExtrudeFeature Interface](#)

[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetSubFeatures Method (IDimXpertExtrudeFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetSubFeatures Method (IDimXpertExtrudeFeature)

Gets all of the sub-features of this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As System.Object
```

```
value = instance.GetSubFeatures()
```

C#

```
System.Object GetSubFeatures()
```

C++/CLI

```
System.Object^ GetSubFeatures();
```

Return Value

Array of [IDimXpertFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetSubFeatures](#).

Remarks

This method returns all sub-features of this extrude feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree.

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetTopBlends Method (IDimXpertExtrudeFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : GetTopBlends Method (IDimXpertExtrudeFeature)

Gets the top blend DimXpert feature for this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTopBlends() As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim value As DimXpertFeature
```

```
value = instance.GetTopBlends()
```

C#

```
DimXpertFeature GetTopBlends()
```

C++/CLI

```
DimXpertFeature^ GetTopBlends();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertExtrudeFeature::GetTopBlends](#).

Remarks

The top blend is typically an [IDimXpertFilletFeature](#).

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IGetSubFeatures Method (IDimXpertExtrudeFeature)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertExtrudeFeature Interface](#) : IGetSubFeatures Method (IDimXpertExtrudeFeature)

Gets all of the sub-features of this DimXpert extrude.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSubFeatures(  
    ByVal Count As System.Integer _  
) As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertExtrudeFeature  
Dim Count As System.Integer  
Dim value As DimXpertFeature  
  
value = instance.IGetSubFeatures(Count)
```

C#

```
DimXpertFeature IGetSubFeatures(  
    System.int Count  
)
```

C++/CLI

```
DimXpertFeature^ IGetSubFeatures(  
& System.int Count  
)
```

Parameters

Count

Number of sub-features of this DimXpert extrude feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [IDimXpertFeatures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Example

[Get DimXpert Extrude Feature Example \(VBA\)](#)
[Get DimXpert Extrude Feature Example \(VB.NET\)](#)

Remarks

This method returns all sub-features of this extrude feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree.

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertExtrudeFeature::GetSubFeatureCount](#) to get the value for the Count parameter.

See Also

[IDimXpertExtrudeFeature Interface](#)
[IDimXpertExtrudeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertFeature (Type)

SolidWorks.Interop.swdimxpert Namespace : IDimXpertFeature Interface

Allows you to access DimXpert features and sub-features on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

Public Interface IDimXpertFeature

Visual Basic (Usage)



Dim instance As [IDimXpertFeature](#)

C#

public interface IDimXpertFeature

C++/CLI

public interface class IDimXpertFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

This interface is the base class for several more specific DimXpert feature interfaces (see the **See Also** section below). Use the [IDimXpertFeature::Type](#) property to find out which specific feature interface is needed to acquire more information for a given DimXpert feature.

Note that some features, such as `swDimXpertFeatureType_e.swDimXpertFeature_Surface`, do not have more specific interfaces. Those particular features are completely defined by the IDimXpertFeature interface.

Accessors

[IAnnotation::GetDimXpertFeature](#)

[IDimXpertAngleBetweenDimTol::OriginFeature](#)

[IDimxpertAnnotation::Feature](#)

[IDimXpertBestfitPlaneFeature::GetSubFeatures](#) and [IDimXpertBestfitPlaneFeature::IGetSubFeatures](#)

[IDimXpertCompositeDistanceBetweenDimTol::GetFeature](#), [IDimXpertCompositeDistanceBetweenDimTol::GetIntraFeature](#), [IDimXpertCompositeDistanceBetweenDimTol::GetOriginFeature](#)

[IDimXpertCompoundClosedSlot3DFeature::GetBottomFeature](#) and [IDimXpertCompoundClosedSlot3DFeature::GetEndFeatures](#)

[IDimXpertCompoundHoleFeature::GetBottomFeature](#), [IDimXpertCompoundHoleFeature::GetReferenceFeature](#), [IDimXpertCompoundHoleFeature::GetSubFeatures](#), [IDimXpertCompoundHoleFeature::IGetSubFeatures](#)

[IDimXpertCompoundNotchFeature::GetBottomFeature](#), [IDimXpertCompoundNotchFeature::GetEndFeature](#), [IDimXpertCompoundNotchFeature::GetOpenSideReferenceFeature](#), [IDimXpertCompoundNotchFeature::GetTopReferenceFeature](#)

[IDimXpertCounterBoreDimTol::ReferenceFeature](#) property

[IDimXpertCounterSinkAngleDimTol::ReferenceFeature](#) property

[IDimXpertCounterSinkDiameterDimTol::ReferenceFeature](#) property

[IDimXpertDepthDimTol::ReferenceFeature](#) property

[IDimXpertDistanceBetweenDimTol::GetFeature](#) and [IDimXpertDistanceBetweenDimTol::GetOriginFeature](#)

[IDimXpertExtrudeFeature::GetBottomBlends](#), [IDimXpertExtrudeFeature::GetTopBlends](#), [IDimXpertExtrudeFeature::GetBottomFeature](#), [IDimXpertExtrudeFeature::GetReferenceFeature](#), [IDimXpertExtrudeFeature::GetSubFeatures](#), [IDimXpertExtrudeFeature::IGetSubFeatures](#)

[IDimXpertFeature::GetAppliedFeatures](#) and [IDimXpertFeature::IGetAppliedFeatures](#)

[IDimXpertIntersectPlaneFeature::GetFeatures](#)

[IDimXpertIntersectPointFeature::GetFeatures](#)

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::IGetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IDimXpertPatternFeature::GetSubFeatures](#) and [IDimXpertPatternFeature::IGetSubFeatures](#)

[IDimXpertTangencyTolerance::OriginFeature](#) property

[IFeature::GetSpecificFeature2](#)

 See Also

- [IDimXpertFeature](#) Members
- [SolidWorks.Interop.swdimxpert Namespace](#)
- [IDimXpertBestfitPlaneFeature](#) Interface
- [IDimXpertChamferFeature](#) Interface
- [IDimXpertCompoundClosedSlot3DFeature](#) Interface
- [IDimXpertCompoundHoleFeature](#) Interface
- [IDimXpertCompoundNotchFeature](#) Interface
- [IDimXpertCompoundWidthFeature](#) Interface
- [IDimXpertConeFeature](#) Interface
- [IDimXpertCylinderFeature](#) Interface
- [IDimXpertExtrudeFeature](#) Interface
- [IDimXpertFilletFeature](#) Interface
- [IDimXpertIntersectCircleFeature](#) Interface
- [IDimXpertIntersectLineFeature](#) Interface
- [IDimXpertIntersectPlaneFeature](#) Interface
- [IDimXpertIntersectPointFeature](#) Interface
- [IDimXpertPatternFeature](#) Interface
- [IDimXpertPlaneFeature](#) Interface
- [IDimXpertSphereFeature](#) Interface

IDimXpertFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFeature Interface

The following tables list the members exposed by [IDimXpertFeature](#).

 Public Properties

Name	Description
 Name	Gets the name of this DimXpert feature.
 Type	Gets the type of this DimXpert feature.

[Top](#)

 Public Methods

Name	Description
 GetAppliedAnnotationCount	Gets the number of annotations applied to this DimXpert feature.
 GetAppliedAnnotations	Gets all of the annotations applied to this DimXpert feature.
 GetAppliedFeatureCount	Gets the number of features that this DimXpert feature applies to.
 GetAppliedFeatures	Gets all of the features that this DimXpert feature applies to.
 GetFaceCount	Gets the number of SOLIDWORKS faces in this DimXpert feature.
 GetFaces	Gets the SOLIDWORKS faces in this DimXpert feature.
 GetModelFeature	Gets the SOLIDWORKS model feature corresponding to this DimXpert feature.
 IGetAppliedAnnotations	Gets all of the annotations applied to this DimXpert feature.
 IGetAppliedFeatures	Gets all of the features that this DimXpert feature applies to.
 IGetFaces	Gets the SOLIDWORKS faces in this DimXpert feature.
 IsCombinedAnnotation	Gets whether the pre-selected annotation is combined or not.
 IsSuppressed	Gets whether this DimXpert feature is suppressed from the view in the model.
 SetCombineAnnotation	Sets whether the pre-selected annotation is a combined annotation.

[Top](#)

See Also

[IDimXpertFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertChamferFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertConeFeature Interface](#)
[IDimXpertCylinderFeature Interface](#)
[IDimXpertExtrudeFeature Interface](#)
[IDimXpertFilletFeature Interface](#)
[IDimXpertIntersectCircleFeature Interface](#)
[IDimXpertIntersectLineFeature Interface](#)
[IDimXpertIntersectPlaneFeature Interface](#)
[IDimXpertIntersectPointFeature Interface](#)
[IDimXpertPatternFeature Interface](#)
[IDimXpertPlaneFeature Interface](#)
[IDimXpertSphereFeature Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertFeature Interface Methods

[See Also](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFeature Interface

For a list of all members of this type, see [IDimXpertFeature members](#).

Public Methods

Name	Description
 GetAppliedAnnotationCount	Gets the number of annotations applied to this DimXpert feature.
 GetAppliedAnnotations	Gets all of the annotations applied to this DimXpert feature.
 GetAppliedFeatureCount	Gets the number of features that this DimXpert feature applies to.
 GetAppliedFeatures	Gets all of the features that this DimXpert feature applies to.
 GetFaceCount	Gets the number of SOLIDWORKS faces in this DimXpert feature.
 GetFaces	Gets the SOLIDWORKS faces in this DimXpert feature.
 GetModelFeature	Gets the SOLIDWORKS model feature corresponding to this DimXpert feature.
 IGetAppliedAnnotations	Gets all of the annotations applied to this DimXpert feature.
 IGetAppliedFeatures	Gets all of the features that this DimXpert feature applies to.
 IGetFaces	Gets the SOLIDWORKS faces in this DimXpert feature.
 IsCombinedAnnotation	Gets whether the pre-selected annotation is combined or not.
 IsSuppressed	Gets whether this DimXpert feature is suppressed from the view in the model.
 SetCombineAnnotation	Sets whether the pre-selected annotation is a combined annotation.

[Top](#)

See Also

[IDimXpertFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertChamferFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertConeFeature Interface](#)
[IDimXpertCylinderFeature Interface](#)
[IDimXpertExtrudeFeature Interface](#)
[IDimXpertFilletFeature Interface](#)
[IDimXpertIntersectCircleFeature Interface](#)
[IDimXpertIntersectLineFeature Interface](#)
[IDimXpertIntersectPlaneFeature Interface](#)
[IDimXpertIntersectPointFeature Interface](#)
[IDimXpertPatternFeature Interface](#)
[IDimXpertPlaneFeature Interface](#)
[IDimXpertSphereFeature Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertFeature Interface Properties

[See Also](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFeature Interface

For a list of all members of this type, see [IDimXpertFeature members](#).

Public Properties

Name	Description
------	-------------

 Name	Gets the name of this DimXpert feature.
 Type	Gets the type of this DimXpert feature.

[Top](#)

See Also

[IDimXpertFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertChamferFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertConeFeature Interface](#)
[IDimXpertCylinderFeature Interface](#)
[IDimXpertExtrudeFeature Interface](#)
[IDimXpertFilletFeature Interface](#)
[IDimXpertIntersectCircleFeature Interface](#)
[IDimXpertIntersectLineFeature Interface](#)
[IDimXpertIntersectPlaneFeature Interface](#)
[IDimXpertIntersectPointFeature Interface](#)
[IDimXpertPatternFeature Interface](#)
[IDimXpertPlaneFeature Interface](#)
[IDimXpertSphereFeature Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetAppliedAnnotationCount Method (IDimXpertFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetAppliedAnnotationCount Method (IDimXpertFeature)

Gets the number of annotations applied to this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature
Dim value As System.Integer
```

```
value = instance.GetAppliedAnnotationCount()
```

C#

```
System.int GetAppliedAnnotationCount()
```

C++/CLI

```
System.int GetAppliedAnnotationCount();
```

Return Value

Number of annotations applied to this DimXpert feature

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetAppliedAnnotationCount](#)

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

GetAppliedAnnotations Method (IDimXpertFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetAppliedAnnotations Method (IDimXpertFeature)

Gets all of the annotations applied to this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature
Dim value As System.Object

value = instance.GetAppliedAnnotations()
```

C#

```
System.object GetAppliedAnnotations()
```

C++/CLI

```
System.Object^ GetAppliedAnnotations();
```

Return ValueArray of [IDimXpertAnnotations](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetAppliedAnnotations](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

GetAppliedFeatureCount Method (IDimXpertFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetAppliedFeatureCount Method (IDimXpertFeature)

Gets the number of features that this DimXpert feature applies to.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature
Dim value As System.Integer
```

```
value = instance.GetAppliedFeatureCount()
```

C#

```
System.int GetAppliedFeatureCount()
```

C++/CLI

```
System.int GetAppliedFeatureCount();
```

Return Value

Number of features that this feature applies to

 Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetAppliedFeatureCount](#).

 Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

 Remarks

Applied features of a DimXpertFeature are its many parents in the feature tree of the DimXpertManager tab of the Management Panel. A single DimXpertFeature can have many applied features.

 See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetAppliedFeatures Method (IDimXpertFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetAppliedFeatures Method (IDimXpertFeature)

Gets all of the features that this DimXpert feature applies to.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedFeatures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Object  
  
value = instance.GetAppliedFeatures()
```

C#

```
System.object GetAppliedFeatures()
```

C++/CLI

```
System.Object^ GetAppliedFeatures();
```

Return Value

Array of [IDimXpertFeatures](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetAppliedFeatures](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

Remarks

Applied features of a DimXpertFeature are its many parents in the feature tree of the DimXpertManager tab of the Management Panel. A single DimXpertFeature can have many applied features.

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetFaceCount Method (IDimXpertFeature)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetFaceCount Method (IDimXpertFeature)

Gets the number of SOLIDWORKS faces in this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Integer  
  
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

Return Value

Number of SOLIDWORKS faces in this feature

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetFaceCount](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

GetFaces Method (IDimXpertFeature)[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetFaces Method (IDimXpertFeature)

Gets the SOLIDWORKS faces in this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Object  
  
value = instance.GetFaces()
```

C#

```
System.Object GetFaces()
```

C++/CLI

```
System.Object^ GetFaces();
```

Return ValueArray of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetFaces](#).

See Also

[IDimXpertFeature Interface](#)[IDimXpertFeature Members](#)

Availability

GetModelFeature Method (IDimXpertFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : GetModelFeature Method (IDimXpertFeature)

Gets the SOLIDWORKS model feature corresponding to this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Object  
  
value = instance.GetModelFeature()
```

C#

```
System.object GetModelFeature()
```

C++/CLI

```
System.Object^ GetModelFeature();
```

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::GetModelFeature](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IGetAppliedAnnotations Method (IDimXpertFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : IGetAppliedAnnotations Method (IDimXpertFeature)

Gets all of the annotations applied to this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAppliedAnnotations( _  
    ByVal Count As System.Integer _  
) As DimXpertAnnotation
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim Count As System.Integer  
Dim value As DimXpertAnnotation  
  
value = instance.IGetAppliedAnnotations(Count)
```

C#

```
DimXpertAnnotation IGetAppliedAnnotations(  
    System.int Count  
)
```

C++/CLI

```
DimXpertAnnotation^ IGetAppliedAnnotations(  
&    System.int Count  
)
```

Parameters

Count

Number of annotations applied to this DimXpert feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [IDimXpertAnnotation](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertFeature::GetAppliedAnnotationCount](#) to get the value for the Count parameter.

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IGetAppliedFeatures Method (IDimXpertFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : IGetAppliedFeatures Method (IDimXpertFeature)

Gets all of the features that this DimXpert feature applies to.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAppliedFeatures( _
    ByVal Count As System.Integer _
) As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature
Dim Count As System.Integer
Dim value As DimXpertFeature

value = instance.IGetAppliedFeatures(Count)
```

C#

```
DimXpertFeature IGetAppliedFeatures(
    System.int Count
)
```

C++/CLI

```
DimXpertFeature^ IGetAppliedFeatures(
    & System.int Count
)
```

Parameters

Count

Number of parent features in the DimXpertManager tree that this feature applies to

Return Value

- in-process, unmanaged C++: Pointer to an array of [IDimXpertFeature](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Applied features of a DimXpertFeature are its many parents in the feature tree of the DimXpertManager tab of the Management Panel. A single DimXpertFeature can have many applied features.

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertFeature::GetAppliedFeatureCount](#) to get the value for the Count parameter.

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IGetFaces Method (IDimXpertFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : IGetFaces Method (IDimXpertFeature)

Gets the SOLIDWORKS faces in this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetFaces(Count)
```

C#

```
System.object IGetFaces(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetFaces(  
& System.int Count  
)
```

Parameters

Count

Number of faces on this DimXpert feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertFeature::GetFaceCount](#) to get the value for the Count parameter.

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IsCombinedAnnotation Method (IDimXpertFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : IsCombinedAnnotation Method (IDimXpertFeature)

Gets whether the pre-selected annotation is combined or not.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCombinedAnnotation() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Boolean  
  
value = instance.IsCombinedAnnotation()
```

C#

```
System.bool IsCombinedAnnotation()
```

C++/CLI

```
System.bool IsCombinedAnnotation();
```

Return Value

True if combined, false if not

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::IsCombinedAnnotation](#).

Remarks

A combined annotation shares a leader in the user interface.

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)
[IDimXpertFeature::SetCombineAnnotation Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IsSuppressed Method (IDimXpertFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : IsSuppressed Method (IDimXpertFeature)

Gets whether this DimXpert feature is suppressed from the view in the model.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSuppressed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.Boolean  
  
value = instance.IsSuppressed()
```

C#

```
System.bool IsSuppressed()
```

C++/CLI

```
System.bool IsSuppressed();
```

Return Value

True if suppressed; false otherwise



Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::IsSuppressed](#).



Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)



See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)



Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Name Property (IDimXpertFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : Name Property (IDimXpertFeature)

Gets the name of this DimXpert feature.



.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

Property Value

Name of DimXpert feature



Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::Name](#).

Example

[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

SetCombineAnnotation Method (IDimXpertFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : SetCombineAnnotation Method (IDimXpertFeature)

Sets whether the pre-selected annotation is a combined annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCombineAnnotation( _  
    ByVal Combine As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature  
Dim Combine As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetCombineAnnotation(Combine)
```

C#

```
System.int SetCombineAnnotation(  
    System.bool Combine  
)
```

C++/CLI

```
System.int SetCombineAnnotation(  
& System.bool Combine  
)
```

Parameters

Combine

True to combine the annotation, false to not

Return Value

Result code as defined in [swDimXpertCombineAnnotation_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::SetCombineAnnotation](#).

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)
[IDimXpertFeature::IsCombinedAnnotation Method \(\)](#)

Availability

Type Property (IDimXpertFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFeature Interface](#) : Type Property (IDimXpertFeature)

Gets the type of this DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Type As [swDimXpertFeatureType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertFeature
Dim value As swDimXpertFeatureType\_e

value = instance.Type
```

C#

```
swDimXpertFeatureType\_e Type {get;}
```

C++/CLI

```
property swDimXpertFeatureType\_e Type {
    swDimXpertFeatureType\_e get();
}
```

Property ValueType of this DimXpert feature as defined in [swDimXpertFeatureType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertFeature::Type](#).

Example

[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

See Also

[IDimXpertFeature Interface](#)
[IDimXpertFeature Members](#)

Availability

IDimXpertFilletFeature (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertFilletFeature Interface

Allows you to access specific information about DimXpert fillets on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertFilletFeature

Visual Basic (Usage)

 Copy Code

Dim instance As [IDimXpertFilletFeature](#)

C#

public interface IDimXpertFilletFeature

C++/CLI

public interface class IDimXpertFilletFeature

 Visual Basic for Applications (VBA) Syntax

See [DimXpertFilletFeature](#).

 Example

- [Get DimXpert Feature Example \(VBA\)](#)
- [Get DimXpert Feature Example \(VB.NET\)](#)
- [Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

 Accessors

- [IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)
- [IDimXpertPart::GetFeature](#)
- [IFeature::GetSpecificFeature2](#)

 See Also

- [IDimXpertFilletFeature Members](#)
- [SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertFilletFeature Interface

The following tables list the members exposed by [IDimXpertFilletFeature](#).

 Public Properties

Name	Description
 Inner	Gets whether this DimXpert fillet is for a hole or a pin.
 Radius	Gets the radius of this DimXpert fillet.

[Top](#)

 See Also

[IDimXpertFilletFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help
IDimXpertFilletFeature Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFilletFeature Interface

For a list of all members of this type, see [IDimXpertFilletFeature members](#).

 Public Properties

Name	Description
 Inner	Gets whether this DimXpert fillet is for a hole or a pin.
 Radius	Gets the radius of this DimXpert fillet.

[Top](#)

 See Also

[IDimXpertFilletFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help
Inner Property (IDimXpertFilletFeature)
[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFilletFeature Interface](#) : Inner Property (IDimXpertFilletFeature)

Gets whether this DimXpert fillet is for a hole or a pin.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property Inner As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertFilletFeature  
Dim value As System.Boolean  
  
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if fillet is for a hole; false if for a pin

 Visual Basic for Applications (VBA) Syntax

See [DimXpertFilletFeature::Inner](#).

 See Also

[IDimXpertFilletFeature Interface](#)
[IDimXpertFilletFeature Members](#)

 Availability

Radius Property (IDimXpertFilletFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFilletFeature Interface](#) : Radius Property (IDimXpertFilletFeature)

Gets the radius of this DimXpert fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Radius As System.Double

Visual Basic (Usage)

Dim instance As [IDimXpertFilletFeature](#)

Dim value As System.Double

value = instance.Radius

C#

System.double Radius {get;}

C++/CLI

```
property System.double Radius {  
    System.double get();  
}
```

Property Value

Radius of the fillet

Visual Basic for Applications (VBA) Syntax

See [DimXpertFilletFeature::Radius](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertFilletFeature Interface](#)[IDimXpertFilletFeature Members](#)

Availability

IDimXpertFlatnessTolerance (Type)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFlatnessTolerance Interface

Allows you to access DimXpert flatness tolerances on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertFlatnessTolerance

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertFlatnessTolerance](#)

C#

public interface IDimXpertFlatnessTolerance

C++/CLI

public interface class IDimXpertFlatnessTolerance

 Visual Basic for Applications (VBA) Syntax

See [DimXpertFlatnessTolerance](#).

 Example

[Get DimXpert Tolerance1 Example \(VBA\)](#)
[Get DimXpert Tolerance1 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general geometric tolerance information using [IDimXpertTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertFlatnessTolerance Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertFlatnessTolerance Interface

The following tables list the members exposed by [IDimXpertFlatnessTolerance](#).

 Public Methods

Name	Description
------	-------------

 GetPerUnitArea	Gets the per unit area for this flatness tolerance.
---	---

[Top](#)

See Also

[IDimXpertFlatnessTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertFlatnessTolerance Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertFlatnessTolerance Interface](#)

For a list of all members of this type, see [IDimXpertFlatnessTolerance members](#).

Public Methods

Name	Description
 GetPerUnitArea	Gets the per unit area for this flatness tolerance.

[Top](#)

See Also

[IDimXpertFlatnessTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetPerUnitArea Method (IDimXpertFlatnessTolerance)

[See Also](#) [Example](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertFlatnessTolerance Interface](#) : [GetPerUnitArea Method \(IDimXpertFlatnessTolerance\)](#)

Gets the per unit area for this flatness tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPerUnitArea( _
    ByRef Enabled As System.Boolean, _
    ByRef Length As System.Double, _
    ByRef Width As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As IDimXpertFlatnessTolerance
Dim Enabled As System.Boolean
Dim Length As System.Double
Dim Width As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetPerUnitArea(Enabled, Length, Width, I, J, K)
```

C#

```
System.bool GetPerUnitArea(
    out System.bool Enabled,
    out System.double Length,
    out System.double Width,
    out System.double I,
    out System.double J,
    out System.double K
)
```

```
System.bool GetPerUnitArea(  
& [Out] System.bool Enabled,  
& [Out] System.double Length,  
& [Out] System.double Width,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

Enabled

True if enabled; false otherwise

Length

Length of the area

Width

Width of the area

I

I component of the unit vector

J

J component of the unit vector

K

K component of the unit vector

Return Value

True if the method call was successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertFlatnessTolerance::GetPerUnitArea](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)

[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertFlatnessTolerance Interface](#)

[IDimXpertFlatnessTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertGtol (Type)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertGtol Interface

Allows you to access a DimXpert Gtol annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertGtol

Visual Basic (Usage) Copy Code

Dim instance As [IDimXpertGtol](#)

C#

public interface IDimXpertGtol

C++/CLI

public interface class IDimXpertGtol

Visual Basic for Applications (VBA) Syntax

See [DimXpertGtol](#).

Remarks

[IDimXpertAnnotation](#) is the parent class of IDimXpertGtol. To access an existing Gtol, call:

- [IDimXpertAnnotation::GetDisplayEntity](#) to get the SOLIDWORKS annotation object.
- [IAnnotation::GetSpecificAnnotation](#) to get the Gtol object.

Accessors

[IDimXpertPart::InsertGtol](#)

See Also

[IDimXpertGtol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertGtol Interface

The following tables list the members exposed by [IDimXpertGtol](#).

Public Properties

Name	Description
Annotation	Gets this Gtol's annotation.

[Top](#)

See Also

[IDimXpertGtol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)



SolidWorks.Interop.swdimxpert Namespace : IDimXpertGtol Interface

For a list of all members of this type, see [IDimXpertGtol members](#).



Public Properties

Name	Description
 Annotation	Gets this Gtol's annotation.

[Top](#)



See Also

[IDimXpertGtol Interface](#)

[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Annotation Property (IDimXpertGtol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertGtol Interface](#) : Annotation Property (IDimXpertGtol)

Gets this Gtol's annotation.



NET Syntax

Visual Basic (Declaration)

ReadOnly Property Annotation As System.Object

Visual Basic (Usage)



```
Dim instance As IDimXpertGtol  
Dim value As System.Object
```

```
value = instance.Annotation
```

C#

```
System.Object Annotation {get;}
```

C++/CLI

```
property System.Object^ Annotation {  
    System.Object^ get();  
}
```

Property Value

[IDimXpertAnnotation](#)



Visual Basic for Applications (VBA) Syntax

See [DimXpertGtol::Annotation](#).



See Also

[IDimXpertGtol Interface](#)

[IDimXpertGtol Members](#)



Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IDimXpertIntersectCircleFeature (Type)

SOLIDWORKS DimXpert API Help Send comments on this topic.

IDimXpertIntersectCircleFeature Interface

See Also [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertIntersectCircleFeature Interface

Allows you to access specific information about DimXpert intersect circles on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertIntersectCircleFeature

Visual Basic (Usage)



Dim instance As [IDimXpertIntersectCircleFeature](#)

C#

public interface IDimXpertIntersectCircleFeature

C++/CLI

public interface class IDimXpertIntersectCircleFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectCircleFeature](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertIntersectCircleFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help Send comments on this topic.

IDimXpertIntersectCircleFeature Interface Methods

See Also

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertIntersectCircleFeature Interface

For a list of all members of this type, see [IDimXpertIntersectCircleFeature members](#).

Public Methods

Name	Description
 GetIntersectFeature	Gets the DimXpert feature that intersects this DimXpert intersect circle.
 GetNominalCircle	Gets the coordinates and vector for this DimXpert intersect circle.
 GetPlaneFeature	Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.

[Top](#)

 See Also

[IDimXpertIntersectCircleFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertIntersectCircleFeature Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectCircleFeature Interface

The following tables list the members exposed by [IDimXpertIntersectCircleFeature](#).

 Public Methods

Name	Description
 GetIntersectFeature	Gets the DimXpert feature that intersects this DimXpert intersect circle.
 GetNominalCircle	Gets the coordinates and vector for this DimXpert intersect circle.
 GetPlaneFeature	Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.

[Top](#)

 See Also

[IDimXpertIntersectCircleFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetIntersectFeature Method (IDimXpertIntersectCircleFeature)

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectCircleFeature Interface](#) : GetIntersectFeature Method (IDimXpertIntersectCircleFeature)

Gets the DimXpert feature that intersects this DimXpert intersect circle.

 .NET Syntax

Visual Basic (Declaration)

Function GetIntersectFeature(_
 ByRef [Feature](#) As DimXpertFeature _
) As System.Boolean

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertIntersectCircleFeature](#)
Dim Feature As DimXpertFeature
Dim value As System.Boolean

value = instance.GetIntersectFeature(Feature)

C#

System.bool GetIntersectFeature(
 out DimXpertFeature [Feature](#)
)

C++/CLI

System.bool GetIntersectFeature(
& [Out] DimXpertFeature^ [Feature](#)
)

Parameters

Feature
[IDimXpertFeature](#)

Return Value

True if the method call is successful; false otherwise

See Also

[IDimXpertIntersectCircleFeature Interface](#)
[IDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalCircle Method (IDimXpertIntersectCircleFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectCircleFeature Interface](#) : GetNominalCircle Method (IDimXpertIntersectCircleFeature)

Gets the coordinates and vector for this DimXpert intersect circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCircle( _  
    ByRef R As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectCircleFeature  
Dim R As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalCircle(R, X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalCircle(  
    out System.double R,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalCircle(  
& [Out] System.double R,  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

R
Radius of the intersect circle
X
X-coordinate of the origin of the intersect circle
Y
Y-coordinate of the origin of the intersect circle
Z
Z-coordinate of the origin of the intersect circle
I
I component of the direction vector of the intersect circle
J
J component of the direction vector of the intersect circle
K
K component of the direction vector of the intersect circle

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectCircleFeature::GetNominalCircle](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)

Remarks

The i, j, and k vector components indicate the pierce direction of a feature. For example, if a feature is sketched on the front x-y plane, its pierce vector is (0, 0, 1).

See Also

[IDimXpertIntersectCircleFeature Interface](#)
[IDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetPlaneFeature Method (IDimXpertIntersectCircleFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectCircleFeature Interface](#) : GetPlaneFeature Method (IDimXpertIntersectCircleFeature)

Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeature(  
    ByRef Plane As DimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectCircleFeature  
Dim Plane As DimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeature(Plane)
```

C#

```
System.bool GetPlaneFeature(  
    out DimXpertPlaneFeature Plane  
)
```

C++/CLI

```
System.bool GetPlaneFeature(  
& [Out] DimXpertPlaneFeature^ Plane
```

)

Parameters

Plane

[IDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectCircleFeature::GetPlaneFeature](#).

See Also

[IDimXpertIntersectCircleFeature Interface](#)

[IDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertIntersectLineFeature (Type)

IDimXpertIntersectLineFeature Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectLineFeature Interface

Allows you to access specific information about DimXpert intersect lines on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertIntersectLineFeature

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertIntersectLineFeature](#)

C#

public interface IDimXpertIntersectLineFeature

C++/CLI

public interface class IDimXpertIntersectLineFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectLineFeature](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertIntersectLineFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertIntersectLineFeature Interface Methods
[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectLineFeature Interface

For a list of all members of this type, see [IDimXpertIntersectLineFeature members](#).

Public Methods

Name	Description
 GetNominalLine	Gets the coordinates and vector for this DimXpert intersect line.
 GetPlaneFeatures	Gets the DimXpert plane features that intersect on this DimXpert intersect line.

[Top](#)

See Also

[IDimXpertIntersectLineFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertIntersectLineFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectLineFeature Interface

The following tables list the members exposed by [IDimXpertIntersectLineFeature](#).

Public Methods

Name	Description
 GetNominalLine	Gets the coordinates and vector for this DimXpert intersect line.
 GetPlaneFeatures	Gets the DimXpert plane features that intersect on this DimXpert intersect line.

[Top](#)

See Also

[IDimXpertIntersectLineFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalLine Method (IDimXpertIntersectLineFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectLineFeature Interface](#) : GetNominalLine Method (IDimXpertIntersectLineFeature)

Gets the coordinates and vector for this DimXpert intersect line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalLine( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectLineFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalLine(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalLine(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalLine(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)
```

Parameters

X
X-coordinate of the intersect line
Y
Y-coordinate of the intersect line
Z
Z-coordinate of the intersect line
I
I component of the direction vector of the intersect line
J
J component of the direction vector of the intersect line
K
K component of the direction vector of the intersect line

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectLineFeature::GetNominalLine](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)

See Also

[IDimXpertIntersectLineFeature Interface](#)
[IDimXpertIntersectLineFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (IDimXpertIntersectLineFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectLineFeature Interface](#) : GetPlaneFeatures Method (IDimXpertIntersectLineFeature)

Gets the DimXpert plane features that intersect on this DimXpert intersect line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _
    ByRef Plane1 As DimXpertPlaneFeature, _
    ByRef Plane2 As DimXpertPlaneFeature _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectLineFeature
Dim Plane1 As DimXpertPlaneFeature
Dim Plane2 As DimXpertPlaneFeature
Dim value As System.Boolean

value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out DimXpertPlaneFeature Plane1,  
    out DimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] DimXpertPlaneFeature^ Plane1,  
& [Out] DimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[IDimXpertPlaneFeature](#)
Plane2
[IDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectLineFeature::GetPlaneFeatures](#).

See Also

[IDimXpertIntersectLineFeature Interface](#)
[IDimXpertIntersectLineFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertIntersectPlaneFeature (Type)

IDimXpertIntersectPlaneFeature Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectPlaneFeature Interface

Allows you to access specific information about DimXpert intersect planes on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

Public Interface IDimXpertIntersectPlaneFeature

Visual Basic (Usage)



Dim instance As [IDimXpertIntersectPlaneFeature](#)

C#

public interface IDimXpertIntersectPlaneFeature

C++/CLI

public interface class IDimXpertIntersectPlaneFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectPlaneFeature](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertIntersectPlaneFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertIntersectPlaneFeature Interface Members
[See Also](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectPlaneFeature Interface

The following tables list the members exposed by [IDimXpertIntersectPlaneFeature](#).

Public Methods

Name	Description
GetFeatures	Gets the DimXpert features that intersect on this DimXpert intersect plane.
GetNominalPlane	Gets the coordinates and vector for this DimXpert intersect plane.

[Top](#)

See Also

[IDimXpertIntersectPlaneFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IDimXpertIntersectPlaneFeature Interface Methods

[See Also](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertIntersectPlaneFeature Interface

For a list of all members of this type, see [IDimXpertIntersectPlaneFeature members](#).

Public Methods

Name	Description
 GetFeatures	Gets the DimXpert features that intersect on this DimXpert intersect plane.
 GetNominalPlane	Gets the coordinates and vector for this DimXpert intersect plane.

[Top](#)

See Also

[IDimXpertIntersectPlaneFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

GetFeatures Method (IDimXpertIntersectPlaneFeature)

[See Also](#) [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectPlaneFeature Interface](#) : GetFeatures Method (IDimXpertIntersectPlaneFeature)
Gets the DimXpert features that intersect on this DimXpert intersect plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatures(  
    ByRef Feature1 As DimXpertFeature, _  
    ByRef Feature2 As DimXpertFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectPlaneFeature  
Dim Feature1 As DimXpertFeature  
Dim Feature2 As DimXpertFeature  
Dim value As System.Boolean  
  
value = instance.GetFeatures(Feature1, Feature2)
```

C#

```
System.bool GetFeatures(  
    out DimXpertFeature Feature1,  
    out DimXpertFeature Feature2  
)
```

C++/CLI

```
System.bool GetFeatures(  
& [Out] DimXpertFeature^ Feature1,  
& [Out] DimXpertFeature^ Feature2  
)
```

Parameters

Feature1
[IDimXpertFeature](#)
Feature2
[IDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectPlaneFeature::GetFeatures](#).

Example

[Get DimXpert Intersect Features Example \(VBA\)](#)
[Get DimXpert Intersect Features Example \(VB.NET\)](#)

See Also

[IDimXpertIntersectPlaneFeature Interface](#)
[IDimXpertIntersectPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalPlane Method (IDimXpertIntersectPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertIntersectPlaneFeature Interface](#) : GetNominalPlane Method (IDimXpertIntersectPlaneFeature)

Gets the coordinates and vector for this DimXpert intersect plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertIntersectPlaneFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,
```

```
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X
X-coordinate of the intersect plane
Y
Y-coordinate of the intersect plane
Z
Z-coordinate of the intersect plane
I
I component of the direction vector of the intersect plane
J
J component of the direction vector of the intersect plane
K
K component of the direction vector of the intersect plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertIntersectPlaneFeature::GetNominalPlane](#).

See Also

[IDimXpertIntersectPlaneFeature Interface](#)
[IDimXpertIntersectPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0