

SOLIDWORKS DimXpert API (VB6 COM) — Reference (2/3): DimXpertDimensionTolerance- swDimXpertDimensionPositionOption_e

SOLIDWORKS API Documentation (converted from CHM)

DimXpertDimensionTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertDimensionTolerance Object

 Object Model

DimXpertDimensionTolerance

SOLIDWORKS DimXpert Type Library
DimXpertDimensionTolerance Object Members

 Public Methods

-  [GetNominalValue](#)
-  [GetPlusAndMinusTolerance](#)
-  [GetUpperAndLowerLimit](#)

 Public Properties

-  [BlockToleranceDecimalPlaces](#)
-  [DimensionType](#)
-  [LimitsAndFitsCode](#)

SOLIDWORKS DimXpert Type Library
BlockToleranceDecimalPlaces Property (DimXpertDimensionTolerance)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property BlockToleranceDecimalPlaces As Long
```

SOLIDWORKS DimXpert Type Library
DimensionType Property (DimXpertDimensionTolerance)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property DimensionType As swDimXpertDimensionToleranceType\_e
```

SOLIDWORKS DimXpert Type Library
GetNominalValue Method (DimXpertDimensionTolerance)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalValue() As Double
```

SOLIDWORKS DimXpert Type Library
GetPlusAndMinusTolerance Method (DimXpertDimensionTolerance)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlusAndMinusTolerance( _  
    ByRef Plus As Double, _  
    ByRef Minus As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

GetUpperAndLowerLimit Method (DimXpertDimensionTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUpperAndLowerLimit( _  
    ByRef Upper As Double, _  
    ByRef Lower As Double _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library

LimitsAndFitsCode Property (DimXpertDimensionTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Property LimitsAndFitsCode As String
```

DimXpertDistanceBetweenDimTol (Type)

SOLIDWORKS DimXpert Type Library

DimXpertDistanceBetweenDimTol Object

Object Model

DimXpertDistanceBetweenDimTol

SOLIDWORKS DimXpert Type Library

DimXpertDistanceBetweenDimTol Object Members

Public Methods

GetDirectionVector

GetFeature

GetOriginFeature

Public Properties

PatternTreatment

SOLIDWORKS DimXpert Type Library

GetDirectionVector Method (DimXpertDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDirectionVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library

GetFeature Method (DimXpertDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature( _  
    ByRef Feature As DimXpertFeature, _  
    ByRef FosUsage As swDimXpertDistanceFosUsage_e _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library

GetOriginFeature Method (DimXpertDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOriginFeature( _  
    ByRef Feature As DimXpertFeature, _  
    ByRef FosUsage As swDimXpertDistanceFosUsage_e _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library

PatternTreatment Property (DimXpertDistanceBetweenDimTol)

Syntax


Visual Basic for Applications (VBA)

Public Property PatternTreatment As [swDimXpertPatternTreatmentType_e](#)

DimXpertExtrudeFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertExtrudeFeature Object

Object Model



SOLIDWORKS DimXpert Type Library
DimXpertExtrudeFeature Object Members

Public Methods

	GetBottomBlends
	GetBottomFeature
	GetReferenceFeature
	GetSubFeatureCount
	GetSubFeatures
	GetTopBlends
	IGetSubFeatures

Public Properties

	Blind
---	-----------------------

SOLIDWORKS DimXpert Type Library
Blind Property (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)
Public Property Blind As Boolean

SOLIDWORKS DimXpert Type Library
GetBottomBlends Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)
Public Function GetBottomBlends() As DimXpertFeature

SOLIDWORKS DimXpert Type Library
GetBottomFeature Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBottomFeature() As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

GetReferenceFeature Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReferenceFeature() As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

GetSubFeatureCount Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatureCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetSubFeatures Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatures() As Variant
```

SOLIDWORKS DimXpert Type Library

GetTopBlends Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTopBlends() As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

IGetSubFeatures Method (DimXpertExtrudeFeature)

Syntax

Visual Basic for Applications (VBA)


```
Public Function IGetSubFeatures( _  
    ByVal Count As Long _  
) As DimXpertFeature
```

DimXpertFeature (Type)

SOLIDWORKS DimXpert Type Library

DimXpertFeature Object

Object Model



SOLIDWORKS DimXpert Type Library

DimXpertFeature Object Members

Public Methods

	GetAppliedAnnotationCount
	GetAppliedAnnotations
	GetAppliedFeatureCount
	GetAppliedFeatures
	GetFaceCount
	GetFaces
	GetModelFeature
	IGetAppliedAnnotations
	IGetAppliedFeatures
	IGetFaces
	IsCombinedAnnotation
	IsSuppressed
	SetCombineAnnotation

Public Properties

	Name
	Type

SOLIDWORKS DimXpert Type Library

GetAppliedAnnotationCount Method (DimXpertFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetAppliedAnnotationCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetAppliedAnnotations Method (DimXpertFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetAppliedAnnotations() As Variant
```

SOLIDWORKS DimXpert Type Library

GetAppliedFeatureCount Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function GetAppliedFeatureCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetAppliedFeatures Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function GetAppliedFeatures() As Variant
```

SOLIDWORKS DimXpert Type Library

GetFaceCount Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function GetFaceCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetFaces Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function GetFaces() As Variant
```

SOLIDWORKS DimXpert Type Library

GetModelFeature Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function GetModelFeature() As Object
```

SOLIDWORKS DimXpert Type Library

IGetAppliedAnnotations Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function IGetAppliedAnnotations( _  
    ByVal Count As Long _  
) As DimXpertAnnotation
```

SOLIDWORKS DimXpert Type Library

IGetAppliedFeatures Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function IGetAppliedFeatures( _  
    ByVal Count As Long _  
) As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

IGetFaces Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function IGetFaces( _  
    ByVal Count As Long _
```

) As Object

SOLIDWORKS DimXpert Type Library

IsCombinedAnnotation Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function IsCombinedAnnotation() As Boolean
```

SOLIDWORKS DimXpert Type Library

IsSuppressed Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function IsSuppressed() As Boolean
```

SOLIDWORKS DimXpert Type Library

Name Property (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Property Name As String
```

SOLIDWORKS DimXpert Type Library

SetCombineAnnotation Method (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Function SetCombineAnnotation( _  
    ByVal Combine As Boolean _  
) As Long
```

SOLIDWORKS DimXpert Type Library

Type Property (DimXpertFeature)



Visual Basic for Applications (VBA)

```
Public Property Type As swDimXpertFeatureType\_e
```

DimXpertFilletFeature (Type)

SOLIDWORKS DimXpert Type Library

DimXpertFilletFeature Object

Object Model

DimXpertFilletFeature

SOLIDWORKS DimXpert Type Library

DimXpertFilletFeature Object Members

Public Properties

Inner

Radius

SOLIDWORKS DimXpert Type Library

Inner Property (DimXpertFilletFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Inner As Boolean

SOLIDWORKS DimXpert Type Library

Radius Property (DimXpertFilletFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Radius As Double

DimXpertFlatnessTolerance (Type)

SOLIDWORKS DimXpert Type Library

DimXpertFlatnessTolerance Object

Object Model

DimXpertFlatnessTolerance

SOLIDWORKS DimXpert Type Library

DimXpertFlatnessTolerance Object Members

Public Methods

 [GetPerUnitArea](#)

SOLIDWORKS DimXpert Type Library

GetPerUnitArea Method (DimXpertFlatnessTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPerUnitArea( _  
    ByRef Enabled As Boolean, _  
    ByRef Length As Double, _  
    ByRef Width As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

DimXpertGtol (Type)

SOLIDWORKS DimXpert Type Library

DimXpertGtol Object

Object Model

DimXpertGtol

SOLIDWORKS DimXpert Type Library

DimXpertGtol Object Members



Public Properties

 [Annotation](#)

SOLIDWORKS DimXpert Type Library

Annotation Property (DimXpertGtol)

Syntax

Visual Basic for Applications (VBA)

Public Property Annotation As Object

DimXpertIntersectCircleFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertIntersectCircleFeature Object

 Object Model

DimXpertIntersectCircleFeature

SOLIDWORKS DimXpert Type Library
DimXpertIntersectCircleFeature Object Members

 Public Methods

-  [GetIntersectFeature](#)
-  [GetNominalCircle](#)
-  [GetPlaneFeature](#)

SOLIDWORKS DimXpert Type Library
GetIntersectFeature Method (DimXpertIntersectCircleFeature)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetIntersectFeature( _
    ByRef Feature As DimXpertFeature _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetNominalCircle Method (DimXpertIntersectCircleFeature)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetNominalCircle( _
    ByRef R As Double, _
    ByRef X As Double, _
    ByRef Y As Double, _
    ByRef Z As Double, _
    ByRef I As Double, _
    ByRef J As Double, _
    ByRef K As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetPlaneFeature Method (DimXpertIntersectCircleFeature)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetPlaneFeature( _
    ByRef Plane As DimXpertPlaneFeature _
) As Boolean
```

DimXpertIntersectLineFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertIntersectLineFeature Object

 Object Model

DimXpertIntersectLineFeature

SOLIDWORKS DimXpert Type Library
DimXpertIntersectLineFeature Object Members

 Public Methods

-  [GetNominalLine](#)
-  [GetPlaneFeatures](#)

SOLIDWORKS DimXpert Type Library
GetNominalLine Method (DimXpertIntersectLineFeature)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalLine( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetPlaneFeatures Method (DimXpertIntersectLineFeature)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlaneFeatures( _  
    ByRef Plane1 As DimXpertPlaneFeature, _  
    ByRef Plane2 As DimXpertPlaneFeature _  
    ) As Boolean
```

DimXpertIntersectPlaneFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertIntersectPlaneFeature Object

 Object Model

DimXpertIntersectPlaneFeature

SOLIDWORKS DimXpert Type Library
DimXpertIntersectPlaneFeature Object Members

 Public Methods

-  [GetFeatures](#)
-  [GetNominalPlane](#)

SOLIDWORKS DimXpert Type Library
GetFeatures Method (DimXpertIntersectPlaneFeature)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatures( _  
    ByRef Feature1 As DimXpertFeature, _  
    ByRef Feature2 As DimXpertFeature _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetNominalPlane Method (DimXpertIntersectPlaneFeature)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```


DimXpertIntersectPointFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertIntersectPointFeature Object

Object Model

DimXpertIntersectPointFeature

SOLIDWORKS DimXpert Type Library
DimXpertIntersectPointFeature Object Members

Public Methods

- [GetFeatures](#)
- [GetNominalPoint](#)
- [GetNominalVector](#)

SOLIDWORKS DimXpert Type Library
GetFeatures Method (DimXpertIntersectPointFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatures( _  
    ByRef Feature1 As DimXpertFeature, _  
    ByRef Feature2 As DimXpertFeature _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetNominalPoint Method (DimXpertIntersectPointFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalPoint( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetNominalVector Method (DimXpertIntersectPointFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

DimXpertLineProfileTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertLineProfileTolerance Object

Object Model

DimXpertLineProfileTolerance

SOLIDWORKS DimXpert Type Library
DimXpertLineProfileTolerance Object Members

Public Methods

 [GetPlanarZoneVector](#)

Public Properties

 [OuterToleranceValue](#)

SOLIDWORKS DimXpert Type Library
GetPlanarZoneVector Method (DimXpertLineProfileTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlanarZoneVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library
OuterToleranceValue Property (DimXpertLineProfileTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OuterToleranceValue As Double
```

DimXpertOrientationTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertOrientationTolerance Object

 Object Model

DimXpertOrientationTolerance

SOLIDWORKS DimXpert Type Library
DimXpertOrientationTolerance Object Members

 Public Methods

 GetMaxTolerance
 GetPlanarZoneVector
 GetProjectedZone
 IsTangentPlane

 Public Properties

 Modifier
 ZoneType

SOLIDWORKS DimXpert Type Library
GetMaxTolerance Method (DimXpertOrientationTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetMaxTolerance( _
    ByRef IsMax As Boolean, _
    ByRef Tolerance As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetPlanarZoneVector Method (DimXpertOrientationTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetPlanarZoneVector( _
    ByRef I As Double, _
    ByRef J As Double, _
    ByRef K As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetProjectedZone Method (DimXpertOrientationTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetProjectedZone( _
    ByRef Enabled As Boolean, _
    ByRef Value As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
IsTangentPlane Method (DimXpertOrientationTolerance)



Visual Basic for Applications (VBA)

```
Public Function IsTangentPlane() As Boolean
```

SOLIDWORKS DimXpert Type Library

Modifier Property (DimXpertOrientationTolerance)



Visual Basic for Applications (VBA)

```
Public Property Modifier As swDimXpertMaterialConditionModifier\_e
```

SOLIDWORKS DimXpert Type Library

ZoneType Property (DimXpertOrientationTolerance)



Visual Basic for Applications (VBA)

```
Public Property ZoneType As swDimXpertOrientationZoneType\_e
```

DimXpertPart (Type)

SOLIDWORKS DimXpert Type Library

DimXpertPart Object

Object Model

DimXpertPart

- GetAnnotation (DimXpertAnnotation)
- GetAutoDimSchemeOption (DimXpertAutoDimSchemeOption)
- GetBlockTolerances (DimXpertBlockTolerances)
- GetDimOption (DimXpertDimensionOption)
- GetFeature (DimXpertFeature)
- IGetAnnotations (DimXpertAnnotation)
- IGetFeatures (DimXpertFeature)
- InsertGtol (DimXpertAnnotation)


SOLIDWORKS DimXpert Type Library

DimXpertPart Object Members

Public Methods

- AutoDimensionScheme
- DeleteAllTolerances
- GetAnnotation
- GetAnnotationCount
- GetAnnotations
- GetAutoDimSchemeOption
- GetBlockTolerances
- GetDimOption
- GetFeature
- GetFeatureCount
- GetFeatures
- IGetAnnotations
- IGetFeatures
- ImportScheme
- InsertAngleDimension
- InsertBasicDimension
- InsertDatum
- InsertGtol
- InsertLocationDimension
- InsertPattern
- InsertSizeDimension

Public Properties



[ShowToleranceStatus](#)

SOLIDWORKS DimXpert Type Library

AutoDimensionScheme Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoDimensionScheme( _  
    ByVal Option As DimXpertAutoDimSchemeOption _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

DeleteAllTolerances Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteAllTolerances() As Boolean
```

SOLIDWORKS DimXpert Type Library

GetAnnotation Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotation( _  
    ByVal Name As String _  
) As DimXpertAnnotation
```

SOLIDWORKS DimXpert Type Library

GetAnnotationCount Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotationCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetAnnotations Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotations() As Variant
```

SOLIDWORKS DimXpert Type Library

GetAutoDimSchemeOption Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAutoDimSchemeOption() As DimXpertAutoDimSchemeOption
```

SOLIDWORKS DimXpert Type Library

GetBlockTolerances Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBlockTolerances() As DimXpertBlockTolerances
```

SOLIDWORKS DimXpert Type Library

GetDimOption Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDimOption() As DimXpertDimensionOption
```

SOLIDWORKS DimXpert Type Library

GetFeature Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature( _  
    ByVal Name As String _  
) As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

GetFeatureCount Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatureCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetFeatures Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatures() As Variant
```

SOLIDWORKS DimXpert Type Library

IGetAnnotations Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotations( _  
    ByVal Count As Long _  
) As DimXpertAnnotation
```

SOLIDWORKS DimXpert Type Library

IGetFeatures Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeatures( _  
    ByVal Count As Long _  
) As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

ImportScheme Method (DimXpertPart)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ImportScheme( _  
    ByVal Filename As String, _  
    ByVal ConfigurationName As String _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertAngleDimension Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAngleDimension( _  
    ByVal Option As DimXpertDimensionOption _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertBasicDimension Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBasicDimension( _  
    ByVal Option As DimXpertDimensionOption _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertDatum Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDatum( _  
    ByVal Option As DimXpertDimensionOption _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertGtol Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertGtol( _  
    ByVal Type As Long _  
) As DimXpertAnnotation
```

SOLIDWORKS DimXpert Type Library

InsertLocationDimension Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertLocationDimension( _  
    ByVal Option As DimXpertDimensionOption _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertPattern Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertPattern( _  
    ByVal Option As DimXpertDimensionOption, _  
    ByVal PatternType As Long, _  
    ByVal FindAll As Boolean _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

InsertSizeDimension Method (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)


```
Public Function InsertSizeDimension( _  
    ByVal Option As DimXpertDimensionOption _  
    ) As Boolean
```

SOLIDWORKS DimXpert Type Library

ShowToleranceStatus Property (DimXpertPart)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowToleranceStatus As Boolean
```

DimXpertPatternFeature (Type)

SOLIDWORKS DimXpert Type Library

DimXpertPatternFeature Object

Object Model

DimXpertPatternFeature

IGetSubFeatures (DimXpertFeature)

SOLIDWORKS DimXpert Type Library

DimXpertPatternFeature Object Members

Public Methods

 [GetSubFeatureCount](#)

 [GetSubFeatures](#)

 [IGetSubFeatures](#)

Public Properties

 [PatternType](#)

SOLIDWORKS DimXpert Type Library

GetSubFeatureCount Method (DimXpertPatternFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatureCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetSubFeatures Method (DimXpertPatternFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatures() As Variant
```

SOLIDWORKS DimXpert Type Library

IGetSubFeatures Method (DimXpertPatternFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSubFeatures( _  
    ByVal Count As Long _  
) As DimXpertFeature
```

SOLIDWORKS DimXpert Type Library

PatternType Property (DimXpertPatternFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternType As swDimXpertFeatureType\_e
```

DimXpertPlaneFeature (Type)

SOLIDWORKS DimXpert Type Library

DimXpertPlaneFeature Object

Object Model

DimXpertPlaneFeature

SOLIDWORKS DimXpert Type Library

DimXpertPlaneFeature Object Members

Public Methods

 [GetNominalPlane](#)

SOLIDWORKS DimXpert Type Library

GetNominalPlane Method (DimXpertPlaneFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

DimXpertPositionTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertPositionTolerance Object

 Object Model

DimXpertPositionTolerance

SOLIDWORKS DimXpert Type Library
DimXpertPositionTolerance Object Members

 Public Methods

 GetMaxTolerance
 GetPlanarZoneVector
 GetProjectedZone

 Public Properties

 Modifier
 ZoneType

SOLIDWORKS DimXpert Type Library
GetMaxTolerance Method (DimXpertPositionTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetMaxTolerance( _
    ByRef IsMax As Boolean, _
    ByRef Tolerance As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetPlanarZoneVector Method (DimXpertPositionTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetPlanarZoneVector( _
    ByRef I As Double, _
    ByRef J As Double, _
    ByRef K As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetProjectedZone Method (DimXpertPositionTolerance)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function GetProjectedZone( _
    ByRef Enabled As Boolean, _
    ByRef Value As Double _
) As Boolean
```

SOLIDWORKS DimXpert Type Library
Modifier Property (DimXpertPositionTolerance)

 Syntax

```
Visual Basic for Applications (VBA)
```

Public Property Modifier As [swDimXpertMaterialConditionModifier_e](#)

SOLIDWORKS DimXpert Type Library

ZoneType Property (DimXpertPositionTolerance)



Visual Basic for Applications (VBA)

Public Property ZoneType As [swDimXpertPositionZoneType_e](#)

DimXpertRadiusDimTol (Type)

SOLIDWORKS DimXpert Type Library

DimXpertRadiusDimTol Object

Object Model

DimXpertRadiusDimTol

SOLIDWORKS DimXpert Type Library

DimXpertRadiusDimTol Object Members

Public Properties

 [PatternTreatment](#)

SOLIDWORKS DimXpert Type Library

PatternTreatment Property (DimXpertRadiusDimTol)

Syntax

Visual Basic for Applications (VBA)

Public Property PatternTreatment As [swDimXpertPatternTreatmentType_e](#)

DimXpertRefPlaneFeature (Type)

SOLIDWORKS DimXpert Type Library
DimXpertRefPlaneFeature Object

 Object Model

DimXpertRefPlaneFeature

SOLIDWORKS DimXpert Type Library
DimXpertRefPlaneFeature Object Members



 Public Methods

 [GetNominalPlane](#)

SOLIDWORKS DimXpert Type Library
GetNominalPlane Method (DimXpertRefPlaneFeature)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

DimXpertSphereFeature (Type)

SOLIDWORKS DimXpert Type Library

DimXpertSphereFeature Object

Object Model

DimXpertSphereFeature

SOLIDWORKS DimXpert Type Library

DimXpertSphereFeature Object Members

Public Methods

GetNominalSphere

Public Properties

Inner

SOLIDWORKS DimXpert Type Library

GetNominalSphere Method (DimXpertSphereFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalSphere( _  
    ByRef R As Double, _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

Inner Property (DimXpertSphereFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Inner As Boolean
```


DimXpertStraightnessTolerance (Type)

SOLIDWORKS DimXpert Type Library

DimXpertStraightnessTolerance Object

Object Model

DimXpertStraightnessTolerance

SOLIDWORKS DimXpert Type Library

DimXpertStraightnessTolerance Object Members

Public Methods

-  [GetMaxTolerance](#)
-  [GetPerUnitLength](#)
-  [GetPlanarZoneVector](#)

Public Properties

-  [Modifier](#)
-  [ZoneType](#)

SOLIDWORKS DimXpert Type Library

GetMaxTolerance Method (DimXpertStraightnessTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaxTolerance( _  
    ByRef IsMax As Boolean, _  
    ByRef Tolerance As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

GetPerUnitLength Method (DimXpertStraightnessTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPerUnitLength( _  
    ByRef Enabled As Boolean, _  
    ByRef Distance As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

GetPlanarZoneVector Method (DimXpertStraightnessTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlanarZoneVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library

Modifier Property (DimXpertStraightnessTolerance)

Syntax

Visual Basic for Applications (VBA)

Public Property Modifier As [swDimXpertMaterialConditionModifier_e](#)

SOLIDWORKS DimXpert Type Library

ZoneType Property (DimXpertStraightnessTolerance)



Syntax

Visual Basic for Applications (VBA)

Public Property ZoneType As [swDimXpertStraightnessZoneType_e](#)

DimXpertSurfaceProfileTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertSurfaceProfileTolerance Object

Object Model

DimXpertSurfaceProfileTolerance

SOLIDWORKS DimXpert Type Library
DimXpertSurfaceProfileTolerance Object Members



Public Properties

 OuterToleranceValue

SOLIDWORKS DimXpert Type Library
OuterToleranceValue Property (DimXpertSurfaceProfileTolerance)

Syntax

Visual Basic for Applications (VBA)

Public Property OuterToleranceValue As Double

DimXpertSymmetryTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertSymmetryTolerance Object

Object Model

DimXpertSymmetryTolerance

SOLIDWORKS DimXpert Type Library
DimXpertSymmetryTolerance Object Members

Public Methods

 [GetMaxTolerance](#)

 [GetZoneDirection](#)

Public Properties

 [Modifier](#)

SOLIDWORKS DimXpert Type Library
GetMaxTolerance Method (DimXpertSymmetryTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaxTolerance( _  
    ByRef IsMax As Boolean, _  
    ByRef Tolerance As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library
GetZoneDirection Method (DimXpertSymmetryTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetZoneDirection( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS DimXpert Type Library
Modifier Property (DimXpertSymmetryTolerance)

Syntax


Visual Basic for Applications (VBA)

```
Public Property Modifier As swDimXpertMaterialConditionModifier\_e
```

DimXpertTangencyTolerance (Type)

SOLIDWORKS DimXpert Type Library
DimXpertTangencyTolerance Object

 Object Model



SOLIDWORKS DimXpert Type Library
DimXpertTangencyTolerance Object Members



 Public Properties

 [OriginFeature](#)

SOLIDWORKS DimXpert Type Library
OriginFeature Property (DimXpertTangencyTolerance)

 Syntax

Visual Basic for Applications (VBA)


Public Property OriginFeature As [DimXpertFeature](#)

DimXpertTolerance (Type)

SOLIDWORKS DimXpert Type Library

DimXpertTolerance Object

Object Model



SOLIDWORKS DimXpert Type Library

DimXpertTolerance Object Members

Public Methods

	GetPrimaryDatumCount
	GetPrimaryDatumModifiers
	GetPrimaryDatums
	GetSecondaryDatumCount
	GetSecondaryDatumModifiers
	GetSecondaryDatums
	GetTertiaryDatumCount
	GetTertiaryDatumModifiers
	GetTertiaryDatums
	IGetPrimaryDatumModifiers
	IGetPrimaryDatums
	IGetSecondaryDatumModifiers
	IGetSecondaryDatums
	IGetTertiaryDatumModifiers
	IGetTertiaryDatums

Public Properties

	Tolerance
---	---------------------------

SOLIDWORKS DimXpert Type Library

GetPrimaryDatumCount Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetPrimaryDatumCount() As Long</pre>

SOLIDWORKS DimXpert Type Library

GetPrimaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetPrimaryDatumModifiers() As Variant</pre>

SOLIDWORKS DimXpert Type Library

GetPrimaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPrimaryDatums() As Variant
```

SOLIDWORKS DimXpert Type Library

GetSecondaryDatumCount Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSecondaryDatumCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetSecondaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSecondaryDatumModifiers() As Variant
```

SOLIDWORKS DimXpert Type Library

GetSecondaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSecondaryDatums() As Variant
```

SOLIDWORKS DimXpert Type Library

GetTertiaryDatumCount Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTertiaryDatumCount() As Long
```

SOLIDWORKS DimXpert Type Library

GetTertiaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTertiaryDatumModifiers() As Variant
```

SOLIDWORKS DimXpert Type Library

GetTertiaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTertiaryDatums() As Variant
```

SOLIDWORKS DimXpert Type Library

IGetPrimaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPrimaryDatumModifiers( _  
    ByVal Count As Long _
```

) As [swDimXpertMaterialConditionModifier_e](#)

SOLIDWORKS DimXpert Type Library

IGetPrimaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPrimaryDatums( _  
    ByVal Count As Long _  
) As DimXpertDatum
```

SOLIDWORKS DimXpert Type Library

IGetSecondaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSecondaryDatumModifiers( _  
    ByVal Count As Long _  
) As swDimXpertMaterialConditionModifier\_e
```

SOLIDWORKS DimXpert Type Library

IGetSecondaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSecondaryDatums( _  
    ByVal Count As Long _  
) As DimXpertDatum
```

SOLIDWORKS DimXpert Type Library

IGetTertiaryDatumModifiers Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTertiaryDatumModifiers( _  
    ByVal Count As Long _  
) As swDimXpertMaterialConditionModifier\_e
```

SOLIDWORKS DimXpert Type Library

IGetTertiaryDatums Method (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTertiaryDatums( _  
    ByVal Count As Long _  
) As DimXpertDatum
```

SOLIDWORKS DimXpert Type Library

Tolerance Property (DimXpertTolerance)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Tolerance As Double
```


swDimXpertAnnotationType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertAnnotationType_e Enumeration

[See Also](#)

Members

Member	Value	Description
swDimXpertAnnotationType_unknown	0	
swDimXpertDatum	150	
swDimXpertDimTol_AngleBetween	106	
swDimXpertDimTol_AngleBetweenCircular	221	
swDimXpertDimTol_AngleSize	220	
swDimXpertDimTol_ChamferDimension	105	
swDimXpertDimTol_CompositeDistanceBetween	113	
swDimXpertDimTol_ConeAngle	108	
swDimXpertDimTol_CounterBore	102	
swDimXpertDimTol_CounterSinkAngle	107	
swDimXpertDimTol_CounterSinkDiameter	104	
swDimXpertDimTol_Depth	103	
swDimXpertDimTol_Diameter	109	
swDimXpertDimTol_DistanceBetween	101	
swDimXpertDimTol_Length	110	
swDimXpertDimTol_PatternAngleBetween	114	
swDimXpertDimTol_Radius	111	
swDimXpertDimTol_Width	112	
swDimXpertGeoTol_Angularity	210	
swDimXpertGeoTol_Circularity	216	
swDimXpertGeoTol_CircularRunout	214	
swDimXpertGeoTol_CompositeLineProfile	206	
swDimXpertGeoTol_CompositePosition	202	
swDimXpertGeoTol_CompositeSurfaceProfile	208	
swDimXpertGeoTol_Concentricity	204	
swDimXpertGeoTol_Cylindricity	217	
swDimXpertGeoTol_Flatness	215	
swDimXpertGeoTol_LineProfile	205	
swDimXpertGeoTol_Parallelism	211	
swDimXpertGeoTol_Perpendicularity	212	
swDimXpertGeoTol_Position	201	
swDimXpertGeoTol_Straightness	218	
swDimXpertGeoTol_SurfaceProfile	207	
swDimXpertGeoTol_Symmetry	203	
swDimXpertGeoTol_Tangency	219	
swDimXpertGeoTol_TotalRunout	213	

swDimXpertAutoDimSchemePartType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertAutoDimSchemePartType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertAutoDimSchemePartType_Prismatic	0	
swDimXpertAutoDimSchemePartType_Turned	1	

swDimXpertAutoDimSchemePatternType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertAutoDimSchemePatternType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertAutoDimSchemePatternType_Linear	0	
swDimXpertAutoDimSchemePatternType_Polar	1	

swDimXpertAutoDimSchemeToleranceType__e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertAutoDimSchemeToleranceType__e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertAutoDimSchemeToleranceType__Geometric	1	
swDimXpertAutoDimSchemeToleranceType__PlusMinus	0	

swDimXpertBlockToleranceType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertBlockToleranceType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertBlockToleranceType_ASMEInch	1	
swDimXpertBlockToleranceType_ISO2768	2	
swDimXpertBlockToleranceType_unknown	0	

swDimXpertChamferAngleType__e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertChamferAngleType__e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertChamferAngleType__Concave	1	
swDimXpertChamferAngleType__Convex	2	
swDimXpertChamferAngleType__unknown	0	

swDimXpertChamferDimensionType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertChamferDimensionType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertChamferDimensionType_Angle	1	
swDimXpertChamferDimensionType_LinearDistance1	2	
swDimXpertChamferDimensionType_LinearDistance2	3	
swDimXpertChamferDimensionType_unknown	0	

swDimXpertChamferType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertChamferType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertChamferType_DistanceAngle	1	
swDimXpertChamferType_DistanceDistance	2	
swDimXpertChamferType_unknown	0	
swDimXpertChamferType_Vertex	3	

swDimXpertCombineAnnotation_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertCombineAnnotation_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertCombineAnnotation_swDimXpertBreakFailed	2	
swDimXpertCombineAnnotation_swDimXpertBreakSucceeded	3	
swDimXpertCombineAnnotation_swDimXpertCombineFailed	0	
swDimXpertCombineAnnotation_swDimXpertCombineSucceeded	1	

swDimXpertCompoundHoleType_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertCompoundHoleType_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertCompoundHoleType_Compound	1	
swDimXpertCompoundHoleType_Counterbore	2	
swDimXpertCompoundHoleType_Countersink	3	
swDimXpertCompoundHoleType_Simple	4	
swDimXpertCompoundHoleType_unknown	0	

swDimXpertDimensionPositionOption_e (Type)

SOLIDWORKS DimXpert Type Library

swDimXpertDimensionPositionOption_e Enumeration

[See Also](#)



Members

Member	Value	Description
swDimXpertDimensionPositionOption_N	0	
swDimXpertDimensionPositionOption_X	1	
swDimXpertDimensionPositionOption_Y	2	
swDimXpertDimensionPositionOption_Z	3	