

SOLIDWORKS Document Manager API (.NET) — Reference (1/19): namespace_hierarchy- ISwDMComponent2

SOLIDWORKS API Documentation (converted from CHM)

namespace_hierarchy (Type)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SolidWorks.Interop.swdocumentmgr Namespace Inheritance Hierarchy

[See Also](#)



Inheritance Hierarchy

System.Object

See Also

[SolidWorks.Interop.swdocumentmgr Assembly](#)

ISwDMApplication (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMApplication Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMApplication Interface

Manages part, assembly, or drawing documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMApplication
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication
```

C#

```
public interface ISwDMApplication
```

C++/CLI

```
public interface class ISwDMApplication
```

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get External References \(C#\)](#)
[Get External References \(VB.NET\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Accessors

[ISwDMClassFactory::GetApplication](#)

[ISwDMConfiguration::Application](#)

[ISwDMConfigurationMgr::Application](#)

See Also

[ISwDMApplication Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMApplication Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMApplication Interface

The following tables list the members exposed by [ISwDMApplication](#).

Public Methods

Name	Description
 CopyDocument	Copies a single document and optionally updates references to it.
 GetDocument	Gets the specified document.
 GetLatestSupportedFileVersion	Gets the latest supported SOLIDWORKS version number that this utility can read.
 GetSearchOptionObject	Gets an ISwDMSearchOption object.
 MoveDocument	Moves a single document and optionally updates references to it.

[Top](#)

 See Also

[ISwDMSearchOption Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication5 Interface](#)

SOLIDWORKS Document Manager API Help [Send comments on this topic.](#)

ISwDMApplication Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMApplication Interface

For a list of all members of this type, see [ISwDMApplication members](#).

 Public Methods

Name	Description
 CopyDocument	Copies a single document and optionally updates references to it.
 GetDocument	Gets the specified document.
 GetLatestSupportedFileVersion	Gets the latest supported SOLIDWORKS version number that this utility can read.
 GetSearchOptionObject	Gets an ISwDMSearchOption object.
 MoveDocument	Moves a single document and optionally updates references to it.

[Top](#)

 See Also

[ISwDMSearchOption Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication5 Interface](#)

SOLIDWORKS Document Manager API Help [Send comments on this topic.](#)

CopyDocument Method (ISwDMApplication)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMApplication Interface](#) : CopyDocument Method (ISwDMApplication)

Copies a single document and optionally updates references to it.

 .NET Syntax

Visual Basic (Declaration)

```
Function CopyDocument( _  
    ByVal fromName As System.String, _  
    ByVal toName As System.String, _  
    ByVal fromChildren As System.Object, _  
    ByVal toChildren As System.Object, _  
    ByVal option As System.Integer, _
```

```
ByVal pSrcOption As SwDMSearchOption _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMAApplication  
Dim fromName As System.String  
Dim toName As System.String  
Dim fromChildren As System.Object  
Dim toChildren As System.Object  
Dim option As System.Integer  
Dim pSrcOption As SwDMSearchOption  
Dim value As System.Integer
```

```
value = instance.CopyDocument(fromName, toName, fromChildren, toChildren, option, pSrcOption)
```

C#

```
System.int CopyDocument(  
    System.string fromName,  
    System.string toName,  
    System.object fromChildren,  
    System.object toChildren,  
    System.int option,  
    SwDMSearchOption pSrcOption  
)
```

C++/CLI

```
System.int CopyDocument(  
& System.String^ fromName,  
& System.String^ toName,  
& System.Object^ fromChildren,  
& System.Object^ toChildren,  
& System.int option,  
& SwDMSearchOption^ pSrcOption  
)
```

Parameters

fromName

Full path and filename of the document to copy

toName

Full path and filename of the document to which to copy fromName

fromChildren

Array containing the full path and filenames of the child documents dependent on the document specified for fromName

toChildren

Array containing the new full path and filenames of the child documents to which to copy the child documents specified for fromChildr

option

Copy options as defined by [SwDmCopyOptions](#)

pSrcOption

Pointer to an [ISwDMSearchOption](#) object

Return Value

Success or error code as defined by [SwDmMoveCopyError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication::CopyDocument](#).

Remarks

If a document is opened, you must call [ISwDMDocument::CloseDoc](#) to close it before calling this method.

See Also

[ISwDMAApplication Interface](#)

[ISwDMAApplication Members](#)

[ISwDMAApplication::MoveDocument Method](#)

Availability

GetDocument Method (ISwDMApplication)

[See Also](#) [Example](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMApplication Interface](#) : GetDocument Method (ISwDMApplication)

Gets the specified document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocument( _
    ByVal FullPathName As System.String, _
    ByVal docType As SwDmDocumentType, _
    ByVal allowReadOnly As System.Boolean, _
    ByRef result As SwDmDocumentOpenError _
) As SwDMDocument
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication
Dim FullPathName As System.String
Dim docType As SwDmDocumentType
Dim allowReadOnly As System.Boolean
Dim result As SwDmDocumentOpenError
Dim value As SwDMDocument

value = instance.GetDocument(FullPathName, docType, allowReadOnly, result)
```

C#

```
SwDMDocument GetDocument(
    System.string FullPathName,
    SwDmDocumentType docType,
    System.bool allowReadOnly,
    out SwDmDocumentOpenError result
)
```

C++/CLI

```
SwDMDocument^ GetDocument(
    & System.String^ FullPathName,
    & SwDmDocumentType docType,
    & System.bool allowReadOnly,
    & [Out] SwDmDocumentOpenError result
)
```

Parameters

FullPathName

Full path and filename of the document to get

*docType*Type of document as defined by [SwDmDocumentType](#)*allowReadOnly*

True to open the document as read-only, false as read-write

*result*Error as defined by [SwDmDocumentOpenError](#)

Return Value

Pointer to an [ISwDMDocument](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication::GetDocument](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)
[Write Parasolid Partition Stream to File \(C++\)](#)
[Open and Close Document \(C++\)](#)
[Get Drawing Sheets' Properties \(C#\)](#)
[Get Drawing Sheets' Properties \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(VB.NET\)](#)

Remarks

If the document is currently open as read-write, then this method fails and returns NULL.

Use [ISwDMAApplication2::GetDocument2](#) to get a document using an IStream or IStorage storage.

See Also

[ISwDMAApplication Interface](#)
[ISwDMAApplication Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetLatestSupportedFileVersion Method (ISwDMAApplication)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMAApplication Interface](#) : GetLatestSupportedFileVersion Method (ISwDMAApplication)

Gets the latest supported SOLIDWORKS version number that this utility can read.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLatestSupportedFileVersion() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMAApplication  
Dim value As System.Integer  
  
value = instance.GetLatestSupportedFileVersion()
```

C#

```
System.int GetLatestSupportedFileVersion()
```

C++/CLI

```
System.int GetLatestSupportedFileVersion();
```

Return Value

Latest supported SOLIDWORKS file version number that this utility can read

Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication::GetLatestSupportedFileVersion](#).

Example

[Open and Close Document \(C++\)](#)

Remarks

Major SOLIDWORKS Release	Return Value
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000
SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000
SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000
SOLIDWORKS 2026	19000

See Also

[ISwDMApplication Interface](#)
[ISwDMApplication Members](#)
[ISwDMDocument::GetVersion Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSearchOptionObject Method (ISwDMApplication)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMApplication Interface](#) : GetSearchOptionObject Method (ISwDMApplication)

Gets an [ISwDMSearchOption](#) object.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSearchOptionObject() As SwDMSearchOption
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication  
Dim value As SwDMSearchOption  
  
value = instance.GetSearchOptionObject()
```

C#

```
SwDMSearchOption GetSearchOptionObject()
```

C++/CLI

```
SwDMSearchOption^ GetSearchOptionObject();
```

Return Value

Pointer to an [ISwDMSearchOption](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication::GetSearchOptionObject](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get External References \(C#\)](#)
[Get External References \(VB.NET\)](#)
[Open and Close Document \(C++\)](#)

See Also

[ISwDMApplication Interface](#)
[ISwDMApplication Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

MoveDocument Method (ISwDMApplication)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMApplication Interface](#) : MoveDocument Method (ISwDMApplication)

Moves a single document and optionally updates references to it.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function MoveDocument( _  
    ByVal fromName As System.String, _  
    ByVal toName As System.String, _  
    ByVal fromChildren As System.Object, _  
    ByVal toChildren As System.Object, _  
    ByVal option As System.Integer, _
```

```
ByVal pSrcOption As SwDMSearchOption _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMAApplication  
Dim fromName As System.String  
Dim toName As System.String  
Dim fromChildren As System.Object  
Dim toChildren As System.Object  
Dim option As System.Integer  
Dim pSrcOption As SwDMSearchOption  
Dim value As System.Integer
```

```
value = instance.MoveDocument(fromName, toName, fromChildren, toChildren, option, pSrcOption)
```

C#

```
System.int MoveDocument(  
    System.string fromName,  
    System.string toName,  
    System.object fromChildren,  
    System.object toChildren,  
    System.int option,  
    SwDMSearchOption pSrcOption  
)
```

C++/CLI

```
System.int MoveDocument(  
& System.String^ fromName,  
& System.String^ toName,  
& System.Object^ fromChildren,  
& System.Object^ toChildren,  
& System.int option,  
& SwDMSearchOption^ pSrcOption  
)
```

Parameters

fromName

Full path and filename of the document to move

toName

Full path and filename of the new document to which to move the document specified for fromName

fromChildren

Array containing the full path and filenames of the child documents dependent on the document specified for fromName

toChildren

Array containing the new full path and filenames for the child documents to which to move the documents specified for fromChildren

option

Move options as defined by [SwDmCopyOptions](#)

pSrcOption

Pointer to an [ISwDMSearchOption](#) object

Return Value

Success or error code as defined by [SwDmMoveCopyError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication::MoveDocument](#).

Remarks

If a document is opened, you must call [ISwDMDocument::CloseDoc](#) to close it before calling this method.

See Also

[ISwDMAApplication Interface](#)

[ISwDMAApplication Members](#)

[ISwDMAApplication::CopyDocument Method](#)

Availability

ISwDMApplication2 (Type)

ISwDMApplication2 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication2 Interface

Manages part, assembly, or drawing documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMApplication2
    Inherits ISwDMApplication
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication2
```

C#

```
public interface ISwDMApplication2 : ISwDMApplication
```

C++/CLI

```
public interface class ISwDMApplication2 : public ISwDMApplication
```

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication2](#).

Remarks

- You can access an SwDMApplication2 object by calling QueryInterface on an [ISwDMApplication](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMApplication object can be assigned to a SwDMApplication2 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMClassFactory::GetApplication](#)

[ISwDMConfiguration::Application](#)

[ISwDMConfigurationMgr::Application](#)

See Also

- [ISwDMApplication2 Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMApplication4 Interface](#)
- [ISwDMClassFactory Interface](#)
- [ISwDMDocument Interface](#)
- [ISwDMSearchOption Interface](#)
- [ISwDMApplication Interface](#)
- [ISwDMApplication3 Interface](#)
- [ISwDMApplication5 Interface](#)

ISwDMApplication2 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication2 Interface

For a list of all members of this type, see [ISwDMApplication2 members](#).

Public Methods

Name	Description
------	-------------

 [GetDocument2](#) Gets the specified document from an IStream or IStorage storage.

[Top](#)

See Also

[ISwDmApplication2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDmApplication4 Interface](#)
[ISwDmClassFactory Interface](#)
[ISwDmDocument Interface](#)
[ISwDmSearchOption Interface](#)
[ISwDmApplication Interface](#)
[ISwDmApplication3 Interface](#)
[ISwDmApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDmApplication2 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDmApplication2 Interface

The following tables list the members exposed by [ISwDmApplication2](#).

Public Methods

Name	Description
 GetDocument2	Gets the specified document from an IStream or IStorage storage.

[Top](#)

See Also

[ISwDmApplication2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDmApplication4 Interface](#)
[ISwDmClassFactory Interface](#)
[ISwDmDocument Interface](#)
[ISwDmSearchOption Interface](#)
[ISwDmApplication Interface](#)
[ISwDmApplication3 Interface](#)
[ISwDmApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetDocument2 Method (ISwDmApplication2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDmApplication2 Interface](#) : GetDocument2 Method (ISwDmApplication2)

Gets the specified document from an IStream or IStorage storage.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocument2( _  
    ByVal documentStream As System.Object, _  
    ByRef result As SwDmDocumentOpenError _  
    ) As SwDmDocument
```

Visual Basic (Usage)



```
Dim instance As ISwDmApplication2  
Dim documentStream As System.Object  
Dim result As SwDmDocumentOpenError  
Dim value As SwDmDocument
```

```
value = instance.GetDocument2(documentStream, result)
```

C#

```
SwDmDocument GetDocument2(  
    System.object documentStream,  
    out SwDmDocumentOpenError result  
)
```

```
SwDMDocument^ GetDocument2(  
& System.Object^ documentStream,  
& [Out] SwDmDocumentOpenError result  
)
```

Parameters

documentStream

Pointer to an unknown type, the IStream or IStorage storage

result

Error as defined by [SwDmDocumentOpenError](#)

Return Value

Pointer to the [ISwDMDocument](#) object

 Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication2::GetDocument2](#).

 Remarks

Use [ISwDMAApplication::GetDocument](#) to get a document using its name.

 See Also

[ISwDMAApplication2 Interface](#)

[ISwDMAApplication2 Members](#)

 Availability

SOLIDWORKS Document Manager API 2007 SP3

ISwDMApplication3 (Type)

ISwDMApplication3 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication3 Interface

Manages part, assembly, or drawing documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMApplication3
    Inherits ISwDMApplication, ISwDMApplication2
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication3
```

C#

```
public interface ISwDMApplication3 : ISwDMApplication, ISwDMApplication2
```

C++/CLI

```
public interface class ISwDMApplication3 : public ISwDMApplication, ISwDMApplication2
```

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication3](#).

Remarks

- You can access an SwDMApplication3 object by calling QueryInterface on an [ISwDMApplication](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMApplication object can be assigned to a SwDMApplication3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

- [ISwDMClassFactory::GetApplication](#)
- [ISwDMConfiguration::Application](#)
- [ISwDMConfigurationMgr::Application](#)

See Also

- [ISwDMApplication3 Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMApplication2 Interface](#)
- [ISwDMApplication4 Interface](#)
- [ISwDMClassFactory Interface](#)
- [ISwDMDocument Interface](#)
- [ISwDMSearchOption Interface](#)
- [ISwDMApplication Interface](#)
- [ISwDMApplication5 Interface](#)

ISwDMApplication3 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication3 Interface

For a list of all members of this type, see [ISwDMApplication3 members](#).

Public Methods

Name	Description
------	-------------



[GetExternalReferenceOptionObject](#)

Gets an ISwDMEExternalReferenceOption object.

[Top](#)

See Also

[ISwDMSApplication3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMSApplication2 Interface](#)
[ISwDMSApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMSApplication Interface](#)
[ISwDMSApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMSApplication3 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMSApplication3 Interface

The following tables list the members exposed by [ISwDMSApplication3](#).

Public Methods

Name



[GetExternalReferenceOptionObject](#)

Description

Gets an ISwDMEExternalReferenceOption object.

[Top](#)

See Also

[ISwDMSApplication3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMSApplication2 Interface](#)
[ISwDMSApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMSApplication Interface](#)
[ISwDMSApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetExternalReferenceOptionObject Method (ISwDMSApplication3)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMSApplication3 Interface](#) : GetExternalReferenceOptionObject Method (ISwDMSApplication3)

Gets an ISwDMEExternalReferenceOption object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExternalReferenceOptionObject() As SwDMEExternalReferenceOption
```

Visual Basic (Usage)



```
Dim instance As ISwDMSApplication3  
Dim value As SwDMEExternalReferenceOption  
  
value = instance.GetExternalReferenceOptionObject()
```

C#

```
SwDMEExternalReferenceOption GetExternalReferenceOptionObject()
```

C++/CLI

```
SwDMEExternalReferenceOption^ GetExternalReferenceOptionObject();
```

Return Value

Pointer to an [ISwDMEExternalReferenceOption](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication3::GetExternalReferenceOptionObject](#).

See Also

[ISwDMApplication3 Interface](#)

[ISwDMApplication3 Members](#)

[ISwDMDocument15::GetExternalFeatureReferences Method](#)

Availability

SOLIDWORKS Document Manager API 2011 SP0

ISwDMApplication4 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMApplication4 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMApplication4 Interface

Manages part, assembly, or drawing documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMApplication4
    Inherits ISwDMApplication, ISwDMApplication2, ISwDMApplication3
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication4
```

C#

```
public interface ISwDMApplication4 : ISwDMApplication, ISwDMApplication2, ISwDMApplication3
```

C++/CLI

```
public interface class ISwDMApplication4 : public
    ISwDMApplication, ISwDMApplication2, ISwDMApplication3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication4](#).

Example

[Get External References for Part \(C#\)](#)
[Get External References for Part \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an SwDMApplication4 object by calling QueryInterface on an [ISwDMApplication](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMApplication object can be assigned to a SwDMApplication4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMClassFactory::GetApplication](#)

[ISwDMConfiguration::Application](#)

[ISwDMConfigurationMgr::Application](#)

See Also

[ISwDMApplication4 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication2 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)
[ISwDMApplication Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMApplication4 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMSApplication4 Interface

For a list of all members of this type, see [ISwDMSApplication4 members](#).

Public Methods

Name	Description
 GetExternalReferenceOptionObject2	Gets an ISwDMSExternalReferenceOption2 object.

[Top](#)

See Also

[ISwDMSApplication4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMSApplication2 Interface](#)
[ISwDMSClassFactory Interface](#)
[ISwDMSDocument Interface](#)
[ISwDMSSearchOption Interface](#)
[ISwDMSApplication Interface](#)
[ISwDMSApplication3 Interface](#)
[ISwDMSApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMSApplication4 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMSApplication4 Interface

The following tables list the members exposed by [ISwDMSApplication4](#).

Public Methods

Name	Description
 GetExternalReferenceOptionObject2	Gets an ISwDMSExternalReferenceOption2 object.

[Top](#)

See Also

[ISwDMSApplication4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMSApplication2 Interface](#)
[ISwDMSClassFactory Interface](#)
[ISwDMSDocument Interface](#)
[ISwDMSSearchOption Interface](#)
[ISwDMSApplication Interface](#)
[ISwDMSApplication3 Interface](#)
[ISwDMSApplication5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetExternalReferenceOptionObject2 Method (ISwDMSApplication4)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMSApplication4 Interface](#) : GetExternalReferenceOptionObject2 Method (ISwDMSApplication4)

Gets an ISwDMSExternalReferenceOption2 object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExternalReferenceOptionObject2() As SwDMSExternalReferenceOption2
```

Visual Basic (Usage)



```
Dim instance As ISwDMSApplication4  
Dim value As SwDMSExternalReferenceOption2  
  
value = instance.GetExternalReferenceOptionObject2()
```

C#

```
SwDMSExternalReferenceOption2 GetExternalReferenceOptionObject2()
```

```
SwDMExternalReferenceOption2^ GetExternalReferenceOptionObject2();
```

Return Value

Pointer to an [ISwDMExternalReferenceOption2](#) object

 Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication3::GetExternalReferenceOptionObject2](#).

 Example

[Get External References for Part \(C#\)](#)
[Get External References for Part \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

 See Also

[ISwDMAApplication4 Interface](#)
[ISwDMAApplication4 Members](#)
[ISwDMDocument18::GetExternalFeatureReferences2 Method\(\)](#)

 Availability

SOLIDWORKS Document Manager API 2014 SP0

ISwDMApplication5 (Type)

ISwDMApplication5 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication5 Interface

Manages part, assembly, or drawing documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMApplication5
    Inherits ISwDMApplication, ISwDMApplication2, ISwDMApplication3, ISwDMApplication4
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication5
```

C#

```
public interface ISwDMApplication5 :
    ISwDMApplication, ISwDMApplication2, ISwDMApplication3, ISwDMApplication4
```

C++/CLI

```
public interface class ISwDMApplication5 : public
    ISwDMApplication, ISwDMApplication2, ISwDMApplication3, ISwDMApplication4
```

Visual Basic for Applications (VBA) Syntax

See [SwDMApplication5](#).

Remarks

- You can access an SwDMApplication5 object by calling QueryInterface on an [ISwDMApplication](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMApplication object can be assigned to a SwDMApplication5 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMClassFactory::GetApplication](#)

[ISwDMConfiguration::Application](#)

[ISwDMConfigurationMgr::Application](#)

See Also

[ISwDMApplication5 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMApplication Interface](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)

ISwDMApplication5 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMApplication5 Interface

The following tables list the members exposed by [ISwDMApplication5](#).

Public Methods

Name	Description
 GetPreviewBitmapForAnnotationFiles	Gets the preview bitmap for the specified annotation file.

[Top](#)

See Also

[ISwDMApplication5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication Interface](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMApplication5 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMApplication5 Interface

For a list of all members of this type, see [ISwDMApplication5 members](#).

Public Methods

Name	Description
 GetPreviewBitmapForAnnotationFiles	Gets the preview bitmap for the specified annotation file.

[Top](#)

See Also

[ISwDMApplication5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication Interface](#)
[ISwDMApplication2 Interface](#)
[ISwDMApplication3 Interface](#)
[ISwDMApplication4 Interface](#)
[ISwDMClassFactory Interface](#)
[ISwDMDocument Interface](#)
[ISwDMSearchOption Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPreviewBitmapForAnnotationFiles Method (ISwDMApplication5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMApplication5 Interface](#) : GetPreviewBitmapForAnnotationFiles Method (ISwDMApplication5)

Gets the preview bitmap for the specified annotation file.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPreviewBitmapForAnnotationFiles( _  
    ByVal fileName As System.String, _  
    ByRef result As SwDmAnnotationFileOpenError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMApplication5  
Dim fileName As System.String  
Dim result As SwDmAnnotationFileOpenError  
Dim value As System.Object
```

```
value = instance.GetPreviewBitmapForAnnotationFiles(fileName, result)
```

C#

```
System.object GetPreviewBitmapForAnnotationFiles(  
    System.string fileName,
```

```
        out SwDmAnnotationFileOpenError result
    )
```

C++/CLI

```
System.Object^ GetPreviewBitmapForAnnotationFiles(
& System.String^ fileName,
& [Out] SwDmAnnotationFileOpenError result
)
```

Parameters

fileName

Name of annotation file

result

Error code as defined by [SwDmAnnotationFileOpenError](#)

Return Value

Pointer to the preview bitmap (.bmp) (an IPictureDisp*)

Visual Basic for Applications (VBA) Syntax

See [SwDMAApplication5::GetPreviewBitmapForAnnotationFiles](#).

Example

Tailor the examples for [ISwDMDocument10::GetPreviewBitmap](#) to call this method after opening an annotation file.

Remarks

This method is only valid for getting the preview bitmaps of the following annotation file types:

*.SLDNOTESTL

*.SLDGTOLSTL

*.SLDSFSTL

*.SLDWELDESTL

*.SLDSFFVT

*.SLDGTOLFVT

*.SLDWELDFVT

*.SLDNOTEFVT

See Also

[ISwDMAApplication5 Interface](#)

[ISwDMAApplication5 Members](#)

[ISwDMDocument10::GetPreviewBitmap Method \(\)](#)

[ISwDMDocument10::GetPreviewPNGBitmap Method \(\)](#)

[ISwDMConfiguration::GetPreviewBitmap Method \(\)](#)

[ISwDMConfiguration7::GetPreviewPNGBitmap Method \(\)](#)

[ISwDMSheet2::GetPreviewPNGBitmap Method \(\)](#)

[ISwDMSheet2::GetPreviewPNGBitmapBytes Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2024 SP1

ISwDMClassFactory (Type)

ISwDMClassFactory Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMClassFactory Interface

Allows you to use the SOLIDWORKS Document Manager API, which requires a valid [license key](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMClassFactory

Visual Basic (Usage)

Dim instance As [ISwDMClassFactory](#)

C#

public interface ISwDMClassFactory

C++/CLI

public interface class ISwDMClassFactory

Visual Basic for Applications (VBA) Syntax

See [SwDMClassFactory](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)
[Get Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)
[Get Whether Component is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component is Envelope and Excluded from BOM \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)
[Get Drawing Sheets' Properties \(C#\)](#)
[Get Drawing Sheets' Properties \(VB.NET\)](#)

Remarks

See the **Application Basics** section in the [Getting Started](#) topic for details on how to write a SOLIDWORKS Document Manager application.

See Also

[ISwDMClassFactory Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMApplication Interface](#)

ISwDMClassFactory Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMClassFactory Interface

The following tables list the members exposed by [ISwDMClassFactory](#).

Public Methods

Name	Description
 GetApplication	Gets the application object for the SOLIDWORKS Document Manager API.

[Top](#)

See Also

[ISwDMClassFactory Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMAApplication Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMClassFactory Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMClassFactory Interface

For a list of all members of this type, see [ISwDMClassFactory members](#).

Public Methods

Name	Description
 GetApplication	Gets the application object for the SOLIDWORKS Document Manager API.

[Top](#)

See Also

[ISwDMClassFactory Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMAApplication Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetApplication Method (ISwDMClassFactory)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMClassFactory Interface](#) : GetApplication Method (ISwDMClassFactory)

Gets the application object for the SOLIDWORKS Document Manager API.

.NET Syntax

Visual Basic (Declaration)

```
Function GetApplication( _  
    ByVal LicKey As System.String _  
) As SwDMAApplication
```

Visual Basic (Usage)



```
Dim instance As ISwDMClassFactory  
Dim LicKey As System.String  
Dim value As SwDMAApplication  
  
value = instance.GetApplication(LicKey)
```

C#

```
SwDMAApplication GetApplication(  
    System.string LicKey  
)
```

C++/CLI

```
SwDMAApplication^ GetApplication(  
& System.String^ LicKey  
)
```

Parameters

LicKey
License key

Return Value

Pointer to the [ISwDMAApplication](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMClassFactory::GetApplication](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)
[Write Parasolid Partition Stream to File \(C++\)](#)
[Open and Close Document \(C++\)](#)

See Also

[ISwDMClassFactory Interface](#)
[ISwDMClassFactory Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

ISwDMComponent (Type)

ISwDMComponent Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMComponent

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [ISwDMComponent](#)

C#

public interface ISwDMComponent

C++/CLI

public interface class ISwDMComponent

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

This object only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later.

Accessors

[ISwDMConfiguration2::Get Components](#)

See Also

- [ISwDMComponent Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent7 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)
- [ISwDMComponent12 Interface](#)

ISwDMComponent Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent Interface

The following tables list the members exposed by [ISwDMComponent](#).

Public Properties

Name	Description
 ConfigurationName	Gets the name of the configuration for this component.
 Name	Obsolete. Superseded by ISwDMComponent11::Name3 .
 Transform	Gets the transform for this component.

[Top](#)

Public Methods

Name	Description
 IsHidden	Gets whether or not the component is hidden.
 IsSuppressed	Gets whether or not the component is suppressed.

[Top](#)

See Also

[ISwDMComponent Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent Interface

For a list of all members of this type, see [ISwDMComponent members](#).

Public Methods

Name	Description
 IsHidden	Gets whether or not the component is hidden.
 IsSuppressed	Gets whether or not the component is suppressed.

[Top](#)

See Also

[ISwDMComponent Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent Interface

For a list of all members of this type, see [ISwDMComponent members](#).

Public Properties

Name	Description
 ConfigurationName	Gets the name of the configuration for this component.
 Name	Obsolete. Superseded by ISwDMComponent11::Name3
 Transform	Gets the transform for this component.

[Top](#)

See Also

[ISwDMComponent Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ConfigurationName Property (ISwDMComponent)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent Interface](#) : ConfigurationName Property (ISwDMComponent)

Gets the name of the configuration for this component.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ConfigurationName As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMComponent
Dim value As System.String

value = instance.ConfigurationName
```

C#

```
System.string ConfigurationName {get;}
```

C++/CLI

```
property System.String^ ConfigurationName {
    System.String^ get();
}
```

Property Value

Name of the configuration for this component

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent::ConfigurationName](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

This property only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMComponent Interface](#)
[ISwDMComponent Members](#)
[ISwDMComponent::Name Property](#)
[ISwDMConfiguration::GetParentConfigurationName Method](#)
[ISwDMConfiguration7::Name2 Property](#)
[ISwDMConfigurationMgr::GetActiveConfigurationName Method](#)
[ISwDMConfigurationMgr::GetConfigurationByName Method](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsHidden Method (ISwDMComponent)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent Interface](#) : IsHidden Method (ISwDMComponent)

Gets whether or not the component is hidden.

.NET Syntax

Visual Basic (Declaration)

```
Function IsHidden() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent  
Dim value As System.Boolean  
  
value = instance.IsHidden()
```

C#

```
System.bool IsHidden()
```

C++/CLI

```
System.bool IsHidden();
```

Return Value

True if component is hidden, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent::IsHidden](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMComponent Interface](#)
[ISwDMComponent Members](#)
[ISwDMComponent::IsSuppressed Method](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsSuppressed Method (ISwDMComponent)

[See Also](#)



Gets whether or not the component is suppressed.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSuppressed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent  
Dim value As System.Boolean  
  
value = instance.IsSuppressed()
```

C#

```
System.bool IsSuppressed()
```

C++/CLI

```
System.bool IsSuppressed();
```

Return Value

True if component is suppressed, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent::IsSuppressed](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMComponent Interface](#)
[ISwDMComponent Members](#)
[ISwDMComponent::IsHidden Method](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Name Property (ISwDMComponent)

[See Also](#) [Example](#)



SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMComponent Interface](#) : Name Property (ISwDMComponent)

Obsolete. Superseded by [ISwDMComponent11::Name3](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

Property Value

Name of the component

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent::Name](#).

Example

[Get Whether Component Is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)

Remarks

This property only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMComponent Interface](#)
[ISwDMComponent Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Transform Property (ISwDMComponent)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent Interface](#) : Transform Property (ISwDMComponent)

Gets the transform for this component.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Transform As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent  
Dim value As System.Object
```

```
value = instance.Transform
```

C#

```
System.object Transform {get;}
```

C++/CLI

```
property System.Object^ Transform {  
    System.Object^ get();  
}
```

Property Value

Array containing 16 elements that define the transform:

- First 12 elements are in a 4x3 matrix:
 $\begin{bmatrix} a & b & c \\ d & e & f \\ g & h & i \\ j & k & l \end{bmatrix}$
- Next 3 elements define translation:
 $\begin{bmatrix} m & n & o \end{bmatrix}$
- Last 1 element is the scaling value:
 $\begin{bmatrix} p \end{bmatrix}$

Be aware that the SOLIDWORKS API method `IComponent2::Transform2` returns an `IMathTransform` object, whose 16 elements are ordered differently. See the SOLIDWORKS API Help for details about `IComponent2::Transform2` and `IMathTransform`.

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent::Transform](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMComponent Interface](#)
[ISwDMComponent Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

ISwDMComponent10 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMComponent10 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent10 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent10
```

```
Inherits
```

```
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent10
```

C#

```
public interface ISwDMComponent10 :
```

```
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

C++/CLI

```
public interface class ISwDMComponent10 : public
```

```
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent10](#).

Example

[Get Component Reference \(VB.NET\)](#)

[Get Component Reference \(C#\)](#)

Remarks

- You can access an ISwDMComponent10 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be cast to an ISwDMComponent10 object by assignment, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent10 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent10 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent10 Interface

The following tables list the members exposed by [ISwDMComponent10](#).

Public Properties

Name	Description
 ComponentReference	Gets this component's reference.

[Top](#)

See Also

[ISwDMComponent10 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent10 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent10 Interface

For a list of all members of this type, see [ISwDMComponent10 members](#).

Public Properties

Name	Description
 ComponentReference	Gets this component's reference.

[Top](#)

See Also

[ISwDMComponent10 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ComponentReference Property (ISwDMComponent10)

[See Also](#)

 

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent10 Interface](#) : ComponentReference Property (ISwDMComponent10)

Gets this component's reference.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ComponentReference As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMComponent10  
Dim value As System.String  
  
value = instance.ComponentReference
```

C#

```
System.string ComponentReference {get;}
```

C++/CLI

```
property System.String^ ComponentReference {  
    System.String^ get();  
}
```

Property Value

Component reference

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent10::ComponentReference](#).

Example

See the [ISwDMComponent10](#) examples.

See Also

[ISwDMComponent10 Interface](#)
[ISwDMComponent10 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

ISwDMComponent11 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMComponent11 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent11 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent11
    Inherits
```

```
    ISwDMComponent, ISwDMComponent10, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent11
```

C#

```
public interface ISwDMComponent11 :
    ISwDMComponent, ISwDMComponent10, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

C++/CLI

```
public interface class ISwDMComponent11 : public
    ISwDMComponent, ISwDMComponent10, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent11](#).

Example

[Get Linked Display States \(VB.NET\)](#)

[Get Linked Display States \(C#\)](#)

Remarks

- You can access an ISwDMComponent11 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be cast to an ISwDMComponent11 object by assignment, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent11 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent11 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent11 Interface

The following tables list the members exposed by [ISwDMComponent11](#).

Public Properties

Name	Description
 Name3	Gets the full name of this component
 SelectName2	Gets the name of the component needed to specify in the component list in ISidWorks.IDocumentSpecification during a selective open using SidWorks.OpenDoc7 .

[Top](#)

See Also

[ISwDMComponent11 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent11 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent11 Interface

For a list of all members of this type, see [ISwDMComponent11 members](#).

Public Properties

Name	Description
 Name3	Gets the full name of this component
 SelectName2	Gets the name of the component needed to specify in the component list in ISidWorks.IDocumentSpecification during a selective open using SidWorks.OpenDoc7 .

[Top](#)

See Also

[ISwDMComponent11 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent Interface](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent12 Interface](#)

Name3 Property (ISwDMComponent11)

[See Also](#)

 

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent11 Interface](#) : Name3 Property (ISwDMComponent11)

Gets the full name of this component

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name3 As System.String
```

```
Dim instance As ISwDMComponent11
Dim value As System.String

value = instance.Name3
```

C#

```
System.string Name3 {get;}
```

C++/CLI

```
property System.String^ Name3 {
    System.String^ get();
}
```

Property Value

Full name of component

 Visual Basic for Applications (VBA) Syntax

See [SwDMComponent11::Name3](#).

 Example

See the [ISwDMComponent11](#) examples.

 Remarks

This property returns the component name appended with an index in the format, "component-1".

 See Also

[ISwDMComponent11 Interface](#)
[ISwDMComponent11 Members](#)

 Availability

SOLIDWORKS Document Manager API 2021 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

SelectName2 Property (ISwDMComponent11)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent11 Interface](#) : SelectName2 Property (ISwDMComponent11)

Gets the name of the component needed to specify in the component list in [ISldWorks::IDocumentSpecification](#) during a selective open using [SldWorks::OpenDoc7](#).

 .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SelectName2 As System.String
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ISwDMComponent11
Dim value As System.String

value = instance.SelectName2
```

C#

```
System.string SelectName2 {get;}
```

C++/CLI

```
property System.String^ SelectName2 {  
    System.String^ get();  
}
```

Property Value

Name to use during a selective open

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent11::SelectName2](#).

Example

See the [ISwDMComponent11](#) examples.

See Also

[ISwDMComponent11 Interface](#)
[ISwDMComponent11 Members](#)

Availability

SOLIDWORKS Document Manager API 2021 SP0

ISwDMComponent12 (Type)

ISwDMComponent12 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent12 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent12
    Inherits
    ISwDMComponent, ISwDMComponent10, ISwDMComponent11, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic (Usage)

```
Dim instance As ISwDMComponent12
```

C#

```
public interface ISwDMComponent12 :
    ISwDMComponent, ISwDMComponent10, ISwDMComponent11, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

C++/CLI

```
public interface class ISwDMComponent12 : public
    ISwDMComponent, ISwDMComponent10, ISwDMComponent11, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8, ISwDMComponent9
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent12](#).

Remarks

- You can access an ISwDMComponent12 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be cast to an ISwDMComponent12 object by assignment, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

- [ISwDMComponent12 Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMComponent Interface](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent7 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)

ISwDMComponent12 Interface Members

[See Also](#) [Methods](#)



The following tables list the members exposed by [ISwDMComponent12](#).

Public Methods

Name	Description
 GetCustomProperty	Gets the specified custom property for this component.

[Top](#)

See Also

- [ISwDMComponent12 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMComponent Interface](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent7 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)

ISwDMComponent12 Interface Methods

[See Also](#)

For a list of all members of this type, see [ISwDMComponent12 members](#).

Public Methods

Name	Description
 GetCustomProperty	Gets the specified custom property for this component.

[Top](#)

See Also

- [ISwDMComponent12 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMComponent Interface](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent7 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)

GetCustomProperty Method (ISwDMComponent12)

[See Also](#) [Example](#)

Gets the specified custom property for this component.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomProperty( _  
    ByVal FieldName As System.String, _  
    ByRef type As System.Integer _  
    ) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent12
Dim FieldName As System.String
Dim type As System.Integer
Dim value As System.String

value = instance.GetCustomProperty(FieldName, type)
```

C#

```
System.string GetCustomProperty(
    System.string FieldName,
    out System.int type
)
```

C++/CLI

```
System.String^ GetCustomProperty(
    & System.String^ FieldName,
    & [Out] System.int type
)
```

Parameters

FieldName

Name of custom property

type

Type of custom property as defined by [SwDMCustomInfoType](#)

Return Value

Value of the custom property

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent12::GetCustomProperty](#).

Example

[Get Configuration-Specific Custom Properties for Components \(VB.NET\)](#)
[Get Configuration-Specific Custom Properties for Components \(C#\)](#)

See Also

[ISwDMComponent12 Interface](#)
[ISwDMComponent12 Members](#)

Availability

SOLIDWORKS Document Manager API 2024 SP0

ISwDMComponent2 (Type)

ISwDMComponent2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMComponent2 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent2
    Inherits ISwDMComponent
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent2
```

C#

```
public interface ISwDMComponent2 : ISwDMComponent
```

C++/CLI

```
public interface class ISwDMComponent2 : public ISwDMComponent
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent2](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent2 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent2 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent2 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent2 Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [ISwDMComponent2](#).

 Public Properties

Name	Description
 DocumentType	Gets the component's document type.

[Top](#)

 See Also

[ISwDMComponent2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent2 Interface Properties

[See Also](#)


SolidWorks.Interop.swdocumentmgr Namespace : ISwDMComponent2 Interface

For a list of all members of this type, see [ISwDMComponent2 members](#).

 Public Properties

Name	Description
 DocumentType	Gets the component's document type.

[Top](#)

 See Also

[ISwDMComponent2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

DocumentType Property (ISwDMComponent2)

[See Also](#)

 
SolidWorks.Interop.swdocumentmgr Namespace > ISwDMComponent2 Interface : DocumentType Property (ISwDMComponent2)

Gets the component's document type.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property DocumentType As [SwDmDocumentType](#)

Visual Basic (Usage)

```
Dim instance As ISwDMComponent2  
Dim value As SwDmDocumentType  
  
value = instance.DocumentType
```

C#



```
SwDmDocumentType DocumentType {get;}
```

C++/CLI

```
property SwDmDocumentType DocumentType {  
    SwDmDocumentType get();  
}
```

Property Value

Component's document type as defined in [swDMDocumentType](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent2::DocumentType](#).

Remarks

This property can distinguish between components and sub-assemblies whose names are the same.

See Also

[ISwDMComponent2 Interface](#)
[ISwDMComponent2 Members](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS