

SOLIDWORKS Document Manager API (VB6 COM)

— Reference (1/8): ISwDMApplication3- ISwDMDimXpertCompoundHoleFeature

SOLIDWORKS API Documentation (converted from CHM)

ISwDMApplication3 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMApplication3 Object

Object Model

ISwDMApplication3

GetExternalReferenceOptionObject (SwDMExternalReferenceOption)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMApplication3 Object Members

Public Methods

 [GetExternalReferenceOptionObject](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetExternalReferenceOptionObject Method (ISwDMApplication3)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExternalReferenceOptionObject() As SwDMExternalReferenceOption
```

ISwDMApplication4 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMApplication4 Object

Object Model

ISwDMApplication4

GetExternalReferenceOptionObject2 (SwDMExternalReferenceOption2)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMApplication4 Object Members

Public Methods

 [GetExternalReferenceOptionObject2](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetExternalReferenceOptionObject2 Method (ISwDMApplication4)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExternalReferenceOptionObject2() As SwDMExternalReferenceOption2
```

ISwDMApplication5 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMApplication5 Object

Object Model

ISwDMApplication5

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMApplication5 Object Members

Public Methods

 [GetPreviewBitmapForAnnotationFiles](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetPreviewBitmapForAnnotationFiles Method (ISwDMApplication5)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPreviewBitmapForAnnotationFiles( _  
    ByVal fileName As String, _  
    ByRef result As SwDmAnnotationFileOpenError _  
    ) As Object
```

ISwDMComponent10 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent10 Object

 Object Model

ISwDMComponent10

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent10 Object Members



 Public Properties

 [ComponentReference](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ComponentReference Property (ISwDMComponent10)

 Syntax

Visual Basic for Applications (VBA)

Public Property ComponentReference As String

ISwDMComponent11 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent11 Object

 Object Model

ISwDMComponent11

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent11 Object Members

 Public Properties

 [Name3](#)

 [SelectName2](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

Name3 Property (ISwDMComponent11)

 Syntax

Visual Basic for Applications (VBA)

Public Property Name3 As String

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

SelectName2 Property (ISwDMComponent11)

 Syntax

Visual Basic for Applications (VBA)

Public Property SelectName2 As String

ISwDMComponent12 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent12 Object

 Object Model

ISwDMComponent12

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent12 Object Members



 Public Methods

 [GetCustomProperty](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetCustomProperty Method (ISwDMComponent12)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCustomProperty( _  
    ByVal FieldName As String, _  
    ByRef type As Long _  
) As String
```

ISwDMComponent7 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMComponent7 Object

Object Model

ISwDMComponent7

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMComponent7 Object Members



Public Properties

 [Name2](#)

 [SelectName](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Name2 Property (ISwDMComponent7)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Name2 As String
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

SelectName Property (ISwDMComponent7)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SelectName As String
```

ISwDMComponent8 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent8 Object

 Object Model

ISwDMComponent8

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent8 Object Members



 Public Properties

 [ConfigurationID](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ConfigurationID Property (ISwDMComponent8)

 Syntax

Visual Basic for Applications (VBA)

Public Property ConfigurationID As Long

ISwDMComponent9 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent9 Object

 Object Model

ISwDMComponent9

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMComponent9 Object Members



 Public Methods

 [GetID](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetID Method (ISwDMComponent9)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetID() As Long

ISwDMConfiguration11 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration11 Object

Object Model

ISwDMConfiguration11

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration11 Object Members

Public Methods

 [GetReplacedComponents](#)

 [IsSpeedPak](#)

Public Properties

 [BOMPartNoSource](#)

 [ShowChildComponentsInBOM](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

BOMPartNoSource Property (ISwDMConfiguration11)

Syntax

Visual Basic for Applications (VBA)

Public Property BOMPartNoSource As Long

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetReplacedComponents Method (ISwDMConfiguration11)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReplacedComponents( _  
    ByRef ComponentNames As Variant, _  
    ByRef ConfigurationNames As Variant, _  
    ByRef NewFileNames As Variant, _  
    ByRef MatesReattached As Variant _  
) As HRESULT
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsSpeedPak Method (ISwDMConfiguration11)

Syntax

Visual Basic for Applications (VBA)

Public Function IsSpeedPak() As Boolean

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ShowChildComponentsInBOM Property (ISwDMConfiguration11)

Syntax

Visual Basic for Applications (VBA)

Public Property ShowChildComponentsInBOM As Long

ISwDMConfiguration12 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration12 Object

Object Model

ISwDMConfiguration12

DimXpertPart (SwMDimXpertPart)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration12 Object Members

Public Methods

 [GetComponentVisibleByDisplayStateName](#)

 [GetID](#)

 [GetLinkedDisplayStates](#)

Public Properties

 [DimXpertPart](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

DimXpertPart Property (ISwDMConfiguration12)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DimXpertPart As SwMDimXpertPart
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetComponentVisibleByDisplayStateName Method (ISwDMConfiguration12)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetComponentVisibleByDisplayStateName( _  
    ByVal DisplayStateName As String, _  
    ByRef ComponentVisibleList As Variant, _  
    ByRef ComponentFileDirectory As Variant _  
) As HRESULT
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetID Method (ISwDMConfiguration12)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetID() As Long
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetLinkedDisplayStates Method (ISwDMConfiguration12)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLinkedDisplayStates( _  
    ByRef DisplayStateNameList As Variant _  
) As Long
```

ISwDMConfiguration13 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration13 Object

 Object Model

ISwDMConfiguration13

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration13 Object Members



 Public Properties

 [type](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

type Property (ISwDMConfiguration13)

 Syntax

Visual Basic for Applications (VBA)

Public Property type As Long

ISwDMConfiguration14 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration14 Object

 Object Model

ISwDMConfiguration14

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration14 Object Members



 Public Methods

 [GetCustomProperty2](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetCustomProperty2 Method (ISwDMConfiguration14)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCustomProperty2( _  
    ByVal FieldName As String, _  
    ByRef type As SwDmCustomInfoType _  
) As String
```

ISwDMConfiguration15 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration15 Object

Object Model

ISwDMConfiguration15

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration15 Object Members

Public Methods

[IsCustomPropertyEditable](#)

Public Properties

[ShowChildComponentsInBOM2](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsCustomPropertyEditable Method (ISwDMConfiguration15)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCustomPropertyEditable( _  
    ByVal FieldName As String, _  
    ByRef IsEditable As Boolean _  
) As HRESULT
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ShowChildComponentsInBOM2 Property (ISwDMConfiguration15)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowChildComponentsInBOM2 As Long
```

ISwDMConfiguration16 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration16 Object

Object Model

ISwDMConfiguration16

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration16 Object Members

Public Methods

 [GetCutListItems](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetCutListItems Method (ISwDMConfiguration16)

Syntax

Visual Basic for Applications (VBA)

Public Function GetCutListItems() As Variant

ISwDMConfiguration17 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration17 Object

Object Model

ISwDMConfiguration17

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfiguration17 Object Members

Public Methods

 [Get3DExperienceType](#)

 [GetRepresentationParent](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Get3DExperienceType Method (ISwDMConfiguration17)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DExperienceType() As Long
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetRepresentationParent Method (ISwDMConfiguration17)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRepresentationParent() As String
```

ISwDMConfiguration18 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration18 Object

Object Model

ISwDMConfiguration18

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ISwDMConfiguration18 Object Members

Public Methods

 [SetCustomProperty2](#)

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

SetCustomProperty2 Method (ISwDMConfiguration18)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetCustomProperty2( _  
    ByVal FieldName As String, _  
    ByVal newValue As String _  
) As Boolean
```

ISwDMConfigurationMgr2 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfigurationMgr2 Object

Object Model

ISwDMConfigurationMgr2

GetConfigurationByName2 (SwDMConfiguration)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMConfigurationMgr2 Object Members

Public Methods

 [GetConfigurationByName2](#)

 [GetConfigurationCount2](#)

 [GetConfigurationNames2](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetConfigurationByName2 Method (ISwDMConfigurationMgr2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConfigurationByName2( _  
    ByVal ConfigurationName As String, _  
    ByRef result As SwDMConfigurationError _  
) As SwDMConfiguration
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetConfigurationCount2 Method (ISwDMConfigurationMgr2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConfigurationCount2( _  
    ByRef result As SwDMConfigurationError _  
) As Long
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetConfigurationNames2 Method (ISwDMConfigurationMgr2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConfigurationNames2( _  
    ByRef result As SwDMConfigurationError _  
) As Variant
```

ISwDMCutListItem3 (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMCutListItem3 Object

Object Model

ISwDMCutListItem3

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMCutListItem3 Object Members



Public Methods

[IsCustomPropertyEditable](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsCustomPropertyEditable Method (ISwDMCutListItem3)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCustomPropertyEditable( _  
    ByVal FieldName As String, _  
    ByRef IsEditable As Boolean _  
) As HRESULT
```

ISwDMCutListItem4 (Type)

SOLIDWORKS Document Manager Type Library

ISwDMCutListItem4 Object

[Send comments on this topic.](#)

 Object Model

ISwDMCutListItem4

SOLIDWORKS Document Manager Type Library

ISwDMCutListItem4 Object Members

[Send comments on this topic.](#)

 Public Properties

 [CutlistType](#)

 [ExcludeFromCutlist](#)

SOLIDWORKS Document Manager Type Library

CutlistType Property (ISwDMCutListItem4)

[Send comments on this topic.](#)

 Syntax

Visual Basic for Applications (VBA)

Public Property CutlistType As [swDMCutListType_e](#)

SOLIDWORKS Document Manager Type Library

ExcludeFromCutlist Property (ISwDMCutListItem4)

[Send comments on this topic.](#)

 Syntax

Visual Basic for Applications (VBA)

Public Property ExcludeFromCutlist As [swDMCutListExclusionStatus_e](#)

ISwDMDimXpertAngleBetweenDimTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAngleBetweenDimTol Object

Object Model

ISwDMDimXpertAngleBetweenDimTol

OriginFeature (SwDMDimXpertFeature)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAngleBetweenDimTol Object Members

Public Methods

 [GetDirectionVector](#)

Public Properties

 [OriginFeature](#)

 [Supplement](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetDirectionVector Method (ISwDMDimXpertAngleBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDirectionVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

OriginFeature Property (ISwDMDimXpertAngleBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OriginFeature As SwDMDimXpertFeature
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Supplement Property (ISwDMDimXpertAngleBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Supplement As Boolean
```

ISwDMDimXpertAngularityGeoTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAngularityGeoTol Object

 Object Model

ISwDMDimXpertAngularityGeoTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAngularityGeoTol Object Members



ISwDMDimXpertAnnotation (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAnnotation Object

Object Model

ISwDMDimXpertAnnotation

Feature (SwDMDimXpertFeature)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertAnnotation Object Members

Public Methods

 [GetCadIdentifierCount](#)

 [GetCadIdentifiers](#)

 [IGetCadIdentifiers](#)

 [IsFreeState](#)

 [IsStatistical](#)

 [IsSuppressed](#)

 [IsToBeInspected](#)

Public Properties

 [Feature](#)

 [Name](#)

 [Type](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Feature Property (ISwDMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property Feature As [SwDMDimXpertFeature](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetCadIdentifierCount Method (ISwDMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Function GetCadIdentifierCount() As Long

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetCadIdentifiers Method (ISwDMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Function GetCadIdentifiers() As Variant

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IGetCadIdentifiers Method (ISwDMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetCadIdentifiers( _  
    ByVal Count As Long _  
    ) As String
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsFreeState Method (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsFreeState() As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsStatistical Method (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsStatistical() As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsSuppressed Method (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSuppressed() As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IsToBeInspected Method (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsToBeInspected() As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Name Property (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Name As String
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

type Property (ISwMDimXpertAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Property type As swDmDimXpertAnnotationType\_e
```

ISwDMDimXpertBestFitPlaneFeature (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertBestFitPlaneFeature Object

Object Model

ISwDMDimXpertBestFitPlaneFeature

IGetSubFeatures (SwDMDimXpertFeature)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertBestFitPlaneFeature Object Members

Public Methods

 [GetNominalPlane](#)

 [GetSubFeatureCount](#)

 [GetSubFeatures](#)

 [IGetSubFeatures](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetNominalPlane Method (ISwDMDimXpertBestFitPlaneFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetSubFeatureCount Method (ISwDMDimXpertBestFitPlaneFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatureCount() As Long
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatures() As Variant
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IGetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSubFeatures( _  
    ByVal Count As Long _  
    ) As SwDMDimXpertFeature
```


ISwDMDimXpertBlockTolerances (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertBlockTolerances Object

Object Model

ISwDMDimXpertBlockTolerances

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertBlockTolerances Object Members

Public Methods

 [GetISO2768PartType](#)

 [GetToleranceValues](#)

Public Properties

 [Type](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetISO2768PartType Method (ISwDMDimXpertBlockTolerances)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetISO2768PartType( _  
    ByRef type As swDmDimXpertISO2768PartType\_e _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetToleranceValues Method (ISwDMDimXpertBlockTolerances)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetToleranceValues( _  
    ByRef Linear1 As Double, _  
    ByRef Linear1Prec As Long, _  
    ByRef Linear2 As Double, _  
    ByRef Linear2Prec As Long, _  
    ByRef Linear3 As Double, _  
    ByRef Linear3Prec As Long, _  
    ByRef Angular As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

type Property (ISwDMDimXpertBlockTolerances)

Syntax

Visual Basic for Applications (VBA)

```
Public Property type As swDmDimXpertBlockToleranceType\_e
```

ISwDMDimXpertChamferDimTol (Type)

SOLIDWORKS Document Manager Type Library

ISwDMDimXpertChamferDimTol Object

[Send comments on this topic.](#)

Object Model

ISwDMDimXpertChamferDimTol

SOLIDWORKS Document Manager Type Library

ISwDMDimXpertChamferDimTol Object Members

[Send comments on this topic.](#)

Public Properties

ChamferType

SOLIDWORKS Document Manager Type Library

ChamferType Property (ISwDMDimXpertChamferDimTol)

[Send comments on this topic.](#)

Syntax

Visual Basic for Applications (VBA)

Public Property ChamferType As [swDmDimXpertChamferDimensionType_e](#)

ISwDMDimXpertChamferFeature (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertChamferFeature Object

Object Model

ISwDMDimXpertChamferFeature

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertChamferFeature Object Members

Public Properties

 [Angle](#)

 [AngleType](#)

 [ChamferType](#)

 [Distance1](#)

 [Distance2](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Angle Property (ISwDMDimXpertChamferFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Angle As Double

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

AngleType Property (ISwDMDimXpertChamferFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property AngleType As [swDmDimXpertChamferAngleType_e](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ChamferType Property (ISwDMDimXpertChamferFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property ChamferType As [swDmDimXpertChamferType_e](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Distance1 Property (ISwDMDimXpertChamferFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Distance1 As Double

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Distance2 Property (ISwDMDimXpertChamferFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Distance2 As Double

ISwDMDimXpertCircularityGeoTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCircularityGeoTol Object

 Object Model

ISwDMDimXpertCircularityGeoTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCircularityGeoTol Object Members



ISwDMDimXpertCircularRunoutGeoTol (Type)

SOLIDWORKS Document Manager Type Library	Send comments on this topic.
ISwDMDimXpertCircularRunoutGeoTol Object	

 Object Model

ISwDMDimXpertCircularRunoutGeoTol

SOLIDWORKS Document Manager Type Library	Send comments on this topic.
ISwDMDimXpertCircularRunoutGeoTol Object Members	
	

ISwDMDimXpertCompositeDistanceBetweenDimTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeDistanceBetweenDimTol Object

Object Model

ISwDMDimXpertCompositeDistanceBetweenDimTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeDistanceBetweenDimTol Object Members

Public Methods

-  [GetDirectionVector](#)
-  [GetFeature](#)
-  [GetIntraFeature](#)
-  [GetNominalValueIntraFeature](#)
-  [GetOriginFeature](#)
-  [GetPlusAndMinusToleranceIntraFeature](#)
-  [GetUpperAndLowerLimitIntraFeature](#)

Public Properties

-  [BlockToleranceDecimalPlacesIntraFeature](#)
-  [DimensionTypeIntraFeature](#)
-  [LimitsAndFitsCodeIntraFeature](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

BlockToleranceDecimalPlacesIntraFeature Property (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

Public Property BlockToleranceDecimalPlacesIntraFeature As Long

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

DimensionTypeIntraFeature Property (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

Public Property DimensionTypeIntraFeature As [swDmDimXpertDimensionToleranceType_e](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetDirectionVector Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDirectionVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
    ) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature( _  
    ByRef Feature As SwDMDimXpertFeature, _  
    ByRef FosUsage As swDmDimXpertDistanceFosUsage\_e _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntraFeature( _  
    ByRef Feature As SwDMDimXpertFeature, _  
    ByRef FosUsage As swDmDimXpertDistanceFosUsage\_e _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetNominalValueIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalValueIntraFeature() As Double
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetOriginFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOriginFeature( _  
    ByRef Feature As SwDMDimXpertFeature, _  
    ByRef FosUsage As swDmDimXpertDistanceFosUsage\_e _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetPlusAndMinusToleranceIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlusAndMinusToleranceIntraFeature( _  
    ByRef Plus As Double, _  
    ByRef Minus As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetUpperAndLowerLimitIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUpperAndLowerLimitIntraFeature( _  
    ByRef Upper As Double, _  
    ByRef Lower As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

LimitsAndFitsCodeIntraFeature Property (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Syntax

Visual Basic for Applications (VBA)

Public Property LimitsAndFitsCodeIntraFeature As String

ISwDMDimXpertCompositeLineProfileGeoTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeLineProfileGeoTol Object

Object Model

ISwDMDimXpertCompositeLineProfileGeoTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeLineProfileGeoTol Object Members

Public Methods

 [GetPlanarZoneVector](#)

Public Properties

 [OuterToleranceValue](#)

 [OuterToleranceValueLowerTier](#)

 [PrimaryInLowerTier](#)

 [SecondaryInLowerTier](#)

 [TertiaryInLowerTier](#)

 [ToleranceLowerTier](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetPlanarZoneVector Method (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlanarZoneVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

OuterToleranceValue Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OuterToleranceValue As Double
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OuterToleranceValueLowerTier As Double
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

PrimaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PrimaryInLowerTier As Boolean
```

SecondaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SecondaryInLowerTier As Boolean
```

TertiaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TertiaryInLowerTier As Boolean
```

ToleranceLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ToleranceLowerTier As Double
```

ISwDMDimXpertCompositePositionGeoTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositePositionGeoTol Object

Object Model

ISwDMDimXpertCompositePositionGeoTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositePositionGeoTol Object Members

Public Methods

 GetMaxTolerance
 GetMaxToleranceLowerTier
 GetPlanarZoneVector
 GetProjectedZone

Public Properties

 Modifier
 ModifierLowerTier
 PrimaryInLowerTier
 SecondaryInLowerTier
 TertiaryInLowerTier
 ToleranceLowerTier
 ZoneType

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetMaxTolerance Method (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetMaxTolerance(_ ByRef <i>IsMax</i> As Boolean, _ ByRef <i>Tolerance</i> As Double _) As Boolean</pre>

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetMaxToleranceLowerTier Method (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetMaxToleranceLowerTier(_ ByRef <i>IsMax</i> As Boolean, _ ByRef <i>Tolerance</i> As Double _) As Boolean</pre>

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetPlanarZoneVector Method (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlanarZoneVector( _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetProjectedZone Method (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProjectedZone( _  
    ByRef Enabled As Boolean, _  
    ByRef Value As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Modifier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Modifier As swDmDimXpertMaterialConditionModifier\_e
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ModifierLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ModifierLowerTier As swDmDimXpertMaterialConditionModifier\_e
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

PrimaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PrimaryInLowerTier As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

SecondaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SecondaryInLowerTier As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

TertiaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TertiaryInLowerTier As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ToleranceLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Syntax

Visual Basic for Applications (VBA)

Public Property ToleranceLowerTier As Double

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ZoneType Property (ISwDMDimXpertCompositePositionGeoTol)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property ZoneType As [swDmDimXpertPositionZoneType_e](#)

ISwDMDimXpertCompositeSurfaceProfileGeoTol (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeSurfaceProfileGeoTol Object

Object Model

ISwDMDimXpertCompositeSurfaceProfileGeoTol

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompositeSurfaceProfileGeoTol Object Members

Public Properties

 [OuterToleranceValue](#)

 [OuterToleranceValueLowerTier](#)

 [PrimaryInLowerTier](#)

 [SecondaryInLowerTier](#)

 [TertiaryInLowerTier](#)

 [ToleranceLowerTier](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

OuterToleranceValue Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OuterToleranceValue As Double
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OuterToleranceValueLowerTier As Double
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

PrimaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PrimaryInLowerTier As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

SecondaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SecondaryInLowerTier As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

TertiaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Syntax

Visual Basic for Applications (VBA)

Public Property TertiaryInLowerTier As Boolean

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

ToleranceLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)



Visual Basic for Applications (VBA)

Public Property ToleranceLowerTier As Double

ISwDMDimXpertCompoundClosedSlot3dFeature (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompoundClosedSlot3dFeature Object

Object Model

ISwDMDimXpertCompoundClosedSlot3dFeature

GetBottomFeature (SwDMDimXpertFeature)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompoundClosedSlot3dFeature Object Members

Public Methods

 [GetBottomFeature](#)

 [GetEndFeatures](#)

 [GetNominalBottomPlane](#)

 [GetNominalClosedSlot](#)

 [GetNominalTopPlane](#)

 [GetPlaneFeatures](#)

Public Properties

 [Blind](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Blind Property (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

Public Property Blind As Boolean

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetBottomFeature Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

Public Function GetBottomFeature() As [SwDMDimXpertFeature](#)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetEndFeatures Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEndFeatures( _  
    ByRef End1 As SwDMDimXpertFeature, _  
    ByRef End2 As SwDMDimXpertFeature _  
    ) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetNominalBottomPlane Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalBottomPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetNominalClosedSlot Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalClosedSlot( _  
    ByRef width As Double, _  
    ByRef Length As Double, _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double, _  
    ByRef LongitudeI As Double, _  
    ByRef LongitudeJ As Double, _  
    ByRef LongitudeK As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetNominalTopPlane Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNominalTopPlane( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double, _  
    ByRef I As Double, _  
    ByRef J As Double, _  
    ByRef K As Double _  
) As Boolean
```

SOLIDWORKS Document Manager Type Library

[Send comments on this topic.](#)

GetPlaneFeatures Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlaneFeatures( _  
    ByRef Plane1 As SwDMDimXpertPlaneFeature, _  
    ByRef Plane2 As SwDMDimXpertPlaneFeature _  
) As Boolean
```


ISwDMDimXpertCompoundHoleFeature (Type)

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompoundHoleFeature Object

Object Model



SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

ISwDMDimXpertCompoundHoleFeature Object Members

Public Methods

	GetBottomFeature
	GetReferenceFeature
	GetSubFeatureCount
	GetSubFeatures
	IGetSubFeatures

Public Properties

	Blind
---	-----------------------

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

Blind Property (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)
Public Property Blind As Boolean

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetBottomFeature Method (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)
Public Function GetBottomFeature() As SwDMDimXpertFeature

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetReferenceFeature Method (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)
Public Function GetReferenceFeature() As SwDMDimXpertFeature

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetSubFeatureCount Method (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatureCount() As Long
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

GetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSubFeatures() As Variant
```

SOLIDWORKS Document Manager Type Library

[Send comments](#) on this topic.

IGetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSubFeatures( _  
    ByVal Count As Long _  
) As SwDMDimXpertFeature
```