To calculate conveyor pulse per inch:

The goal is to calculate how many inches a roller travels for 20 pulses then divide the inch measurement by 20.

- 1. Lay a tape measure out starting where the roller comes out of the gate
- 2. Start the conveyor
- 3. Have a helper watch the TCS ready to count out pulses
- 4. Manually run a roller up,
- 5. When the roller passes up the ramp onto the conveyor, have the helper start counting pulses from 1 to 20 out the over the phone
- 6. Follow the roller while the helper is counting
- 7. When the pulse count reaches 20, take note of the amount in inches the roller has traveled
- 8. Divide the amount traveled in inches by 20 pulses to calculate the pulse distance per inch