## **Conveyor Installation/Platform Process**

- \*Conveyor to be level for the first 25', regardless of FWP or RWP. (intent is to limit the roll of the car).
- \*On RWP, the first 15' section after the 25', should rise 1 1/2". It will continue on at approximately 1 1/2" above the PS determined elevation.
- \*On FWP, the first 15' after the 25', should fall 1". It will continue on at approximately 1" below the PS determined elevation.
- \*Do Not, manipulate the conveyor to overcome the concrete.
- \*Most concrete is not poured perfect. We are trying to establish an elevation like it was.
- \*Our main goal is for the conveyor to be straight, whether it be level or rising.

