

esp32-c3-devkitm-1

Top View

USB C Up

AITRIP

ESP32-C3 FN4 SUPER MINI

#	IAQ Device Use	boot button		reset button		IAQ Device Use	#
		Left	Right	Left	Right		
1	RX Safe	GPIO5/A5/MISO/ADC1_5		5V		5V	1
2	MOSI	GPIO6/MOSI		GND		GND	2
3	USB Detect	GPIO7/SS		3V3		3V3	3
4	SDA	GPIO8/SDA/I2C/LED		SCK/RX/A4/GPIO4/ADC1_4		from MHZ19 TX	4
5	SLC	GPIO9/SCL/I2C		A3/GPIO3/TX		from MHZ19 RX	5
6	Status LED/RX Safe	GPIO10		A2/GPIO2		Stay Awake Switch	6
7	from PMS TX	GPIO20/UART0_RX		A1/GPIO1		Deep Sleep Wake Button	7
8	from PMS RX	GPIO21/UART0_TX		A0/GPIO0		Safe Boot Button	8

BOTTOM VIEW