Produced by: AEROSPACE AND DEFENCE INDUSTRIES ASSOCIATION OF EUROPE

Brake system

Manual test

Table of Contents

References	1
Preliminary requirements	
Procedure	2
Requirements after job completion	2

List of Tables

1	References	•
2	Required conditions	•
3	Required persons	
4	Support equipment	•
5	Consumables, materials and expendables	2
6	Spares	2
7	Required conditions	2

References

Table 1 References

Data Module/Technical publication	Title
None	

Preliminary requirements

Required conditions

Table 2 Required conditions

Action/Condition	Data module/Technical publication
None	

Required persons

Table 3 Required persons

Person	Category	Skill Level	Trade/Trade code	Estimated time
Man A	Basic user		Operator	0,3 h

Support equipment

Table 4 Support equipment

Name	Identification/Reference	Quantity	Remark
None			

Consumables, materials and expendables

Table 5 Consumables, materials and expendables

Name	Identification/Reference	Quantity	Remark
None			

Spares

Table 6 Spares

Name	Identification/Reference	Quantity	Remark
None			

Safety Conditions

None

Procedure

- 1 Pre-Operational Checks
- 1.1 Inspect the brake lever for signs of wear or corrosion.
- 1.2 Ensure the hydraulic fluid is at the recommended level.
- 1.3 Verify that all mounting bolts are properly secured.
- 2 Put the bicycle in a vertical position.
- 3 Hold the handle bars and push the bicycle forwards.
- 4 Apply the brakes.
- 5 Make sure that the wheels lock and the bicycle stops.

Requirements after job completion

Required conditions

Table 7 Required conditions

Action/Condition	Data module/Technical publication
None	

End of data module