## **GH60 Manual**

## (Poker-61key)

## 1. Introduction

- (1) GH60 mechanical keyboard with USB connection.
- (2) Automatic recognition and compatible with Windows, Android, Mac, IOS.
- (3) Keyboard can be re-programmable and re-flashed by QMK open source.
- (4) Technical surpport,email: laura\_zhou@126.com
- 2. PCBA is flashed with following layout



3. Fn+key Functions

		W	<u> </u>
		A	<b>←</b>
		S	<b>↓</b>
		D	<b>→</b>
	+	Q	RGB Toggle
		Е	RGB Mode
		R	RGB HUI(RGB hue increase)
		T	RGB HUD(RGB hue decrease)
		Y	RGB SAI(RGB saturation increase)
		U	RGB SAD(RGB saturation decrease)
		I	RGB VAI(RGB brightness increase)
Fn		0	RGB VAD(RGB brightness decrease)
		P	PrtSC
		[	ScrLK
		}]	Pause/Break
		• ;	Home
		<i>"</i>	PgUp
		X	Led-
		С	LED on/off
		V	Led+
		N	Vol-
		M	Mute
		< ,	Vo1+

>.
?/
Z

End							
PgDn							
Reset	or	enter	re-flashing	mode	of	QMK	

## 4. Reset:

Anything abnormal of the keyboard, you can reset it:

Press the metal button on the back of the PCBA (or press "Fn+Z"),

you'll reset the keyboard to default layout,unplug and re-plug the USB cable,the keyboard is workable again.

By the above reset method, you can also enter flashing mode of QMK.

4.Instructions for removing of the Modifier with the stabilizers

Use hard tweezers to strongly hold the bean of the stabilizers, then remove the keycap little by little, end by end. (You'll not pull out or damage the stabilizers and switches by this way.)

