


Required Components



BOM

- 1. Handle
- 2. M10 Nut
- 3. Left Side Shell
- 4. Rubber Gasket
- 5. Right Side Shell
- 6. M10 x 70 Bolt

Required Tools

- No tools required for assembly.
- Hammer or mallet may be used to slide nut and bolt into friction fit.
- Glue may be used to secure nut and bolt in place.

Required Personal Protective Equipment (PPE)

• No Personal Protective Equipment required.


^{*}Parts may slightly vary depending on metric or imperial configuration. Assembly is the same for both.



Assembly Instructions

Step 1

Refer to printing guide and print all components.



Step 2
Slide bolt into place on right side shell (the shell with the hexagonal hole).





Step 3

Turn the assembly so that the head of the bolt is on a flat surface, and press down on the joint until the bolt is flush with the shell, alternatively a hammer or mallet may be used to get the bolt in place.



Step 4 Place the rubber gasket on the bolt.





Step 5

Place the left shell on the bolt above the rubber gasket.



Step 6
Place the nut at the end of the bolt, above the left shell.





Step 7



Step 4
Congratulations! The joint is assembled! Now just slide the PVC in the slots to use with the PVC Assistive Mounting System (PAMS).

