### Scope

This document describes how to test USB Host PHDC example.

# **Preparation**

#### Host

A board, i.e. twrk22f120m, which is running host\_phdc example.

#### **Device**

A board, i.e. twrk70f120m, which is running dev\_phdc\_weighscale example.

## **Steps**

Follow the steps to run the PHDC host demo.

- 1. Run the host\_phdc example.
- 2. Plug-in the PHDC device and you will see some attach information printed out.
- 3. The PHDC device will automatic send reports to host. You can see information of scan report number, time, value and unit of each data field in terminal tool