DEMBody User's Guide

1. Change input_points.txt according to particle material.

2. (Optional) Change RestartData.txt, including Hertz memory and time variables (Time, Tnext, Step, CheckPointTnext).

3. Change systemControl.txt. Console params describes the timesteps; Mesh params describes the mesh grid; System control describes several logicals. Gravity describes constant gravity.

4. Change makefiles.