

**NOTES:** 

В

1. Torque all screws to 2.5 in-lbs

2. Leaf springs of item 8 should be soldered on while aligned with small dowel pins and aluminum

3. Metal face of item 6 should be flush with surrounding lip face of item 7. It is recommended to push against a flat surface while installing PCBs.

4. Item 6 should compress leaf springs on 2x item 8. Verify conductivity between matching traces from one PCB to the other.

SIZE		Top bulb ho	lder
SCALE:	2:1	DIMENSIONS ARE IN INCHES	SHEET 1 OF 2

2

-

Δ

В

В

ITEM NO.	PART NUMBER	SW-Configuration Name(Configuration Name)	VENDOR, MATERIAL ETC	QTY.
1	#2 screw - phillips	.15625	MCMASTER 91772A073	4
2	#2 screw - phillips	.375	MCMASTER 91772A079	4
3	#2 screw - phillips	.25	MCMASTER 91772A077	4
4	#2 spacer	0.1875	MCMASTER 92510A689	4
5	#2 standoff F-F	0.7500	MCMASTER 91780A113	2
6	UV bulb	Default		1
7	Faceplate	Default	PEI PLASTIC	1
8	UV Connector PCB	Default		2
9	Nutplate	Default	SUBASSEMBLY	2
10	Silicone o-ring	-015	MCMASTER 1173N015	1

A

SIZE TITLE:

A Top bulb holder

SCALE: 2:1 DIMENSIONS ARE IN INCHES SHEET 2 OF 2

В


2

1

В

NOTES:
1. Insert item 2 with helicoil insertion tool and prong breakoff tool

ITE	M NO.	PART NUMBER	SW-Configuration Name(Configuration Name)	VENDOR, MATERIAL ETC	QTY.
	1	Nutplate	Default	ALUMINUM	1
	2	Helicoil	2-56	MCMASTER 91732A203	6



В