

PE-EC703B — Wireless Sensor Networks

Semester VII • 3L:0T:0P • 3 Credits

Module 3 Exam Notes: MAC Protocols, Routing Protocols, IEEE 802.15.4 & ZigBee

CGEC | B.Tech ECE (2023–27) | *Biraj Sarkar*

Contents

1	MAC Protocols for WSN	2
1.1	Major Energy Waste Sources at MAC Layer	2
2	Classification of MAC Protocols	2
3	S-MAC Protocol (Sensor-MAC)	2
3.1	S-MAC Working Principle	3
3.2	S-MAC Frame Structure	3
3.3	S-MAC: Advantages and Disadvantages	3
4	B-MAC Protocol (Berkeley-MAC)	3
4.1	B-MAC Low-Power Listening (LPL) Mechanism	4
4.2	B-MAC vs S-MAC	4
5	IEEE 802.15.4 Standard	4
5.1	Key Specifications of IEEE 802.15.4	5
5.2	Device Types in IEEE 802.15.4	5
5.3	Superframe Structure	5
6	ZigBee	5
6.1	ZigBee Protocol Stack	6
6.2	ZigBee Device Types	6
6.3	ZigBee Network Topologies	6
7	Routing Protocols for WSN	6
7.1	Flooding and Gossiping	6
7.2	SPIN (Sensor Protocols for Information via Negotiation)	7
7.3	Directed Diffusion	7
7.4	LEACH Protocol (Low-Energy Adaptive Clustering Hierarchy)	7
7.5	TEEN and APTEEN Protocols	8
7.6	Location-Based (Geographic) Routing Protocols	9

1. MAC Protocols for WSN

MAC Protocol — Definition

A **Medium Access Control (MAC) protocol** governs how sensor nodes share the common wireless channel. In WSN, the MAC layer has an additional critical responsibility: **energy management** — scheduling the radio's sleep/wake cycle to minimize idle listening, overhearing, and collision-related retransmissions.

1.1 Major Energy Waste Sources at MAC Layer

- **Idle listening:** Radio is ON but no packet arrives — most wasteful (equal to RX energy).
- **Overhearing:** A node receives a packet destined for another node.
- **Collision:** Two nodes transmit simultaneously; packets are corrupt and must be retransmitted.
- **Control packet overhead:** RTS/CTS/ACK consume energy without carrying data.
- **Overmitting:** Transmitting to a node not yet ready to receive.

2. Classification of MAC Protocols

WSN MAC protocols are broadly classified as:

Category	Mechanism	Advantages	Disadvantages
Contention-based (CSMA family)	Nodes contend for channel; random back-off on collision	Simple, no coordination needed, handles variable load	Collisions, idle listening, scalability issues
Schedule-based (TDMA family)	Nodes assigned fixed time slots; radio OFF in other slots	Collision-free, predictable energy, no idle listening	Requires synchronization, poor adaptability
Hybrid	Combines TDMA + CSMA dynamically	Balanced energy and adaptability	Complex design

3. S-MAC Protocol (Sensor-MAC)


S-MAC — Definition

S-MAC (Sensor-MAC) is a contention-based MAC protocol for WSN that introduces **periodic sleep-wake schedules** for all nodes in a neighborhood. Nodes synchronize their schedules, go to sleep during idle periods, and wake up to exchange data only during active periods, dramatically reducing idle-listen energy.

3.1 S-MAC Working Principle

1. **Listen–Sleep schedule:** Time is divided into frames. Each frame has a **LISTEN** period and a **SLEEP** period. All nodes in a cluster share the same schedule.
2. **Schedule exchange (SYNC):** On startup, a node listens for SYNC packets. If it hears a neighbor's schedule, it adopts it. Otherwise it creates its own and broadcasts a SYNC packet.
3. **Data exchange:** Data is sent only during the LISTEN period using CSMA with RTS/CTS.
4. **In-band signaling:** A NAV (Network Allocation Vector) field in RTS/CTS tells neighboring nodes how long to stay asleep (virtual carrier sensing).
5. **Message passing:** For long messages, S-MAC uses message passing where a node stays awake for consecutive frames to receive the entire message — reduces latency.

3.2 S-MAC Frame Structure



3.3 S-MAC: Advantages and Disadvantages

Advantages	Disadvantages
Reduces idle listening significantly	Fixed duty cycle may waste energy at low traffic
Simple schedule coordination (SYNC packets)	Increased latency due to sleep periods
Collision avoidance via virtual carrier sense (NAV)	Border nodes may follow two schedules, reducing sleep time
Works well in dense, static networks	Not adaptive to varying traffic loads

4. B-MAC Protocol (Berkeley-MAC)


B-MAC — Definition

B-MAC (Berkeley-MAC) is a contention-based MAC protocol that uses **Low-Power Listening (LPL)** (also called **preamble sampling**) to reduce idle-listen energy. A node wakes up briefly at intervals to check for channel activity (preamble) and only stays awake if it detects a transmission directed to it.

4.1 B-MAC Low-Power Listening (LPL) Mechanism

1. **Receiver side:** Each node wakes up periodically (every check interval T_c) for a short duration (~ 1 ms), samples the channel using Clear Channel Assessment (CCA).
 - If channel is idle: back to sleep.
 - If channel is busy: stay awake and receive the full packet.
2. **Sender side:** Before data, the sender transmits a **long preamble** of duration $\geq T_c$ (the check interval). This ensures the receiver wakes up at least once and detects the preamble.
3. After detecting the preamble, the receiver stays awake and receives the data packet.

B-MAC Low-Power Listening — Timing



4.2 B-MAC vs S-MAC

Parameter	S-MAC	B-MAC
Approach	Synchronized sleep schedules	Asynchronous preamble sampling
Synchronization	Required (SYNC packets)	Not required
Latency	Higher (must wait for LISTEN period)	Lower (no schedule dependency)
Preamble overhead	Short	Long (= check interval)
Adaptability	Fixed duty cycle	Check interval tunable per traffic load
Complexity	Moderate	Low

5. IEEE 802.15.4 Standard

IEEE 802.15.4 — Definition

IEEE 802.15.4 is the wireless standard defining the **Physical (PHY)** and **MAC** layers for Low-Rate Wireless Personal Area Networks (LR-WPANs). It is the foundation protocol used by ZigBee, 6LoWPAN, Thread, and WirelessHART. It targets low data rate, low power, and low cost sensor/actuator applications.

5.1 Key Specifications of IEEE 802.15.4

Parameter	Value / Description
Frequency band	2.4 GHz (global), 915 MHz (Americas), 868 MHz (Europe)
Data rate	250 kbps (2.4 GHz); 40 kbps (915 MHz); 20 kbps (868 MHz)
Range	10–100 m (LOS); 10–30 m indoor
TX power	−3 dBm to +3 dBm (1–2 mW)
Modulation	O-QPSK (2.4 GHz), BPSK (868/915 MHz)
Channels	16 channels at 2.4 GHz (Ch. 11–26, 5 MHz spacing)
Addressing	16-bit short or 64-bit extended IEEE address
Network topology	Star or peer-to-peer (mesh)
Security	AES-128 encryption optional

5.2 Device Types in IEEE 802.15.4

- **Full Function Device (FFD):** Can act as coordinator, router, or end device. Supports all MAC functions.
- **Reduced Function Device (RFD):** Simplified device; can only communicate with a coordinator. Cannot relay packets. Lower cost, lower power.
- **PAN Coordinator:** The master FFD of the network; manages the PAN (Personal Area Network), assigns addresses, and generates beacon frames.

5.3 Superframe Structure

IEEE 802.15.4 optionally uses a **beacon-enabled superframe** structure for scheduled access:


- **Beacon:** Sent by PAN coordinator to synchronize all devices.
- **CAP (Contention Access Period):** CSMA-CA based contention slots for general data.
- **CFP (Contention-Free Period):** Guaranteed Time Slots (GTS) assigned to specific devices — collision-free, low latency.
- **Inactive period:** All nodes sleep; radio off.

6. ZigBee

ZigBee — Definition

ZigBee is a high-level wireless communication protocol stack built on top of IEEE 802.15.4 (PHY + MAC layers). It adds the **Network Layer (NWK)** and **Application Layer (APL)** to enable mesh networking, self-healing, multi-hop routing, and device/service discovery for IoT and WSN applications.

6.1 ZigBee Protocol Stack



6.2 ZigBee Device Types

- **ZigBee Coordinator (ZC):** One per network; initiates network formation, stores network map, and bridges to other networks.
- **ZigBee Router (ZR):** Participates in routing; relays data for other nodes; always-on (not battery-optimized).
- **ZigBee End Device (ZED):** Leaf node; communicates only with its parent (coordinator or router); can sleep aggressively; lowest power.

6.3 ZigBee Network Topologies

- **Star:** All devices communicate directly to the coordinator. Simple, limited range.
- **Tree (Cluster tree):** Hierarchical network; data flows up the tree toward the coordinator. Scalable.
- **Mesh:** Any router can communicate with any other router. Self-healing; most robust; supports AODV-based routing.

7. Routing Protocols for WSN

Routing in WSN must be energy-aware, since the network lifetime depends on balancing energy consumption across nodes.

7.1 Flooding and Gossiping

- **Flooding:** A node broadcasts a packet to all neighbors; each receiving node rebroadcasts to its neighbors, and so on. Simple but causes **implosion** (same data arrives at a node multiple times), **overlap** (nearby nodes sense same region and send duplicate data), and **resource blindness** (does not consider node energy).
- **Gossiping:** Instead of broadcasting, a node randomly selects one neighbor and forwards the packet. Reduces implosion but creates random latency.

7.2 SPIN (Sensor Protocols for Information via Negotiation)

SPIN — Definition

SPIN is a data-centric routing protocol that uses **metadata negotiation** to eliminate redundant transmissions. Nodes advertise data descriptors (meta-data) before sending actual data, and only nodes that do not have the data request it.

SPIN uses three message types:

- **ADV:** Advertisement — “I have new data with this descriptor”.
- **REQ:** Request — “I want that data”.
- **DATA:** Actual data payload.

7.3 Directed Diffusion

Directed Diffusion — Definition

Directed Diffusion is a data-centric, interest-driven routing protocol where the sink **floods interests** (queries) into the network. Sensor nodes that have matching data respond by sending data along the gradient (path) that was set up by the interest. Reinforcement is used to select the best path.

Three phases:

1. **Interest propagation:** Sink broadcasts interest (query) with parameters (attribute=value pairs, duration, frequency).
2. **Gradient setup:** Each intermediate node records the direction of the interest source and sets up a gradient toward the sink.
3. **Data delivery + Path reinforcement:** Data flows back along gradients. The sink reinforces the best-quality path by increasing data rate on that path; other gradients are suppressed.

7.4 LEACH Protocol (Low-Energy Adaptive Clustering Hierarchy)

LEACH — Definition

LEACH is a hierarchical, cluster-based routing protocol for WSN that distributes energy load by rotating the **Cluster Head (CH)** role among all nodes in rounds. Each CH aggregates data from its cluster members and forwards compressed data to the base station via single-hop.

LEACH Operation: Two Phases per Round

Phase 1 — Setup Phase:

- Each node decides to become a CH with probability p :

LEACH — Cluster Head Probability

$$P(n) = \begin{cases} \frac{p}{1 - p \cdot (r \bmod \frac{1}{p})} & \text{if } n \notin G \\ 0 & \text{if } n \in G \end{cases}$$

where p = desired fraction of CHs (typically $0.05 = 5\%$), r = current round number, G = set of nodes that were CHs in the last $1/p$ rounds.


Optimal CH fraction: $p_{\text{opt}} = \sqrt{\frac{A}{2\pi}} \cdot \frac{1}{d_{BS}} \cdot \sqrt{\frac{\varepsilon_{fs}}{\varepsilon_{mp}}}$

where A = field area, d_{BS} = distance to base station.

- Nodes that become CHs broadcast an advertisement. Non-CH nodes join the nearest CH (based on RSSI).
- CH creates a TDMA schedule for its cluster members.

Phase 2 — Steady-State Phase:

- Cluster members transmit data in their assigned TDMA slot; radio is OFF in other slots.
- CH aggregates received data and transmits compressed aggregate to base station using long-range radio.
- After a fixed number of frames, a new setup phase begins with new CH selection.

LEACH Cluster Formation Diagram**7.5 TEEN and APTEEN Protocols**

For applications with time-critical events, standard proactive clustering like LEACH is inefficient because it transmits data periodically even when there is no change in the sensed environment. Hierarchical routing has reactive and hybrid extensions:

TEEN (Threshold sensitive Energy Efficient sensor Network) — Definition

TEEN is a **reactive** hierarchical routing protocol designed for time-critical applications. Motes sense their environment continuously, but only transmit data to their cluster heads if the sensed value crosses a **Hard Threshold** (H_T) (to trigger on events of interest) and changes by an amount equal to or greater than a **Soft Threshold** (S_T) (to reduce transmission of small, insignificant fluctuations).

TEEN Threshold Conditions for Transmission: Let V_{sensed} be the current sensed value, and $V_{\text{last_tx}}$ be the value of the last transmitted data. A node transmits if and only if:

$$(V_{\text{sensed}} > H_T) \quad \wedge \quad (|V_{\text{sensed}} - V_{\text{last_tx}}| \geq S_T)$$

- **Hard Threshold (H_T):** The absolute value above which a sensor node must turn on its transmitter and report (e.g., Temperature $> 60^\circ\text{C}$).
- **Soft Threshold (S_T):** A small change in the value of the sensed attribute that triggers the node to transmit again (e.g., change of $\geq 2^\circ\text{C}$).

APTEEN (Adaptive Periodic Threshold sensitive Energy Efficient) — Definition

APTEEN is a **hybrid** protocol that extends TEEN to support both periodic (proactive) data collection and event-driven (reactive) transmissions. It allows the user to specify a **Count Time (T_C)**: if a node does not send data for a duration equal to T_C , it is forced to transmit its current reading, ensuring the user receives regular heartbeats.

Comparison: LEACH vs. TEEN vs. APTEEN

Parameter	LEACH	TEEN	APTEEN
Network Type	Proactive (periodic)	Reactive (event-driven)	Hybrid (periodic + event)
Data transmission	Continuous at time slots	Only when thresholds met	Periodic + threshold triggers
Energy efficiency	Moderate	Very High	High
Delay	Higher (scheduled)	Minimal (immediate TX)	Minimal for events
Best suited for	Constant monitoring	Disaster/fire detection	Dynamic query systems

7.6 Location-Based (Geographic) Routing Protocols

Geographic routing protocols use geographic coordinates (localization or GPS) to route data, eliminating the need to maintain routing tables or flood interests.

GEAR (Geographical and Energy-Aware Routing) — Definition

GEAR is a location-based routing protocol that routes queries to a target region using geographic coordinates and remaining energy levels of neighbors. It replaces interest flooding (in Directed Diffusion) with localized geographic forwarding to the target region, saving significant energy.

GEAR Forwarding Strategy:

- A node forwards packets to the neighbor closest to the target region that has high remaining energy.
- If a node encounters a “hole” (no neighbor is closer to the target than itself), it routes using a **learned cost** based on neighbor energy and distance.

GAF (Geographic Adaptive Fidelity) — Definition

GAF is an energy-conserving location-based routing protocol that divides the network area into a **virtual grid**. Since all nodes within a grid cell can route packets to adjacent cells equally, GAF keeps only **one node active** in each cell while putting all other nodes

in a low-power sleep state, maximizing network lifetime.

GAF Grid Size Constraint: To ensure any node in a grid cell (x, y) can communicate with any node in adjacent cells (like $(x + 1, y)$), the grid cell size r must satisfy:

$$r \leq \frac{R}{\sqrt{5}}$$

where R is the wireless transmission range of the nodes.

Quick Revision — Module 3

MAC & Routing Protocols | PE-EC703B

Key Formulas at a Glance

LEACH CH Probability	$P(n) = \frac{p}{1 - p \cdot (r \bmod \frac{1}{p})}$ for non-recent CH nodes; 0 otherwise
Optimal CH Fraction	$p_{\text{opt}} \propto \frac{1}{d_{BS}} \cdot \sqrt{\frac{\varepsilon_{fs}}{\varepsilon_{mp}}}$
TEEN Tx Condition	$(V_{\text{sensed}} > H_T) \wedge (V_{\text{sensed}} - V_{\text{last_tx}} \geq S_T)$
GAF Grid Cell Constraint	$r \leq \frac{R}{\sqrt{5}} \quad (R = \text{transmission range})$
B-MAC Preamble Length	$T_{\text{preamble}} \geq T_{\text{check}} \quad (T_{\text{check}} = \text{receiver check interval})$

One-Line Definitions

- **S-MAC:** Synchronized sleep-wake MAC; nodes share a schedule and sleep during idle periods.
- **B-MAC:** Preamble sampling MAC; receiver wakes briefly to check for long preamble before receiving.
- **IEEE 802.15.4:** PHY+MAC standard for LR-WPAN; 250 kbps at 2.4 GHz; foundation of ZigBee.
- **ZigBee:** Network+application layer stack on IEEE 802.15.4; mesh routing, self-healing, IoT standard.
- **SPIN:** Metadata negotiation protocol — nodes advertise before sending to avoid redundant transmissions.
- **Directed Diffusion:** Interest-driven data-centric routing; sink floods interests, nodes set up gradients.
- **LEACH:** Cluster-based hierarchical routing; rotates cluster head role to distribute energy consumption.
- **TEEN:** Reactive hierarchical routing; transmits only when sensed parameters cross thresholds.
- **APTEEN:** Hybrid hierarchical routing; combines periodic reporting (Count Time) and threshold-triggered event reporting.
- **GEAR:** Location-based routing routing queries to target region using coordinates and remaining energy.
- **GAF:** Grid-based geographic routing; keeps only one active node per grid cell while others sleep.

Frequently Asked / Viva Questions

Q1. Explain the working of S-MAC protocol.

S-MAC introduces synchronized sleep-wake scheduling. Nodes exchange SYNC packets to agree on a schedule with a fixed LISTEN period and a longer SLEEP period per frame. During LISTEN, data is exchanged using CSMA with RTS/CTS and NAV virtual carrier sense. During SLEEP, the radio is OFF saving idle-listen energy.

Q2. What is Low-Power Listening (LPL) in B-MAC?

In B-MAC, each receiver wakes up briefly every T_c (check interval) and performs CCA (Clear Channel Assessment). If it detects a long preamble (of duration $\geq T_c$ sent by the transmitter), it stays awake to receive the full data packet. Otherwise it goes back to sleep.

Q3. Compare S-MAC and B-MAC.

S-MAC uses *synchronous* fixed sleep schedules (requires SYNC overhead, higher latency). B-MAC uses *asynchronous* preamble sampling (no synchronization needed, lower latency, but long preamble wastes TX energy). B-MAC is more adaptive; S-MAC is better for dense static networks.

Q4. What is IEEE 802.15.4? List its key specifications.

IEEE 802.15.4 is the PHY+MAC standard for Low-Rate WPAN. Key specs: 250 kbps at 2.4 GHz (O-QPSK), 16 channels (Ch.11–26), 10–100 m range, ~ 1 –2 mW TX power, AES-128 optional security, 16-bit or 64-bit addressing, star or mesh topology. It is the PHY/MAC base for ZigBee, 6LoWPAN, Thread.

Q5. What is ZigBee and how does it relate to IEEE 802.15.4?

ZigBee is a higher-layer protocol stack that adds a Network Layer (mesh routing, AODV, joining) and Application Layer (profiles, device objects) on top of IEEE 802.15.4 PHY and MAC. ZigBee defines three device types: Coordinator (one per network), Router (always-on relay), and End Device (sleepy leaf node).

Q6. Explain the working of LEACH protocol.

LEACH operates in rounds. In the **setup phase**, each node independently decides to become a CH with probability p (typically 5

Q7. Compare LEACH, TEEN, and APTEEN.

(1) **LEACH** is proactive (sends continuous periodic data, suited for constant monitoring); (2) **TEEN** is reactive (only sends data when thresholds are exceeded, suited for time-critical fire/explosion alerts, extremely energy efficient); (3) **APTEEN** is hybrid (sends periodic data at Count Time T_C and immediate alerts when thresholds are crossed, offering a trade-off).

Q8. Explain the location-based routing protocols GEAR and GAF.

GEAR routes queries to a target region using geographic positions and remaining energy levels of neighbors, avoiding global flooding. **GAF** divides the WSN area into a virtual grid, and keeps only one active node per grid cell while others

Frequently Asked / Viva Questions (contd.)

sleep. Any node in a cell can route for the cell, which saves energy without losing connectivity.

Q9. What is Directed Diffusion?

The sink broadcasts an **interest** (query with attribute-value pairs like “type=temperature, duration=10s, rate=1/s”). Nodes receiving the interest cache it and set up gradients back toward the sink. Nodes with matching data send low-rate exploratory data along all gradients. The sink **reinforces** the best path (highest quality) by requesting higher data rate on that path; other paths suppress.

Q10. What are the three problems with flooding in WSN?

(1) **Implosion**: A node receives duplicate copies of the same data from multiple neighbors. (2) **Overlap**: Nodes sensing the same region all report the same data, wasting bandwidth. (3) **Resource blindness**: Flooding ignores node energy; energy-poor nodes forward packets the same as full-battery nodes.

Q11. What is SPIN and how does it improve on flooding?

SPIN uses three messages: **ADV** (metadata advertisement), **REQ** (data request), **DATA**. A node with new data sends ADV to neighbors. Only neighbors who don't have this data reply with REQ; then data is sent. This prevents implosion (a node that already has the data ignores the ADV) and overlap (metadata negotiation ensures only interested nodes receive data).

Q12. What is the superframe in IEEE 802.15.4?

The superframe (in beacon-enabled mode) consists of: **Beacon** (synchronization), **CAP (Contention Access Period)** using CSMA-CA for general nodes, **CFP (Contention-Free Period)** with Guaranteed Time Slots (GTS) for latency-critical nodes, and an **Inactive period** where all nodes sleep. The beacon interval and active period are configurable.

Summary: MAC & Routing Protocols at a Glance

Protocol	Type	Key Mechanism	Strength
S-MAC	MAC	Synchronized sleep-wake	Reduces idle-listen
B-MAC	MAC	Preamble sampling (LPL)	No synchronization
IEEE 802.15.4	PHY+MAC	CSMA-CA + GTS	Standard, interoperable
ZigBee	Network+App	Mesh routing, device types	Self-healing mesh
Flooding	Routing	Broadcast to all	Simple, no setup
SPIN	Routing	Metadata negotiation	No implosion/overlap
Directed Diffusion	Routing	Interest + gradient	Data-centric, efficient
LEACH	Routing	CH rotation + aggregation	Balanced energy load
TEEN	Routing	Reactive threshold-driven	Very high energy savings
APTEEN	Routing	Hybrid periodic + event	Versatile, query-based
GEAR	Routing	Energy	Geographic routing to region
GAF	Routing	Grid-based sleep management	Topology control, sleep cells