COMIC READER

THE GUIDE!

Comics and manuals on your cabinet. Pages on the playfield, the cover on the backglass, where you are on the DMD.

PLAYFIELD

Your library, and the page you're reading at full resolution.

BACKGLASS

The book's cover.

DMD

The title and the page number.

GETTING AROUND CONTROLS

BUTTON	IN THE LIBRARY	WHILE READING
FLIPPERS	Previous or next shelf	Previous or next page. Hold to flip fast.
JOYSTICK	Move between books	Turn the page; zoomed in, move around it
A	Open the book or series	Next page
START	Open	Zoom in: 2x, 3x, then the whole page
Y	The book's details	Zoom in
B	Back, or exit the app	The whole page, or back to the library

YOUR BOOKS SHELVES

Continue lists the books you're partway through. A book always opens on the page where you stopped.

Comics and Manuals hold your books. A folder of books shows as a series: open it to see the issues.

Settings has Wi-Fi upload (next page), Check for updates, the Page turn (curl, slide or none), Reading direction (right to left for manga), Forget reading history, Redraw covers and About.

ADDING BOOKS

WI-FI UPLOAD

1. In Settings, open Wi-Fi upload. The cabinet shows an address and a four-digit PIN.
2. On a phone or computer on the same network, open the address in a browser and enter the PIN.
3. Choose Comics or Manuals, and a series if you like (or make a new one).
4. Drop in your files, or a folder of page pictures. Press B when they're sent: they're in your library.

OR COPY THEM

ON THE USB STICK

Put books in `external/comic-reader/comics/` or `manuals/`. A folder inside makes a series:
`comics/Planet Comics/Planet Comics 037.cbr`

WHAT IT OPENS

FILE TYPES

PDF, CBZ, CBR and CBT comics, single pictures (JPG, PNG, WebP, GIF, BMP, TIFF), and a folder of pictures as one book, its pages in name order. A ComicInfo.xml inside a comic gives it its series, issue and credits (press Y).