COMIC READER

THE GUIDE

Comics and manuals on your cabinet. Pages on the playfield, the cover on the backglass, where you are on the DMD.

PLAYFIELD
Your library, and the page you're reading at full resolution.

BACKGLASS
The book's cover.

DMD
The title and the page number.

GETTING AROUND

CONTROLS

BUTTON	IN THE LIBRARY	WHILE READING
Flippers	Previous or next shelf	Previous or next page. Hold to flip fast.
Joystick	Move between books	Left and right turn the page
A	Open the book or series	Next page
Start	Open	Show the title and page number
B	Back, or exit the app	Back to the library

YOUR BOOKS

SHELVES

Continue lists the books you're partway through. A book always opens on the page where you stopped.

Comics and **Manuals** hold your books. A folder of books shows as a series: open it to see the issues.

Wi-Fi upload lets you send books from a phone or computer (next page).

ADDING BOOKS

WI-FI UPLOAD

1. Go to the **Wi-Fi upload** shelf. The cabinet shows an address and a four-digit PIN.
2. On a phone or computer on the same network, open the address in a browser and enter the PIN.
3. Choose **Comics** or **Manuals**, and a series if you like (or make a new one).
4. Drop in your files, or a folder of page pictures. Leave the shelf when they're sent: they're in your library.

OR COPY THEM

ON THE USB STICK

Put books in `external/comic-reader/comics/` or `manuals/`. A folder inside makes a series:
`comics/Planet Comics/Planet Comics 037.cbr`

WHAT IT OPENS

FILE TYPES

PDF, **CBZ**, **CBR** and **CBT** comics, single pictures (JPG, PNG, GIF, BMP, TIFF), and a folder of pictures as one book, its pages in name order.