A Reply

▼ Follow

Downloads Training Ecosystem Forums Q 🚨 Join Login

Home > CUDA ZONE > Forums > Accelerated Computing > CUDA Setup and Installation > View Topic

[Solved] Titan X for CUDA 7.5 login-loop error [Ubuntu 14.04]



I have a similar error to the thread described here

https://devtalk.nvidia.com/default/topic/872967/?comment=4656571

I do however, have a perfect install, and I run all the post-install tests and everything looks fine, up until I reboot. I'm faced with the login-loop, and from what I read it seems its conflicting with the Xorg system. I banned the nouveau display system (and did a \$update-initramfs -u) post-install, and rebooted, and still have the same problem. I'm not really sure what's going on. Do I have to reinstall a program? I've already had to do a fresh install on my system and since this is a new computer cluster, it's imperative to have CUDA working, but only use the Titan X for GPU processing and not for rendering (rendering will be done by onboard integrated graphics card on motherboard).

Also: \$nvidia-smi works fine, but doesn't show any processes running But: \$nvidia-settings shows an error message:

ERROR: The control display is undefined; please run 'nvidia-settings --help' for usage information.

In this thread I also found that it was a good idea to put 'no' in the install OpenGL part of the CUDA driver install. https://devtalk.nvidia.com/default /topic/864024/cuda-setup-and-installation/howto-ubuntu-14-04-intel-igpu-for-display-and-gtx-960-for-cuda/. Perhaps that is my problem and I should do a new install like in the first link I posted? Any other suggestions? I now recall that by installing CUDA, it asked me if I wanted to install the Nvidia driver too, I believe I said yes. Maybe this was the mistake?

Other questions:

1) If I am only installing CUDA for parallel processing with my Titan X, am I still supposed to blacklist the nouveau driver? (It seems as if that is only for display, but I would need it if I'm using an integrated graphics card for that)

2) Do I still need to install an Nvidia driver if I am not going to use the drive for visualization? Only installing the CUDA drive makes more sense to me.

I used this guide to perform my install:

https://www.quantstart.com/articles/Installing-Nvidia-CUDA-on-Ubuntu-14-04-for-Linux-GPU-Computing

Other specs & details:

Linux Kernel version: 3.19.0-25-generic 64-bit machine.

I also don't happen to have an xorg.conf file

\$sudo apt-get install ubuntu-desktop ; outputs 'ubuntu-desktop is already the newest version'

\$nvcc -V ; seemed to work perfect after install, but it stopped working after reboot.

I login to my system through Ctrl + Alt + F1

Posted 09/16/2015 06:26 AM

#1



NeuroSurfer said:

In this thread I also found that it was a good idea to put 'no' in the install OpenGL part of the CUDA driver install. https://devtalk.nvidia.com/default/topic/864024/cuda-setup-and-installation/howto-ubuntu-14-04-intel-igpu-for-display-and-gtx-960-for-cuda/. Perhaps that is my problem and I should do a new install like in the first link I posted? Any other suggestions? I now recall that by installing CUDA, it asked me if I wanted to install the Nvidia driver too, I believe I said yes. Maybe this was the mistake?

Yes, the installation of the openGL libs by the driver is affecting your GUI and login.

- 1. Do a new, clean install, without the NVIDIA GPU installed
- 2. Establish an xorg.conf file so that the X server does not use display autodetection (please google for how to do this based on your linux distro, it's not an NVIDIA issue). Get everything working the way you want, GUI-wise.
- 3. Remove the nouveau driver. The method is given in the CUDA linux getting started guide.
- 4. Power down, install the NVIDIA GPU.
- 5. Power up again, make sure nothing changes regarding login and GUI through reboots.
- 6. Download and install the appropriate driver *runfile installer* for your GPU. You get this by downloading it from www.nvidia.com. During the install of the runfile, select the command line option to *not* install OpenGL libs. If you're not sure what that is, use --help on the runfile install command line to see the command line options, then re-run with the command line option to disable installation of the OpenGL libs. Select "no" if prompted to modify your xora.conf file.
- 7. At this point you should be able to reboot and login. If so, you are past the trouble.
- 8. Now download the CUDA runfile installer (do not use package install method), but answer "no" when asked if you want to install the driver. Follow the other directions in the cuda linux getting started guide:

http://docs.nvidia.com/cuda/cuda-installation-guide-linux/index.html#abstract

Posted 09/16/2015 02:11 PM



Will the above install still work if I don't remove my NVIDIA graphics card? (I think this is what you mean when you say "Without the NVIDIA GPU installed".) This is an expensive computer and I don't want to accidentally shortcircuit the Titan X or any other component by bringing the computer apart.

Posted 09/16/2015 08:00 PM

<u>#3</u>

#2

1 of 5 2016年11月20日 11:03



It should, yes, assuming that you create a proper xorg.conf and the X autodetect feature doesn't trip you up.

_

Posted 09/16/2015 08:11 PM

#4



**& **

Ok, I'm about do start from scratch by uninstalling CUDA and deleting the nouveau ban, but in the manual you sent me it says:

\$ sudo /usr/local/cuda-7.5/bin/uninstall_cuda_7.5.pl
to uninstall, but such file doesn't exist! (The /usr/local/cuda-7.5/bin/ folder does exist though).

I used a .deb file for installation.

*Nevermind, I did this for clean nvidia uninstall:

\$sudo apt-get remove --purge nvidia-* && apt-get autoremove

\$sudo apt-get install ubuntu-desktop

\$sudo rm /etc/X11/xorg.conf

\$echo 'nouveau' | sudo tee -a /etc/modules

I am still stuck on how to create a proper xorg.conf file. (I see that some people leave it blank)

Do I need to run \$sudo nvidia-xconfig? (Answer seems like **no**, from here https://elementaryforums.com/index.php?threads/howto-install-latest-nvidia-driver-on-linux-without-getting-black-screen.7/

I'm also still not sure why I'm supposed to blacklist the nouveau driver if I don't want to use the Titan X for rendering. If I do blacklist it, when am I suppose to re-enable it to get my GUI working? I'm stumped here.

Posted 09/16/2015 08:53 PM

<u>#5</u>



That isn't what I was suggesting at all.

Clean install of the operating system, i.e. reload the operating system.

Then use the runfile installer.

Obviously the uninstall .pl script won't be there before you install it (the driver runfile installer) the first time.

There are quite a few questions here. Perhaps you should try installing a few times. I'm just offering suggestions. You're welcome to do whatever you wish

The nouveau driver *only* pertains to the NVIDIA GPU. It is not required to "get your GUI working" if the GUI is hosted by another (non-NVIDIA) GPU.

Posted 09/16/2015 11:46 PM

<u>#6</u>



txbob said:

That isn't what I was suggesting at all.

Clean install of the operating system, i.e. reload the operating system.

Then use the runfile installer.

Obviously the uninstall .pl script won't be there before you install it [the driver runfile installer] the first time.

There are quite a few questions here. Perhaps you should try installing a few times. I'm just offering suggestions. You're welcome to do whatever you wish.

The nouveau driver *only* pertains to the NVIDIA GPU. It is not required to "get your GUI working" if the GUI is hosted by another (non-NVIDIA) GPU.

No worries, this has been very helpful! Since the computer is new a fresh OS install is not a problem, but I'd prefer to not over do it.

txbob said

The nouveau driver *only* pertains to the NVIDIA GPU. It is not required to "get your GUI working" if the GUI is hosted by another (non-NVIDIA) GPU.

Ok, perfect. Thanks for clarifying things! I will give it another try and keep you posted.

Posted 09/17/2015 12:04 AM

<u>#7</u>



Update: I get stuck in step 5. After installing the NVIDIA Driver, I do

\$sudo service lightdm start

and it takes me back to the login menu with GUI activated, but when I try to log in, I encounter the login-loop again. After reboot, the same error persists.


Posted 09/17/2015 12:47 AM

<u>#8</u>

Scroll To To

#9

#10



Posted 09/17/2015 01:28 PM #11



True

txbob said:

NeuroSurfer said:

Maybe I missed something?

 $\textbf{Update:} \ \textbf{I will re-install adding the --driver and --no-open gl-libs flags (although my .run file never prompted be about this...)}$

Yes, you missed the part where I said:

"During the install of the runfile, select the command line option to *not* install OpenGL libs. If you're not sure what that is, use --help on the runfile install command line to see the command line options, then re-run with the command line option to disable installation of the OpenGL libs."

This is a (the) critical step to avoid the "login loop".

And if you've already installed this way, a reinstall may not fix anything. You may need to start over with a clean load of the OS.

Scroll To To

I reinstalled the OS and re-ran everything same as before adding the --no-opengl-libs flag. This is the critical part. I would like to add something else though! I did not install have to install the NVIDIA driver explicitly first. I ran the cuda.run file instead, and said yes to install the NVIDIA driver when it prompted me to. I feel like doing this in one straight run made everything way easier. Thanks for everything!

Post of final script and solution

0) Download your relevant CUDA.run file: mine was: cuda_7.0.28_linux.run

Note, that once again this install is if you purely want to use your graphics card (Titan X) for GPU/CUDA purposes and not for rendering.

Also run: \$sudo apt-get install build-essential

1) I start off with the regular GUI and Ubuntu working with no login problems.

2) No need to create an xorg.conf file. If you have one, remove it lassuming you ahve a fresh OS install). \$ sudo rm /etc/X11/xorg.conf

3) Create the /etc/modprobe.d/blacklist-nouveau.conf file with :

blacklist nouveau

option nouveau modeset=0

Then \$sudo update-initramfs -u

4) Reboot computer. Nothing should have changed in loading up menu. You should be taken to the login screen. Once there type: Ctrl + Alt + F1, and login to your user.

5) Go to the directory where you have the CUDA driver, and run

\$chmod a+x

7) Now, run \$ sudo service lightdm stop

The top line is a necessary step for installing the driver.

8) I run the CUDA driver run file. *Notice that I explicitly don't want the OpenGL flags to be installed:

\$ sudo bash cuda-7.0.28_linux.run --no-opengl-libs

9) During the install:

Accept EULA conditions

Say YES to installing the NVIDIA driver

SAY YES to installing CUDA Toolkit + Driver

Say YES to installing CUDA Samples

Say NO rebuilding any Xserver configurations with Nvidia

10) Installation should be complete. Now check if device nodes are present:

Check if /dev/nvidia* files exist. If they don't, do :

\$ sudo modprobe nvidia

11) Set Environment path variables:

\$ export PATH=/usr/local/cuda-7.0/bin:\$PATH

\$ export LD_LIBRARY_PATH=/usr/local/cuda-7.0/lib64:\$LD_LIBRARY_PATH

*Change depending on your cuda version.

12) Verify the driver version:

\$ cat /proc/driver/nvidia/version

13) Check CUDA driver version:

\$ nvcc -V

[Optional] At this point you can switch the lightdm back on again by doing:

\$ sudo service lightdm start.

You should be able to login to your session through the GUI without any problems or login-loops.

14) Create CUDA Samples. Go to your NVIDIA_CUDA-7.5_Samples folder and type $\mbox{\tt \$make}.$

15] Go to NVIDIA_CUDA-7.5_Samples/bin/x86_64/linux/release/ for the demos, and do the two standard checks:

./deviceQuery

to see your graphics card specs and

./bandwidthTest

to check if its operating correctly.

Both tests should ultimately output a 'PASS' in your terminal.

16) Reboot. Everything should be ok.

Posted 09/17/2015 10:15 PM



old post but THANK YOU for posting these complete instructions.



Thanks for this great solution, it is lifesaving

Posted 01/06/2016 11:04 AM


Here is a little correction for 3. part. (option--->options) options nouveau modeset=0

Scroll To To

<u>#13</u>

#12

4 of 5 2016年11月20日 11:03



GET STARTED LEARN MORE GET INVOLVED COMPUTEWORKS About CUDA Forums Training and Courseware Parallel Computing Tools and Ecosystem Parallel Forall Blog GAMEWORKS Academic Collaboration CUDA Toolkit Developer Program JETPACK CUDACasts Documentation Contact Us DESIGNWORKS

Copyright © 2016 NVIDIA Corporation | Legal Information | Privacy Policy | Support

Scroll To To

5 of 5 2016年11月20日 11:03