

Security Classification:

Most Confidential( ) Confidential( ) Internal(  $\sqrt{ }$  ) Public( )

# Attestation\_Keybox Guide for RK3328

(Technical Department, Product Team)

Mark:	Current Ver.:	V1.0
[ ] Editing	Drafted By:	ZW
$[\sqrt{\ }]$ Issued	Fulfill Date:	2018-03-15
	Checked By:	CW
	Completed Date:	2018-03-15

福州瑞芯微电子股份有限公司

Fuzhou Rockchips Electronics Co., Ltd

(All rights reserved)



# **Revision History**

Ver. No	Author	Revised Date	Note for Revision	Remark
V1.0	ZW	2018-03-15	First edition	



# Index

1 Peri	mise
1.	1 Support Product
	2 Reader
	estation Keybox Generate
	1 Introduce
	l Use
3.	1 Keybox Tool
	<b>1</b>
4.	1 Gets the random secret key failed
	2 Key exceeds the allocated space
	3 Write key to misc failed
	4 Verify key failed



# 1 Permise

This paper introduces the attestation keybox burning scheme of the core micro platform, including how to generate the attestation keybox.

# **1.1 Support Product**

芯片类型
RK3126C
RK3328
RK3368

#### 1.2 Reader

**Production Technician** 

# 2 Attestation Keybox Generate

#### 2.1 Introduce

The rkpacker tool provided by rk converts a set of attestation keyboxes provided by Google to a burning record KDB data file:

rkpacker test\_keybox. xml - o keybox. kdb


The first parameter: test\_keybox.xml specifies the keybox data file to be converted;



The second parameter: -o parameter specifies the file path of the converted output, if not specified, a file will be generated in the current directory.

#### 3 Tool Use

# 3.1 Keybox Tool



Use steps:



- 1. Click "KeyFile" and select the keybox file.
- 2. Click "Run" to automatically detect Loader device.
- 3. After the tool is detected, select a key from the keybox file and burn it.
- 4. Multiple loader devices can be connected at the same time.

#### Note:

The location of Key's burn position is specified by config.ini "DestPosition" parameter

```
#DestPosition = 1:write key to misc; attestation choose this one
```


#DestPosition = 2:write key to vendor storage;

#DestPosition = other value:write key to old vendor;



# 4 Q&A


# 4.1 Gets the random secret key failed



Reason: All keys in the Keybox file are used up.




# 4.2 Key exceeds the allocated space



Reason:The size of the Key is over 64k




# 4.3 Write key to misc failed



Reason: The device does not answer, check whether the loader supports key burning



# 4.4 Verify key failed



Reason:Back to the key data failure, confirm whether the loader supports keybox burning.