

REV	DESCRIPTION	DATE	BY
P1	Making sketch for the prototype build plan	2026-09-30	AC
P2	13 mm spanner flats near the bottom shoulder	2026-10-02	AC



WHERE IT GOES

This part in colour, its neighbours in grey

HOW TO MAKE IT AND HOW IT FITS

Cut 1,032 mm of 16 mm rod; face both ends square.
Bottom end: turn an M12 x 1.75 stud 12 mm long (12.0 mm diameter) and cut the thread; leave a square, flat 16 mm shoulder.
Top end: turn an M12 stud 20 mm long the same way.
Spanner flats: mill two flats 13 mm across, 20 mm long, starting 8 mm above the bottom shoulder.
The shoulders are 1,000 mm apart. Both shoulders carry every blow, so face them square and break the edge 0.5 mm.
Engrave a ring every 10 mm, deeper every 100 mm, measured up from the cone point with the cone fitted (the point is 29.3 mm below the bottom shoulder). This is the backup depth scale.
Fit: the cone screws on the bottom stud, the anvil on the top stud; the clamp collar slides on from the top before the anvil.
Check: straight within 1 mm over its length when rolled on a flat bench; both studs take an M12 nut by hand.

Broken view: the middle of the rod is left out. True length 1,032 mm overall.



TOP VIEW

Scale 1:2; looking down (along -Z)



FRONT VIEW

Scale 1:2; looking at the front (along +Y)



RIGHT VIEW

Scale 1:2; looking at the right side (along -X)

CONEPRO

github.com/BoujeeEnjinia1701/conepro

ConePro lower drive rod: making sketch

DRAWING NO. CNP-DWG-102			REV P2	SHEET 1 of 1		SIZE ANSI B	
SCALE 1:2	UNITS mm	PROJECTION 		DATE 2026-10-02		DRAWN Amish Chadha	
MATERIAL / NOTES 16 mm 4140 class steel rod, ground or bright							
Licensed CERN-OHL-S-2.0 · Design Molecule Lab · designmolecule.com							
Generated from cad/src; do not edit by hand							