BUILD PLAN SKETCH, PLAN NOT YET BUILT

DewDrive · github.com/BoujeeEnjinia1701/dewdrive

REV	DESCRIPTION	DATE	BY
P1	Making sketch for the prototype build plan	2026-10-01	AC



TOP VIEW

Scale 1:5; looking down (along -Z)

FRONT VIEW

Scale 1:5; looking at the front (along +Y)

RIGHT VIEW

Scale 1:5; looking at the right side (along -X)

WHERE IT GOES

This part in colour, its neighbours in grey

HOW TO MAKE IT AND HOW IT FITS

Cut two 878 mm lengths of 30 x 30 x 3 angle; ends square.
Drill a 9 mm hole 12 from each end on the flat leg's centre line:
854 between centres.
It runs from the south leg, 395 above the bottom, down to the north leg, 145 above the bottom, at 17 degrees.
Fit: the flat leg lies on the outer face of both legs' face legs, the other leg standing out at its lower edge. One M8 bolt at each end.
This brace makes each side frame a rigid triangle.
Check: hole centres within 1 mm of the length above.

DEWDRIVE

github.com/BoujeeEnjinia1701/dewdrive

DewDrive side brace (make 2, a left and a right): making sketch

DRAWING NO.	REV	SHEET	SIZE
DWD-DWG-117	P1	1 of 1	ANSI B

SCALE	UNITS	PROJECTION	DATE	DRAWN
1:5	mm		2026-10-01	Amish Chadha

MATERIAL / NOTES

Galvanized steel angle 30 x 30 x 3 mm

Licensed CERN-OHL-S-2.0 · Design Molecule Lab · designmolecule.com

Generated from cad/src; do not edit by hand