

H2BENCH · BUILD PLAN

H2Bench prototype build plan

Design Molecule Lab · designmolecule.com

DOCUMENT CONTROL

Document ID	HBN-BLD-001	Version	0.1
Status	Draft	Date	2026-10-01
Author	Amish Chadha	License	CERN-OHL-S-2.0
Project TRL	TRL 3 Proof of concept		
Repository	github.com/BoujeeEnjinia1701/h2bench		
Source	docs/05-build-plan.md @ uncommitted		

REVISION HISTORY

Version	Date	Author	Change
0.1	2026-10-01	Amish Chadha	First build plan; design made constructable (HBN-DDR-003)

H2Bench prototype build plan


Plan, not yet built. How to build the first proof-of-concept prototype, component by component. Building and testing to it is TRL 4 work. Decisions still to be made are kept in the design decisions register ([docs/06-design-decisions.md](#)), not here.

■ 1. What you are building

H2Bench prototype: every component, pulled apart

Numbered in build order. Seen from the front right and above; the hood frame is pulled back, the bench parts forward

- 1 Frame: six rails and corner brackets
- 2 Deck and water post
- 3 Drip lip angles
- 4 Posts and foot brackets
- 5 Instrument back panel
- 6 Top frame and brackets
- 7 Canopy, duct collar, outlet hanger
- 8 Reservoir stand
- 9 Reservoir, cartridge, band clips
- 10 Electrolyzer feet
- 11 Electrolyzer stack
- 12 Column bracket
- 13 Separator, drier, pipe clips
- 14 Arrestor saddle, arrestor, clip
- 15 Tank cradle
- 16 Guard rods and lower nuts
- 17 Hydrogen buffer tank
- 18 Tank manifold
- 19 Guard top plate
- 20 Regulator and solenoid valve
- 21 Fuel cell on its bridge
- 22 Electronic load and lamp
- 23 Gas and water lines
- 24 Bench power supply
- 25 Meters, logger and display
- 26 H2Guard sensor, fan, controller



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1781/h2bench

Figure 1. Every component pulled apart and numbered in build order.

The prototype is one H2Bench: a 900 x 450 mm aluminium-framed deck that sits on an existing lab table, with a clear canopy hood 570 mm above it on four posts and a printed instrument panel across the back. On the deck, from left to right in the order the energy flows, stand a bench power supply, a water reservoir and deionizer, a small electrolyzer stack, a separator and drier, a check valve and flame arrestor, a 2 L hydrogen tank in a rod guard with its manifold, a regulator, a fuel cell and a lamp load. The H2Guard detector, fan and controller sit at the high point of the hood. Figure 1 shows the 26 components in the order you make or fit them. The frame, deck, lip, posts, top frame, panel, canopy and eight small mounts are made in a workshop; the rest are bought and fitted. The work is sawing and drilling aluminium extrusion, folding thin aluminium sheet, cutting HDPE and polycarbonate sheet, fitting compression fittings to 6 mm tubing and wiring bought modules. The parts cost about USD 999 from the bill of materials.

Safety: This bench makes, stores and uses hydrogen, which burns in air from about 4 to 74 % and ignites very easily, and holds it at up to 300 kPa gauge. Nothing in sections 3 and 4 uses hydrogen: the build is dry until the safety stops of section 6. Never connect the electrolyzer, pressurize the tank or open the hydrogen line until those stops say so, and never run the bench without H2Guard active. The bench supply is mains powered: use it only on an earthed socket with a 30 mA RCD. Cut aluminium and polycarbonate edges are sharp; deburr everything.

■ 2. What changed to make it buildable

The concept showed what the bench does; some of its parts could not be made or fixed as drawn. Each change below keeps what the bench does, and all of them are recorded in decision record HBN-DDR-003, made under Amish's 2026-09-30 instruction to make the design physically buildable and open for his review.

Table 1. Changes from the concept.

Component	The concept had	The buildable design has	Why
Frame	One fused shape, bars overlapping at every corner	Six cut lengths of slotted extrusion joined by inside corner brackets (Figure 3)	Standard parts, no welding
Drip lip	Moulded into the HDPE deck	Aluminium angle screwed on a silicone bead; the panel closes the back (Figure 8)	HDPE cannot be glued or moulded in a workshop
Posts and canopy	Two front posts standing on the lip; the canopy held only at the front; the panel held by nothing	Four posts on the frame, a top frame, the canopy screwed to it, the panel screwed to the rear posts (Figures 6, 8, 10)	A closed frame carries the canopy and fan
Duct collar	Fused into the canopy	Bought flanged spigot through a 106 mm hole (Figure 13)	Bought part
Relief and vent lines	Relief line pressed against the canopy, unsupported; no vent line	Both lines clipped to a hanger, ending 7 mm below the canopy (Figure 12)	The gas must get out into the hood
Water side	Not drawn	Reservoir on a 60 mm stand, three water lines to and from the stack (Figures 14, 25)	The stack is fed by gravity
Electrolyzer	Tie rods through its cell plates; feet that could not be screwed down	Rods clear of the plates; two angle feet bolted to the end plates (Figure 16)	Every screw can be reached
Separator and drier	Loose, 3 mm apart in line with no room for fittings	On a column bracket with pipe clips; gas loops over from one top to the other (Figure 18)	Room for every fitting
Arrestor	150 mm up on a post block	60 mm up in an HDPE saddle straight off the drier outlet (Figure 20)	Short, supported run clear of the tank
Tank guard	Rods standing loose; a top ring that would need welding	Threaded rods in tee nuts, a bolted top plate, the tank in a pocketed cradle (Figure 22)	No welding; the tank cannot tip or lift
Fuel cell stand	A solid block in the fan's air path	A folded bridge, open front and back (Figure 24)	Air flows through the stack

■ 3. Making the components

Make and check each component before the assembly step that needs it. Sizes are in millimetres. "Left" and "right" are as seen standing at the front of the bench (the student side); "front" is the student side and "back" the instrument panel. Heights are above the lab table unless a step says otherwise; the deck top is 32 mm above the table. Workshop tolerance is 0.5 mm unless a step says otherwise; drawings do not carry tolerances before TRL 4.

All extrusion, brackets and T-nuts are one 20-series system (20 x 20 mm profile, 6 mm slot). Mounts are fixed to the deck with 5 mm stainless self-tapping screws in 4 mm pilot holes, 10 mm deep, marked through the mount's own holes with the mount in place (Table 2).

Table 2. Where each mount goes on the deck, measured from the left end and from the front edge of the deck.

Mount	From the left end	From the front edge
Reservoir stand (top)	20 to 134	25 to 145
Water post (centre)	146	80
Electrolyzer end plates	235 to 365, feet 215 to 385	centred 185
Separator and drier (centres)	422 and 480	185
Column bracket (face)	402 to 502	220
Arrestor saddle (centre)	530	185
Tank cradle and guard (centre)	625	185
Regulator (centre)	730	185
Fuel cell bridge	790 to 875	centred 185
Load and lamp	750 to 890	10 to 65
Bench supply (on its feet)	10 to 160	201 to 415

3.1 Frame




Figure 2. Frame making sketch (HBN-DWG-101).

What it is and what it is made from. The rectangle the deck sits on and the posts stand on. 20 x 20 mm slotted aluminium extrusion, 3.44 m in all.


How to make it.

1. Cut two rails 900 long (front and back) and four rails 410 long (two end rails and two cross rails). Saw square within 0.3 mm and deburr every end.
2. Lay the rails upside down on a flat bench: the long rails run the full 900; the short rails fit between them, the end rails flush with the ends and the cross rails centred 150 each side of the middle.
3. Before closing the frame, slide drop-in T-nuts into the top slots: three in each long rail and two in each short rail, for the deck screws.
4. Join each meeting with one inside corner bracket on the inside faces, two M5 x 10 screws into T-nuts.

How it fits the parts next to it.

Joint 1: frame corner (front left, seen from inside the frame, deck off)

The end rail fits between the long rails; one inside bracket with two M5 screws into T-nuts



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 3. The end rail butts between the long rails; one inside bracket holds each meeting.

The deck lies on the top faces. The front posts stand on the end rails and the rear posts on the ends of the back rail (Figure 6).

Check before moving on. The diagonals are equal within 2 mm and the frame lies flat on the bench without rocking.

3.2 Deck, water post and drip lip




Figure 4. Deck making sketch (HBN-DWG-102), with the drip lip and the holes that must be made before the deck goes on.

What it is and what it is made from. The wet tray everything stands on. HDPE sheet 12 mm, 900 x 450; aluminium angle 10 x 10 x 1.5 mm for the lip; a 200 mm length of the frame extrusion for the water post.

How to make it.

1. Cut the sheet to 900 x 450 and round the corners lightly.
2. Cut the front notches, one at each end: 20 in from the end edge, from 85 to 145 back from the front edge. Cut the rear notches 40 x 20 at each back corner.
3. Set the deck on the frame, mark through from the T-nuts, and drill 5.5 mm, countersunk from the top, for the frame screws.
4. Drill four 10.5 mm holes for the guard rods on a 156 mm square centred 625 from the left end and 185 from the front edge. Press an M10 tee nut into each from below.
5. Drill one 5.5 mm hole, countersunk from below, 146 from the left end and 80 from the front edge, and screw the water post (Figure 5) to the deck through it, into its tapped end.
6. Cut the lip angle: one piece 900 for the front, and two pieces 75 and two pieces 282 for the ends (they stop at the post notches and at the panel).

How it fits the parts next to it. The deck lies on the frame on countersunk M5 screws into the T-nuts. The lip angles go on in step 2 with one leg flat on the deck at its edge and the other standing 10 up, screwed every 100 mm on a bead of silicone; the panel closes the back edge (Figure 8).

Check before moving on. The deck lies flat on the frame with every notch clear of the brackets; the tee nuts are flush underneath; the water post stands upright.

3.3 Posts




Figure 5. Post and water post making sketch (HBN-DWG-103).

What it is and what it is made from. Four uprights that carry the top frame, canopy and panel. 20 x 20 mm extrusion.


How to make it.

1. Cut four lengths of 582, square, and deburr. (Cut the 200 mm water post from the same bar.)
2. Tap the centre hole M5, 12 deep, at both ends of every post; the water post needs its bottom end only.
3. Slide four T-nuts into the front slot of each rear post for the panel screws.

How it fits the parts next to it.

Joint 2: front post foot (right side)

The post stands on the end rail through a notch in the deck; a bracket in front and one behind



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 6. A front post stands on the end rail through a notch in the deck, held by an inside bracket in front and one behind. A rear post has one bracket, on its inner side (Figure 8).

Check before moving on. Every post is upright within 1 mm over its length.

3.4 Instrument back panel




Figure 7. Instrument back panel making sketch (HBN-DWG-105).

What it is and what it is made from. The back wall of the bench, printed with the energy-chain schematic, carrying the display and the three stage meters. Aluminium composite panel 3 mm.


How to make it.

1. Cut the panel 900 wide x 550 tall. Have the schematic printed on the front first, or apply it as printed vinyl.
2. Drill four 5.5 mm holes 10 in from each side edge, at 60, 220, 380 and 530 up from the bottom edge.
3. Cut the display opening 230 x 100, centred, 355 to 455 up from the bottom edge.
4. Cut three meter openings 80 x 50, 225 to 275 up, with their left edges 75, 205 and 705 from the left side. Check each opening against the meter you bought before cutting; the bezels cover the cut edges.

How it fits the parts next to it.

Joint 4: panel foot and rear post (right side, seen from behind)

The panel screws to the post's front face and stands on the deck on a silicone bead; the foot bracket sits inside the post



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 8. Seen from behind. The panel screws to the front face of the rear post and stands on the deck; the post's foot bracket sits on its inner side.

The back face sits flat on the rear posts on M5 button-head screws into the T-nuts; the bottom edge stands on the deck on a bead of silicone, which closes the back of the drip tray; the top edge meets the underside of the side top rails.

Check before moving on. The panel is flat and square to the deck.

3.5 Top frame




Figure 9. Top frame making sketch (HBN-DWG-104).

What it is and what it is made from. The rectangle at the top of the posts that the canopy lies on. 20 x 20 mm extrusion and eight inside corner brackets.


How to make it.

1. Cut two rails 860 (front and back) and two rails 305 (sides).
2. Slide T-nuts into the top slots for the canopy screws: four in each long rail and two in each side rail.

How it fits the parts next to it.

Joint 3: top frame corner (front right, seen from inside the hood, canopy off)

Rails butt against the post; a bracket under the front rail and one inside the side rail; the canopy lies on top



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 10. Seen from inside the hood with the canopy off. The rails butt against the post; a bracket under each long rail and one inside each side rail; the canopy lies on top.

All rail tops are flush with the post tops, 570 above the deck.

Check before moving on. The diagonals across the top are equal within 2 mm.

3.6 Canopy, duct collar and outlet hanger




Figure 11. Canopy making sketch (HBN-DWG-106).

What it is and what it is made from. The clear hood that gathers any hydrogen at one high point, the duct, for the H2Guard sensor and fan. Polycarbonate sheet 3 mm, a bought 100 mm flanged duct collar, and a 70 mm length of 20 x 20 x 2 mm aluminium angle for the outlet hanger.

How to make it.

1. Cut the sheet 900 x 345, keeping the film on while working.
2. Cut the duct hole 106 across, centred on the middle line, 240 back from the front edge, with a hole saw at low speed.
3. Drill 6 mm screw holes (oversize, so the sheet can move with heat) 10 in from the edges: front and back at 110 and 330 each side of the middle; each side 120 and 220 back from the front edge.
4. Drill two 4.5 mm hanger holes 93 back from the front edge, 150 and 200 right of the middle.
5. Make the outlet hanger (Figure 12): two 4.5 mm holes in the flat leg 10 from each end, two 6.5 mm clip holes in the hanging leg 15 and 55 from the left end, 10 below the canopy.





Figure 12. Outlet hanger making sketch (HBN-DWG-114).

How it fits the parts next to it.

Joint 9: duct collar through the canopy (cut open)

Seen from behind the cut. The spigot passes through a 106 mm hole; the flange sits on a silicone bead; the fan sits on the spigot



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 13. Cut open. The spigot passes through the hole and its flange sits on the sheet on a silicone bead with four M4 screws; the H2Guard fan sits on the spigot.

The sheet lies on the top frame on M5 screws with large washers. The hanger is screwed under the sheet above the tank manifold with two M4 screws, nuts on top.

Check before moving on. No cracks run from any hole; the sheet lies flat.

3.7 Reservoir stand




Figure 14. Reservoir stand making sketch (HBN-DWG-107).

What it is and what it is made from. A folded stand that lifts the water reservoir 60 mm, so its water stands above the electrolyzer's water inlet and feeds it by gravity. Aluminium sheet 2 mm.

How to make it.

1. Cut a blank 114 wide x about 260 long (top 120, legs 58, feet 15); check the bend allowance on a scrap first.
2. Fold the legs down 90 degrees along the two long-side lines, then the feet outward 90 degrees.
3. Drill two 5.5 mm holes in each foot, 30 and 85 from the left edge.

How it fits the parts next to it. The feet lie flat on the deck, the left edge against the left front post and the front foot against the drip lip. The reservoir stands on the top; a band clip holds it to the water post at mid height, and a second band clip holds the deionizer cartridge to the other side of the post.

Check before moving on. The top is level and the stand does not rock.

3.8 Electrolyzer feet




Figure 15. Electrolyzer feet making sketch (HBN-DWG-108).

What it is and what it is made from. Two feet that carry the bought electrolyzer by its end plates. Aluminium unequal angle 40 x 20 x 3 mm.


How to make it.

1. Cut two 70 lengths and deburr.
2. Upright 40 leg: two 6.5 mm holes 30 up from the deck, 25 each side of the middle, to suit the stack's end-plate mounting holes (check them on the stack before drilling).
3. Flat 20 leg: two 5.5 mm holes 11.5 out from the end-plate face, 25 each side of the middle.

How it fits the parts next to it.

Joint 5: electrolyzer foot (right end)

The upright leg bolts to the end plate (two M6); the flat leg screws to the deck (two M5)



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 16. The upright leg bolts flat to the outside face of an end plate, below the lower tie rods; the flat leg points outward and screws to the deck.

The stack's base sits 20 above the deck.

Check before moving on. With the feet on, the stack stands level and does not rock.

3.9 Column bracket




Figure 17. Column bracket making sketch (HBN-DWG-109).

What it is and what it is made from. An upright plate behind the separator and drier that their pipe clips screw to. Aluminium sheet 3 mm.


How to make it.

1. Cut a blank 100 wide x 170 long and fold the bottom 23 back 90 degrees to make a foot; the face is 150 tall.
2. Drill two 5.5 mm holes in the foot, 14 behind the face, at 20 and 78 from the left edge.
3. Drill two 4 mm clip holes 115 above the deck at 20 and 78 from the left edge, in line with the separator and drier centres.

How it fits the parts next to it.

Joint 7: separator and drier clipped to the column bracket

Seen from above the front, columns cut just above the clips. Each clip wraps its column and screws to the bracket.



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 18. A 60 mm pipe clip round the separator and a 40 mm clip round the drier, each screwed through the bracket.

The bracket stands 5 behind the separator, its foot pointing back.

Check before moving on. The face is square to the deck and the clips line up with the column centres.

3.10 Arrestor saddle




Figure 19. Arrestor saddle making sketch (HBN-DWG-110).

What it is and what it is made from. A small block that the check valve and flame arrestor rest in. HDPE 16 mm, 16 x 32 x 24.


How to make it.

1. Cut the block 16 long x 32 wide x 24 tall.
2. Bore a 31 mm half-round seat across the top, its centre 28 above the deck.
3. Drill a 4.2 mm hole 10 up the middle from below for a 5 mm self-tapping screw put up through the deck, and two 3 mm pilot holes in the sides for the band clip ends.

How it fits the parts next to it.

Joint 8: arrestor on its saddle

The arrestor screws straight onto the drier outlet and rests in the saddle seat



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 20. The arrestor screws straight onto the drier outlet and rests in the seat under a band clip.

Check before moving on. The arrestor sits level with the drier outlet and is not strained by its fittings.

3.11 Tank cradle




Figure 21. Tank cradle making sketch (HBN-DWG-111).

What it is and what it is made from. A pocketed block the tank stands in. HDPE 20 mm, 130 x 130.


How to make it.

1. Cut a 130 square.
2. Bore a pocket 112 across and 10 deep, centred, with a router and circle jig (or a hole saw and chisel).
3. Drill four 5.5 mm holes 12 in from each corner.

How it fits the parts next to it.

Joint 6: tank in its cradle, guard rods through the deck (cut open)

Cut through the tank axis. The tank stands 10 mm deep in the pocket; each rod has a nut each side of the deck



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 22. Cut through the tank axis. The tank stands 10 deep in the pocket, 1 clear all round; each guard rod screws into a tee nut under the deck and is locked by a nut above it.

The cradle sits inside the four guard rods, 8 clear of their nuts.

Check before moving on. The tank drops in and stands upright without rocking.

3.12 Guard rods and top plate




Figure 23. Guard rods and top plate making sketch (HBN-DWG-112).

What it is and what it is made from. The guard round the tank: four rods and a top plate. M10 stainless threaded rod; aluminium plate 4 mm.

How to make it.

1. Plate: cut 176 x 176; cut a 130 x 130 opening in the middle (drill the corners, cut with a jigsaw, file straight). Drill four 10.5 mm holes on a 156 square.
2. Rods: cut four lengths of 363. File the ends and run a nut over each end to clean the thread.

How it fits the parts next to it. Each rod screws into its tee nut and is locked with a nut and washer on the deck (Figure 22). The plate is clamped between two nuts on each rod, 60 above the top of the tank; the manifold, gauge and lines pass up through the opening.

Check before moving on. The plate is level within 1 mm, and the tank can be lifted out only once the plate is off.

3.13 Fuel cell bridge




Figure 24. Fuel cell bridge making sketch (HBN-DWG-113).

What it is and what it is made from. A folded stand that lifts the fuel cell 40 mm, open at front and back so its fan can move air through the stack. Aluminium sheet 2 mm.

How to make it.

1. Cut a blank 57 wide x about 190 long (top 85, legs 38, feet 15); check the bend allowance on a scrap first.
2. Fold the legs down 90 degrees, then the feet outward 90 degrees.
3. Drill the top to the stack's mounting holes, and two 5.5 mm holes in each foot, 15 each side of the middle.

How it fits the parts next to it. The stack sits on the top with its hydrogen inlet on the left side, facing the regulator, 5 above the bridge top.

Check before moving on. The stack is level and its fan face is clear of the bridge.

3.14 Bought components, lines and wiring


Buy to specification, not brand. Line numbers are those of the bill of materials.

- **Bench power supply (line 4).** Lab supply 0 to 30 V, 0 to 10 A, constant-current mode, earthed, with a plug-in 30 mA RCD (line 18).
- **Reservoir and deionizer (line 5).** 500 mL HDPE reservoir about 110 across and 170 tall with a low side outlet and a vented lid; mixed-bed resin cartridge with color change, about 50 across and 150 tall, with 6 mm fittings; conductivity check to 1 $\mu\text{S}/\text{cm}$.

- **Electrolyzer (line 6).** 4-cell PEM stack, about 7.8 V at 9 A, end plates about 110 square, hydrogen side rated to 332 kPa or more over the oxygen side, two mounting holes in each end plate, water in and oxygen out on one end plate.
- **Separator and drier (line 7).** Separator column about 60 across and 160 tall with a drain valve at its foot; 50 g indicating silica gel drier about 40 across and 130 tall; both rated 1 MPa or more.
- **Check valve and flame arrestor (line 8).** Stainless check valve, 7 kPa cracking, and a sintered flame arrestor rated for hydrogen, joined in line, about 28 across and 50 long.
- **Tank (line 9).** 2 L aluminium or stainless vessel, 110 across or less, flat base, working pressure 1 MPa or more.
- **Tank manifold (line 10).** Neck adapter carrying a 0 to 600 kPa absolute transducer, a 10 k Ω thermistor bonded to the shell, a relief valve set to 325 kPa gauge, a 0 to 600 kPa gauge, a needle valve set so venting 300 to 20 kPa gauge takes 3 min or more, and a pressure switch set to open at 310 kPa gauge.
- **Regulator and solenoid (line 11).** Regulator 0 to 100 kPa out, set near 50 kPa gauge; 12 V normally closed solenoid on the tank outlet.
- **Fuel cell (line 12).** Air-cooled PEM stack, 12 W class, 13 cells, about 75 x 47 x 70, with fan and purge valve.
- **Load and lamp (line 13), meters and logger (line 14).** Constant-current load 0 to 3 A with a 5 W LED lamp; logger board with three power monitors and shunts, pressure and temperature inputs, a 3.5 in display, and a 12 V relay rated 10 A DC or more.
- **Lines and fixings (lines 16 and 17).** PTFE or polyamide tubing 6 mm and compression fittings rated for hydrogen; 2.5 mm² wire for the electrolyzer supply; stainless M4, M5 and M6 fasteners, M10 tee nuts and nuts, drop-in T-nuts, 5 mm self-tapping screws, silicone sealant, hazard and flow-direction labels.

H2Bench prototype: gas and water lines

Every line is 6 mm tubing with compression fittings rated for hydrogen. Flow runs left to right. Pressures are kPa gauge.



Never open a fitting under pressure. The relief and vent lines end 7 mm below the canopy, so gas they release rises to the H2Guard sensor and the duct.

Blue: water. Red: oxygen with water. Teal: hydrogen. Grey dashed: relief and vent into the hood.


BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 25. Gas and water lines, block level.

H2Bench prototype: power, cut and interlock wiring

Block level. The supply cut and the H2Guard interlock are hardwired and work without the logger firmware.



Safety: the supply is mains powered. Use an earthed supply on the RCD, keep the mains lead off the wet deck, and do not power up until the safety stops in section 6 of the plan are passed. Fuse the 12 V control supply at 1 A.

Red: electrolyzer power. Grey: cut and interlock circuit (any open contact stops the electrolyzer). Blue: measurement.

BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Figure 26. Power, cut and interlock wiring, block level. No circuit board is laid out at this stage; bought modules stand in for it.

The pressure switch on the manifold and the H2Guard relay output are wired in series in the coil circuit of the cut relay, which breaks the positive line from the bench supply to the electrolyzer: any open contact stops the electrolyzer, with no software in the path. H2Guard also breaks the 12 V supply to the normally closed tank solenoid, which closes the tank.


■ 4. Putting it together

In each picture the parts already fitted are grey and the parts being fitted are in colour, with an arrow showing the way they go in.

Step 1: frame rails and corner brackets

Step 1: frame rails and corner brackets

Rails upside down on a flat bench; one inside bracket at each meeting; T-nuts in the top slots



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Rails upside down on a flat bench; one inside bracket at each meeting; T-nuts in the top slots before each joint closes. Turn the frame right way up.

Step 2: deck, water post and drip lip

Step 2: deck and drip lip onto the frame

Countersunk M5 screws into the T-nuts; lip angles screwed every 100 mm on a silicone bead



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Fit the guard-rod tee nuts and the water post to the deck first (section 3.2). Then lay the deck on the frame and fix it with countersunk M5 screws into the T-nuts. Screw the lip angles down every 100 mm on a bead of silicone.

Step 3: posts onto the frame

Step 3: posts onto the frame

Each post through its deck notch onto the frame; front posts two brackets, rear posts one



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Each post stands through its deck notch onto the frame. Front posts: one bracket in front and one behind, on the end rail. Rear posts: one bracket on the inner side, on the back rail. Square each post before tightening.

Step 4: instrument panel and top frame

Step 4: instrument panel and top frame

Panel on the rear posts, four M5 each side, silicone at its foot; then the four top rails and brackets



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Run a bead of silicone along the deck where the panel stands, set the panel against the rear posts and fit four M5 button-head screws each side. Then fit the four top rails and their eight brackets, flush with the post tops.

Step 5: canopy, duct collar and outlet hanger

Step 5: canopy, duct collar and outlet hanger

Sheet on the top frame with M5 screws and large washers; collar flange on silicone; hanger under the sheet



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the hanger under the sheet, then lay the sheet on the top frame and fit twelve M5 screws with large washers, snug, not tight. Fit the duct collar through its hole, flange on a bead of silicone, four M4 screws.

Step 6: reservoir stand, reservoir and cartridge

Step 6: reservoir stand, water post, reservoir and cartridge

Stand and post screwed to the deck; reservoir on the stand; band clips round both vessels to the post



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the stand down (Table 2). Stand the reservoir on it and the cartridge on the deck beside the water post; fit a band clip round each to the post.

Step 7: electrolyzer on its feet

Step 7: electrolyzer on its feet

Feet bolted to the end plates first (two M6 each), then the stack set down and the feet screwed to the deck



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Bolt the feet to the end plates first, two M6 each. Set the stack down with its hydrogen outlet to the right and its water ports to the back, and screw the feet to the deck.

Step 8: column bracket, separator, drier and arrestor

Step 8: column bracket, separator, drier and arrestor

Bracket and saddle screwed down; columns clipped to the bracket; arrestor screwed onto the drier outlet



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the column bracket and the arrestor saddle down. Clip the separator and drier to the bracket. Screw the check valve and arrestor onto the drier's outlet, arrow toward the tank, and close the band clip over it.

Step 9: cradle, guard rods and tank

Step 9: cradle, guard rods and tank

Cradle screwed down; rods through the deck with a nut each side; tank lowered into the pocket



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the cradle down. Screw each rod into its tee nut and lock it with a nut and washer on the deck. Lower the tank into the pocket, neck up.

Step 10: tank manifold and guard top plate

Step 10: tank manifold and guard top plate

Manifold into the tank neck on hydrogen thread sealant; plate onto the rods, nut below and above



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the manifold into the tank neck on thread sealant rated for hydrogen, gauge to the front, cut switch to the back. Run a nut down each rod to 56 above the tank top, drop the plate on, and fit a nut above it.

Step 11: regulator, fuel cell and load

Step 11: regulator, fuel cell and load

Regulator and bridge screwed down; stack screwed to the bridge; load case screwed to the deck



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Screw the regulator and the fuel cell bridge down, then the fuel cell to the bridge, hydrogen inlet to the left. Screw the load case to the deck at the front right.

Step 12: gas and water lines

Step 12: gas and water lines

Cut each line square, deburr, compression fittings; relief and vent lines clipped to the hanger. Hold point: leak check



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Fit every line as Figure 25 shows: cut each tube square, deburr it, fit the inserts and compression nuts, and keep every gas line at least 5 clear of the tank. Clip the relief and vent lines to the hanger, ends 7 below the canopy. Label each line with its flow direction. **Hold point:** the leak checks of safety stop S3.

Step 13: power supply, meters and wiring

Step 13: power supply, meters and wiring

Meters into the panel cut-outs; supply on its feet; wire as the wiring diagram. Hold point: wiring checks



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT


github.com/BoujeeEnjinia1701/h2bench

Fit the meters and display into the panel openings and the logger behind the panel. Stand the supply on the deck at the left, mains lead routed off the deck. Wire as Figure 26 with the supply switched off and unplugged. **Hold point:** the wiring checks of safety stop S2.

Step 14: H2Guard sensor, fan and controller

Step 14: H2Guard sensor, fan and controller

Sensor under the canopy beside the duct, fan on the collar, controller on the canopy; interlock wired to the supply cut



BUILD PLAN ILLUSTRATION, PLAN NOT YET BUILT

github.com/BoujeeEnjinia1701/h2bench

Fit the H2Guard sensor under the canopy beside the duct, the fan on the collar and the controller on the canopy, as the H2Guard project describes. Wire its relay output in series with the cut switch and in the solenoid supply (Figure 26). **Hold point:** safety stop S4.

■ 5. First checks

These are the checks a TRL 4 test report would record; this plan only lists them. Requirement numbers are those of HBN-REQ-001.

Table 3. First checks.

Check	Requirement	How	Pass when
Size and mass	R13	Measure the envelope; weigh the bench with and without the supply	Within 1,000 x 500 x 800 mm; mass recorded against 25 kg
Guard and lines	R15	Look at the guard and every line end	Tank inside the guard, top plate on; relief and vent lines end under the canopy; no fitting opens without a tool
Water quality	R11	Conductivity at the stack inlet after the cartridge	1 μ S/cm or less
Leak tightness	R5, R7	Nitrogen at 300 kPa gauge for 30 min, soapy water on every fitting (S3)	No bubbles; pressure fall within the transducer's resolution after temperature correction
Supply cut	R6	Raise the manifold pressure with nitrogen to the switch point while watching the relay (S3)	The relay opens at 310 kPa gauge, give or take 5
Relief valve	R6	Bench test of the relief valve before fitting	Lifts at 325 kPa gauge, give or take 10
Interlock	R8	H2Guard test input or test gas at the sensor with the supply on a dummy load (S4)	Supply cut and solenoid closed within 2 s; fan runs
Electrolyzer power	R3	Constant current 9 A, first fill (S5)	100 W or less at the stack
Fill and cycle time	R2	Time one fill from 70 to 300 kPa gauge and one discharge	Fill plus discharge within 60 min
Fuel cell output	R4	Lamp load at 1.5 A (S6)	10 W or more net
Logging	R12	Log one cycle	Voltage, current, power, pressure and temperature at 1 Hz in a CSV file
Measurement	R1	Hydrogen counted by gas law and by charge for three fills	Stage efficiencies repeat within 5 % relative
Vent and shutdown	R16	Vent 300 to 20 kPa gauge through the needle valve; time a full setup and shutdown	Vent 3 min or more; bench safe within 5 min; setup within 15 min

■ 6. Safety stops

Stop at each point. Carry on only when everything listed is true.

- **S1. Before any work with the parts.** The workspace has a fire extinguisher for electrical fires, a clear route out, and no open flames, heaters or sparking tools near the bench. Safety glasses and gloves for cutting and drilling.
- **S2. Before the bench supply is plugged in.** The supply is earthed and plugged into the 30 mA RCD, which trips on its test button. The mains lead runs off the deck. With the supply off, the cut relay is open whenever the cut switch or the H2Guard contact is open (meter check). Wire sizes and polarity are checked against Figure 26.

- **S3. Before any gas pressure.** Every fitting is tight and labelled. Leak test with nitrogen, not air or hydrogen: 50 kPa gauge first, then 300 kPa gauge, soapy water on every fitting, 30 min hold. Check the cut switch at 310 kPa gauge with nitrogen. Vent the nitrogen through the needle valve, never by opening a fitting.
- **S4. Before any hydrogen is made.** H2Guard is fitted and tested: its alarm, its cut of the electrolyzer supply and its close of the tank solenoid all work within 2 s, and the fan extracts through the duct to outdoors. The relief valve has been bench tested. A trained supervisor is present.
- **S5. First fill.** Purge the tank of nitrogen and air by three fill and vent cycles to 300 kPa gauge, venting slowly through the needle valve each time (3 min or more). Attended the whole time, hood fan running. Stop at any H2Guard warning, any smell of burning, or any pressure above 300 kPa gauge that the cut does not stop. Keep the tank above 20 kPa gauge from then on so air cannot enter.
- **S6. Before the fuel cell runs.** The fuel cell supplier has accepted the gas the bench makes, or the deoxidizer is fitted (see the register). The regulator is set to about 50 kPa gauge with the solenoid closed and the fuel cell disconnected.
- **S7. Before students use the bench.** All first checks of section 5 are recorded; the supervisor knows the vent, purge and shutdown sequence; the room meets the site's hydrogen risk assessment.

■ 7. Tools, skills and workspace

Tools. Hacksaw with a 24 teeth per inch blade, or a mitre saw with a non-ferrous blade; bench vice with soft jaws; drill in a stand; drills 3 to 10.5 mm; countersink; M5 tap; hole saws 106 and 112 mm, or a router with a circle jig; jigsaw with metal and plastic blades; files and deburring tool; scribe, engineer's square, steel rule and calipers; hand sheet folder (or hardwood angle in the vice) for 2 and 3 mm aluminium up to 120 mm wide; tube cutter for 6 mm tubing; spanners for compression fittings; torque screwdriver; caulking gun; multimeter; conductivity meter; stopwatch; scale to 30 kg; nitrogen cylinder with a regulator to 0 to 400 kPa gauge for leak testing; leak detection fluid.

Skills. No certified trade is needed for the build. Basic metalwork (marking out, sawing, drilling, tapping, folding thin sheet), plastic sheet work, making compression fittings on small tubing, and low-voltage wiring. The mains side is a bought, earthed supply plugged into an RCD; no mains wiring is part of this build. Running the bench with hydrogen needs a supervisor trained in hydrogen handling.

Workspace. A bench about 1.5 x 0.8 m in a ventilated room; a metalwork corner kept apart from the electronics; for the first fill, a lab with an extraction route outdoors for the H2Guard duct.

Personal protective equipment. Safety glasses for cutting, drilling and all gas work; cut-resistant gloves for aluminium and polycarbonate; hearing protection when sawing; no gloves near a turning drill.

■ 8. Where the numbers come from

- Model and constructability checks: `cad/src/model.py` (`python cad/src/model.py --check` , 135 checks); STEP and STL exports in `cad/step/` and `cad/stl/` .
- Pictures: `cad/src/build_plan_media.py` , using `.kit/build_views.py` ; written to `docs/05-build-plan/` and `cad/drawings/HBN-DWG-101` to `HBN-DWG-114` .
- General arrangement: `cad/drawings/HBN-DWG-001.pdf` , Rev P3.
- Calculations: `docs/04-calcs/01-sizing.md` (HBN-CAL-001 v0.4) and `docs/04-calcs/sizing.py` ; mass in section 9, cost in section 10.

- Bill of materials: `bom/bom.csv` .
- Decisions: `docs/decisions/0003-design-for-construction.md` (HBN-DDR-003), with HBN-DDR-001 and HBN-DDR-002; the register `docs/06-design-decisions.md` (HBN-DEC-001).
- Requirements: `docs/03-requirements.md` (HBN-REQ-001 v0.6).