BUILD PLAN SKETCH, PLAN NOT YET BUILT

SeedLine · github.com/BoujeeEnjinia1701/seedline

REV	DESCRIPTION	DATE	BY
P1	Making sketch for the prototype build plan	2026-10-01	AC
P2	Kit 1.9 detailed model; SDL-DEC-001 F1 to F8	2026-10-24	AC



TOP VIEW

Scale 1:5; looking down (along -Z)

FRONT VIEW

Scale 1:5; looking at the front (along +Y)

RIGHT VIEW

Scale 1:5; looking at the right side (along -X)

WHERE IT GOES

This part in colour, its neighbours in grey

HOW TO MAKE IT AND HOW IT FITS

Cut 275 mm of 18 x 1.5 tube.
Flatten 13 mm at each end and set each flat to lie on the front of a side tube (about 10 degrees); length between the flats 249 mm.
Drill 6.5 mm through each flat.
Fit: across the front of the two lower tubes, about 30 % of the way up from the drop plates; drill each lower tube through the flat and bolt with an M6 bolt and nyloc nut.
Check: the side tubes stay parallel to the grip ends with the brace on.

SEEDLINE

github.com/BoujeeEnjinia1701/seedline

SeedLine handle brace: making sketch

DRAWING NO.	REV	SHEET	SIZE
SDL-DWG-122	P2	1 of 1	ANSI B

SCALE	UNITS	PROJECTION	DATE	DRAWN
1:5	mm		2026-10-24	Amish Chadha

MATERIAL / NOTES

Steel round tube 18 x 1.5 mm

Licensed CERN-OHL-S-2.0 · Design Molecule Lab · designmolecule.com

Generated from cad/src; do not edit by hand