

REV	DESCRIPTION	DATE	BY
P1	Making sketch for the prototype build plan	2026-10-03	AC



WHERE IT GOES

This part in colour, its neighbours in grey

HOW TO MAKE IT AND HOW IT FITS

Cut 600 of 50 mm tubular webbing with a hot knife so the ends are sealed. Mark its middle.

Feed the chain's adjustable end through it before the master link is fitted, and slide it to the middle of the loop.

It lies on the bark at the back of the trunk, opposite the frame, where the chain presses hardest.

On a 200 trunk it covers almost the whole loop; on bigger trunks the chain each side of it is bare.

Replace it when it is cut through to the chain.



TOP VIEW

Scale 1:5; looking down (along -Z)



FRONT VIEW

Scale 1:5; looking at the front (along +Y)



RIGHT VIEW

Scale 1:5; looking at the right side (along -X)

TRUNKBELAY

github.com/BoujeeEnjinia1701/trunkbelay

TrunkBelay: chain sleeve (make 1)

DRAWING NO. TKB-DWG-109			REV P1	SHEET 1 of 1	SIZE ANSI B
SCALE 1:5	UNITS mm	PROJECTION 	DATE 2026-10-03	DRAWN Amish Chadha	
MATERIAL / NOTES 50 mm (2 in) tubular nylon webbing					

Licensed CERN-OHL-S-2.0 · Design Molecule Lab · designmolecule.com

Generated from cad/src; do not edit by hand