Cut Sheet

Board Design Summary

Style: brick-basketweave
Dimensions: 12.000" (12") × 18.000" (18") × 1.500" (1 1/2")
Species: Walnut, Maple

[Step Diagram]

Cut List

Part	Qty	Width	Thickness	Length	Species
Board strips (Walnut)	10	1.000" (1")	1.500" (1 1/2")	16.000" (16")	Walnut
Board strips (Maple)	10	1.000" (1")	1.500" (1 1/2")	16.000" (16")	Maple

Board Layout (Top View)

[Step Diagram]

Step 1: Mill rough stock

Joint edges on the jointer. Plane to final thickness using multiple passes.

Settings:

Planer depth: 38.1 mm (1.5")
Feed rate: Slow
+ 1 more settings, see step text

WARNING: Keep hands away from cutterhead. Use push blocks.

CAUTION: Ensure stock is flat before planing.

[Step Diagram]

Step 2: Rip strips to width

Set rip fence to 25.4 mm (1"). Cut all strips to uniform width.

Settings:
Rip fence: 25.4 mm (1")
Blade height: 45 mm

WARNING: Use push stick. Keep hands clear of blade.

[Step Diagram]

Step 3: Crosscut strips to length

Use stop block on crosscut sled. Cut all strips to exact length.

Settings:
Stop block position: 406.4 mm (16")
Blade height: 45 mm

WARNING: Never reach over the blade.

[Step Diagram]

Step 4: Glue-up checkerboard pattern

Arrange strips in alternating pattern. Apply even pressure with clamps. Let dry 24 hours.

[Step Diagram]