Cut Sheet

Board Design Summary

Style: chevron
Dimensions: 12.000" (12") × 18.000" (18") × 1.500" (1 1/2")
Species: Walnut, Maple

[Step Diagram]

Cut List

Part	Qty	Width	Thickness	Length	Species
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple
Walnut/Maple strip-set panel: glue 22 strips (one per species, alternating) edge-to-edge; flatten and square ends (never fence)	1	12.000" (12")	1.500" (1 1/2")	18.000" (18")	Walnut, Maple

Board Layout (Top View)

[Step Diagram]

Step 1: Mill rough stock

Joint one face and one edge on the jointer, then plane to final thickness plus 1/8" (3 mm). Rest overnight, then plane to final thickness. Take ~1/64" (0.4 mm) passes for the last two passes.

Settings:

Final pass depth: ~1/64" (0.4 mm)

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.

[Step Diagram]

Step 2: Rip strips

Rip strips with the jointed edge against the fence. Measure from the fence face to the near side of a tooth set toward the fence.

Settings:

Fence to blade: strip width from cut list

WARNING: Use the riving knife and blade guard on every through cut.

WARNING: Use a push stick for any rip narrower than 6" (152 mm). Never reach over or behind the blade.

[Step Diagram]

Step 3: Glue up

Glue the strip panel. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 4: Angled cuts

Cut the panel into parallelograms at the chevron angle on a sled with a hold-down.

Settings:

Angle: from design

Piece width: from cut list

WARNING: Make angled cuts on a sled or miter gauge with a hold-down, never against the rip fence alone.

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

[Step Diagram]

Step 5: Flip and pair

Flip alternate pieces so the stripes meet in a V.

[Step Diagram]

Step 6: Glue up

Glue pieces, using cauls to stop them sliding on the angle. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 7: Trim to rectangle

Trim the pointed ends square on a crosscut sled.

DANGER: Never use the rip fence as a length stop for crosscuts. Use a crosscut sled with a stop block set before the blade, so the offcut is never trapped between blade and fence.

[Step Diagram]

Step 8: Flatten and sand

Scrape glue, then plane flat if the panel is no wider than 12" (305 mm), otherwise use the router sled or drum sander. Sand 80, 120, 180 grit. Break edges (180 grit).

Settings:

Grits: 80 / 120 / 180

WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.

[Step Diagram]

Step 9: Edge profile

Rout the edge profile, default: 1/8" (3 mm) roundover. Optional finger grips: core box / round-nose bit 3/8–1/2" (9.5–12.7 mm).

Settings:

Bit: 1/8" (3 mm) roundover

WARNING: Climb cuts can grab. Feed the router against the bit rotation and take shallow passes.

[Step Diagram]

Step 10: Finish

Raise the grain with a damp cloth, sand 180 again, then flood with food-safe mineral oil and top with board butter.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.