Cut Sheet

Board Design Summary

Style: scrap-chaotic
Dimensions: 12.008" ("H12 1/64") × 15.984" ("H15 63/64") × 1.496" ("H1 1/2")
Species: Walnut, Maple, Cherry
Rubber Feet: 4 rubber feet, 1" (25.4 mm) diameter × 3/8" (9.5 mm) high, foo
from the edges (underside).

[Step Diagram]

Cut List

Part	Qty	Width	Thickness	Length	Species
Maple blank (mill & rip, then crosscut 3 slices)	1	[illegible]	[illegible]	[illegible]	Maple
Walnut blank (mill & rip, then crosscut 3 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Walnut blank (mill & rip, then crosscut 5 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Walnut blank (mill & rip, then crosscut 1 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Maple blank (mill & rip, then crosscut 4 slices)	1	[illegible]	[illegible]	[illegible]	Maple
Cherry blank (mill & rip, then crosscut 3 slices)	1	[illegible]	[illegible]	[illegible]	Cherry
Walnut blank (mill & rip, then crosscut 3 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Maple blank (mill & rip, then crosscut [illegible] slices)	1	[illegible]	[illegible]	[illegible]	Maple
Walnut blank (mill & rip, then crosscut 4 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Cherry blank (mill & rip, then crosscut 6 slices)	1	[illegible] [Width exceeds jointer; use planer sled or hand flatten]	[illegible]	[illegible]	Cherry
Cherry blank (mill & rip, then crosscut 2 slices)	1	[illegible]	[illegible]	[illegible]	Cherry
Walnut blank (mill & rip, then crosscut 4 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Walnut blank (mill & rip, then crosscut 2 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Walnut blank (mill & rip, then crosscut 3 slices)	1	[illegible]	[illegible]	[illegible]	Walnut
Maple blank (mill & rip, then crosscut 2 slices)	1	[illegible]	[illegible]	[illegible]	Maple

Board Layout (Top View)

[Step Diagram]

Step 1: Mill rough stock

Joint one face and one edge on the jointer, then plane to final thickness plus 1/8" (3 mm). Rest overnight, then plane to final thickness. Take ~1/64" (0.4 mm) passes for the last two passes.

Settings:

Final pass depth: ~1/64" (0.4 mm)

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.

[Step Diagram]

Step 2: Sort offcuts

Discard pieces with checks, knots or softwood. Only pieces at least 12" (305 mm) long go through the jointer and planer; glue shorter offcuts onto a 305 mm carrier panel first or sand them to thickness. Cut pieces of 6" (152 mm) or less only on a sled with a hold-down.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

Step 3: Glue up

Glue offcuts into rough panels. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 4: Crosscut slices

Crosscut slices on a crosscut sled with a stop block.

DANGER: Never use the rip fence as a length stop for crosscuts. Use a crosscut sled with a stop block set before the blade, so the offcut is never trapped between blade and fence.

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

[Step Diagram]

Step 5: Glue up

Glue slices end grain up in random order. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 6: Flatten and sand

Flatten with a router sled or drum sander, never the thickness planer. Sand 80, 120, 180 grit. Break edges (180 grit).

Settings:

Grits: 80 / 120 / 180

DANGER: Never run an end-grain glue-up through the thickness planer. It can blow apart. Flatten with a router sled or drum sander.

[Step Diagram]

Step 7: Edge profile

Rout the edge profile, default: 1/8" (3 mm) roundover. Optional finger grips: core box / round-nose bit 3/8–1/2" (9.5–12.7 mm).

Settings:

Bit: 1/8" (3 mm) roundover

WARNING: Climb cuts can grab. Feed the router against the bit rotation and take shallow passes.

[Step Diagram]

Step 8: Finish

Raise the grain with a damp cloth, sand 180 again, then flood with food-safe mineral oil and top with board butter.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.