# Cut Sheet

## Board Design Summary

Style: edge-grain

Dimensions: 300 mm × 450 mm × 38 mm

Species: Walnut, Maple

Juice Groove: Perimeter loop, 10 mm wide × 8 mm deep, 20 mm from the edge, corner radius 25.5 mm, top face.

Rubber Feet: 4 rubber feet, 1" (25.4 mm) diameter × 3/8" (9.5 mm) high, foot centres 25.4 mm in from the edges (underside).

[Step Diagram]

## Cut List

| Part | Qty | Width | Thickness | Length | Species |
|---|---|---|---|---|---|
| Walnut blank (mill & rip, then crosscut 3 × 450.0 mm slices) | 1 | 47.3 mm | 43 mm | 915 mm | Walnut |
| Maple blank (mill & rip, then crosscut 3 × 450.0 mm slices) | 1 | 47.3 mm | 43 mm | 915 mm | Maple |
| Maple blank (mill & rip, then crosscut 3 × 450.0 mm slices) | 1 | 42.5 mm | 43 mm | 503.2 mm | Maple |

## Board Layout (Top View)

[Step Diagram]

## Step 1: Mill rough stock

Joint one face and one edge on the jointer, then plane to final thickness plus 1/8" (3 mm). Rest overnight, then plane to final thickness. Take ~1/64" (0.4 mm) passes for the last two passes.

**Settings:**

Final pass depth: ~1/64" (0.4 mm)

**WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).**

**WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.**

[Step Diagram]

## Step 2: Rip strips

Rip strips to the board's final thickness plus 1/8" (3 mm) with the jointed edge against the fence. Measure from the fence face to the near side of a tooth set toward the fence.

**Settings:**

Fence to blade: strip width from cut list

**WARNING: Use the riving knife and blade guard on every through cut.**

**WARNING: Use a push stick for any rip narrower than 6" (152 mm). Never reach over or behind the blade.**

[Step Diagram]

## Step 3: Rotate strips

Turn every strip 90° so the edge faces up. Keep growth rings alternating.

[Step Diagram]

## Step 4: Glue up

Glue strips edge to edge. Alternate clamps above and below the panel and check for flat with a straightedge.

**Settings:**

Clamp spacing: about 8" (200 mm)

**NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.**

[Step Diagram]

## Step 5: Trim to length

Square both ends on a crosscut sled.

**DANGER: Never use the rip fence as a length stop for crosscuts. Use a crosscut sled with a stop block set before the blade, so the offcut is never trapped between blade and fence.**

[Step Diagram]

## Step 6: Flatten and sand

Scrape glue, then plane flat if the panel is no wider than 12" (305 mm), otherwise use the router sled or drum sander. Sand 80, 120, 180 grit. Break edges (180 grit).

**Settings:**

Grits: 80 / 120 / 180

**WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.**

[Step Diagram]

## Step 7: Edge profile

Rout the edge profile, default: 1/8" (3 mm) roundover. Optional finger grips: core box / round-nose bit 3/8–1/2" (9.5–12.7 mm).

**Settings:**

Bit: 1/8" (3 mm) roundover

**WARNING: Climb cuts can grab. Feed the router against the bit rotation and take shallow passes.**

[Step Diagram]

## Step 8: Finish

Raise the grain with a damp cloth, sand 180 again, then flood with food-safe mineral oil and top with board butter.

**NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.**