LK Motor Firmware Upgrade Instruction 上海瓴控科技电机固件升级说明

1. Connect Motor via UART port to LK motor tool software 通过串口将电机连接到 LK motor tool software 上位机



2. Select Product tab, Click Open File button, Choose proper firmware 在上位机中选择 Product 页,点击 Open File 按钮,选择对应的固件

Motor: MG8016E

Motor version: V2.0

Driver: DG80C7E

Hardware version: V2.0

Firmware version: V2.31

DG80C7V2-MG8016E V2.31.Bin	Open File
	Download
Chip ID: 373238200A50325234002000	Re

3. Click Download, firmware upgrading will be initiated in 5 seconds 点击 Download 按钮. 固件升级将会在 5 秒内开始

Hardware version: V2.0

Firmware version: V2.31



4. Wait until firmware upgrading finished

等待电机固件升级完成

Driver: DG80C7E

Hardware version: V2.0

Firmware version: V2.31



DG80C7V2-MG8016E V2.31.Bin

Open File

Writing