

Sunplus DVD 通信协议

Communication Interface Specification(Sunplus)

Version 0.4

制作/Prepared: 软件部/Software Department

确认/Checked:

审核/ Approved: ?

公司:惠州市华阳多媒体电子有限公司

地址: 厂东省惠州市东江高新科技产业园上霞北路1号

邮编: 516005

软件负责人: 蒋琪海

联系电话: 0086-752-5300583

Contact: Mini Jiang

Company: Foryou Multimedia Electronics Co., Ltd

Addr:North Shangxia Road,Dongjiang Hi-tech Industry Park, Huizhou City, Guangdong China.

Tel: 0086-752-5300583 Fax: 0086-752-5300666

www:Http://www.foryoumedia.com.cn



版本更新/Version Update(与 ZORAN 差异部分/Diffenrences from ZORAN CIS,具体不同部分参考各个命令的红色部分/Please refer to the red part of each command for details of the differences):

| 日期/Date | Author | 实现/realize | 输入差异 | 输出差异/Ouput Diff | 备注/Remarks |
|------------|--------|---|--|--|---|
| 2013.9.27 | 郑旭群 | 查询文件系统概况 Request Summary of FileSystem(0x9F)/发 送文件系统概况 Report(0xEF) | None | 帧格式保持与 Zoran一致,但内 容不像Zoran提 供树目录结构, Sunplus目录只 有单层。/Suplus has only single directory | 暂以Sunplus目录结构为准/ Use the Directory structure of Sunplus |
| 2013.9.27 | 郑旭群 | 查询文件及文件夹信息Request the Attribute of File or Folder(0xA0)/发送文件及文件夹信息 Report(0xF0) | None | 1.单层目录结构的信息: / Only single directory 2.文件文件夹名使用 Unicode 编码 /the file and the file name use the Unicode for decoding 3.文件类型和文件扩展名类型有差异。/The file type and Extension Name has difference | 暂以Sunplus目录结构为准/ Use the Directory structure of Sunplus |
| 2013.10.8 | 文志勋 | 播放模式回复Play Mode Report(0xDA) | None | PlayMode有差异 /Diff on Playmode | Cancel Random mode, add ShuffleAndIntro |
| 2013.10.8 | 文志勋 | 旁白/字幕回复 Audio/Subtitle Information Report(0xDE) | None | AudioType 有 差 异 /Diff on AudioType | 暂以Sunplus提 供AudioType为 准/Use the audio type supplied by sunplus |
| 2013.10.08 | 商伟 | 视频比例设置/ Video Shape Config(0x09) 与/and 设置填充模式/ View Mode Config(0x0a) 合并。保留0x09 | Aspect Ratio: 0x00→16:9; 0x01→4:3LB ; 0x02→4:3PS | None | Done |



| | ı | | | I | |
|------------|------------|---|---|--|---|
| | | | ; | | |
| 2013.10.10 | 卓文洪/ 商伟 | 视频设置响应/Video Setup Report(0xc3) | None | Ox06位: 保留位, 输出为OXFF; Ox07位: 由图像 输出模式/ Smart Picture 改为锐利 度/Sharpness Ox0b位: 由色彩 /color改为饱和度 / Saturation Byte6:Realase, default Oxff; Byte7:change Smart Picture to Sharpness; Byte0b:change color to Saturation | Ox0a位: 色调为0时,SETUP选项中为 -6/byte 0x0a:when the value of Hue is 0,the value on setup menu equal to -6 |
| 2013.10.12 | 梁瑞庆 | 机芯错误状态回复 Error Status Report(0xC1) | None | 见详细命令中的 灰色字体为不支 持参数/ The parameter in gray color is N/A | Done |
| 2013.10.15 | 文志勋 | 遥控指令IR Command(0x6B) | 增加上下翻 页IR/add IR_PAGE_U P and IR_PAUGE_ DOWN | None | Done |
| 2013.10.15 | 文志勋 | 选择clips曲目播放 Goto Mp3 File(0x67) | 返回文件夹 菜单发送 Item 0/return to folder by Item 0 | None | Done |
| 2013.10.16 | 郑旭群 | 查询clips文件名Clips Name Request(0x8F)/ clips文件名回复 Report(0xD9) | None | 1. 命令长度由 0x26 改 为 0x16;/the length of cmd change from 0x26 to 0x16 2. 文件扩展名类 型有差异./Diff on | 发送是混合不同 类型文件的数 据,与当前 Sunplus分类型 显示的菜单不一 致。/the report file name is a mixed type data |



| | | | | Extension Name | but not cale |
|----------------------|-------|-----------------------|------------|-------------------|-------------------|
| | | | | Extension Name | but not only |
| | | | | | single type(sunc |
| | | | | | only |
| | | | | | music/video/pho |
| | | | | | to) data |
| | | | | | ZORAN是整碟 |
| | | | | | 连续播放,而 |
| | | | | | Sunplus是分类 |
| | | | | | 型播放结束。 |
| | | | | | /Zoran indicate |
| | | clips碟自动播放结束 | | 1.结束的时刻不 | the end of the |
| 2013.10.17 | 郑旭群 | 回复End of Auto Play | None | 同 /the end of | whole |
| 2013.10.17 | 70/巴什 | | None | time is different | disc,Sunplus |
| | | for Clips Disc(0xE8) | | than befor | only indicate the |
| | | | | | end of one type |
| | | | | 9 | playback type |
| | | | | • | such as |
| | | | | 3 | music/video/pho |
| | | | | | to |
| | | | Cancel the | Y | |
| | | | IR: | | |
| | | 遥控指令/IR | 0x39、0x52、 | | _ |
| 2013.10.30 | 丁春玉 | Command(0x6B) | 0x53 、 | None | Done |
| | | | 0x62-0x65、 | | |
| | | 20' | 0x6e-0x78 | | |
| | D#4 | 快/慢进/Fast/Slow | | 无慢退功能/No | _ |
| 2013.11.1 | 吴其东 | Forward (0x4D) | None | SlowB Speed | Done |
| | | 快/慢退/Fast/Slow | | 无慢退功能/No | |
| 2013.11.1 | 吴其东 | Backward (0x4E) | None | SlowB Speed | Done |
| | | | | 1. 慢进(慢退) | |
| | 4 | | | 功能速度是由2 | |
| 4 | | | | 倍数递增修改为 | |
| ~~ | 3 | | | 1倍数递增/ | |
| ∇O_{λ} | | | | SlowF(SlowR) | |
| X | | 播放状态获取/Play_ | | Speed increase | |
| , | 吴其东/ | State Request(0x84) / | | by two times to | |
| 2013.11.1 | 卓文洪 | 机芯播放状态回复 | None | one times | Done |
| | 1 200 | /Mechanism Play | | 2.播放状态减少 | |
| | | State Report(0xCC) | | Reverse Still | |
| | | | | Wait UI等状态 | |
| | | | | /delete Reverse | |
| | | | | Still and Wait UI | |
| | | | | state | |
| 2013.11.1 | 丁春玉 | 设备状态回复 | None | | Done |
| 2013.11.1 | 丁春玉 | 设备状态回复 | None | 见详细命令中的 | Done |



| | | | | T | |
|------------|---------|--------------------------------|---------------|-------------------|-------------|
| | | Mechanism State | | 灰色字体为不支 | |
| | | Report(0xCB) | | 持参数/ | |
| | | | | The parameter | |
| | | | | in gray color is | |
| | | | | N/A | |
| | | 当前设备状态查询 | 增加当前设 | 见详细命令中的 | |
| | | /Mechanism State | 备查询,发送 | 红色字体为变更 | |
| | | Request(0x83) | 0Xff/Get | 含义参数/ | |
| 2013.11.7 | 文志勋 | 设备状态回复 | current | The parameter | Done |
| | | Mechanism State | device | in red color is | . 4 |
| | | Report(0xCB) | state,Devicel | different | |
| | | <u>rtoport(oxob)</u> | D is 0xFF. | meaning. | |
| | | | | 见详细命令中的 | 0' |
| | | | | 灰色字体为不支 | > |
| | | 当前连接设备/Current | | 持参数红色字体 | |
| 2013.11.7 | 文志勋 | Connect Device | None | 为变更含义参数/ | Done |
| 2010.11.7 | Z10.797 | Report(0xDD) | 140110 | The parameter | Bono |
| | | <u>ποροπίολου</u> | | in gray is N/A,in | |
| | | | | red is different | |
| | | | _ | meaning. | |
| | | | | 增加不同方式的 | |
| | | 设备状态回复 | | 进 仓 参 数 /The | |
| 2013.11.18 | 文志勋 | Mechanism State | None | parameter for | Done |
| | | Report(0xCB) | > | close tray | |
| | | | | differently | |
| | | 打开版本菜单/Open | | | |
| 2013.11.25 | 王彬 | 打开版本来手/Open | New cmd | | |
| 2013.11.23 | 1.40 | Version Menu(0x7b) | added | | |
| | | | | | |
| | | | | 红色为新增加的 | |
| | | | | 参数,碟片类型与 | |
| | | | | Zoran 不一样 | |
| | | 媒体信息回复/Media | | //the parameter | |
| 2013.12.18 | 梁瑞庆 | | None | in red color is | Done |
| | | Status Report(0xCD) | | added,and the | |
| | | | | disc type is | |
| | | | | different from | |
| | | | | Zoran | |
| | | Update clips file type | | Clips file type | |
| | | and externsion name | | and externsion | |
| 2013.12.29 | 梁瑞庆 | on 0xF0, update the | None | name update,pls | Done |
| | | clips file type on <u>0xD9</u> | | see details on | |
| | | | | CMD | |
| | | | | • | • |



| 2014.01.10 | 王彬 | OSD设置/ OSD Setting (0x13) | New cmd added | | |
|------------|--------|---|---|---|--|
| 2014.02.7 | 文志勋 | 语言设置/ Language Setup (0x05) | 完善语言对 照表/ Modify Unicode Table | None | Done |
| 2014.3.4 | Declan | Memory data 0x73 <=> 0xED | The length of this cmd is variable according to each memory type,memory type is updated | The length of this cmd is variable according to each memory type,memory type is updated | Done |
| 2014.3.24 | 蒋琪海 | Parental Control (0x14) Dynamic Range(0x17) | ~ | oc | |
| 2014.3.27 | 文志勋 | 语言设置响应 /Language Setup Report(0xC5) | | Divx Language unsupported | Done |
| 2014.12.02 | 卓文洪 | 视频设置/Video Setup (0x03) | None | Ox06位: 保留位, 输出为OXFF; Ox07位: 由图像 输出模式/ Smart Picture改为锐利 度/Sharpness Ox0b位: 由色彩 /color改为饱和度 / Saturation Byte6:Realase, default Oxff; Byte7:change Smart Picture to Sharpness; Byte0b:change color to Saturation | Ox0a位: 色调为0时,SETUP选项中为 -6/byte 0x0a:when the value of Hue is 0,the value on setup menu equal to -6 |



| | | 3.18 设置 DRM MODE ID/ Set DRM MODE ID(0x18) |
|-----------|--------|---|
| | | 4.23 DRM Control(0x7d) add this command |
| | | 5.31 DRM Mode ID Request (0xa4) add this command |
| | Add | 5.32 DRM Register and Deregister Code Request(0xa5) |
| | DRM | 5.33 DRM Register State Request (0xa7) add this command |
| | relate | 5.34 DRM Rental Count Request (0xa8) add this command |
| 2015.8.06 | Comm | 6.46 DRM Main Status Report (0xD3) add this command |
| | and | 6.47 DRM Rental Count Report (0xD4) add this command |
| | | 6.48 DRM Register and Deregister Code Report (0xF3) added |
| | | 6.49 DRM Register State Report (0xF5) add this command |
| | | 6.50 DRM Mode ID 回复/DRM Mode ID Report (0xF6) |
| | | |

Entropy Confindential For



目录/Contents

| Chapter 1 名词解释/ Introduction | 12 |
|---|----|
| Chapter 2 协议规范/ Specification | 13 |
| 2.1 命令格式定义/Command Definition | 13 |
| 2.2 UART | 14 |
| Chapter 3 设置命令/Configuration Commands | |
| 3.1 区域码设置/ Region Code (0x02) | 15 |
| 3.2 视频设置/ Video Setup (0x03)(Invalid) | 15 |
| 3.3 音频设置/ Audio Setup (0x04) (Invalid) | 17 |
| 3.3 音频设置/ Audio Setup (0x04) (Invalid) | 18 |
| 3.5 视频比例设置/ Video Shape Config(0x09) | 20 |
| 3.6 设置填充模式/ View Mode Config (0x0a) (Invalid) | 20 |
| 3.7 设置视频制式/ TV System Config(0x0b) | 21 |
| 3.8 设置视频输出模式/ Video Output Config (0x0c) | 21 |
| 3.9 Jpeg 播放设置/JPEG Play Config (0x0d)(Invalid) | 22 |
| 3.10 光标跟随设置/Cursor Follow Config (0x0e) (Invalid) | 22 |
| 3.11 设置 CD 模式/CD Mode config(0x0f) | 23 |
| 3.12 设置 CD Ripping 参数/CD Ripping Config(0x10) | 24 |
| 3.13 设置 CD Ripping 路径/CD Ripping Destination Config(0x11) | 24 |
| 3.14 恢复默认设置/Use Default Setting (0x12) | 25 |
| 3.15 OSD 设置/ OSD Setting (0x13) | 25 |
| 3.16 设置童锁/ Set Parental Level (0x14) | 26 |
| 3.17 设置动态范围压缩/ Set Dynamic Range (0x17) | 27 |
| 3.18 设置 DRM MODE ID/ Set DRM MODE ID (0x18) | 27 |
| Chapter 4 播放控制命令/Play Commands | 29 |
| 4.1 选择标题和章节播放/PLAY PTT (0x47) | 29 |
| 4.2 选时播放/Play Time (0x48) | 29 |
| 4.3 快进/Fast Forward (0x4D) | 30 |
| 4.4 快退/Fast Rewind (0x4E) | 30 |
| 4.5 选标题播放/Goto Title(0x63) | 31 |
| 4.6 选曲目播放/Goto Chapter(0x64) | 31 |
| 4.7 选择 clips 曲目播放/Goto Mp3 File(0x67) | 32 |
| 4.5 播放设备/Play Device(0x69) | 32 |
| 4.9 遥控指令/IR Command(0x6B) | 33 |
| 4.10 触摸播放/Touch Function(0x6C) | 35 |
| 4.11 设置 DVD 配音/字幕/角度/Select DVD Audio/Subtitle/ Angle(0x6d) | 35 |
| 4.12 设置光标位置/Set Focus On Clips File(0x6e) (Invalid) | 36 |



| | 4.13 保存记忆/Save Play Position(0x6f) | . 36 |
|---|--|------|
| | 4.14 发送 iPod 命令/Write ipod binary data(0x70) (Invalid) | . 37 |
| | 4.15 设置 USB 高阻状态/Set USB HighZ state(0x71) (Invalid) | . 38 |
| | 4.16 选择 USB 工作模式/USB work way select(0x72) (Invalid) | . 39 |
| | 4.17 发送记忆数据/Send Memory Data(0x73) | . 39 |
| | 4.18 Clips 绝对索引选曲/Play Clips File With Absolute Index Request (0x76) | . 40 |
| | 4.19 Ripping 曲目选择/Select the tracks to rip (0x77) | |
| | 4.20 Ripping 选择曲目取消/ Deselect the tracks to rip (0x78) | . 41 |
| | 4.21 Ripping 开始/Ripping Start (0x79) | . 42 |
| | 4.22 Ripping 返回/Ripping Cancel (0x7a) | 43 |
| | 4.23 打开版本菜单/Open Version Menu(0x7b) | . 43 |
| | 4.24 打开测试模式/Open Test Mode(Invalid) | . 44 |
| | 4.25 DRM 播放控制/DRM Control(0x7D) | . 44 |
| | Chapter 5 状态查询命令/ Status Request Commands | |
| (| | |
| | 5.1 查询配置信息/Configuration Request(0x82) | 45 |
| | 5.2 当前设备状态查询/Mechanism State Request(0x83) | |
| | 5.3 播放状态获取/Play State Request(0x84) | . 46 |
| | 5.4 媒体类型查询/Media Status Request(0x85) | . 47 |
| | 5.5 查询时间/Media Time Request(0x86) | |
| | 5.6 查询 PTT 信息/Media PTT Request (0x87) | . 48 |
| | 5.7 开启主动发送显示信息/Display Information State Request (0x89) | |
| | 5.8 查询 ID-3/CD-TEXT 信息/ID3/CD-TEXT Request(0x8C) | |
| | 5.9 查询旁白/字幕/角度信息/Audio Subtitle Angle State Request(0x8E) | |
| | 5.10 查询 clips 文件名/Clips Name Request(0x8F) | |
| | 5.11 播放模式查询/Play Mode REQUEST(0x90) | |
| | 5.12 查询 Clips 光标位置/Clips Cursor Request (0x91) | |
| | 5.13 查询角度和放大/Angle&Zoom Request(0x92) | |
| | 5.14 查询当前连接设备/Current Connect Device(0x93) | . 54 |
| | 5.15 获取旁白/字幕/Get Subtitle/Audio Information(0x94) | |
| | 5.16 查询预览图片尺寸/Get PreViewing Picture Size(0x95) (Invalid) | . 55 |
| | 5.17 查询高亮文件索引/Get High Ligth File Index(0x96) | . 55 |
| | 5.18 查询光标所在的文件夹名/Get Path Name(0x97) | . 56 |
| | 5.19 查询软件版本/Get Software Version(0x98) | . 56 |
| | 5.20 查询 BIN 代码内容/Request Bin Code(0x99) (Invalid) | . 57 |
| | 5.21 查询 BIN 文件长度/Request Bin Length(0x9a) (Invalid) | . 58 |
| | 5.22 查询 USB 高阻状态/Request USB HighZ (0x9b) (Invalid) | . 58 |
| | 5.23 查询 USB VID&PID/Request USB VID&PID(0x9c) (Invalid) | . 59 |
| | 5.24 查询 USB 工作模式/Request USB work way(0x9D) (Invalid) | . 59 |
| | 5.25 查询文件文件夹数/ Request the Total of Files and Folders (0x9E) | . 60 |
| | 5.26 查询文件系统概况/Request Summary of FileSystem (0x9F) | . 61 |
| | 5.27 查询文件文件夹信息/Request the Attribute of File or Folder(0xA0) | . 61 |
| | 5.28 查询当前播放文件所在的文件夹名/Get Playing Folder Name(0xA1) | . 62 |
| | 5.29 查询 iPod 信息/Get iPod information(0xa2) (Invalid) | . 62 |
| | | |



| 5.31 | 查询 DRM Mode ID/DRM Mode ID Request (0xa4) | 63 |
|--------|--|----|
| 5.32 | 查询 DRM 注册及反注册码/DRM Register and Deregister Code Request (0xa5) | 64 |
| 5.33 | 查询 DRM 注册状态/DRM Register State Request (0xa7) | 64 |
| 5.34 | 查询 DRM Rental 次数/DRM Rental Count Request (0xa8) | 65 |
| | | |
| Chap | ter 6 相应命令/Mechanism Status Reports | 66 |
| 6.1 杉 | l芯状态错误回复/Error Status Report (0xC1) | 66 |
| | 区域码设置响应/Region Code Setting Report(0xC2) | |
| | 见频设置响应/Video Setup Report(0xc3) | |
| 6.4 音 | 看频设置响应/Audio Setup Report(0xC4) (Invalid) | 70 |
| 6.5 语 | 语言设置响应/Language Setup Report(0xC5) | 70 |
| 6.6 长 | 子备状态回复/Mechanism State Report(0xCB) | 71 |
| 6.7 杉 | L芯播放状态回复/Mechanism Play State Report(0xCC) | 73 |
| 6.8 竧 | 某体信息回复/Media Status Report(0xCD) | 74 |
| 6.9 摺 | 據於时间回复/Play Time Report(0xCE) | 76 |
| 6.10 | 媒体 PTT 信息回复/Media Track Position Report(0xCF) | 77 |
| | 播放显示信息发送/Playback Display Information state Report(0xD2) | |
| 6.12 I | D3/CD-Text 信息回复/ ID3/CD-Text Report(0xD5) | 79 |
| 6.13 | 旁白/字幕/角度信息回复/Audio/Subtitle/Angle information state Report(0xD7) | 80 |
| 6.14 (| CLIPS 文件光标位置/Clips Cursor Position(0xD8) | 81 |
| 6.15 (| CLIPS 文件名回复/Clips Name Report(0xD9) | 82 |
| 6.16 | 播放模式回复/Play Mode Report(0xDA) | 82 |
| 6.17 | 机芯初始化完成信息发送/Initialized Report(0xDB) | 83 |
| 6.18 | 角度和放大倍数回复/Angle&Zoom Report(0xDC) | 84 |
| 6.19 | 当前连接设备/Current Connect Device Report(0xDD) | 85 |
| 6.20 | 旁白/字幕查询/Audio/Subtitle Information(0xDE) | 85 |
| 6.21 | 预览图片尺寸/Picture Preview Size Report(0xdf)(Invalid) | 86 |
| | 高亮文件索引回复/High Light File Index(0xE0) | |
| 6.23 | 文件夹名回复/File Path Report(0xE1) | 87 |
| 6.24 | 软件版本回复/Software Version Report(0xe2) | 88 |
| | BIN 代码发送/Bin Code Report(0xe3)(Invalid) | |
| | Bin Code 内容越界信息发送/Bin Code Content Spillage Return(0xe4) (Invalid) | |
| | 发送 Bin 文件长度/Bin File Length Return(0xe5)(Invalid) | |
| | Bin 文件类别发送/Bin File Type(0xe6)(Invalid) | |
| | 当前碟片是升级碟/It is an Upgrade Disc(0xE7) | |
| | Clips 碟自动播放结束/End of Auto Play for Clips Disc(0xE8) | |
| | 返回 USB HighZ 状态/Return USB HighZ(0xe9)(Invalid) | |
| | 返回 USB VID&PID/USB VID&PID Report(0xea) (Invalid) | |
| | 返回 USB 工作模式/USB work way report(0xeb) (Invalid) | |
| | 发送 iPod 数据/lpod data report(0xec) (Invalid) | |
| | 发送记忆数据/Memory data report(0xed) | |
| | 发送文件文件夹数/The Total of Files and Folders Report (0xEE) | |
| | 发送文件系统信息概况/The Summary of File System Report (0xef) | |
| 6.38 | 发送文件文件夹信息/The Attribute of File or Folder Report(0xF0) | 97 |



| 6.39 发送 Ripping 当前界面/the Menu of Ripping Report(0xF7) | |
|---|----------|
| 0.40 // 2/ 51 / 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2 | |
| 6.40 发送 Ripping 进度/the progress of Ripping Report(0xF1)(Invalid) | 100 |
| 6.41 发送 iPod 信息/iPod information report(0xF2)(Invalid) | 100 |
| 6.46 DRM 主状态回复/ DRM Main Status Report (0xD3) | 102 |
| 6.47 DRM Rental 次数回复/DRM Rental Count Report (0xD4) | 103 |
| 6.48 DRM 注册码及反注册码回复/DRM Register and Deregister Code Report (0 | xF3) 104 |
| 6.49 DRM 注册状态回复/DRM Register State Report (0xF5) | 105 |
| 6.50 DRM Mode ID 回复/DRM Mode ID Report (0xF6) | 106 |
| | |
| 附录/Attachment | 107 |
| | 17 |
| 附录/Attachment | (), |

Foryou Confidential For



Chapter 1 名词解释/ Introduction

| Clips | 除了 DVD、VCD 碟片以外的其他所有文件,包含 CDDA、MP3、 JPEG、WMA、AVI、MPEG 等文件格式(DVD Audio 不支持) All of the files except DVD/VCD disc. This file format includes: CDDA, MP3, JPEG, WMA, AVI, MPEG (DVD Audio is not supported). | | |
|--|---|--|--|
| DVD Menu | DVD 碟片的根目录 DVD Root Menu | | |
| NO DEVICE | 无设备状态 No Device State | | |
| UNKNOWN | 设备不能识别(坏碟、坏卡、坏 USB) Can't identify devices(bad disc/bad card/bad USB) | | |
| TRAY OPENING | | | |
| TRAY CLOSING | 碟片进仓 Disc is closing | | |
| TRAY OPENED | 碟片出仓到位 No disc or disc is ejected | | |
| LOADING | 读碟状态 Disc is loading | | |
| IDENTIFIED 设备已检测到 Device has been identified | | | |
| DEVICE_READY 已切换到设备 Has been switch to the device | | | |
| DEVICE_REMOVED 设备拨除 Device has been removed | | | |

FOTYOU



Chapter 2 协议规范/ Specification

2.1 命令格式定义/Command Definition

命令格式: 同步字节 长度 命令 参数 1 参数 N CRC

Command Format: Synchronization Bytes Length Command Parameter 1

Parameter N CRC

Length: Command+Parameters1+.....+ParametersN

 $\textbf{CRC:} \ \sim (\textbf{Length} + \textbf{Command} + \textbf{Parameters1} + + \textbf{ParametersN})$

| 7 (bit) | 6 | 5 | 4 | 3 | 2 | 1 0,0 | | |
|--------------------------------|------------------------------------|---|---|---|---|-------|--|--|
| 同步Bytes/ Synchronization Bytes | | | | | | | | |
| | 长度/Length | | | | | | | |
| 命令类型/ | 命令类型/Command Type 命令 ID/Command ID | | | | | | | |
| | 参数1/ Parameter 1 Byte | | | | | | | |
| | 参数2/ Parameter 2Byte | | | | | | | |
| 参数N/ Parameter N Byte | | | | | | | | |
| | 校验和/CRC | | | | | | | |

同步Byte/ Synchronization Bytes:

UART: 0xff 0x55

SPI: 0xas

命令长度/Length:

命令长度 = 1(命令)+ N (参数 byte的个数)

Length=Command+Parameter 1+.....+Parameter N

命令类型/ Command Type:

00 - 设置命令/ Configuration Commands

01 - 播放控制命令/ Player Commands

10 - 状态查询命令/ Mechanism Status Request Commands

11 - 响应命令/ Mechanism Status Reports Commands

命令 ID/Command ID:

定义每个命令类型的命令ID号。

This defines the specific behavior and/or response for each message type.



参数 1~ 参数 N/ Parameter:

命令参数 byte

Command Parameter Byte

校验和/CRC:

校验和 = ~ (命令长度 + 命令 + 参数1+ ...+参数N)

CRC=~ (Length+Command+Parameter 1+.....+Parameter N)

2.2 UART

波特率: 最低 19200, 最高 115200, 公版设定为 57600。

Baud rate: 19200, limited to: 115200, general: 57600

数据位:8 Byte size:8 校验位:1 Parity:None 停止位:1

Stopbits:1

同步: 2个同步字节——0xff 0x55

Synchronization: Two Synchronization Bytes--0xff 0x55

命令格式: 0xff 0x55 长度 命令 参数 1 参数 N CRC

Command Format: 0xff 0x55 Length Command Parameters1 ParametersN CRC

注: 1.每条命令都有对应的返回命令、请根据返回命令判断通信是否成功,是否被系统处理。

2.需要频繁获取的命令,可与我们协商DVD主动发送。

For oill only

FORYOU



Chapter 3 设置命令/Configuration Commands

3.1 区域码设置/ Region Code (0x02)

方向: MCU-DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|-----------------|----------|---------------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x02 | 命令/ Command |
| 0x04 | 0x0N | 区域码/ Region Code (DEFAULT 0) |
| (last byte) | 0xNN | CRC of |

Region Code:

| | Informal term meaning "worldwide". Region 0 is not an official setting; discs | |
|---|---|--|
| 0 | that bear the region 0 symbol either have no flag set or have regions 1–6 flags | |
| | set. Region 0 is commonly referred to as "Region Free". | |
| 1 | United States, Canada, Bermuda, Caribbean, U.S. territories | |
| 2 | Europe, Middle East, Egypt, Japan, South Africa, Swaziland, Lesotho, | |
| | Greenland, French Overseas departments and territories | |
| 3 | Southeast Asia, South Korea, Taiwan, Hong Kong, Macau | |
| 4 | South America, Central America, Mexico, New Zealand, Australia, Papua | |
| 4 | New Guinea and much of Oceania | |
| | Bangladesh, India, Nepal, Afghanistan, Sri Lanka, Ukraine, Belarus, Russia, | |
| 5 | Kazakhstan, Pakistan, Africa (except Egypt, South Africa, Swaziland, | |
| | Lesotho), Central Asia, Mongolia, North Korea | |
| 6 | China | |
| | | |

NOTE: The configuration only valid when the playstate is stop.

MCU发送值: FF 55 02 02 0N CRC

MCU SEND VALUE: FF 55 02 02 0N CRC

DVD 返回值: 无

DVD RETURN VALUE: NOTHING

3.2 视频设置/ Video Setup (0x03)(Invalid)

视频设置: 0x03 Video Setup: 0x03

适用范围: DVD 停止状态, 无碟状态;

Command Summary: DVD Stop PlayState, or No Disc;

方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:



| 0x00 | 0xFF | 同步/ Sync Byte |
|-------------|------|--|
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x09 | 长度/ Length |
| 0x03 | 0x03 | 命令/ Command |
| 0x04 | 0x0N | 视频输出模式 视频制式 Video Out Mode TVSystem |
| 0x05 | 0x0N | 宽高比/ Aspect Ratio |
| 0x06 | 0x0N | 查看制式/View Mode (注: 保留/Realase) |
| 0x07 | 0x0N | 锐利度 sharpness |
| 0x08 | 0x0N | 对比度 Constrast |
| 0x09 | 0x0N | 亮度 Brightness |
| 0x0a | 0x0N | 色调 hue |
| 0x0b | 0x0N | 饱和度 saturation |
| (last byte) | 0xNN | CRC |

参数表/ Parameters:

| | | · · · · · · · · · · · · · · · · · · · | | |
|---|-------------------|---------------------------------------|-------------|------------------|
| | | | 0000b | CVBS |
| | | | 0001b | YUV |
| | • | 视频输出模式 | 0010b | RGB |
| | C^ | Bit[7:4] | 0011b | S-Video |
| | 视频输出模式 视频制式 | Video Out Mode | 0100b | 逐行 YUV |
| | Video Qut | Bit[7:4] | | YUV Progressive |
| | Mode TVSystem | | 0101b | 逐行 RGB |
| | . | | | RGB Progressive |
| | | 视频制式 Bit[3:0] TVSystem Bit[3:0] | 0000b | NTSC |
| | | | 0001b | PAL |
| | \(\) | | 0010b | Auto |
| Y | | | 0x00 | 16:9 |
| > | 宽高比/ Aspect Ratio | | 0x01 | 4:3LB(Letterbox) |
| | | | 0x02 | 4:3PS(Panscan) |
| | 查看制式 | | 0x00 | 自动/ Auto Fit |
| | View Mode | | 0x01 | 原图大小/ Original |
| | 锐利度/ sharpness | | 0xNN (0-8) | |
| | 对比度/ Constrast | | 0xNN (0-12) | |
| | 亮度/ Brightness | | 0xNN (0-12) | |
| | 色调/ Clolor | | 0xNN(0-12) | |
| | 色彩/ Tint | | 0xNN(0-12) | |
| | | · | | |



MCU发送值: FF 55 09 03 0N 0N 0N 0N 0N 0N 0N NN MCU SEND VALUE : FF 55 09 03 0N 0N 0N 0N 0N 0N 0N 0N NN

DVD 返回值: 无

DVD RETURN VALUE: NOTHING

注: 请注意整机设置与DVD设置的区别

Note: Please distinguish the difference between the DVD setup and the MCU setup

3.3 音频设置/ Audio Setup (0x04) (Invalid)

音频设置: 0x04 Audio Setup (0x04) 适用范围: Stop 状态

Command Summary: Stop PlayState

方向: MCU->DVD Direction:MCU->DVD

命令格式/Command Format:

| 设置: 0x04 | | 1 |
|------------------|--------------|--|
| o Setup (0x04) | | |
| 范围: Stop 状态 | | W. A. C. |
| mand Summary: St | op PlayState | |
| : MCU->DVD | | |
| ction:MCU->DVD | | |
| 格式/Command Forn | nat: | <u> </u> |
| 位数/Byte Num | 值/ Value | 含义/ Meafing |
| 0x00 | 0xFF | 同步 Swoc Byte |
| 0x01 | 0x55 | 开始创 Start Byte |
| 0x02 | 0x07 | 泛友/ Length |
| 0x03 | 0x04 | 命令/ Command |
| 0x04 | 0x0N | Spdif信息/ Spdif information |
| 0x05 | 0x0N | 声道设置信息/ Channel Setup Info |
| 0x06 | 0x0N | 压缩模式/ Compression |
| 0x07 | QXQN | 音频控制/ Audio Control |
| 0x08 | DXON | 中置扬声器延时/ Center Delay |
| 0x09 | 0x0N | 环绕扬声器延时/ Rear Delay |
| (last byte) | 0xNN | CRC |

| Codit 信自 | | BitStream | 0x00 |
|-------------------------------|--------------------|-------------|------|
| Spdif 信息 Spdif information | | PCM | 0x01 |
| Spail information | | No Digital | 0x02 |
| | 前置 Bit[7:6] | Large | 00b |
| | Front CH Bit[7:6] | Small | 01b |
| 声道设置信息 | 中置 Bit[5:4] | | |
| Channel Setup | Center CH Bit[5:4] | Not Present | 10b |
| information | 环绕 Bit[3:2] | | |
| | Rear CH Bit[3:2] | | |
| | 低音 Bit[1:0] | Not Present | 00b |



| | Bass Bit[1:0] | Present | 01b |
|---------------|---------------|---------|-------------|
| 压缩模式 | | | |
| Compression | | | |
| 音频控制 | | 关闭/Off | 0x00 |
| Audio Control | | 开/On | 0x01 |
| | | 0ms | 0 |
| | | 1ms | 0x08 |
| 中置扬声器延时 | | 2ms | 0x12 |
| Center Delay | | 3ms | 0x18 |
| | | 4ms | 0x20 |
| | | 5ms | 0x28 |
| | | 0ms | 0x00 |
| | | 3ms | 0x18 |
| 环绕扬声器延时 | | 6ms | % 30 |
| Rear Delay | | 9ms | 0x48 |
| | | 12ms | 0x60 |
| | | 15ms | 0x78 |

MCU发送值: FF 55 07 04 0N 0N 0N 0N 0N NN

MCU SEND VALUE: FF 55 07 04 0N 0N 0N 0N 0N 0N NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

注: 请注意整机设置与DVD设置的区别

Note: Please distinguish the difference between the DVD setup and the MCU setup

3.4 语言设置 Language Setup (0x05)

语言设置: 0x05

Language Setup (0x05) 适用范围: Stop 状态へ

Command Summary: Stop PlayState

方向: MCU->DVD Direction:MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x04 | 长度/ Length |
| 0x03 | 0x05 | 命令/ Command |
| 0x04 | 0x0N | 设置语言选项/ Setup Language |
| 0x05 | 0x0N | Char1 (ASCII) |
| 0x06 | 0x0N | Char2 (ASCII) |
| (last byte) | 0xNN | CRC |



设置语言选项/ Setup Language:

| 0x00 | OSD |
|------|---------------|
| 0x01 | Subtitle |
| 0x02 | Divx Subtitle |
| 0x03 | Audio |
| 0x04 | DVD Menu |

常用音频、字幕语言对照表/ Unicode Table:

| ar | Arabic | |
|-----|---------------------|-------------------------------|
| c s | Czech | |
| d a | Danish | . 4 |
| d e | German | only |
| e | Greek | |
| e n | English | |
| e s | Spanish | • 1 |
| fr | French | |
| h u | Hungarian | C. |
| i t | Italian | |
| h e | Hebrew | \$\langle \(\sigma^{\chi} \) |
| jа | Japanese | |
| ko | Korean | |
| lа | Latin | |
| l n | Indonesian | |
| m s | Malay | |
| nΙ | Dutch | |
| n o | Norwegian | |
| pΙ | Polish | |
| рt | Portuguese | |
| ro | Romanian C | |
| ru | Russian | |
| sl | Slovenian | |
| s v | Swedish | |
| t h | Thai | |
| tr | Turkish | |
| z h | Simplied Chinese | |
| a 2 | Traditional Chinese | |
| b 6 | brazil | |
| | | |

MCU发送值: FF 55 04 05 0N 0N 0N NN MCU SEND VALUE: FF 55 04 05 0N 0N 0N NN

DVD返回值: NOTHING

DVD RETURN VALUE: NOTHING



3.5 视频比例设置/ Video Shape Config(0x09)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x09 | 命令/ Command |
| 0x04 | 0x0N | Shape Config Param |
| (last byte) | 0xNN | CRC |

Shape Config Param:

| 0 | 16:9 |
|---|------------------|
| 1 | 4:3LB(Letterbox) |
| 2 | 4:3PS(Panscan) |

MCU发送值 : FF 55 02 09 0N NN

MCU SEND VALUE: FF 55 02 09 0N NN

DVD 返回值 : 无

DVD RETURN VALUE: NOTHING

3.6 设置填充模式/ View Mode Config(0x0a)

(Invalid)

填充模式: 0x0a

View mode setup (0x0a)

使用范围: Stop状态

Command Summary: Stop Playstate

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning | |
|-------------|----------|-----------------|--|
| 0x00 | 0xFF | 同步/ Sync Byte | |
| 0x01 | 0x55 | 开始位/ Start Byte | |
| 0x02 | 0x02 | 长度/ Length | |
| 0x03 | 0x0a | 命令/ Command | |
| 0x04 | 0x0N | 填充模式/ View mode | |
| (last byte) | 0xNN | CRC | |

填充模式/ View mode:



| 0x00 | 全屏显示/ Full screen |
|------|-------------------|
| 0x01 | 原图大小显示/ original |
| 0x04 | 自动/ auto |
| 0x05 | Pan Scan |

MCU发送值 : FF 55 02 0A 0N NN MCU SEND VALUE: FF 55 02 0a 0N NN

DVD 返回值 : 无

DVD RETURN VALUE: NOTHING

3.7 设置视频制式/ TV System Config (0x0b)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|----------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0x0B | 命令/ Command |
| 0x04 | 0x0N | 视频制式/ TV system mode |
| (last byte) | 0xNN | CRC |

视频制式/TV system mode:

| 0x00 | NTSC |
|------|------|
| 0x01 | PAL |
| 0x02 | Auto |

MCU发送值 FF 55 02 0b 0N NN MCU SEND VALUE: FF 55 02 0b 0N NN

DVD 返回值 : 无

DVD RETURN VALUE: NOTHING

3.8 设置视频输出模式/ Video Output Config

(0x0c)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning | |
|-------------|----------|-----------------|--|
| 0x00 | 0xFF | 同步/ Sync Byte | |
| 0x01 | 0x55 | 开始位/ Start Byte | |



| 0x02 | 0x02 | 长度/ Length | | |
|-------------|------|------------------------|--|--|
| 0x03 | 0x0C | 命令/ Command | | |
| 0x04 | 0x0N | 视频输出模式/ Video out mode | | |
| (last byte) | 0xNN | CRC | | |

视频输出模式/Video out mode:

| 0x00 | CVBS | | |
|------|---------|--|--|
| 0x01 | YUV | | |
| 0x02 | RGB | | |
| 0x03 | S-Video | | |

NOTE: The configuration only valid when the playstate is stop.

MCU发送值 : FF 55 02 0C 0N NN MCU SEND VALUE: FF 55 02 0C 0N NN

DVD 返回值 : 无

DVD RETURN VALUE: NOTHING

3.9 Jpeg播放设置/JPEG Play Config (0x0d)

ential

(Invalid)

Jpeg 播放设置: 0x09 Jpeg play setup (0x09)

适用范围: Jpeg

Command Summary:: Jpeg

方向: MCU->DVD Direction: MCU->DVD

命令格式/ Command Format()

| 位数/Byte Num | (X) Value | 含义/ Meaning | | |
|-------------|-----------|--|--|--|
| 0x00 | oxFF | 同步/ Sync Byte | | |
| 0x01 | 0x55 | 开始位/ Start Byte | | |
| 0x02 | 0x02 | 长度/ Length | | |
| 0x03 | 0x0d | 命令/ Command | | |
| 0x04 | 0x0N | 1: 自动播放, 0: 每播放一张等待 1:auto play, 0: wait after playing a picture | | |
| (last byte) | 0xNN | CRC | | |

MCU 发送值 : FF 55 02 0d 0N NN MCU SEND VALUE: FF 55 02 0d 0N NN

DVD 返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.10 光标跟随设置/Cursor Follow Config



(0x0e) (Invalid)

光标跟随设置: 0x0e

Cursor following config (0x0e)

适用范围: Audio

Command Summary: Audio

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x0e | 命令/ Command |
| 0x04 | 0x0N | 1: 不跟随, 0: 致随 |
| | | 1: Not follow 0: Follow |
| (last byte) | 0xNN | CRQ O |

MCU发送值 : FF 55 02 0e 0N NN MCU SEND VALUE: FF 55 02 0e 0N NN

DVD 返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.11 设置CD模式/CD Mode config(0x0f)

设置 CD 模式: 0x0f CD Mode (0x0f)

适用范围: CDDA Ripping

Command Summary: CDDA Ripping

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning | | | |
|-------------|----------|-------------------|--|--|--|
| 0x00 | 0xFF | 同步/ Sync Byte | | | |
| 0x01 | 0x55 | 开始位/ Start Byte | | | |
| 0x02 | 0x02 | 长度/ Length | | | |
| 0x03 | 0x0f | 命令/ Command | | | |
| | | 0 Normal | | | |
| 0x04 | 0x0N | CD Mode 1 Ripping | | | |
| (last byte) | 0xNN | CRC | | | |

MCU发送值 : FF 55 02 0f 0N NN



MCU SEND VALUE: FF 55 02 0f 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.12 设置CD Ripping参数/CD Ripping

Config(0x10)

设置 CD Ripping 参数: 0x10 CD Ripping Config (0x10)

适用范围: CDDA Ripping option menu

Command Summary: CDDA Ripping option menu

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| ipping Config(0x10) | | | | | | | |
|-----------------------------|--|-------------------------|------|---------|--|--|--|
| 包围:CDDA Ripping option menu | | | | | | | |
| mand Summary: Cl | nand Summary: CDDA Ripping option menu | | | | | | |
| : MCU->DVD | | | 4 | O's | | | |
| ction: MCU->DVD | | | | | | | |
| 格式/Command Forn | nat: | | | | | | |
| 位数/Byte Num | 位数/Byte Num 值/ Value 含义/ Meaning | | | | | | |
| 0x00 | 0xFF | 同步/ Sync Byte | | | | | |
| 0x01 | 0x55 | 开始位/ St art Byte | | | | | |
| 0x02 | 0x03 | 长度/ Length | | | | | |
| 0x03 | 0x10 | 命令/ Comm | nand | | | | |
| | \times | 速度 | 0 | 1X | | | |
| 0x04 | 0x0N | /Speed () | 1 | 4X | | | |
| | 76 ₂ | | 0 | 128KBPS | | | |
| | • 0 | | 1 | 160KBPS | | | |
| | Š, Ž | | 2 | 192KBPS | | | |
| Ripping 3 256KBPS | | | | | | | |
| 0x05 | 0x0N | Rate | 4 | 320KBPS | | | |
| (last byte) 0xNN CRC | | | | | | | |

MCU发送值 : FF 55 03 10 0N 0N NN

MCU SEND VALUE: FF 55 03 10 0N 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.13 设置CD Ripping路径/CD Ripping

Destination Config(0x11)

设置 CD Ripping 路径: 0x11

CD Ripping Destination Config (0x11) 适用范围: CDDA Ripping option menu

Command Summary: CDDA Ripping option menu



方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x11 | 命令/ Command |
| 0x04 | 0x0N | Device ID |
| (last byte) | 0xNN | CRC |

Device ID:

| 0x0 | Disc |
|------|-------------------|
| 0x1 | USB |
| 0x2 | SD |
| 0xFF | Current Device ID |

MCU发送值 : FF 55 02 11 0N NN

MCU SEND VALUE: FF 55 02 11 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.14 恢复默认设置/Use Default Setting (0x12)

恢复默认设置: 0x12

Use Default Setting (0x12)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x12 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 12 EC MCU SEND VALUE: FF 55 01 12 EC

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.15 OSD设置/ OSD Setting (0x13)

OSD 设置(关闭 GUI): 0x13 OSD Setting(close GUI)(0x13)



方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x03 | 长度/ Length |
| 0x03 | 0x13 | 命令/ Command |
| 0x04 | 0x0N | OSD Set (Open : 01 Close : 00) |
| | | 00:OSD 01: GUI(except OSD) |
| 0x05 | 0x0N | 02:All GUI |
| (last byte) | 0xNN | CRC |

注:在无碟无设备状态才能设置 OSD。

Note: Only in no disc and no device status to set OSD.

MCU发送值 : FF 55 03 13 0N NN

MCU SEND VALUE: FF 55 03 13 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.16 设置童锁/Set Parental Level (0x14)

设置童锁: 0x14

Set parental level (0x14)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x14 | 命令/ Command |
| 0x04 | 0x0N | Parental level |
| (last byte) | 0xNN | CRC |

童锁级别/Parental level:

| 0x01 | Kid safe |
|------|----------|
| 0x02 | G |
| 0x03 | PG |
| 0x04 | PG13 |
| 0x05 | PG-R |
| 0x06 | R |
| 0x07 | NC-17 |
| 0x08 | Adult |



MCU发送值 : FF 55 02 14 0N NN

MCU SEND VALUE: FF 55 02 14 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.17 设置动态范围压缩/ Set Dynamic Range

(0x17)

设置动态范围压缩: 0x17 Set Dynamic Range (0x17)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0x17 | 命令/ Command |
| 0x04 | 0x0N | Dynamic Range |
| (last byte) | 0xNN | CRC |

动态范围/Dynamic Range:

| OFF |
|------|
| 1/8 |
| 2/8 |
| 3/8 |
| 4/8 |
| 5/8 |
| 6/8 |
| 7/8 |
| Full |
| |

MCU发送值 : FF 55 02 17 0N NN

MCU SEND VALUE: FF 55 02 17 0N NN

DVD返回值 : NOTHING

DVD RETURN VALUE: NOTHING

3.18 设置DRM MODE ID/ Set DRM MODE ID

(0x18)

设置 DRM MODE ID: 0x18 Set DRM MODE ID (0x18)

方向: MCU->DVD Direction: MCU->DVD



Note: Mode ID is saved in SDRAM when MCU send it to DVD,MCU must resend Mode ID when DVD power on.

命令格式/Command Format:

| 0x01 0x02 0x03 0x04 0x05 (last byte) MCU发送值: MCU SEND VAI DVD返回值: | | ON ON NN |
|---|--|---|
| 0x02 0x03 0x04 0x05 (last byte) MCU发送值 : MCU SEND VAI DVD返回值 : | 0x03 0x18 0x0N 0x0N 0xNN FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | 开始位/ Start Byte 长度/ Length 命令/ Command DRM ID H DRM ID L CRC N NN ON ON NN |
| 0x03 0x04 0x05 (last byte) MCU发送值: MCU SEND VAI DVD返回值: | 0x18 0x0N 0x0N 0xNN FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | 命令/ Command DRM ID H DRM ID L CRC N NN ON ON NN |
| 0x04 0x05 (last byte) MCU发送值 : MCU SEND VAI DVD返回值 : | 0x0N 0x0N 0xNN FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | 命令/ Command DRM ID H DRM ID L CRC N NN ON ON NN |
| 0x05 (last byte) MCU发送值 : MCU SEND VAI DVD返回值 : | 0x0N 0xNN FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | DRM ID L CRC N NN ON ON NN |
| (last byte) MCU发送值 : MCU SEND VAI DVD返回值 : | 0xNN FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | CRC N NN ON ON NN |
| MCU发送值 : MCU SEND VAI DVD返回值 : | FF 55 03 18 0N 0N LUE: FF 55 03 18 NOTHING | N NN ON ON NN |
| MCU SEND VAI DVD返回值 : | LUE: FF 55 03 18 NOTHING | ON ON NN |
| CYON CC | VALUE: NOTHIN | |



Chapter 4 播放控制命令/Play Commands

4.1 选择标题和章节播放/PLAY PTT (0x47)

播放指定标题和章节: 0x47

Select DVD Title&Chapter (0x47)

适用范围: 仅仅适用于 DVD Video 播放状态

Command Summary: Valid mechanism state is only play.

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x04 | 长度/ Length |
| 0x03 | 0x47 | 命令/ Command |
| 0x04 | 0x0N | Title |
| 0x05 | 0x0N | Chapter H |
| 0x06 | 0x0N | Chapter L |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 04 47 0N 0N 0N NN

MCU Send Value : FF 55 04 47 0N 0N 0N NN

DVD 返回值: 无。

DVD Return Value NOTHING

4.2 选时播放/Play Time (0x48)

播放指定的时间起始点: 0x48

Goto Time (0x48)

适用范围:适用于所有碟片、USB、SD播放状态 Command Summary: Valid mechanism state is Play.

方向: MCU->DVD Direction: MCU->DVD

命令格式/ Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x04 | 长度/ Length |
| 0x03 | 0x48 | 命令/ Command |
| 0x04 | 0x0N | Hour |
| 0x05 | 0x0N | Min |



| 0x06 | 0x0N | Sec |
|-------------|------|-----|
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 04 48 0N 0N 0N NN

MCU SEND VALUE: FF 55 04 48 0N 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.3 快进/Fast Forward (0x4D)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0x4D | 命令/ Command |
| 0x04 | 0x0N | 速度设定/FastF Speed |
| (last byte) | 0xNN | CRC |

速度设定/FastF Speed:

| | 0x1 | 2x |
|---|------|-----|
| | 0x2 | 4x |
| 1 | -0x3 | 8x |
| | 0x4 | 16x |
| ŗ | | |

MCU发送值: FF 55 02 4D 0N NN MCU SEND VALUE: FF 55 02 4D 0N NN

DVD 返回值: 无

DVD RETURN VALUE: NOTHING

4.4 快退/Fast Rewind (0x4E)

Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x4E | 命令/ Command |
| 0x04 | 0x0N | 速度设定/FastR Speed |
| (last byte) | 0xNN | CRC |

速度设定/FastR Speed:



| 0x1 | 2x |
|-----|-----|
| 0x2 | 4x |
| 0x3 | 8x |
| 0x4 | 16x |

MCU发送值: FF 55 02 4E 0N NN MCU SEND VALUE: FF 55 02 4E 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.5 选标题播放/Goto Title(0x63)

播放指定的标题: 0x63

Goto Title (0x63)

适用范围: 仅仅适用于 DVD Video 播放状态

Command Summary: Valid mechanism state is Play in DVD Video

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义 Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 周步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x63 | 命令/ Command |
| 0x04 | 0x0N | Title |
| (last byte) | 0×NN | CRC |

MCU发送值: FF 55 02 63 0N NN

MCU SEND VALUE: FF 55 02 63 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.6 选曲目播放/Goto Chapter(0x64)

播放指定的曲目: 0x64 Goto Chapter (0x64)

适用范围: 仅仅适用于 DVD Video Chapter 和 VCD Track 数字选曲播放

Command Summary: This command is used to go to select DVD Video

chapter or VCD track 方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num 值/ Value | 含义/ Meaning |
|----------------------|-------------|
|----------------------|-------------|



| 0x00 | 0xFF | 同步/ Sync Byte |
|-------------|------|-----------------|
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x03 | 长度/ Length |
| 0x03 | 0x64 | 命令/ Command |
| 0x04 | 0x0N | Chapter H |
| 0x05 | 0x0N | Chapter L |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 03 64 0N 0N NN

MCU SEND VALUE: FF 55 03 64 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.7 选择clips曲目播放/Goto Mp3 File(0x67)

播放指定的 clips 曲目或打开指定 clips 文件夹: 0x67

Select Clips File to play Or Open Clips Folder (0x67)

适用范围:仅仅适用于 Clips 文件(包含 cd/mp3/wma/jpg/avi/等) Command Summary: Used for selecting the file in clips menu.

注: Clips 碟片不在文件夹目录时,返回文件夹菜单选项 item 为曲目 0(CDDA 碟片不支持) Note: When the clips file is not in root directory, the item which returns to its parent

directory is the first item(Not Supported in CDDA).

方向: MCU->DVD Direction: MCU->DVD

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x03 | 长度/ Length |
| 0x03 | 0x67 | 命令/ Command |
| 0x04 | 0x0N | Clips Item H |
| 0x05 | 0x0N | Clips Item L |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 03 67 0N 0N NN MCU SEND VALUE: FF 55 03 67 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.5 播放设备/Play Device (0x69)

方向: MCU->DVD Direction: MCU->DVD



| 位数/Byte Num | 值/ Value | | 含义/ Meaning | |
|------------------------------|----------------|----------|------------------|--|
| 0x00 | 0xFF | | 同步/ Sync Byte | |
| 0x01 | 0x55 | | 开始位/ Start Byte | |
| 0x02 | 0x03 | | 长度/ Length | |
| 0x03 | 0x69 | | 命令/ Command | |
| 0x04 | 0x0N | | 设备类型/Device Type | |
| 0x05 | 0x0N | | 播放方式/ Play Mode | |
| (last byte) | 0xNN | | CRC | |
| Device Type: | | | | |
| | 0x0 | Di | Disc | |
| | 0x1 | US | JSB | |
| | 0x2 | SI | D | |
| Play Mode: | | | | |
| - | 0x0 | Re | Resume Play | |
| | 0x1 | Re | Replay | |
| MCU发送值: FF 55 03 69 0N 0N NN | | | | |
| MCU SEND VAI | LUE : FF 55 03 | 69 ON 01 | ON NN 🔨 🔾 | |

| 0x0 | Disc |
|-----|------|
| 0x1 | USB |
| 0x2 | SD |

| 0x0 | Resume Play |
|-----|-------------|
| 0x1 | Replay |

MCU SEND VALUE : FF 55 03 69 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.9 遥控指令/IR Command(0x6B)

方向: MCU->DVD Direction: MCU->DVD

| 位数/Byte Num | 值义Value | 含义/ Meaning |
|-------------|---------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x6B | 命令/ Command |
| 0x04 | 0x0N | 遥控值/IR Key |
| (last byte) | 0xNN | CRC |

| Value | Function |
|-------|----------|
| 0x0 | IR_NUM_0 |
| 0x1 | IR_NUM_1 |
| 0x2 | IR_NUM_2 |
| 0x3 | IR_NUM_3 |
| 0x4 | IR_NUM_4 |
| 0x5 | IR_NUM_5 |
| 0x6 | IR_NUM_6 |
| 0x7 | IR_NUM_7 |



| | | Sumplus DVD通信协议 |
|------|-----------------|-----------------|
| 0x8 | IR_NUM_8 | |
| 0x9 | IR_NUM_9 | |
| 0xd | IR_UP | |
| 0xe | IR_LEFT | |
| 0xf | IR_RIGHT | |
| 0x10 | IR_DOWN | |
| 0x11 | IR_ENTER | |
| 0x14 | IR_PLAY | |
| 0x15 | IR_PAUSE | |
| 0x17 | IR_STOP | |
| 0x18 | IR_NEXT | 1 |
| 0x19 | IR_PREVIOUS | |
| 0x1a | IR_REPEAT | (1), |
| 0x1f | IR_INTRO | |
| 0x20 | IR_RESUME | |
| 0x21 | IR_FASTFORWARD | |
| 0x27 | IR_FASTREWIND | C, Y |
| 0x2d | IR_SLOWFORWARD | |
| 0x33 | IR_SLOWREWIND < | |
| 0x3e | IR_TITLE | |
| 0x3f | IR_MENU | |
| 0x40 | IR_RETURN | |
| 0x44 | IR_AUDIO | |
| 0x45 | IR_SUBTITLE | |
| 0x47 | IR_ANGLE | |
| 0x48 | IR_DISPLAY | |
| 0x4a | IR_GOTO | |
| 0x4d | IR_PBC | |
| 0x50 | IR_SHUFFLE | |
| 0x54 | IR_TVSYSTEM | |
| 0x59 | IR_ZOOM | |
| 0x60 | IR_SETUP | |
| 0x67 | IR_REPEATOFF | |
| 0x68 | IR_REPEATSINGLE | |
| 0x69 | IR_REPEATFOLDER | |
| 0x6A | IR_REPEATALL | |
| 0x6b | IR_MUTE | |
| 0x7C | IR_EJECT | |
| 0x95 | IR_DISC | |
| 0x96 | IR_USB | |
| 0x97 | IR_SD | |
| | | |

FORYOU

MCU发送值: FF 55 02 6B 0N NN MCU SEND VALUE: FF 55 02 6B 0N NN

DVD 返回值: 无

DVD RETURN VALUE: NOTHING



4.10 触摸播放/Touch Function(0x6C)

适用范围: DVD Video 根目录菜单,不支持 VCD PBC 菜单;

DVD Clips Menu (整机采用 DVD 界面的情况下);

Command Summary: used in the root menu of DVD Video, not supported in PBC menu of

VCD

used in the clips menu(only in NTSC)

方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:

| 150 Sammara Farmara | | |
|---------------------|------------------------------------|--|
| 值/ Value | 含义/ Meaning | |
| 0xFF | 同步/ Sync Byte | |
| 0x55 | 开始位/ Start Byte | |
| 0x05 | 长度/ Length | |
| 0x6c | 命令/ Command | |
| 0x0N | X Coordinate H | |
| 0x0N | X Coordinate L | |
| 0x0N | Y Coordinate H | |
| 0x0N | Y Coordinate L | |
| 0xNN | CRC | |
| | 0xFF 0x55 0x05 0x6c 0x0N 0x0N 0x0N | |

MCU发送值: FF 55 05 6C 0N 0N 0N 0N NN MCU SEND VALUE: FF 55 05 6C 0N 0N 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

说明: 坐标以屏的左个角为(0,0), 公版软件屏幕坐标范围720*480

Note: The coordinate origin is in the top left corner of the screen of which the area

is 720*480.

4.11 设置DVD配音/字幕/角度/Select DVD

Audio/Subtitle/ Angle (0x6d)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x03 | 长度/ Length |
| 0x03 | 0x6d | 命令/ Command |



| 0x04 | 0x0N | 0x00:Audio 0x01:Subtitle 0x02:Angle |
|-------------|------|---|
| 0x05 | 0x0N | Num |
| (last byte) | 0xNN | CRC |

NOTE: The command only valid in DVD-Video media.

MCU 发送值: FF 55 03 6D 0N 0N NN

MCU SEND VALUE: FF 55 03 6D 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

4.12 设置光标位置/Set Focus On Clips

File(0x6e) (Invalid)

设置光标位置: 0x6e Fouce change (0x6e)

适用范围: Clips 文件(cd/mp3/wma/avi/jpg 等文件)

Command Summary: Clips document

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value 🗸 | X/ Meaning |
|-------------|------------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0×03 | 长度/ Length |
| 0x03 | Qx8e | 命令/ Command |
| 0x04 | 0x0N | Item H |
| 0x05 | 0x0N | Item L |
| (last byte) | 0xNN | CRC |

MCL 发送值: FF 55 03 6E 0N 0N NN

MCU SEND VALUE: FF 55 03 6E 0N 0N NN

DVD 返回值:无

DVD RETURN VALUE: NOTHING

备注:如果使用此命令预览图片,必须停止(FullStop)音乐播放。

Note: if using this function to preview Jpeg, must fullstop the music playing

4.13 保存记忆/Save Play Position(0x6f)

保存记忆: 0x6f

save play position (0x6f)

使用范围: 所有设备, 播放状态

Command Summary: All devices and all playstates



方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x6f | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 6F 8F

MCU SEND VALUE: FF 55 01 6F 8F

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.14 发送iPod命令/Write ipod binary data(0x70)

(Invalid)

lpod 命令送信(0x70)

Write ipod binary data(0x70)

使用范围: Ipod 设备

Command Summary: iPod

方向: MCU->DVD Direction: MCU->DVD

dential 命令格式/Command Format:

| | 位数/Byte Num | 值/ Value | 含义/ Meaning |
|----------|-------------|----------|---|
| | 0x00 | 0xFF | 同步/ Sync Byte |
| | 0x01 | 0x55 | 开始位/ Start Byte |
| | 0xQ2 | 0XNN | 长度/ Length |
| | 0x03 | 0x70 | 命令/ Command |
| X | 0x04 | 0xNN | Item H Ipod命令数据长高位 Item H Ipod CMD Iength H (包含同步、开始、长度、校验位) (contain iPod sync/start/length/CRC) |
| | 0x05 | 0xNN | Item L Ipod命令数据长低位 Item H Ipod CMD length L |
| | 0x06 | 0xNN | Item H BlockNr index of block |
| | 0x07 | 0xNN | Item L BlockNr index of block |
| | 0x08 | 0xNN | Item H PacketNr index of I2C |



| | | packet within current block |
|-------------|------|--|
| 0x09 | 0xNN | Item L PacketNr index of I2C packet within current block |
| | | Ipod packet information: |
| | | Bitmap: |
| | | bit0: 0 = not First I2C packet of this file or image |
| | | 1 = First I2C packet of this file or image |
| | | bit1: 0 = not continuing I2C packet of this block |
| | | 1 = Continuing I2C packet of this block |
| | | bit2: 0 = not last I2C packet of this block |
| | | 1 = Last I2C packet of this block |
| | | Bit3 0 = not last I2C packet of this file or image |
| | | 1 = Last I2C packet of this file or image |
| 0x0A | 0x0N | \circ |
| | | array of IPOD Data(省略同步、开始 |
| 0X0B0X0N | 0xNN | 位) |
| (last byte) | 0xNN | CRE |

DVD 返回值 : 无

DVD RETURN VALUE:

4.15 设置USB高阻状态/Set USB HighZ state(0x71) (Invalid)

设置 USB 高阻状态(0x)4 Set USB HighZ state (0x71)

使用范围: USB 设备 Command Supphary: USB

方向: MCD > DVD Direction: MCU->DVD

於格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x71 | 命令/ Command |
| | | USB HighZ state: |
| | | 1 = set USB pads to HighZ(在USB |
| 0x04 | 0x0N | HighZ状态,只检测USB设备是否插 |



| | | 入,不和USB设备发生任何通信) 0 = set USB pads to normal state |
|-------------|------|--|
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 02 71 0N NN MCU SEND VALUE: FF 55 02 71 0N NN

DVD 返回值 :无

DVD RETURN VALUE: NOTHING

4.16 选择USB工作模式/USB work way

select(0x72) (Invalid)

选择 USB 工作模式 (0x72) USB work way select (0x72)

使用范围: USB 设备/IPOD 设备

Command Summary: 方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 4.16 选择USB工作模式/USB work way | | | |
|---|-----------|--|--|
| select(0x72) | (Invalid) | | |
| SB 工作模式(0x72) ork way select(0x72) 适用: USB 设备/IPOD ideand Summary: MCU->DVD on: MCU->DVD cd:式/Command Format: | | FOX OIM | |
| 位数/Byte Num | 值/ Value | AX/ Meaning | |
| 0x00 | 0xFF | 同步/ Sync Byte | |
| 0x01 | 0x55 | 开始位/ Start Byte | |
| 0x02 | Qx(02) | 长度/ Length | |
| 0x03 | | 命令/ Command | |
| 0x04 | | Device work way select: 0x02 =USB Mystory 0x04 =IPOD HID | |
| (last byte) | 0xNN | CRC | |

值 : FF 55 02 72 0N NN SEND VALUE: FF 55 02 72 0N NN

DVD RETURN VALUE: NOTHING

4.17 发送记忆数据/Send Memory Data(0x73)

发送记忆数据(0x73)

Send memory data (0x73)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

位数/ Byte Num 值/ Value 含义/ Meaning



| 0x00 | 0xFF | 同步 / Sync Byte | |
|-----------|------|----------------------------------|--|
| 0x01 | 0x55 | 开始位 / Start Byte | |
| | | 长度/Length(Length=memory data | |
| 0x02 | 0xNN | length+3) | |
| 0x03 | 0x73 | 命令/ Command | |
| | | 记忆类型(0: DVD-V; 1: VCD; 2: | |
| | | CD;3:CD-ROM) | |
| | | Memory Type(0: DVD-V; 1: VCD; 2: | |
| 0x04 | 0xNN | CD;3:CD-ROM) | |
| 0x05 | 0xNN | 记忆数据长度/Memory data length | |
| 0x06~0xNN | 0xNN | 记忆数据/Memory data | |
| (last | | | |
| byte) | 0xNN | CRC | |

Note: From 0x04 to 0xNN data just copy from 6.35 Memory data (eport(0xed)

Host send this CMD after receive 6.17 Initialized Report(0xDB),

MCU 发送值 : FF 55 NN 73 0N 0N 0N 0N 0N 0N 0N NN

MCU SEND VALUE: FF 55 NN 73 0N 0N 0N 0N 0N 0N 0N 0N NN

DVD 返回值 :无

DVD RETURN VALUE: NOTHING

对应文档 / Correlation Document •: ① ED

4.18 Clips绝对索引选曲/Rlay Clips File With Absolute Index

Request (0x76)

绝对索引选曲: 0x76(

Play Clips File With Absolute Index: 0x76

使用范围: 所有设备, 播放状态

Command Summary: Used for selecting the file in clips menu

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/ Length |
| 0x03 | 0x76 | 命令/ Command |
| 0x04 | 0xNN | Parent folder index H |
| 0x05 | 0xNN | Parent folder index L |



| 0x06 | 0xNN | File index H |
|-------------|------|--------------|
| 0x07 | 0xNN | File index L |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 05 76 NN NN NN NN NN NN

MCU SEND VALUE: FF 55 05 76 NN NN NN NN NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.19 Ripping曲目选择/Select the tracks to rip (0x77)

Ripping 曲目选择: 0x77 Select the tracks to rip: 0x77

使用范围: CDDA

Command Summary: CDDA

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| Ripping曲自选择/Select the tracks to rip (0x//) 🔪 🔾 | | | |
|---|---------------------|---|--|
| g 曲目选择: 0x77 | | | |
| the tracks to rip: 0x | 77 | | |
| 范围:CDDA | | | |
| and Summary: CDD | PΑ | | |
| MCU->DVD | | \mathcal{O}_{λ} | |
| on: MCU->DVD | | | |
| 各式/Command Form | at: | \sim | |
| 位数/Byte Num | 值/ Value | 含义/ Meaning | |
| 0x00 | 0xFF | 同步 / Sync Byte | |
| 0x01 | 0x55 | 开始位/Start Byte | |
| 0x02 | 0x04 | 长度/ Length | |
| 0x03 | 0x77 | 命令/ Command | |
| 0x04 | 0xNN | Select all items or not.(0:not 1:yes) | |
| | $\zeta \rightarrow$ | File Num H(while selecting all items,the file | |
| 0x05 | OXNN | number is 0xffff) | |
| \sim O | | File Num L(while selecting all items,the file | |
| 0x06 | 0xNN | number is 0xffff) | |
| (last byte) | 0xNN | CRC | |

MCU发送值: FF 55 04 77 NN NN NN NN

MCU SEND VALUE: FF 55 04 77 NN NN NN NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.20 Ripping选择曲目取消/ Deselect the tracks

to rip (0x78)

选择取消曲目: 0x78

Deselect the tracks to rip: 0x78

使用范围: CDDA

Command Summary: CDDA



方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning | |
|-------------|----------|--|--|
| 0x00 | 0xFF | 同步 / Sync Byte | |
| 0x01 | 0x55 | 开始位 / Start Byte | |
| 0x02 | 0x04 | 长度/ Length | |
| 0x03 | 0x78 | 命令/ Command | |
| 0x04 | 0xNN | Deselect all items or not.(0:not 1:yes) | |
| 0x05 | 0xNN | File Num H(while deselecting all items, the file number is 0xffff) | |
| | | File Num L(while deselecting all items,the | |
| 0x06 | 0xNN | file number is 0xffff) | |
| (last byte) | 0xNN | CRC | |

MCU发送值: FF 55 04 78 NN NN NN NN

MCU SEND VALUE: FF 55 04 78 NN NN NN NN NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.21 Ripping开始/Ripping Start (0x79)

Ripping 开始: 0x79 Ripping Start: 0x79 使用范围: CDDA

Command Summary: CDDA

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 1 | 位数/Byte Num | 值/ Value | 含义/ Meaning |
|---|-------------|----------|------------------|
| (| 0x00 | 0xFF | 同步 / Sync Byte |
| 0 | 0x01 | 0x55 | 开始位 / Start Byte |
| (| 0x02 | 0x01 | 长度/ Length |
| (| 0x03 | 0x79 | 命令/ Command |
| (| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 79 85

MCU SEND VALUE: FF 55 01 79 85

DVD返回值:无

DVD RETURN VALUE: NOTHING



4.22 Ripping返回/Ripping Cancel (0x7a)

Ripping 返回: 0x7a Ripping Cancel: 0x7a

使用范围: CDDA Ripping Progress/complete menu

Command Summary: CDDA Ripping Progress/ complete menu

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x7a | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 7a NN

MCU SEND VALUE: FF 55 01 79 NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.23 打开版本菜单/Open Version Menu(0x7b)

版本菜单(0x7b)

Version Menu (0x7b)

使用范围: 无碟的时候使用

Command Summary:valid when no disc mode

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/Length |
| 0x03 | 0x7b | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU 发送值 : FF 55 01 7b NN MCU SEND VALUE: FF 55 01 7b NN

DVD 返回值 :无

DVD RETURN VALUE: NOTHING



4.24 打开测试模式/Open Test Mode(Invalid)

打开测试模式开始: 0x7C Open Test mode start: 0x7C

使用范围: reserve

Command Summary:reserve

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x7C | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 7C 85

MCU SEND VALUE: FF 55 01 7C 85

DVD返回值:无

DVD RETURN VALUE: NOTHING

4.25 DRM播放控制/DRM Control (0x7D)

DRM 播放控制: 0x7d DRM control: 0x7d

使用范围: 当 DRM 提示用户需要确认是否播放时

Command Summary: When DRM prompt the user to vefiry to play or not

方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x7d | 命令/ Command |
| 0x04 | OxNN | 播放控制(00:cancel;01:ok) |



| | | control CMD(00: 00:cancel;01:ok) |
|-------------|------|----------------------------------|
| (last byte) | OxNN | CRC |

MCU发送值: FF 55 02 7d NN NN

MCU SEND VALUE: FF 55 02 7d NN NN

DVD返回值:无

DVD RETURN VALUE: NOTHING

Chapter 5 状态查询命令/Status Requestion Commands

5.1 查询配置信息/Configuration

Request(0x82)

配置信息获取: 0x82

Configuration Request (0x82)

方向: MCU->DVD Direction:MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x82 | 命令/ Command |
| 0x04 | 0x0N | Configuration Item |
| (last byte) | 0xNN | CRC |

Configuration Item:

| Ī | 0x02 | Region Code |
|---|------|----------------|
| | 0x03 | Video Setup |
| ĺ | 0x05 | Language Setup |

MCU发送值: FF 55 02 82 0N NN MCU SEND VALUE: FF 55 02 82 0N NN

区域码对应文档/Correlation Document: 0xC2



视频设置对应文档/Correlation Document: 0xC3 语言设置对应文档/Correlation Document: 0xC5

5.2 当前设备状态查询/Mechanism State

Request(0x83)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x83 | 命令/ Command |
| 0x04 | 0x0N | Device ID |
| (last byte) | 0xNN | CRC |

Device ID:

| 0x0 | Disc |
|------|-------------------|
| 0x1 | USB |
| 0x2 | S D |
| 0xFF | Current Device ID |

MCU发送值 : FF 55 02 83 0N NN

MCU SEND VALUE : FF 55 02 83 ON CN DVD返回值 : FF 55 04 CB 0N 0N 0N NN

DVD RETURN VALUE : FF 55 04 CB 0N 0N 0N NN

对应文档/Correlation Document: <u>0xCB</u> 注: 获取当前播放设备状态,设备 ID 发送 0xFF。 Note: Get current device state, DeviceID is 0xFF.

5.3 播放状态获取/Play State Request(0x84)

播放状态信息获取: 0x84 Get Play state (0x84) 适用范围: 任何状态

Command Summary: Any State

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |



| 0x02 | 0x01 | 长度/ Length |
|-------------|------|-------------|
| 0x03 | 0x84 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 84 7A

MCU SEND VALUE: FF 55 01 84 7A DVD返回值: FF 55 03 CC 0N 0N NN

DVD RETURN VALUE: FF 55 03 CC 0N 0N NN

对应文档/Correlation Document: 0xCC

5.4 媒体类型查询/Media Status Request(0x85)

媒体类型获取: 0x85

Media status request (0x85)

适用范围: 所有碟片、USB、SD, 播放状态。

Command Summary: all DISC, USB, SD, play state.

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF . (| 同步/ Sync Byte |
| 0x01 | 0x55 × | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x85 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 85 79

MCU SEND VALUE : FF 55 01 85 79

DVD返回值: FF 55 05 CD 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 05 CD 0N 0N 0N 0N NN

对应文档/Correlation Document: <u>0xCD</u>

5.5 查询时间/Media Time Request(0x86)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x86 | 命令/ Command |



| 0x04 | 0x0N | 时间类型/Time Type |
|-------------|------|----------------|
| (last byte) | 0xNN | CRC |

Time Type:

0x0Playing Time0x1Total Time(DVD:Title Time)

MCU发送值: FF 55 02 86 0N NN

MCU SEND VALUE: FF 55 02 86 0N NN DVD返回值: FF 55 05 CE 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 05 CE 0N 0N 0N 0N NN

对应文档/Correlation Document: 0xCE

5.6 查询PTT信息/Media PTT Request (0x87)

媒体 PTT 信息获取: 0x87 Media PTT information (0x87)

适用范围: 所有碟片、USB、SD, 当前播放设备的曲目, 时间信息。

Command Summary: all DISC USB SD, play state.

方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x87 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 87 77

MCU SEND VALUE : FF 55 01 87 77 DVD返回值 : FF 55 0D CF 0N...0N NN

DVD RETURN VALUE : FF 55 0D CF 0N...0N NN

对应文档/Correlation Document: 0xCF

5.7 开启主动发送显示信息/Display Information

State Request (0x89)

开启或关闭主动发送显示信息: 0x89

Turn on or off to send display information automatically 适用范围: 所有碟片、USB、SD,设备处于 Ready 状态。

Command Summary: all DISC USB SD, device state is ready

方向: MCU->DVD Direction: MCU->DVD



命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0x89 | 命令/ Command |
| 0x04 | 0x0N | Cmd to send automaticly |
| (last byte) | 0xNN | CRC |

参数表:

| 参数/ Parameter | 意义/ meanimg |
|---------------|--|
| 0x00 | 关闭自动发送功能 |
| | Turn off the fouction of automatically sending |
| 0x01 | 自动发送 <u>0xd2</u> 和 <u>0xd7</u> (4s) |
| | Automatically send 0xd2 and 0xd7 |
| 0x02 | 自动发送 <u>0xd2</u> (200ms) |
| | Automatically send 0xd2 |
| 0x03 | 自动发送 <u>0xd7</u> (200ms) |
| | Automatically send 0xd7 |

注:以上四种情况只能使用一种,不能同时使用

Note: only use one in the same time

MCU发送值: FF 55 02 89 0N NN

MCU SEND VALUE: FF 55 02 89 0N NN DVD返回值: FF 55 15 D2 0N...0N NN

FF 55 0B D7 0N NN

DVD RETURN VALUE: FF 55 15 D2 0N...0N NN

FF 55 0B D7 0N 0N

ON NN

对应文档/Correlation Document: <u>0xD2</u> 对应文档/Correlation Document: <u>0xD7</u>

5.8 查询ID-3/CD-TEXT信息/ID3/CD-TEXT

Request(0x8C)

ID3/CD-Text 信息获取: 0x8c

ID3/CD-Text information request (0x8c)

适用范围: 当前播放的 MP3、WMA、M4A 音频文件的 ID3,或 CD-Text 信息,其他文件不支持

Command Summary: ID3 of the current play of M4A、WMA or MP3, other files are not unsupported.

方向: MCU->DVD Direction: MCU->DVD



命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x03 | 长度/ Length |
| 0x03 | 0x8c | 命令/ Command |
| 0x04 | 0x0N | 信息类型/ID3 Type |
| 0x05 | 0x0N | 0x00: 原码 0x01:转码为Unicode 0x02: 转码为UTF8(只适用录M4A文件) 0x00:original 0x01: transcode to Unicode 0x02: transcode to UTF8 (only apply to M4A) |
| (last byte) | 0xNN | CRC |

信息类型/ ID3 Type:

| ±/100 Type. | ▲ (* |
|-------------|-------------------------------|
| 0x10 | MP3 名字/ MP3 name |
| 0x11 | MP3 艺术家/ MP3 artist |
| 0x12 | MP3 专辑/ MP3 album |
| 0x20 | WMA 标题/ WMAtitle |
| 0x21 | WMA 作家/WMA author |
| 0x22 | WMA 专辑/WMA album |
| 0x50 | CD_TEXT 专辑/CD-TEXT album |
| 0x51 | CD-TEXT 歌曲名/CD-TEXT trackname |
| 0x52 | CD-TEXT 艺术家/CD-TEXT artist |
| 0x60 | M4A 名字/ M4A name |
| 0x61 | M4A 艺术家/ M4A artist |
| 0x62 | M4A 专辑/ M4A album |

MCU发送值: FF 55 03 8C 0N 0N NN

MCU SEND VALUE: FF 55 03 8C 0N 0N NN

DVD返回值: FF 55 45 D5 0N...0N NN

DVD RETURN VALUE: FF 55 45 D5 0N...0N NN

对应文档/Correlation Document: <u>0xD5</u>

5.9 查询旁白/字幕/角度信息/Audio Subtitle

Angle State Request(0x8E)

获取 Audio、Subtitle、Angle 信息: 0x8e

Audio、Subtitle、Angle info (0x8e) 适用范围: DVD Video,播放状态。

Command Summary: DVD Video, play state.

方向: MCU->DVD



Direction: MCU->DVD 命令格式/Command:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x8e | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 8E 70

MCU SEND VALUE: FF 55 01 8E 70

DVD 返回值 : FF 55 0B D7 0N NN

DVD RETURN VALUE: FF 55 0B D7 0N 0N 0N 0N 0N 0N 0N 0N

ON ON NN

对应文档/Correlation Document: 0xD7

5.10 查询clips文件名/Clips Name

Request(0x8F)

获取 Clips 文件名: 0x8F

ClipsFile Name Request (0x8F)

适用范围: 所有 Clips 碟片、USB、SD

Command Summary: All Clips Disc USB SD

注意: 先获取当前的文件和文件夹数量(0x91),文件夹和文件名分开获取, Item

Num 从 0 到文件 (夹) 总数-1;

Notice: Requested to get the total amount of file and folder by 0x91 before

using this command. Item starts from 0.

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x05 | 长度/ Length |
| 0x03 | 0x8f | 命令/ Command |
| 0x04 | 0x0N | File (0x01) /Folder(0x00) |
| 0x05 | 0x0N | File Item H |
| 0x06 | 0x0N | File Item L |
| 0x07 | 0x0N | File/folder amount requested |
| (last byte) | 0xNN | CRC |



注: 获取文件名时, FileItem 为 0xFFFF, 则获取的文件名为当前播放的文件的 文件名。

NOTE:Return current playing file/folder name if the file/folder item is 0xFFFF.

MCU发送值 : FF 55 05 8F 0N 0N 0N 0N NN

MCU SEND VALUE: FF 55 05 8F 0N 0N 0N ON NN

DVD返回值 : FF 55 26 D9 0N...0N NN

DVD RETURN VALUE: FF 55 26 D9 0N...0N NN

对应文档/Correlation Document: 0xD9

5.11 播放模式查询/Play Mode

REQUEST(0x90)

获取播放模式: 0x90

Play Mode Request (0x90) 适用范围: 所有碟片、USB、SD

Command Summary: all DISC, USB, SD

方向: MCU->DVD Direction: CU->DVD

命令格式/Command Format:

| 5.11 播放模式查询/Play Mode | | |
|---|------------|-----------------|
| REQUEST(0x90) | | |
| 放模式: 0x90 ode Request (0x90) 围: 所有碟片、USB、SD and Summary: all DISC、 MCU->DVD on: CU->DVD 式/Command Format: | USB、SD | For all |
| 位数/Byte Num | 值/ Value 🕜 | 含义/ Meaning |
| 0x00 | 0xFF X | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x90 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU SEND VALUE: FF 55 01 90 6E DVD返回值 : FF 55 02 DA 0N NN

DVD RETURN VALUE: FF 55 02 DA 0N NN

对应文档/Correlation Document : <u>0xDA</u>

5.12 查询Clips光标位置/Clips Cursor Request

(0x91)

获取 Clips 光标位置: 0x91 Get clips focus position (0x91)

适用范围: 所有 Clips 碟片、USB、SD 任意状态(clips 文件指 cd/mp3/wma/jpg/avi 等文件)

Command Summary: all Clips disc, USB, SD, any state

方向: MCU->DVD Direction: MCU->DVD



命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x91 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 91 6D

MCU SEND VALUE: FF 55 01 91 6D

DVD返回值 : FF 55 08 D8 0N 0N 0N 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 08 D8 0N 0N 0N 0N 0N 0N 0N NN

对应文档/Correlation Document: 0xD8

5.13 查询角度和放大/Angle&Zoom

Request(0x92)

获取角度和放大倍数(0x92)

Get current angle and zoom level (0x92)

适用范围:角度只适用于 DVD-Video 和 JPEG,放大信息适用 DVD-Video、JPEG、

VCD

Command Summary: Valid in DVD-Video/JPEG/VCD, But VCD has no zoom

info.

方向: MCU->DVD Direction: MCU->DVD

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x92 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 92 6C

MCU SEND VALUE: FF 55 01 92 6C DVD返回值: FF 55 03 DC 0N 0N NN

DVD RETURN VALUE: FF 55 03 DC 0N 0N NN

对应文档/Correlation Document: <u>0xDC</u>



5.14 查询当前连接设备/Current Connect

Device(0x93)

获取当前连接的设备: 0x93

Get Current Connect Device (0x93)

适用范围: Loading 状态无效,DVD 检测比较慢,建议 MCU 硬件检测 Card 和 USB;如果MCU 可以检测 USB/Card,可以不使用此命令。

Command Summary: It is invalid when device state is loading. It's a little slow if detected by DVD, so we suggest that USB/SD is detected by hardware. If MCU can detect USB/SD, don't use this command.

方向: MCU->DVD Direction: MCU->DVD

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x93 | 命令Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 93 6B、 ()

MCU SEND VALUE: FF 55 01 93 6B DVD返回值: FF 55 04 DD 0N 0N 0N NN

DVD RETURN VALUE: OFF 55 04 DD 0N 0N 0N NN

对应文档/Correlation Document: OxDD

5.15 获取旁白/字幕/Get Subtitle/Audio

Information (0x94)

获取旁白/字幕信息: 0x94

Get audio/subtitle info (0x94)

适用范围: DVD-Video播放状态;请先获取音频/字幕总数(<u>0x8e</u>);仅限于获取当前章节的音频/字幕。

Command Summary: DVD-Video play state, first get total number of audio/subtitle (command 0x8e), you can only get the audio and subtitle in current chapter

方向: MCU->DVD Direction: MCU->DVD

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |



| 0x02 | 0x03 | 长度/ Length |
|-------------|------|---|
| 0x03 | 0x94 | 命令/ Command |
| 0x04 | 0x0N | 信息类型 (0x00: 音频 0x01: 字幕) Info type (0x00: audio 0x01: subtitel) |
| 0x05 | 0x0N | 信息序数/ Info index |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 03 94 0N 0N NN

MCU SEND VALUE: FF 55 03 94 0N 0N NN DVD返回值: FF 55 06 DE 0N 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 06 DE 0N 0N 0N 0N 0N NN

对应文档/Correlation Document: OxDE

5.16 查询预览图片尺寸/Get PreViewing

Picture Size(0x95) (Invalid)

获取预览图片的尺寸: 0x95

Get Previewing Picuture Size (0x95)

适用范围:必须是JPEG图片,且Play State处于为PST_STILL; Command Summary: must be JPEG, and the play state is still.

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | ♠ Value | 含义/ Meaning |
|-------------|---------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x95 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 95 69

MCU SEND VALUE: FF 55 01 95 69

DVD返回值: FF 55 05 DF 0N 0N 0N 0N NN DVD RETURN VALUE: FF 55 05 DF 0N 0N 0N 0N NN

对应文档/Correlation Document: 0xDF

5.17 查询高亮文件索引/Get High Ligth File

Index(0x96)

获取高亮文件索引: 0x96



Get High Ligth File index (0x96)

适用范围: Clips文件

Command Summary: Clips file

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x96 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 96 68

MCU SEND VALUE: FF 55 01 96 68 DVD 返回值: FF 55 03 E0 0N 0N NN

DVD RETURN VALUE: FF 55 03 E0 0N 0N NN

对应文档/Correlation Document: 0xE0

5.18 查询光标所在的文件夹名/Get Path

Name(0x97)

适用范围: Clips文件

Command Summary: Clips file

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x97 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 97 67

MCU SEND VALUE: FF 55 01 97 67 DVD返回值: FF 55 21 E1 0N...0N NN

DVD RETURN VALUE: FF 55 21 E1 0N...0N NN

对应文档/Correlation Document: 0xE1

5.19 查询软件版本/Get Software



Version(0x98)

获取软件版本号: 0x98 Get Software Version(0x98)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x98 | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 98 66

MCU SEND VALUE: FF 55 01 98 66

DVD返回值: FF 55 NN E2 0N...0N 0N...0N NN

DVD RETURN VALUE: FF 55 NN E2 0N...0N 0N...0N NN

对应文档/Correlation Document: 0xE2

5.20 查询BIN代码内容/Request Bin Code(0x99)

(Invalid)

请求Bin Code内容: 0x99

Request Bin Code (0x99)

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command.

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 6x82 | 0x06 | 长度/ Length |
| 0x03 | 0x99 | 命令/ Command |
| 0x04 | 0xNN | code offset byte 3 |
| 0x05 | 0xNN | code offset byte 2 |
| 0x06 | 0xNN | code offset byte 1 |
| 0x07 | 0xNN | code offset byte 0 |
| 0x08 | 0xNN | 长度/Length |
| last byte | 0xNN | CRC |

MCU发送值: FF 55 06 99 0N 0N 0N 0N 0N NN



MCU SEND VALUE: FF 55 06 99 0N 0N 0N 0N 0N NN

DVD返回值: FF 55 87 E3

FF 55 07 E4 0N 0N 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 87 E3

FF 55 07 E4 0N 0N 0N 0N 0N 0N NN

对应文档/Correlation Document: 0xE3 0xE4

5.21 查询BIN文件长度/Request Bin

Length(0x9a) (Invalid)

| Length(0 | (9a) | d) QIM OILLY |
|-------------|----------|----------------------------|
| 位数/Byte Num | 值/ Value | 含义/ Mearting |
| 0x00 | 0xFF | 同步/ Syne Byte |
| 0x01 | 0x55 | 开始文/ Start Byte |
| 0x02 | 0x01 | 人(人) Length |
| 0x03 | 0x9a | <mark>√</mark> 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FX55 MCU SEND VALUE FF 55 01 9A 64

DVD 返回值 个: OFF 55 05 E5 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 05 E5 0N 0N 0N 0N NN

对应文档 Correlation Document: 0xE5

5.22 查询USB高阻状态/Request USB HighZ

(0x9b) (Invalid)

查询 USB 高阻状态(0x9b) Request USB HighZ (0x9b) 使用范围: USB 设备 Command Summary: USB

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num 值/ Value 含义/ Meaning | |
|----------------------------------|--|
|----------------------------------|--|



| 0x00 | 0xFF | 同步/ Sync Byte |
|-------------|------|-----------------|
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x9b | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 9b 63 MCU SEND VALUE: FF 55 01 9b 63 DVD 返回值 : FF 55 02 E9 0N NN

VID&PID(0x9c) (Invalid)

查询 USB VID&PID (0x9c)

Request USB VID&PID (0x9c)

使用范围: USB 设备 Command Summary: USB

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| DVD 返回值 : FF 55 02 | 2 E9 ON NN | |
|---|---------------|------------------|
| DVD RETURN VALUE | : FF 55 02 E9 | ON NN |
| 对应文档/ Correlation D | ocument :0xE | <u> </u> |
| | | |
| 5.23 查询 | USB VID | &PID/Request USB |
| VID&PID(0x9 | c) (Invalid | |
| SB VID&PID(0x9c) st USB VID&PID(0x9c) 适用: USB 设备 and Summary: USB MCU->DVD on: MCU->DVD | | A FOX |
| 位数/Byte Num | 值/₩alue | 含义/ Meaning |
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x9c | 命令/ Command |
| (last byte) | 0xNN | CRC |

MC以关结 : FF 55 01 9C NN MCU SEND VALUE: FF 55 01 9C NN

DYD 返回值 : FF 55 07 EA 0N 0N 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 07 EA 0N 0N 0N 0N 0N 0N NN

对应文档/ Correlation Document : 0xEA

5.24 查询USB工作模式/Request USB work

way(0x9D) (Invalid)

查询 USB 工作模式 (0x9d) Request USB work way (0x9d)

使用范围: USB 设备



Command Summary: USB

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x9D | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 9D NN MCU SEND VALUE : FF 55 01 9D NN DVD 返回值 : FF 55 04 EB 0N 0N 0N NN

DVD RETURN VALUE : FF 55 04 EB 0N 0N 0N NN

对应文档 / Correlation Document: 0xEB

5.25 查询文件文件夹数/ Request the Total of

Files and Folders (0x9E)

查询文件系统中的文件、文件夹数量: Ox9E

Request the Total of Files and Folders in the filesystem: 0x9e

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0x9E | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9E 60

MCU SEND VALUE: FF 55 01 9E 60

DVD返回值 : FF 55 05 EE NN NN NN NN NN

DVD RETURN VALUE: FF 55 05 EE NN NN NN NN NN

对应文档/Correlation Document: 0xEE



5.26 查询文件系统概况/Request Summary of

FileSystem (0x9F)

查询文件系统信息概况: 0x9f

Request Summary of File System: 0x9f

方向: MCU->DVD Direction:MCU->DVD

命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/Length |
| 0x03 | 0x9F | 命令/ Command |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9F 5F

MCU SEND VALUE: FF 55 01 9F 5F

DVD返回值 : FF 55 NN EF NN...NN NN

DVD RETURN VALUE : FF 55 NN EF NN...NN NN

对应文档/Correlation Document •: *() xEF

5.27 查询文件文件夹信息/Request the

Attribute of File or Folder (0xA0)

方向: MCU->DVD Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|----------------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/ Length |
| 0x03 | 0xa0 | 命令/ Command |
| 0x04 | 0x0N | Type(Folder: 0 File: 1) |
| 0x05 | 0xNN | File/Folder Abs Index H |
| 0x06 | 0xNN | File/Folder Abs Index L |
| 0x07 | 0x0N | Offset(Better less than 6) |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 05 A0 0N NN NN 0N NN

MCU SEND VALUE : FF 55 05 A0 0N NN NN 0N NN



DVD返回值: FF 55 NN F0 NN...NN NN DVD RETURN VALUE: FF 55 NN F0 NN...NN NN

对应文档/Correlation Document: 0xF0

5.28 查询当前播放文件所在的文件夹名/Get

Playing Folder Name(0xA1)

适用范围: Clips文件

Command Summary: Clips file

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0xA1 | 命令/ Command |
| (last byte) | 0x5D | CRO |

MCU发送值: FF 55 01 A1 5D. ()

MCU SEND VALUE: FF 55 01 A1 5D DVD返回值: FF 55 21 E1 0N...0N NN

DVD RETURN VALUE CFF 55 21 E1 0N...0N NN

对应文档/Correlation Document: 0xE1

5.29 查询iPod信息/Get iPod information(0xa2)

(Invalid)

查询iPod信息: 0xA2

Get iPod information (0xA2)

适用范围: iPod播放时

Command Summary: iPod playing

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0xa2 | 命令/ Command |



| 0x04 | 0x0N | 信息类型/Type |
|-------------|------|-----------|
| (last byte) | 0xNN | CRC |

类型/Type

| Туре | Value | Meaning |
|-----------------|-------|---|
| Play state&Mode | 0x00 | contain play state/repeat mode/shuffle mode |
| total time | 0x01 | the total time of current playing file |
| Current time | 0x02 | the current time of current playing file |
| Artist | 0x03 | the artist name of current playing file |
| album | 0x04 | the album name of current playing file |
| Title | 0x05 | the title name of current playing file |
| Item Name | 0x06 | the items' name |
| Current item | 0x07 | the playing track index |
| total item | 0x08 | the total track in the list |

MCU发送值: FF 55 02 A2 0N NN

MCU SEND VALUE: FF 55 02 A2 0N NN

DVD返回值: FF 55 NN F2 NN NN ... NN NN

DVD RETURN VALUE: FF 55 NN F2 NN NN NN

对应文档/Correlation Document: 0xF2

5.31 查询DRM Mode ID/DRM Mode ID Request

(0xa4)

查询DRM Mode ID: 0xa4

Request DRM Mode ID: 0xa4

方向: MCU->DVD

Direction: MCU->DVD

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0xa4 | 命令/ Command |
| (last byte) | OxNN | CRC |

MCU发送值 : FF 55 01 A4 CRC MCU SEND VALUE : FF 55 01 A4 CRC



DVD返回值 : FF 55 03 f6 0N 0N CRC
DVD RETURN VALUE : FF 55 03 f6 0N 0N CRC

5.32 查询DRM注册及反注册码/DRM Register and

Deregister Code Request (0xa5)

查询DRM注册及反注册码: 0xa5

Request DRM register and deregister code:0xa5

适用范围: DVD stop状态

Command Summary: DVD stop state

方向: MCU->DVD
Direction: MCU->DVD
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|--------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0xa5 | 命令/ Command |
| | 6.7 | 00:register code, |
| 0x04 | OXON | 01:deregister code |
| (last byte) | OxNN | CRC |

MCU发送值 : FF 55 02 A5 ON CRC

MCU SEND VALUE: FF 55 02 A5 ON CRC

DVD返回值 : FF 55 1b f3 ON ON ON CRC

DVD RETURN VALUE: FF 55 1b f3 ON ON ON CRC

对应文档/Correlation Document: C648

5.33 查询DRM注册状态/DRM Register State

Request (0xa7)

查询DRM注册状态: 0xa7

Request DRM register state:0xa7

适用范围: DVD stop状态



Command Summary: DVD stop state

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0xa7 | 命令/ Command |
| (last byte) | 0x57 | CRC |

MCU发送值 : FF 55 01 A7 57

MCU SEND VALUE: FF 55 01 A7 57

DVD返回值 : FF 55 03 f5 0N ON CRC

DVD RETURN VALUE: FF 55 03 f5 ON ON CRC

对应文档/Correlation Document: C849

5.34 查询DRM Rental 次数/DRM Rental Count Request (0xa8)

查询DRM Rental 次数: 0xa8

Request DRM Rental Count:0xa8

适用范围:播放VOD文件时

Command Summary: Play the VOD file

方向: MCU->DVD Direction: MCU->DVD 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0×00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x01 | 长度/ Length |
| 0x03 | 0xa8 | 命令/ Command |
| (last byte) | 0x56 | CRC |



MCU发送值 : FF 55 01 A8 56

MCU SEND VALUE: FF 55 01 A8 56

DVD返回值 : FF 55 05 D4 ON ON ON ON CRC

DVD RETURN VALUE: FF 55 05 D4 ON ON ON CRC

对应文档/Correlation Document: C647

Chapter 6 相应命令/Mechanism Status Reports

6.1 机芯状态错误回复/Error Status Report

(0xC1)

发送机芯状态错误信息: 0xc1

Send Error State (0xc1) 适用范围: 所有碟片, 所有状态

Command Summary: All Device&Any State

方向: DVD->MCU Direction:DVD->MCU

命令格式/Command Format:

| 6.1 机芯状态错误回复/Error Status Report | | | | |
|--|------------|---|--|--|
| (0xC1) | | | | |
| E机芯状态错误信息: 0xc1 ad Error State(0xc1) d Error State(0xc1) d 范围: 所有碟片,所有状态nmand Summary: All Devior: DVD->MCU ection:DVD->MCU h A式/Command Format: | | Fox | | |
| 位数/Byte Num | 值/ Value 🧳 | 含义/ Meaning | | |
| 0x00 | 0xFF X | 同步/ Sync Byte | | |
| 0x01 | 0x55 | 开始位/ Start Byte | | |
| 0x02 | 0x04 | 长度/ Length | | |
| 0x03 | 0xc1 | 命令/ Command | | |
| 0x04 | 0x0N | 错误类型/ Error Type | | |
| 1017 | | 命令类型;错误类型为0x13时,返回接收到的命令,其他为0x00 Command Type, if the error type is 0x15,return the received | | |
| 0x05 | 0x0N | command, or return 0x00 | | |
| 0x06 | 0x0N | IR值;命令类型为0x6b时,为IR值, 其他为0x00 IR key code,if the Command Type is 0x6b,return the IR key code,or return 0x00 | | |
| (last byte) | 0xNN | CRC | | |

错误类型

| · · · · · · · · · · · · · · · · · · · | | |
|---------------------------------------|-------------|--|
| 0x00 | 命令响应 | |
| | Command ACK | |
| 0x01 | 错误的命令 | |



| | Sunplus DVD 通信 例以 | | | |
|------|--|--|--|--|
| | Invalid command | | | |
| 0x02 | 命令参数错误 | | | |
| | Invalid control parameter | | | |
| 0x03 | 命令长度错误 | | | |
| | Command length error | | | |
| 0x04 | 校验错误 | | | |
| | Checksum error | | | |
| 0x05 | 当前不允许操作 | | | |
| | 日前でルロ森市 Current operation not allowed | | | |
| 0x06 | 区域码错误 | | | |
| | Region error | | | |
| 0x07 | 视频文件不支持 | | | |
| | Video File unsupport | | | |
| 0x08 | 坏碟 | | | |
| | Bad Disc | | | |
| 0x09 | 进仓异常 | | | |
| | Closing error | | | |
| 0x0a | 出仓异常 | | | |
| | Eject error | | | |
| 0x0b | 初始化异常 | | | |
| | Initialization error | | | |
| 0x0c | 无碟不允许操作 | | | |
| | Disc not present | | | |
| 0x0d | 播放状态错误 | | | |
| • 0 | Play state error | | | |
| 0x0e | 命令不支持 | | | |
| y | Unsupported command | | | |
| 0x0f | 记忆成功(对应命令 0x6f) | | | |
| | save play position success | | | |
| 0x10 | 不支持的 USB | | | |
| | USB not support | | | |
| 0x11 | 当前处于 DVD ROOT MENU | | | |
| | it's in DVD root menu | | | |
| 0x12 | 无可支持文件 | | | |
| - | there is no supported file | | | |
| 0x13 | DVD 接收到命令 | | | |
| | Receive command | | | |
| 0x14 | 自动播放到下一个文件夹(主动发送) | | | |
| | play to next folder | | | |
| 0x15 | 对应命令 0x67 返回 | | | |
| | Correlation with command 0x67 | | | |
| 0x16 | 对应命令 0x6d 返回 | | | |
| | Correlation with command 0x6d | | | |



| | 光标刷新完成(对应 6B 71) |
|-------|--|
| 0x17 | cursor refresh finished(Correlation with command 6 B |
| | 71) |
| 0x18 | 不允许切换设备 |
| UXTO | switch device is not allowed |
| 0.40 | 切换设备失败 |
| 0x19 | switch device failed |
| 0.40 | 触摸响应 |
| 0x1a | Touching ack |
| | 触摸无效 |
| 0x1b | Touching no response |
| 0.40 | 碟片已停转 (MCU控制进出仓有效) |
| 0x1c | Spindle is down, valid for MCU controlling the tray. |
| 0x1d | track contains video(iPod) |
| 0x1e | queued to play as a video(iRod) |
| 0x1f | Music track(iPod) |
| 0x20 | queued to play as a music(iPod) |
| 0.405 | 完成恢复出厂设置 |
| 0x25 | Set default done |
| 0,406 | 音频文件不支持 |
| 0x26 | Audeo File unsupport |
| 0.07 | 文件loading完成 |
| 0x27 | File loading finish |

DVD返回值 : FF 55 04 C1 0N 0N 0N NN

DVD RETURN VALUE : FF 55 04 C1 0N 0N NN

MCU 发送值 : 任意控制指令

MCU SEND VALUE: Any control command

6.2 区域码设置响应/Region Code Setting

Report(0xC2)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0xc2 | 命令/ Command |
| 0x04 | 0x0N | 区域码/ Region Code |
| (last byte) | 0xNN | CRC |



Region Code:

| 0 | Informal term meaning "worldwide". Region 0 is not an official setting; discs that bear the region 0 symbol either have no flag set or have regions 1–6 flags set. Region 0 is commonly referred to as "Region Free". | | | |
|---|---|--|--|--|
| 1 | United States, Canada, Bermuda, Caribbean, U.S. territories | | | |
| 2 | Europe, Middle East, Egypt, Japan, South Africa, Swaziland, Lesotho, | | | |
| | Greenland, French Overseas departments and territories | | | |
| 3 | Southeast Asia, South Korea, Taiwan, Hong Kong, Macau | | | |
| 1 | South America, Central America, Mexico, New Zealand, Australia, Papua | | | |
| + | New Guinea and much of Oceania | | | |
| | Bangladesh, India, Nepal, Afghanistan, Sri Lanka, Ukraine, Belarus, Russia, | | | |
| 5 | Kazakhstan, Pakistan, Africa (except Egypt, South Africa, Swaziland, | | | |
| | Lesotho), Central Asia, Mongolia, North Korea | | | |
| 6 | China | | | |

DVD返回值: FF 55 02 C2 0N NN

DVD RETURN VALUE: FF 55 02 C2 0N NN

MCU发送值: FF 55 02 82 02 79

MCU SEND VALUE : FF 55 02 82 02 79 对应文档/ Correlation Document: 0x82

6.3 视频设置响应/Video Setup Report(0xc3)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x09 | 长度/ Length |
| 0x03 | 0xc3 | 命令/ Command |
| 0x04 | 0x0N | VidOut TVSys |
| 0x05 | 0x0N | 宽高比/ Aspect Ratio |
| 0x06 | 0xFF | 填充模式/View Mode |
| 0x07 | 0x0N | 锐度/Sharpness |
| 0x08 | 0x0N | 对比度/ Contrast |
| 0x09 | 0x0N | 亮度/ Brightness |
| 0x0a | 0x0N | 色调/ Hue |
| 0x0b | 0x0N | 饱和度/ Saturation |
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 09 C3 0N 0N 0N 0N 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 09 C3 0N 0N 0N 0N 0N 0N 0N 0N NN

MCU发送值: FF 55 02 82 03 78



MCU SEND VALUE: FF 55 02 82 03 78 对应文档/Correlation Document: 0x82

6.4 音频设置响应/Audio Setup Report(0xC4)

(Invalid)

发送音频设置信息: 0xc4

Send Audio Setup configuration (0xc4)

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|---------------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x07 | 长度/ Leggth |
| 0x03 | 0xc4 | 命次Command |
| 0x04 | 0x0N | Spdi/信息/ Spdif Info |
| 0x05 | 0x0N | ▶道设置信息/ Channel Setup Info |
| 0x06 | 0x0N | 压缩模式/ Compression |
| 0x07 | 0x0N | 音频控制/ Audio Control |
| 0x08 | Ox0N | 中置扬声器延时/Center Channel Delay |
| 0x09 | 0x0N | 环绕扬声器延时/ Rear Channel Delay |
| (last byte) | 0xNN | CRC |

DVD返回值 字 FF 55 07 C4 0N 0N 0N 0N 0N 0N NN

DVD RENURN VALUE: FF 55 07 C4 0N 0N 0N 0N 0N NN

MCU发送值: FF 55 02 82 04 77

MCU SEND VALUE: FF 55 02 82 04 77

对应文档/ Correlation Document:

6.5 语言设置响应/Language Setup

Report(0xC5)

发送语言设置信息: 0xc5

Send Language Setup configuration (0xc5)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:



| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|----------------------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x0b | 长度/ Length |
| 0x03 | 0xc4 | 命令/ Command |
| 0x04 | 0x0N | OSD语言 H/OSD Language H |
| 0x05 | 0x0N | OSD语言 L/ OSD Language L |
| | | DVD Subtitle语言 H |
| 0x06 | 0x0N | DVD Subtitle Language H |
| | | DVD Subtitle语言 L |
| 0x07 | 0x0N | DVD Subtitle Language L |
| | | DIVX Subtitle语言 H |
| 0x08 | 0x0N | DIVX Subtitle Language H |
| | | DIVX Subtitle语言 L |
| 0x09 | 0x0N | DIVX Subtitle Language L |
| 0x0a | 0x0N | Audio语言 H/Audio Language H |
| 0x0b | 0x0N | Audio语言 L/Audio Language L |
| | ^ | DVD Menu语言 H |
| 0x0c | 0x0N 🔩 🕜 | DVD Menu Language H |
| | XX | DVD Menu语言 L |
| 0x0d | 0x0N | DVD Menu Language L |
| (last byte) | OXNN | CRC |

DVD返回值 : FF 55 0B C5 0N NN DVD RETURN VALUE: FF 55 0B C5 0N NN

MCU发送值: 55 02 82 05 76

MCU SEND VALUE: FF 55 02 82 05 76

对应文档/ Correlation Document:0x82

6.6 设备状态回复/Mechanism State

Report(0xCB)

方向: DVD->MCU Direction:DVD->MCU 命令格式/ Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 /Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x04 | 长度/ Length |
| 0x03 | 0xcb | 命令/ Command |



| | | ID (0x00~0x03: |
|-------------|------|--------------------|
| 0x04 | 0x0N | Disc/USB/SD/iPod) |
| 0x05 | 0x0N | 设备状态/ Device State |
| 0x06 | 0x0N | 设备类型/ Device Type |
| (last byte) | 0xNN | CRC |

参数/Parameter

| /Parameter: | | |
|--|--------|--|
| | 0x00 | NO DEVICE |
| | 0x01 | UNKNOWN |
| | 0x02 | TRAY OPENING |
| | 0x03 | TRAY CLOSING |
| | 0x04 | TRAY OPENED |
| | 0x05 | LOADING |
| | 0x06 | IDENTIFIED |
| | | DEVICE_IDLE(插入 USB/SD 但不播放)/ |
| | 0x07 | (Insert USB/SD but not play) |
| 1几夕心大/ | | DEVICE_INIT_TO_NON_DISC(进出仓 |
| 设备状态/ | | 不影响 (/SB/SD)/ (Not influence USB/SD |
| Device | 0x08 | when disc eject) |
| State | ^ | DEVICE_READY(设备读出进入列表或 |
| | 0x09 | Play 状态)/ (If device playing or in menu) |
| | | DEVICE_REMOVED(移除 USB/SD 时发 |
| | 0x0a | 送)/ (Remove USB/SD) |
| | 0x0b | 碟片到位/Device is closed |
| | 0x0c | 进仓异常/Devive tray in error |
| | 0x0d C | 出碟异常/ Devive tray out error |
| | 0x0e | 用户入碟/Close tray by user |
| | 0x0f | 推碟入仓/ Close tray by Push |
| | 0x10 | 发命令进仓/Send close tray command |
| . ^ | 0x11 | 自动进仓/Auto close tray |
| | 0x00 | EMPTY |
| | 0x01 | SD |
| \$\frac{1}{2}\tag{1} | 0x02 | MMC |
| , O | 0x03 | MS |
| \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | 0x04 | MSPRO |
| 当前设备/ | 0x05 | CF |
| Current | 0x06 | SM |
| Device | 0x07 | XD |
| Туре | 0x08 | USB |
| | 0x09 | Disc |
| | 0x0a | Serial Card |
| | 0x0b | Nand |
| | 0x0c | iPod |



DVD 返回值 : FF 55 04 CB 0N 0N 0N NN

DVD RETURN VALUE : FF 55 04 CB 0N 0N 0N NN

MCU发送值: FF 55 02 83 0N NN

MCU SEND VALUE : FF 55 02 83 0N NN 对应文档/ Correlation Document: 0x83

6.7 机芯播放状态回复/Mechanism Play State

Report(0xCC)

方向: DVD->MCU Direction:DVD->MCU 命令格式/ Command Format:

| - | | |
|--------------|----------|------------------|
| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 /Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x03 | 长度/Length |
| 0x03 | 0xcc | 命令/ Command |
| | | 播放速度 播放状态/Scan |
| 0x04 | 0x0N | Speed/PlayState |
| 0x05 | 0x0N | Menu |
| (last byte) | 0xNN | CRC |

参数/Parameter:

| - xx/Farameter: | | | | |
|---------------------|------------------------------|---|--|--|
| | Bit[4:7] | 快(慢)进速度/FF/FR(SF/SR)Speed | | |
| | 00006 | 1x 正常速度/ Normal Speed | | |
| | 0001p | 2x 快进/Fast Forward | | |
| | 0010b | 4x | | |
| | 0011b | 8x | | |
| 10 | 0100b | 16x | | |
| ~> | 0101b | -2x 快退/Fast Rewind | | |
| + | 0110b | -4x | | |
| | 0111b | -8x | | |
| speed PlaySta te | 1000b | -16x | | |
| | 0000b | 1x 正常速度/ Normal Speed | | |
| | 0001b | 1/2x 慢进/Slow Forward | | |
| | 0010b | 1/3x | | |
| | 0011b | 1/4x | | |
| | 0100b | 1/5x | | |
| | 0101b | 1/6x | | |
| | 0110b | 1/7x | | |
| | 0111b | 1/8x | | |
| | 播放状态/ Speed PlaySta te | 00006 00006 00006 00006 0010b 0010b 0100b 0110b 0111b 1000b 0000b 0000b 0001b 0010b 0010b 0100b 0100b 0100b 0100b 0100b 0110b 011 | | |



| | 1000b | -1/2x 慢退/Slow Rewind |
|---------------|----------|----------------------|
| | 1001b | -1/3x |
| | 1010b | -1/4x |
| | 1011b | -1/5x |
| | 1100b | -1/6x |
| | 1101b | -1/7x |
| | 1110b | -1/8x |
| | Bit[0:3] | 播放状态/ Play State |
| | 0000 | Stop |
| | 0001 | Play |
| | 0010 | Pause |
| | 0011 | Scan |
| | 0100 | Slow |
| 当前菜单 | 0x00 | N/A |
| /Current Menu | 0x01 | Root Menu |

DVD 返回值 : FF 55 03 CC 0N 0N NN

DVD RETURN VALUE : FF 55 03 CC 0N 0N NN

MCU发送值: FF 55 01 84 7A

MCU SEND VALUE: FF 55 01 84 7A 对应文档/ Correlation Document: 0x84

6.8 媒体信息回复/Media Status Report(0xCD)

方向: DVD->MCU Direction:DVD->MCU

命令格式/Command Format: C

| 350 Commune Format. | | |
|---------------------|---------|-----------------------------|
| 位数/ Byte Num | 值/Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x04 | 长度/Length |
| 0x03 | 0xcd | 命令/ Command |
|) | | 媒体类型(文件类型)/ Media Type(File |
| 0x04 | 0x0N | Type) |
| 0x05 | 0x0N | 媒体信息/ Media Info |
| 0x06 | 0x0N | 碟片类型/Disc Type |
| (last byte) | 0xNN | CRC |

参数意义:

| | Bit[7:4] | Media type |
|----------------|----------|-----------------|
| 媒体类型 | 0000b | 无媒体类型/ No media |
| /media type | 0001b | 未初始化媒体/ No init |
| type | 0010b | Clips |



| | | Sunprus D v D 短目 |
|--------------------|----------|-------------------------|
| | 0011b | DVD AUDIO |
| | 0100b | DVD VIDEO |
| | 0101b | SVCD |
| | 0110b | VCD |
| | 0111b | IPOD |
| | 1000b | 保留/ reserve |
| | 1001b | Unknown |
| | 1010b | MEDIA_TYPE_SW_UPDATE |
| | Bit[3:0] | File type(Clips) |
| | 0x00 | None |
| | 0x01 | MP3 |
| | 0x02 | WMA |
| | 0x03 | CDDA |
| | 0x04 | JPEG |
| | 0x05 | MPEG |
| | 0x06 | AVI |
| | 0x07 | SUBTITLE |
| | 0x08 | MP4 |
| | 0x09 | M4a |
| | 0x0a | RMF |
| | 0x0b | AAC |
| | 0x0c | DAT |
| | 0x0d | FLV |
| | 0x0e | CDDTS |
| | 0x0f | BMP |
| | Bit[7:6] | Video Mode |
| | 00b | NTSC |
| | 01b | PAL |
| | 10b | AUTO |
| | Bit[5:0] | Audio coding |
| | 0x00 | AUDIO_STREAM_UNKNOWN |
| | 0x01 | AUDIO_STREAM_AC3 |
| 媒体信息 | 0x02 | AUDIO_STREAM_DTS |
| /media | 0x03 | AUDIO_STREAM_MPEG |
| infor. | 0x04 | AUDIO_STREAM_MP3 |
| | 0x05 | AUDIO_STREAM_WMA |
| | 0x06 | AUDIO_STREAM_LPCM |
| \downarrow | 0x07 | AUDIO_STREAM_PCM |
| > | 0x08 | AUDIO_STREAM_DTSCD |
| | 0x09 | AUDIO_STREAM_AAC |
| | 0x0a | AUDIO_STREAM_MPEG4 |
| | 0x0b | AUDIO_STREAM_RM_COOK |
| | 0x0c | AUDIO_STREAM_RM_AAC |
| | 0x00 | DEC_DISC_TYPE_CDDA |
| 卅七少四 | 0x01 | DEC_DISC_TYPE_DVD_VIDEO |
| 碟片类型 /Disc type | 0x02 | DEC_DISC_TYPE_MINI_DVD |
| /Disc type | 0x03 | DEC_DISC_TYPE_SVCD |
| | 0x04 | DEC_DISC_TYPE_VCD |
| L | l | |



| 0x05 | DEC_DISC_TYPE_MP3 |
|------|------------------------------------|
| 0x06 | DEC_DISC_TYPE_JPG |
| 0x07 | DEC_DISC_TYPE_WMA |
| 0x08 | DEC_DISC_TYPE_MPEG |
| 0x09 | DEC_DISC_TYPE_HOST |
| 0x0A | DEC_DISC_TYPE_AVI |
| 0x0B | DEC_DISC_TYPE_AUX |
| 0x0C | DEC_DISC_TYPE_MPEG_DETECT |
| 0x0D | DEC_DISC_TYPE_SVCD_DETECT |
| 0x0E | DEC_DISC_TYPE_CDROM |
| 0x0F | DEC_DISC_TYPE_DVD_ROM |
| 0x10 | DEC_DISC_TYPE_FUJICOLOR_PICTURE_CD |
| 0x11 | DEC_DISC_TYPE_KADAK_PICTURE_CD |
| 0x12 | DEC_DISC_TYPE_SW_UPDATE |
| 0x13 | DEC_DISC_TYPE_UNSUPPORT |
| 0x14 | DEC_DISC_TYPE_BAD_DISK |
| 0x15 | DEC_DISC_TYPE_NO_DISK |

DVD返回值: FF 55 03 CD 0N 0N 0N

DVD RETURN VALUE: FF 55 03 CD 0N 0N 0N

MCU发送值: FF 55 01 85 79 MCU SEND VALUE: FF 55 01 85 79 对应文档/ Correlation Document: 0x85

6.9 播放时间回复/Play Time Report(0xCE)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/Length |
| 0x03 | 0xce | 命令/ Command |
| 0x04 | 0x0N | Time Type |
| 0x05 | 0x0N | Hour |
| 0x06 | 0x0N | Minute |
| 0x07 | 0x0N | Second |
| (last byte) | 0xNN | CRC |

Time Type:

| 0x0 | Playing Time |
|-----|----------------------------|
| 0x1 | Total Time(DVD:Title Time) |



DVD返回值: FF 55 05 CE 0N 0N 0N 0N NN

DVD RETURN VALUE: FF 55 05 CE 0N 0N 0N 0N NN

MCU发送值: FF 55 02 86 0N NN

MCU SEND VALUE: FF 55 02 86 0N NN 对应文档/ Correlation Document: 0x86

6.10 媒体PTT信息回复/Media Track Position

Report(0xCF)

发送媒体轨道位置: 0xcf

Media Track Position Report (0xcf)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| 媒体轨道位置: 0xcf ia Track Position Report(0xcf) : DVD->MCU | | Kin |
|--|----------|-----------------|
| ction: DVD->MCU | | |
| 格式/Command Forma | ıt: | . W |
| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位)Start Byte |
| 0x02 | 0x0d | 长度/Length |
| 0x03 | 0xcf | 命令/ Command |
| 0x04~0x15 | 0x0N | PTT信息/ PTT Info |
| (last byte) | 0xNN | CRC |
| 信息 | | |

PTT 信息

| Param | 参数意义/Parameter | | | | |
|---------|----------------|---------------|----------------|--|--|
| Falalli | DVD-Video | VCD | Clips | | |
| 0 | Current Title | | | | |
| 1 | Current Char H | | Current file H | | |
| 2 | Current Char L | Current Track | Current file L | | |
| 3 | Total Title | | | | |
| 40 | Total char H | | Total File H | | |
| 5 | Total char L | Total Track | Total File L | | |
| 6 | Escape Hour | Escape Hour | Escape Hour | | |
| 7 | Escape Min | Escape Min | Escape Min | | |
| 8 | Escape Sec | Escape Sec | Escape Sec | | |
| 9 | Total Hour | Total Hour | Total Hour | | |
| 10 | Total Min | Total Min | Total Min | | |
| 11 | Total Sec | Total Sec | Total Sec | | |
| | | | | | |

DVD返回值: FF 55 0D CF 0N...0N NN

DVD RETURN VALUE: FF 55 0D CF 0N...0N NN

MCU发送值: FF 55 01 87 77 MCU SEND VALUE: FF 55 01 87 77

对应文档/ Correlation Document: 0x87



6.11 播放显示信息发送/Playback Display

Information state Report(0xD2)

方向: DVD->MCU(Display On 自动发送)

Direction:DVD->MCU(when Display On, auto send every 200ms)

命令格式/Command Format:

| 位数/Byte | | |
|------------------|----------|------------------|
| Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x15 | 长度/Length |
| 0x03 | 0xd2 | 命令/ Command |
| $0x04 \sim 0x15$ | 0x0N | Display Info |
| (last byte) | 0xNN | CRC |

Display Info:

| Param | 参数意义/Parameter | | |
|----------|---|----------------------|---------------------|
| 1 araiii | DVD-Video | VCD | Clips |
| 0 | Current Title | 1 | |
| 1 | Current Char H | · 2 | Current file H |
| 2 | Current Char L | Current Track | Current file L |
| 3 | Total Title | <u>)</u> | |
| 4 | Total char H | | Total File H |
| 5 | Total char L | Total Track | Total File L |
| 6 | Escape Hour | Escape Hour | Escape Hour |
| 7 | Escape Min | Escape Min | Escape Min |
| 8 | Escape Sec | Escape Sec | Escape Sec |
| 9 | Total Hour | Total Hour | Total Hour |
| 10 | Total Min | Total Min | Total Min |
| 11 | Total Sec | Total Sec | Total Sec |
| 12 | Play Mode | Play Mode | <u>Play Mode</u> |
| 13 | Audio Type | Audio Type | <u>File Type</u> |
| 14 | 播放状态(参照命令 | > 0xcc) / Play State | (refer to CMD 0xcc) |
| | 菜单类型(参照命令 0xcc)仅 DVD 有效 | | |
| 15 | Menu Type (refer to CMD 0xcc) only for DVD | | |
| 16 | <u>设备状态</u> (参照命令 0xcb) /Device State (refer to CMD 0xcb) | | |
| 17 | 当前设备类型/ Current Device Type | | |
| | 高亮文件索引 H(参照命令 0xe0) | | |
| 18 | High Light Index H(refer to CMD 0xe0) | | |
| | 高亮文件索引 L(参 | 照命令 0xe0) | |
| 19 | High Light Index L(refer to CMD 0xe0) | | |

DVD返回值: FF 55 16 D2 0N...0N NN



DVD RETURN VALUE : FF 55 16 D2 0N...0N NN

MCU 发送值: FF 55 02 89 0N NN MCU SEND VALUE: FF 55 02 89 0N NN 对应文档/ Correlation Document: 0x89

6.12 ID3/CD-Text信息回复/ ID3/CD-Text

Report(0xD5)

发送 ID3/CD-Text 信息: 0xd5

Send ID3 Info(0xd5) 方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|-----------------------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x45 | 长度/Length |
| 0x03 | 0xd5 | 命令/ Command |
| 0x04 | 0x0N | I <u>D3/CD-Text Type</u> |
| 0x05 | 0x0N | ID3编码/ID3 Code Page |
| 0x06∼0x47 | 0x0N | JD3/CD-Text (Unicode,End: 0x0000) |
| (last byte) | 0xNN | CRC |

注/Note:

Every ID3 type is end with 0x0000;

2.MP3 ID3 长度最大为 3 个字, WMA ID3 最大长度为 33 个字。

Max length of MP3 ID3 is 31 words, WMA is 33 words.

3.ID3 原码发送时、0xFF 表示 ID3V1; WMA Tag 信息一般为 Unicode 编码; CD-Text(暂不支持)默认为16 8859_1;

The code page in MP3 ID3V1 is 0xFF;Unicode for wma'tag;and ISO8859_1 for CD-Text(Not Supported).

ID3 编码/ID3 Code Page

| • • | |
|-------|---------------------------|
| Value | Code Page |
| 0x00 | CODEPAGE_ASCII |
| 0x01 | CODEPAGE_UNICODE |
| 0x02 | CODEPAGE_UTF8 |
| 0x03 | CODEPAGE_WESTERN_EUROPEAN |
| 0x04 | CODEPAGE_CENTRAL_EUROPEAN |
| 0x05 | CODEPAGE_CYRILLIC |
| 0x06 | CODEPAGE_GREEK |
| 0x07 | CODEPAGE_TURKISH |



| 0x08 | CODEPAGE_HEBREW |
|------|------------------------------|
| 0x09 | CODEPAGE_ARABIC |
| 0x0A | CODEPAGE_BALTIC |
| 0x0B | CODEPAGE_VIETNAM |
| 0x0C | CODEPAGE_THAI |
| 0x0D | CODEPAGE_CHINESE |
| 0x0E | CODEPAGE_KOREAN |
| 0x0F | CODEPAGE_LATIN1_ISO8859 |
| 0x10 | CODEPAGE_LATIN2_ISO8859 |
| 0x11 | CODEPAGE_LATIN3_ISO8859 |
| 0x12 | CODEPAGE_LATIN4_ISO8859 |
| 0x13 | CODEPAGE_CYRILLIC_ISO8859 |
| 0x14 | CODEPAGE_ARABIC_ISO8859 |
| 0x15 | CODEPAGE_GREEK_ISO8859 |
| 0x16 | CODEPAGE_HEBREW_ISO8859 |
| 0x17 | CODEPAGE_LATIN5_ISO8859 |
| 0x18 | CODEPAGE_LATIN6_ISO8859 |
| 0x19 | CODEPAGE_THAI_ISO8859 |
| 0x1A | CODEPAGE_INDIAN_ISO8859 |
| 0x1B | CODEPAGE_LATIN7_ISO8859 |
| 0x1C | CODEPAGE_LATIN8_ISO8859 |
| 0x1D | CODEPAGE_LATIN9_ISO8859 |
| 0x1E | CODEPAGE_CYRILLIC_KOI8_R |
| 0x1F | CODEPAGE_UTF16_LITTLE_ENDIAN |
| 0x20 | CODEPAGE_UTF16_BIG_ENDIAN |
| 0x21 | CODEPAGE_JAPANESE |
| 0xFF | ID3V1 |

DVD返回值: FF 55 45 D5 0N...0N NN DVD RETURN VALUE: FF 55 45 D5 0N...0N NN

MCU 发送值 : FF 55 03 8C 0N NN MCU SEND VALUE : FF 55 03 8C 0N NN 对应文档/Correlation Document: 0x8C

6.13 旁白/字幕/角度信息回复

/Audio/Subtitle/Angle information state

Report(0xD7)

发送信息旁白/字幕/角度信息状态: 0xd7 Send Audio/Subtitle/Angle info(0xd7)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:



| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|----------------------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x0b | 长度/Length |
| 0x03 | 0xd7 | 命令/ Command |
| 0x04 | 0x0N | 当前Audio/ Current Audio Num |
| 0x05 | 0x0N | Audio总数/ Total Audio Num |
| 0x06 | 0x0N | Audio语言种类 |
| 0x07 | 0x0N | Current Audio Language |
| 0x08 | 0x0N | 当前Subtitle/ Current Subtitle Num |
| 0x09 | 0x0N | Subtitle总数/ Total Subtitle Num |
| 0x0a | 0x0N | Subtitle语言种类 |
| 0x0b | 0x0N | Current Subtitle Language |
| 0x0c | 0x0N | 当前Angle(Current Angle Num |
| 0x0d | 0x0N | Angle总数/ Total Angle Num |
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 0B D7 0N NN DVD RETURN VALUE: FF 55 0B D7 0N NN

MCU发送值: FF 55 01 8E 70

MCU SEND VALUE : FF 55 01 8E 70 对应文档/ Correlation Document: 0x89 对应文档/ Correlation Document: 0x8E

6.14 CLIPS文件光标位置/Clips Cursor

Position(0xD8)

方向: DVD-MCU Direction: DVD-MCU

命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|--------------|
| 0x00 | 0xFF | Sync Byte |
| 0x01 | 0x55 | Start Byte |
| 0x02 | 0x08 | Length |
| 0x03 | 0xd8 | Command |
| 0x04 | 0x0N | Cusor Item H |
| 0x05 | 0x0N | Cusor Item L |
| 0x06 | 0x0N | Total Item H |



| 0x07 | 0x0N | Total Item L |
|-------------|------|--------------|
| 0x08 | 0x0N | Folder Num H |
| 0x09 | 0x0N | Folder Num L |
| 0xa0 | 0x0N | Root menu |
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 08 D8 0N 0N 0N 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 08 D8 0N 0N 0N 0N 0N 0N 0N NN

MCU发送值: FF 55 01 91 6D

MCU SEND VALUE : FF 55 01 91 6D 对应文档/Correlation Document: <u>0x91</u>

6.15 CLIPS文件名回复/Clips Name

Report(0xD9)

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| 值/ Value | 含义Meaning |
|----------|---|
| 0xFF | Sync Byte |
| 0x55 | Start Byte |
| 0x26 | Length |
| 0xd9 | Command |
| 0x0N | Item H |
| 0x0N | Item L |
| 0x0N | File Index H/Folder(0xff) |
| 0x0N | File Index L/Folder(0xff) |
| 0x0N | Folder(0)/ <u>File Type</u> |
| 0x0N | Folder/File Name(Unicode) |
| 0xNN | CRC |
| | 0xFF 0x55 0x26 0xd9 0x0N 0x0N 0x0N 0x0N 0x0N 0x0N |

DVD返回值: FF 55 26 D9 0N...0N NN

DVD RETURN VALUE: FF 55 26 D9 0N...0N NN

MCU发送值: FF 55 05 8F 0N 0N 0N 0N NN

MCU SEND VALUE: FF 55 05 8F 0N 0N 0N 0N NN

对应文档/ Correlation Document: C510

6.16 播放模式回复/Play Mode Report(0xDA)

发送播放模式: 0xda Send Play Mode (0xda)



方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| 位数/ Byte | | |
|-------------|----------|-------------------|
| Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0xda | 命令/ Command |
| 0x04 | 0x0N | 播放模式/ Repeat mode |
| (last byte) | 0xNN | CRC |

参数:播放模式/Parameters: Repeat Mode

| Bit[3:0] | Repeat Mode |
|----------|-------------------------------|
| 0000b | Repeat Off Mode Normal |
| 0001b | Repeat Single/Repeat Charpter |
| 0010b | Repeat All/Repeat Title |
| 0011b | Repeat Folder |
| 0100b | Repeat Disc |
| Bit[7:4] | Play Mode |
| 0000b | Normal |
| 0001b | Shuffle |
| 0010b | Intro |
| 0011b | ShuffleAndIntro |

DVD返回值: EF 55 02 DA 0N NN

DVD RETURN VALUE: FF 55 02 DA 0N NN

MCU发送值: FF 55 01 90 6E

MCU SEND VALUE: FF 55 01 90 6E 对应文档Correlation Document: 0x90

6.17 机芯初始化完成信息发送/Initialized

Report(0xDB)

机芯上电初始化信息完成报告: 0xdb

Initialize Done (0xdb)

适用范围: DVD 机芯初始化完成,可以进行通信。

Command Summary: The mechanism initialize OK, communication is ready now.

方向: DVD->MCU , DVD 初始化完成主动发送

Direction: DVD->MCU, DVD auto send when Initialized Done

命令格式/Command Format:



| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/Length |
| 0x03 | 0xdb | 命令/ Command |
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 01 DB 23

DVD RETURN VALUE : FF 55 01 DB 23

MCU发送值: 无

MCU SEND VALUE : NONE

6.18 角度和放大倍数回复/Angle&Zoom

Report(0xDC)

方向: DVD->MCU Direction: DVD->MCU

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|-------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x03 | 长度/Length |
| 0x03 | 0xdc | 命令/ Command |
| 0x04 | 0x0N | Jpeg Rotate Angle |
| 0x05 | 0x0N | Zoom Level |
| (last byte) | 0xNN | CRC |

Jpeg Rotate Angle:

0x0 0° 0x1 90° 0x2 180° 0x3 270°

Zoom Level:

| 0x0 | 1x |
|-----|------|
| 0x2 | 2x |
| 0x3 | 3x |
| 0x4 | 4x |
| 0x6 | 1/2x |
| 0x7 | 1/3x |
| 0x8 | 1/4x |

NOTE: The command only valid in DVD-Video or JPEG media.

DVD返回值: FF 55 03 DC 0N 0N NN

DVD RETURN VALUE : FF 55 03 DC 0N 0N NN



MCU发送值: FF 55 01 92 6C

MCU SEND VALUE : FF 55 01 92 6C 对应文档/ Correlation Document: 0x92

6.19 当前连接设备/Current Connect Device

Report(0xDD)

方向: DVD->MCU Direction: DVD->MCU

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/Length |
| 0x03 | 0xdd | 命令/ Command |
| 0x04 | 0x0N | Device Type 0 |
| 0x05 | 0x0N | Device Type 1 |
| 0x06 | 0x0N | Device Type 2 |
| 0x07 | 0x0N | Device Type 3 |
| (last byte) | 0xNN | CRE |

Device Type:

| | 0x00 | Empty |
|---|------|-------|
| | 0x8 | USB |
| | 0x9 | Disc |
| A | 0xA | SD |
| | 0xC | iPod |

DVD返回值: FF 55 05 DD 0N 0N 0N 0N NN

DVD RETURN) VALUE: FF 55 05 DD 0N 0N 0N 0N NN

MCU发送值: FF 55 01 93 6B

MCUSEND VALUE: FF 55 01 93 6B 对应文档/ Correlation Document: 0x93

6.20 旁白/字幕查询/Audio/Subtitle

Information(0xDE)

方向: DVD->MCU Direction: DVD->MCU

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x06 | 长度/Length |



| 0x03 | 0xde | 命令/ Command |
|-------------|------|-------------------------------|
| 0x04 | 0x0N | 0x0: Audio 0x1: Subtitle |
| 0x05 | 0x0N | Index |
| 0x06 | 0x0N | Audio Type |
| 0x07 | 0x0N | Language Char1(Unicode Table) |
| 0x08 | 0x0N | Language Char2(Unicode Table) |
| (last byte) | 0xNN | CRC |

Audio Type:

| x] | NN | CRC | |
|----|---------------------------|---------|------------------------|
| | | | . 4 |
| | 0x0 | UNKNOWN | 73 |
| | 0x1 | AC3 | |
| | 0x2 | DTS | |
| | 0x3 | MPEG | |
| | 0x4 | MP3 | |
| | 0x5 | WMA | 7. |
| | 0x6 | LPCM | |
| | 0x7 | PCM | |
| | 0x8 | DTSCD (| \mathcal{O}^{\prime} |
| | 0x9 | AAC | |
| F | F 55 06 DE 0N 0N 0N 0N NN | | |

DVD返回值: FF 55 06 DE 0N 0N QN 0N 0N NN

DVD RETURN VALUE : FF 55 06 DE ON ON ON ON ON NN

MCU发送值: FF 55 03 94 0N 0N NN

MCU SEND VALUE : FF 55 03 94 0N 0N NN

对应文档/ Correlation Document: 0x94

6.21 预览图片尺寸/Picture Preview Size

Report(0xdf) (Invalid)

发送预览图片尺寸: Oxdf

Return Preview Picture Size (0xdf)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| \ \ \ | 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|-------------|--------------|----------|------------------|
| , | 0x00 | 0xFF | 同步 / Sync Byte |
| | 0x01 | 0x55 | 开始位 / Start Byte |
| | 0x02 | 0x05 | 长度/Length |
| | 0x03 | Oxdf | 命令/ Command |
| | 0x04 | 0x0N | Width H |
| | 0x05 | 0x0N | Width L |
| | 0x06 | 0x0N | Height H |



| 0x07 | 0x0N | Height L |
|-------------|------|----------|
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 05 DF 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 05 DF 0N 0N 0N 0N NN

MCU发送值: FF 55 01 95 69

MCU SEND VALUE : FF 55 01 95 69

对应文档 : 0x95

6.22 高亮文件索引回复/High Light File oill out

Index(0xE0)

发送高亮文件索引: 0xE0

Return High Ligth File Index (0xE0)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|-------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 × | 长度/Length |
| 0x03 | 0xe0 | 命令/ Command |
| 0x04 | 0xFF | Highlight Index H |
| 0x05 | 0xFF | Highlight Index L |
| (last byte) | 0×NN | CRC |

DVD返回值: FF 55 05 E0 NN NN CRC

DVD RETURN VALUE: FF 55 05 E0 NN NN CRC

MCU发送值: FF 55 01 96 68

MCUSEND VALUE : FF 55 01 96 68 对应文档/ Correlation Document: 0x96

6.23 文件夹名回复/File Path Report(0xE1)

发送文件夹名: 0xe1

Return Path Name (0xe1)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |



| 0x02 | 0x21 | 长度/Length |
|-------------|------|-------------|
| 0x03 | 0xE1 | 命令/ Command |
| 0x04∼0xNN | 0x0N | Path Name |
| (last byte) | 0xNN | CRC |

DVD返回值: FF 55 21 E1 0N...0N NN

DVD RETURN VALUE : FF 55 21 E1 0N...0N NN

MCU发送值: FF 55 01 97 67

MCU SEND VALUE : FF 55 01 97 67 对应文档/ Correlation Document: 0x97 对应文档/ Correlation Document: 0xA1

6.24 软件版本回复/Software Version

Report(0xe2)

发送软件版本号: 0xe2

Return Softmare Version (0xe2)

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| THE PARTICIPATION | mac. | |
|-------------------------------|----------|---------------------------------|
| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步/Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0xNN | 长度/Length |
| 0x03 | 0xe2 | 命令/ Command |
| 0x04 | 0x0N | 解码版本长度/The length of BE version |
| 0x05 | 0x0N | 伺服版本长度/The length of FE version |
| 0x06~0x06+BE Len | 0x0N | BE Version |
| 0x07+BE Len~0x07+FE Len | 0x0N | FE Version |
| (last byte) | 0xNN | CRC |

DVD返回值 : FF 55 NN E2 0N...0N 0N...0N NN

DVD RETURN VALUE: FF 55 NN E2 0N...0N 0N...0N NN

MCU发送值: FF 55 01 98 66

MCU SEND VALUE: FF 55 01 98 66 对应文档/ Correlation Document: 0x98

6.25 BIN代码发送/Bin Code Report(0xe3)



(Invalid)

发送Bin code: 0xe3 Report Bin code (0xe3)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|--|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x87 | 长度/Length |
| 0x03 | 0xe3 | 命令/ Command |
| 0x04 | 0xNN | code offset byte 3 |
| 0x05 | 0xNN | code offset byte |
| 0x06 | 0xNN | code offset byte 1 |
| 0x07 | 0xNN | code offeet byte 0 |
| 0x08 | 0XNN | 长度/Length |
| 0x09~0x88 | 0xNN | Bin Oode |
| (last byte) | 0xNN | CHE CONTRACTOR OF THE CONTRACT |

MCU发送值: FF 55 06 99 0N 0N 0N 0N 0N NN MCU SEND VALUE: FF 55 08 99 0N 0N 0N 0N 0N NN

DVD返回值: FF 55 (N...0N NN

DVD RETURN VALUE: FF 55 87 E3 0N...0N NN

对应文档/ Correlation Document: 0x99

6.26 Bin Code内容越界信息发送/Bin Code

Content Spillage Return(0xe4) (Invalid)

发送Bin Code越界: 0xe4

Return Bin Code Spillage (0xe4)

方体。DVD->MCU

Derection: DVD->MCU 命令格式/Command Format:

| 位数/ Byte | | |
|----------|----------|------------------|
| Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x07 | 长度/Length |
| 0x03 | 0xe4 | 命令/ Command |



| 0x04 | 0xNN | code offset byte 3 |
|-------------|------|----------------------|
| 0x05 | 0xNN | code offset byte 2 |
| 0x06 | 0xNN | code offset byte 1 |
| 0x07 | 0xNN | code offset byte 0 |
| 0x08 | OXNN | 请求长度/ Request Length |
| 0x09 | 0xNN | 真实长度/ Actual Lengths |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 06 99 0N 0N 0N 0N 0N NN MCU SEND VALUE: FF 55 06 99 0N 0N 0N 0N 0N NN

DVD返回值 : FF 55 07 E4 0N 0N 0N 0N 0N 0N NN

6.27 发送Bin文件长度/Bin File Length

Return(0xe5) (Invalid)

发送Bin文件长度: 0xe5

Return Bin File Length (0xe5)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte | 76, | |
|-------------|---------|------------------|
| Num | 值/Value | 含义/ Meaning |
| 0x00 | 0xPE | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/Length |
| 0x03 | 0xe5 | 命令/ Command |
| 0x04\ | 0xNN | Length Byte 3 |
| 0005 | 0xNN | Length Byte 2 |
| 0x06 | 0xNN | Length Byte 1 |
| 0x07 | 0xNN | Length Byte 0 |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9A 64

MCU SEND VALUE : FF 55 01 9A 64 DVD返回值: FF 55 05 E5 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 05 E5 0N 0N 0N 0N NN

对应文档/ Correlation Document: 0x9A



6.28 Bin文件类别发送/Bin File Type(0xe6)

(Invalid)

发送Bin文件类别: 0xe6 Bin File Tyte (0xe6)

注: 当设备里所有文件为Bin文件时, DVD主动发送;

Notice: When all the files in device are BIN files, DVD sends it automatically

方向: DVD->MCU
Direction: DVD->MCU

命令格式/Command Format:

| 位数/ Byte | /t- / \ / | |
|-------------|-----------|-----------------|
| Num | 值/ Value | 含义/ Meaning |
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Star Byte |
| 0x02 | 0x01 | 长度/Length |
| 0x03 | 0xe6 | 命令/Command |
| (last byte) | 0xNN | CRC |

MCU发送值:无

MCU SEND VALUE: NONE,

DVD返回值: FF 55 01 E6 18

DVD RETURN VALUE : F 35 01 E6 18

6.29 当前碟片是升级碟/It is an Upgrade

Disc(0xE7)

注: 当碟片为DVD升级碟时, 主动发送

Note: DVD sends it automatically when the disc is an upgrade one.

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0xe7 | 命令/ Command |
| 0x04 | 0x01 | |
| (last byte) | 0xNN | CRC |

MCU发送值 : 无

MCU SEND VALUE: NONE DVD返回值: FF 55 02 E7 01 15



DVD RETURN VALUE : FF 55 02 E7 01 15

6.30 Clips碟自动播放结束/End of Auto Play for

Clips Disc(0xE8)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|---------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x01 | 长度/Length |
| 0x03 | 0xE8 | 命令/ Command ^ |
| (last byte) | 0xNN | CRC |
| 1011/D. W. /± | | |

MCU发送值 : 无

MCU SEND VALUE: NONE DVD返回值: FF 55 01 E8 16

DVD RETURN VALUE : FF 55 01 E8 16

6.31 返回USB HighZ 状态/Return USB

HighZ(0xe9) (Invalid)

返回USB HighZ状态(0xeg

Return USB HighZ(0xe9)

方向: DVD->MCU

Direction: DVD->MCD 命令格式/Command Format:

| 位数/ Bote Num | 值/ Value | 含义/ Meaning |
|--------------|----------|---|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 03/91 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x02 | 长度/Length |
| 0x03 | 0xe9 | 命令/ Command |
| 0x04 | 0x0N | USB HighZ 状态: 1 = USB pads are set to HighZ(在USB HighZ状态,只检测USB设备是否插入,不和USB设备发生任何通信) 0 = USB pads are set to normal state |
| (last byte) | 0xNN | CRC |

MCU发送值 : FF 55 01 9b 63



MCU SEND VALUE: FF 55 01 9b 63 DVD 返回值 : FF 55 02 E9 0N NN

DVD RETURN VALUE : FF 55 02 E9 0N NN 对应文档 / Correlation Document: 0x9B

6.32 返回USB VID&PID/USB VID&PID

Report(0xea) (Invalid)

报告USB/IPOD VID&PID (0xea) USB VID&PID Report (0xea)

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| | JSB/IPOD VID&PID (0xea) | | | | |
|------------------------------------|-------------------------|------------------------------|--|--|--|
| VID&PID Report (0xea) | | | | | |
| : DVD->MCU | | | | | |
| ction:DVD->MCU 格式/Command Forma | at. | | | | |
| 位数/ Byte Num | 值/ Value | 含义/ Meaning | | | |
| | | | | | |
| 0x00 | 0xFF | 同步 / Sync Byte | | | |
| 0x01 | 0x55 | 开始位 / Start Byte | | | |
| 0x02 | 0x07 | 长度/Length | | | |
| 0x03 | 0xea | 命令/Sommand | | | |
| | | Device ID: | | | |
| | 0x0N | 1 = USB Mystory | | | |
| 0x04 | \sim | ≥ IPOD HID | | | |
| | 10) | Message provided | | | |
| | 0x0N | 0x00: automatically returned | | | |
| 0x05 | Ç Y | 0x01: on request | | | |
| 0x06 | OXNN | USB VendorID Item H | | | |
| 0x07 | 0xNN | USB VendorID Item L | | | |
| 0x08 | 0xNN | USB ProductID Item H | | | |
| 0x09 | 0xNN | USB ProductID Item L | | | |
| (last byte) | 0xNN | CRC | | | |
| (1) 1) 生送店 | EE 55 01 0C | NINI | | | |

MCU发送值 : FF 55 01 9C NN MCU SEND VALUE: FF 55 01 9C NN

DVD 返回值 : FF 55 07 EA 0N 0N 0N 0N 0N NN

DVD RETURN VALUE : FF 55 07 EA 0N 0N 0N 0N 0N 0N NN

对应文档/ Correlation Document : 0x9C



6.33 返回USB工作模式/USB work way

report(0xeb) (Invalid)

返回USB工作模式(0xeb) USB Work way report(0xeb)

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|-----------|---|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x04 | 长度/Length |
| 0x03 | 0xeb | 命令/ Command |
| 0x04 | 0x0N | Device work as: 0x02 =USE mystory 0x04 =IROD HID |
| 0x05 | 0x0N | Message provided 0x00: automically returned 0x01: request retruned |
| 0x06 | OXON OXON | Result: 0 = indicates that the select has not done or has some error. 1 = indicates that the select has finished. |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9D NN MCU SEND VALUE: FF 55 01 9D NN

DVD 总值: FF 55 04 EB 0N 0N 0N NN

DVD RETURN VALUE : FF 55 04 EB 0N 0N 0N NN

对应文档/ Correlation Document : <u>0x9D</u>

6.34 发送iPod数据/lpod data report(0xec)

(Invalid)

发送 iPod 数据(0xec) iPod data report(0xec) 方向: DVD->MCU

Direction: DVD->MCU 命令格式/Command Format:



| 位数/ Byte Num | 值/ Value | 含义/ Meaning | |
|----------------|----------|---|--|
| 0x00 | 0xFF | 同步 / Sync Byte | |
| 0x01 | 0x55 | 开始位 / Start Byte | |
| 0x02 | 0xNN | 长度/Length | |
| 0x03 | 0xEC | 命令/ Command | |
| 0x04 | 0xNN | Ipod data block number item H | |
| 0x05 | 0xNN | Ipod data block number item L | |
| 0x06 | 0xNN | Ipod data packet number item H | |
| 0x07 | 0xNN | Ipod data packet number item L | |
| 0x08 | 0xNN | Ipod data length item H (包含同步、开始、长度、校验位) (contain iPod sync/start/lengt/CRC) | |
| 0x09 | 0xNN | Ipod data length item L | |
| 0x0A | 0x0N | Data infor: Bit0 0 = not last I2C packet of this block 1 = Last I2C packet of this block Bit1 1 = not last I2C packet of this file or image 1 = Last I2C packet of this file or image | |
| 0x0B0x0B+N | 0xNN | Jood data(省略同步、开始位) | |
| (last byte) | 0×NN | CRC | |

MCU发送值 : Nothing(该命令自动返回) MCU SEND VALUE Nothing(Auto report CMD)

DVD 返回值 FF 55 NN EC ON NN NN NN NN NN NN NN NN NN NN

DVD RETURN VALUE : FF 55 NN EC 0N NN NN

对应文本 Correlation Document : Nothing

6.35 发送记忆数据/Memory data report(0xed)

发送记忆数据(0xed) Memory data report(0xed)

方向: DVD->MCU

Direction: DVD->MCU 命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/ Meaning |
|--------------|----------|------------------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0xNN | 长度/Length(Length=memory data |



| | | length+3) |
|-------------|--------|---|
| 0x03 | 0xED | 命令/ Command |
| 0.04 | OVAINI | 记忆类型(0: DVD-V; 1: VCD; 2: CD;3:CD-ROM) Memory Type(0: DVD-V; 1: VCD; 2: CD;3:CD POM) |
| 0x04 | 0xNN | CD;3:CD-ROM) |
| 0x05 | 0xNN | 记忆数据长度/Memory data length |
| 0x06~0xNN | 0xNN | 记忆数据/Memory data |
| (last byte) | 0xNN | CRC |

MCU发送值 : Nothing(该命令自动返回)

MCU SEND VALUE: Nothing(Auto report CMD)

DVD 返回值 : FF 55 NN ED 0N NN NN NN NN NN NN NN NN NN

DVD RETURN VALUE : FF 55 NN ED 0N NN NN

对应文档 / Correlation Document : 0x73

6.36 发送文件文件夹数/The Total of Files and

Folders Report (0xEE)

方向: DVD->MCU Direction:DVD->MCU

命令格式/ Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x05 | 长度/Length |
| 0x03 | 0xee | 命令/ Command |
| 0x04 | 0xNN | Total Folder H |
| 0x05 | 0xNN | Total Folder L |
| 0x06 | 0xNN | Total File H |
| 0x07 | 0xNN | Total File L |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9E 60

MCU SEND VALUE: FF 55 01 9E 60 DVD返回值: FF 55 NN EE NN...NN NN

DVD RETURN VALUE: FF 55 NN EE NN...NN NN

对应文档 / Correlation Document: 0x9E

6.37 发送文件系统信息概况/The Summary of



File System Report (0xef)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| 位数/Byte Num | 值/Value | 含义/Meaning |
|-----------------|---------|----------------------------|
| 0x00 | 0xFF | 同步/Sync Byte |
| 0x01 | 0x55 | 开始位/Start Byte |
| 0x02 | 0xNN | 长度/Length |
| 0x03 | 0xef | 命令/Command |
| 0x04 | 0xNN | Folder Block Num |
| 0x05 | 0xNN | Folder index H |
| 0x06 | 0xNN | Folder index L |
| 0x07 | 0xNN | Parent folder index |
| 0x08 | 0xNN | Parent folder index L |
| 0x09 | 0xNN | 0 |
| 0x0A | 0xNN | 0 |
| 0x0B | 0xNN | File num H |
| 0x0C | 0xNN | Fîle num L |
| $(0x0C+n) \sim$ | ~ | |
| (0x0C+8n) | 0xNN | Next Folder Info(8 bytes) |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 01 9F 5F

MCU SEND VALUE : FF 55 01 9F 5F

DVD返回值: FF 55 NN EF NN...NN NN

DVD RETURN VALUE: FF 55 NN EF NN...NN NN

对应文档 / Correlation Document: 0x9F

6.38 发送文件文件夹信息/The Attribute of File

or Folder Report (0xF0)

发送文件(夹)信息(0xF0)

The Attribute of File or Folder Report(0xF0)

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| 位数/ Byte Num | 值/ Value | 含义/Meaning |
|--------------|----------|--------------|
| 0x00 | 0xFF | 同步/Sync Byte |



| 0x01 | 0x55 | 开始位/Start Byte |
|-------------|--------------|-------------------------------|
| 0x02 | 0xNN | 长度/Length |
| 0x03 | 0xF0 | 命令/Command |
| 0x04 | 0xNN | Folder index H |
| 0x05 | 0xNN | Folder index L |
| 0x06 | 0xNN | Parent folder index H |
| 0x07 | 0xNN | Parent folder index L |
| 0x08 | 0xNN | FileType/(foler:0) |
| 0x09 | 0xNN | Extension Name(Folder : 0xFF) |
| 0x0a~0xNN | 0xNN0 xNN | File/Folder Name(Unicode) |
| (last byte) | 0xNN | CRC |

MCU发送值: FF 55 05 A0 0N NN NN 0N NN

MCU SEND VALUE: FF 55 05 A0 0N NN NN 0N NN

DVD返回值 : FF 55 NN F0 NN...NN NN

DVD RETURN VALUE: FF 55 NN F0 NN...NN NN

对应文档/ Correlation Document: 0xA0

Extension Name:

```
eClipExtensionName None =0,//
                                   "MP2"
eClipExtensionName MP2 = 1,
                                   <sup>≁</sup>MP3"
eClipExtensionName_MP3 = 2,
eClipExtensionName_WMA = 3, (
                                   "WMA"
eClipExtensionName_CDA
                                   "CDA"
eClipExtensionName JPEG = 5,
                                   "JPEG"
                               //
eClipExtensionName JPG
                           = 6, //
                                   "JPG"
eClipExtensionName_JPE
                                   // "JPE"
                           =7,
eClipExtensionName_MPEG =8,
                               //
                                   "MPEG"
eClipExtensionName_MPG
                           =9, //
                                   "MPG"
eClipExtensionName_MPE
                           =10, //
                                   "MPE"
eClipExtensionName_DAT
                           =11, //
                                   "DAT"
eClipExtensionName_VOB
                           =12,//
                                   "VOB"
eCtipExtensionName_AVI
                           =13,//
                                   "AVI"
eClipExtensionName_DIVX
                           =14, //
                                   "DIVX"
eClipExtensionName_DIV
                           =15,
                                       "DIV"
eClipExtensionName_XVID
                            =16,
                                       "XVID"
eClipExtensionName_VID
                            = 17,
eClipExtensionName_OGG
                             =18,
eClipExtensionName_MP4
                          =19, //
                                   "MP4"
eClipExtensionName_M4A
                          =20, //
                                   "M4A"
eClipExtensionName MPA = 21,
eClipExtensionName_BIN
eClipExtensionName_WAV =23,
```



eClipExtensionName_RM =24, eClipExtensionName_RMVB =25, eClipExtensionName_RMV = 26, eClipExtensionName_RA = 27, eClipExtensionName_RV=28, eClipExtensionName_AAC =29, eClipExtensionName BMP =30, eClipExtensionName_MOV = 31, eClipExtensionName_FLV =32, eClipExtensionName_ASF = 33.

6.39 发送Ripping当前界面/the Menu of

发送Ripping menu (0xF7)

The Progress of ripping Report(0xF7)

方向: DVD->MCU

Direction:DVD->MCU

命令格式/ Command Format:

| Ripping Report (0xF7) | | | | |
|-----------------------|-----------------------|------------------|--|--|
| Ripping menu (0xF | Ripping menu (0xF7) | | | |
| Progress of ripping | Report(0xF7) | Y | | |
| : DVD->MCU | | | | |
| etion:DVD->MCU | | | | |
| 格式/ Command For | 格式/ Command Format: | | | |
| 位数/Byte Num | 值/ Value | 含义/ Meaning | | |
| 0x00 | 0xFF | 同步 / Sync Byte | | |
| 0x01 | 0x55 | 开始位 / Start Byte | | |
| 0×02 | 0x02 | 长度/Length | | |
| 0x03 | 0xF7 | 命令/ Command | | |
| 0x04 | 0xNN | Ripping menu | | |
| (last byte) | 0xNN | CRC | | |

Ripping menu:

| Byte num | Ripping menu |
|----------|-----------------------|
| 0x01 | Ripping option menu |
| 0x02 | Ripping progress menu |
| 0x03 | Ripping complete menu |



DVD返回值 : FF 55 02 F7 NN NN

DVD RETURN VALUE : FF 55 02 F7NN NN

对应文档 / Correlation Document:

6.40 发送Ripping进度/the progress of

oily oult Ripping Report (0xF1) (Invalid)

发送Ripping进度(0xF1)

The Progress of ripping Report(0xF1)

方向: DVD->MCU Direction:DVD->MCU

命令格式/ Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|----------------|----------|---------------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位入Start Byte |
| 0x02 | 0x09 | 茂度/Length |
| 0x03 | 0xF1 | ♦ Command |
| 0x04 | 0xNN | Elapse time (bit24~bit31) |
| 0x05 | 0xXN | Elapse time (bit16~bit24) |
| 0x06 | OXIN | Elapse time (bit8~bit15) |
| 0x07 | 0xNN | Elapse time (bit0~bit7) |
| 0x08 | 0xNN | Total time (bit24~bit31) |
| 0x09 | 0xNN | Total time (bit16~bit24) |
| 0x0A | 0xNN | Total time (bit8~bit15) |
| Ox OB | 0xNN | Total time (bit0~bit7) |
| (last byte) | 0xNN | CRC |

MCU发送值:

MCU SEND VALUE:

DVD返回值 : FF 55 09 F1 NN DVD RETURN VALUE: FF 55 09 F1 NN NN NN NN NN NN NN NN NN

NN

对应文档 / Correlation Document:

6.41 发送iPod信息/iPod information report



(0xF2) (Invalid)

发送iPod数据(0xF2)

The Progress of ripping Report(0xF2)

方向: DVD->MCU Direction:DVD->MCU

命令格式/ Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|----------------|----------|------------------|
| 0x00 | 0xFF | 同步 / Sync Byte |
| 0x01 | 0x55 | 开始位 / Start Byte |
| 0x02 | 0x0N | 长度/Length |
| 0x03 | 0xF2 | 命令/ Command |
| 0x04 | 0xNN | 类型/Type |
| 0x05~0xNN | 0xNN | data |
| (last byte) | 0xNN | CRC |

Data format:

Play state & Mode

| Byte num | Meaning |
|----------|--------------|
| 0x01 | Play state |
| 0x02 | Repeat mode |
| 0x03 | Shuffle mode |

Play state

| - | |
|--------|-----------|
| 0x00 | STOPPED |
| 0x01 | PLAYING |
| 0x02 | PAUSED |
| 0x03 | FF |
| 0x04 | REW |
| 0x05 C | END_FF_FB |

Repeat mode

| | 0000 | Repeat Off |
|---|------|------------|
| | 0x01 | Repeat One |
| - | 0x02 | Repeat All |

Shuffle Mode

| 0x00 | Shuffle Off |
|------|---------------|
| 0x01 | Shuffle Song |
| 0x02 | Shuffle Album |

Time format:

| Byte num | Meaning |
|----------|---------|
| 0x01 | Hour |
| 0x02 | Minute |



| 0x03 | Sacand |
|------|--------|
| UXUS | Second |

Artist/Album/Title format:

| Byte num | Meaning |
|-----------|-------------|
| 0x01~0xNN | UTF8 string |

Item name format:

| Byte num | Meaning | |
|-----------|--------------------|--|
| 0x01 | HIERARCHY | |
| 0x02 | Track Index(31:24) | |
| 0x03 | Track Index(23:16) | |
| 0x04 | Track Index(15:8) | |
| 0x05 | Track Index(7:0) | |
| 0x06~0xNN | UTF8 string | |

Hierarchy

When the hierarchy is the root/music/photo,track index string are invalid.

| Value | Hierarchy | List |
|-------|-----------|-------------------------------------|
| 0x00 | Root | "MUSIC" "VIDEO""PHOTO""NOW PLAYING" |
| 0x01 | Music | "PLAYLISTS""ARTIST"(ALBUM""SONG""GE |
| | | NRES""COMPOSERS""PODCAST""AUDIOB |
| | | OOK" |
| 0x02 | Video | UTF8 strings 🏠 |
| 0x03 | Photo | Null X |
| 0x04 | Now | UTF8 strings |
| | playing | 10 x 0 x |
| 0x05 | Podcast | •UTE® strings |

Current/Total item format:

| Byte num | Meaning |
|----------|--------------------|
| 0x01 | Track Index(31:24) |
| 0x02 | Frack Index(23:16) |
| 0x03 | Track Index(15:8) |
| 0x04 | Track Index(7:0) |

MCD发送值: FF 55 02 A2 0N NN

MCU SEND VALUE: FF 55 02 A2 0N NN

DVD返回值 : FF 55 NN F2 NN NN ... NN NN

DVD RETURN VALUE: FF 55 NN F2 NN NN ... NN NN

对应文档 / Correlation Document: 0xA2

6.46 DRM主状态回复/ DRM Main Status Report (0xD3)

DRM 主状态回复: 0xD3

DRM Main Status Report: (0xD3) 方向: DVD->MCU(DVD 自动发送)



Direction: DVD->MCU (DVD will send the main status to host automatically)

命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |
| 0x02 | 0x02 | 长度/ Length |
| 0x03 | 0xd3 | 命令/ Command |
| 0x04 | OxON | 主状态/Main Status |
| (last byte) | O×NN | CRC CRC |

DRM主状态/DRM Main Status:

| 0x01 | 显示注册码界面/display register tode UI |
|------|-------------------------------------|
| 0x02 | VOD 未授权/VOD no authorized |
| 0x03 | VOD 过期/VOD expired |
| 0x04 | 需要用户确认Rental/need rental confirm |
| 0x05 | 硬件不支持/ hardwaxe unsupport |
| 0x06 | AES only |
| 0x07 | 显示反注册码界面/display unregister code UI |

DVD返回值 : FF 55 02 D3 0N CRC DVD RETURN VALUE: FF 55 02 D3 0N CRC

MCU发送值:

MCU SEND VALUE, NOTHING

6.47 DRM Rental次数回复/DRM Rental Count Report (0xD4)

DRM Rental 次数回复: 0xD4 DRM Rental Count Report: (0xD4)

方向: DVD->MCU
Direction: DVD->MCU
命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |



| 0x02 | 0x05 | 长度/ Length |
|-------------|----------|----------------------|
| 0x03 | 0xd4 | 命令/ Command |
| | | Rental总数 H |
| 0x04 | OxON | Total Rental Count H |
| | | Rental总数 L |
| 0x05 | 0x0N | Total Rental Count L |
| | | Rental剩余次数 |
| 0x06 | OxON | Left Renta Count H |
| | | Rental剩余次数 L |
| 0x07 | 0x0N | Left Rental Count L |
| (last byte) | OxNN • 7 | CRC |

DVD返回值: FF 55 05 D4 0N 0N 0N 0N CRC DVD RETURN VALUE: FE 55 05 D4 0N ON ON ON CRC

MCU发送值 : FF 55 01 A8 56 MCU SEND VALUE: FF 55 01 A8 56

对应文档/ Correlation Document: <u>C534</u>

6.48 DRM 注册码及反注册码回复/DRM Register and

Deregister Code Report (0xF3)

DRM Rental 次数回复: 0xF3 DRM Rental Count Report: 0xF3

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|----------|-----------------|
| 0x00 | 0xFF | 同步/ Sync Byte |
| 0x01 | 0x55 | 开始位/ Start Byte |



| 0x02 | 0x1b | 长度/ Length |
|-------------|------|-----------------------------------|
| 0x03 | 0xf3 | 命令/ Command |
| | | 类型 (00:register,01:deregister) |
| 0x04 | OxON | Type((00:register,01:deregister) |
| | | 注册码/反注册码内容(0x0000结束) |
| 0x05~0xNN | OxON | Code context(end with 0x0000) |
| (last byte) | OxNN | CRC |

DVD返回值 : FF 55 1b f3 ON ON ····· ON CRC

DVD RETURN VALUE: FF 55 1b f3 0N ON ON CRC

MCU发送值 : FF 55 02 A5 ON CRC

MCU SEND VALUE: FF 55 02 A5 ON CRC

对应文档/ Correlation Document: C532

6.49 DRM 注册状态回复/DRM Register State Report (0xF5)

DRM 注册状态回复: 0xF5

DRM Register State Report: 0xF5

方向: DVD->MCU Direction: DVD->MCU

命令格式/Command Format:

| | 位数/Byte Num | 值/ Value | 含义/ Meaning |
|-------------|-------------|----------|--|
| | 0x00 | 0xFF | 同步/ Sync Byte |
| | 0x01 | 0x55 | 开始位/ Start Byte |
| > | 0x02 | 0x03 | 长度/ Length |
| | 0x03 | 0xf5 | 命令/ Command |
| | 0x04 | OxON | 00:not register,01:register |
| | 0x05 | OxON | 00:this is not the 1st time resgister 01:this is the 1st resgister |
| | (last byte) | OxNN | CRC |



DVD返回值 : FF 55 03 f5 0N ON CRC DVD RETURN VALUE: FF 55 03 f5 0N ON CRC

MCU发送值 : FF 55 01 A7 57 MCU SEND VALUE: FF 55 01 A7 57

对应文档/ Correlation Document: C533

6.50 DRM Mode ID回复/DRM Mode ID Report (0xF6)

DRM Mode ID 回复: 0xF6 DRM Mode ID Report: 0xF5

方向: DVD->MCU Direction: DVD->MCU 命令格式/Command Format:

| Mode ID 回复: 0xF6 | | Λ | | | |
|----------------------|----------|----------------|--|--|--|
| Mode ID Report: 0xF5 | | | | | |
| DVD->MCU | | | | | |
| tion: DVD->MCU | | O ₂ | | | |
| 各式/Command Format: | | | | | |
| 位数/Byte Num | 值/ Value | 含义/ Meaning | | | |
| 0x00 | 0xFF | 同步/ Symo Byte | | | |
| 0x01 | 0x55 | 开始位/Start Byte | | | |
| 0x02 | 0x03 | 长度/ Length | | | |
| 0x03 | 0xf6 | 命令/ Command | | | |
| 0x04 | OXON | Mode Id H | | | |
| 0x05 | 0x0N | Mode Id L | | | |
| (last byte) | OxNN | CRC | | | |
| | | | | | |

DVD返回值 : FF 55 03 f6 ON ON CRC DVD RETURN VALUE: FF 55 03 f6 0N ON CRC

MCU发送值 : FF 55 01 A4 5A MCU SEND VALUE: FF 55 01 A4 5A



附录/Attachment

附录一 MCU 升级过程

Attachment 1. MCU Upgrade Process

e Pror 1. DVD 识别只有 Bin 文件后, 通知 MCU 碟片为升级碟; 如果是升级碟片, MCU 以如下流程升级, 否则以正常播放碟片的流程处理;

If there is nothing except bin files in the disc, DVD gives a message to MCU that the disc is an upgrade disc. If there is an upgrade disc, MCU upgrades according to processes as follows, otherwise, DVD plays disc as normal processes.

2. MCU 获取文件名列表;

MCU requests the list of file names.

3. 用户选择播放 Bin 文件:

User selects a bin file to play.

4. MCU 请求 Bin 文件长度, DVD 返回当前播放 Bin 文件的长度;

MCU requests the length of the bin code, and DVD returns the length of the file which is played currently.

5. MCU 请求 Bin 文件的软件版本,根据软件版本判断是否需要升级;如果需要 升级,继续处理;

MCU requests the software version of the bin file, and determines whether



the software needs to upgrade according to the version. If need upgrade, please continue.

6. MCU 请求 Bin 文件信息,DVD 返回 Bin 文件信息。MCU 每次最多获取 128Bytes 数据。重复第六步,直到获取到 Bin 文件的所有信息; MCU requests the information of the bin file, and DVD returns it. MCU can get 128 bytes each time. Repeat step 6 till achieving end of the file.

注意/Note:

升级碟判定方法:

Determine upgrade disc:

- a. DISC 或者 USB 只包含后缀为.bin 的文件,则判定为升级文件; Consider it as an upgrade disc if there are only bin files in disc or USB.
- b. 不满足条件 a 的视为正常 DISC/USB, 播放列表中忽略后缀为 bin 的文件:

Ignore bin files in the play list if it is not an upgrade disc.

升级过程中,MCU 处于主动状态,DVD 完全处于被动状态,DVD 不主动 读取 Bin 文件任何字段;

MCU is active and DVD is always passive in upgrading process. DVD does not send any data automatically.

附录二 MCU 如何作 Clips 菜单

Attachment 2. How to make a clips menu by MCU

一、 文件(夹)列表的获取

Get the list of files and folders

1.当 Device 处于 Ready 状态时,获取当前文件夹下的文件以及文件夹信息,主要获取文件以及文件夹的数量,命令: 0x91<->0xD8;

Get the information of current folder and files in this folder, when the device state is ready, mainly get the number of files and folders. CMD:0x91<->0xD8

2.获取文件(夹)名(0x8F)。获取文件(夹)名称的索引为文件(夹)在 当前文件夹中的序号,其中的索引号都是从0到当前文件夹下文件(夹)总数一 1,文件和文件夹分开获取,这就是为什么必须先发送 0x91 获取文件(夹)数量的原因了;

Get the file and folder name (0x8F). The index of files and folders is sequence number in current folder, and the range of index is from zero to (tatol number-1). Get the file and folder separately. That is why get the total number first using command 0x91.

通过第一、二两步的操作,可以获取文件列表,获取的文件列表为当前 DVD 所在文件夹下的文件(夹)列表,只获取当前 DVD 所在文件夹中的文件(夹)



列表的原因主要是 DVD 选曲通过相对编号选曲,虽然文件(夹)可以通过文件的绝对编号获取到文件(夹)名,但是 DVD 在不更新显示列表的情况下要通过绝对编号选曲实现比较困难,所以为了选曲方便简单地实现,所以要求 MCU 显示的列表与 DVD 显示的列表同步,通过相对编号进行选曲。

Through step 1 and 2, we can get the file list in the current folder. It is the reason that DVD selects a file through relative index. Though the name of files and folders can be got from absolute index, but it is difficult to select a file through absolute index, so in order to selecting files simply, the DVD list must be synchronized with the MCU list through relative index.

Note: 1.请在文件列表刷新完成后再获取文件名; 进入一个文件夹后, 请等待约 400ms 后再获取文件名;

Get the name after refreshing list. When entering a folder, please wait at least 400 millisecond.

2. 当播放到下一个文件夹时, 自动发送 C1 0F 命令:

Send command 0xc1 0x0f automatically when playing into next folder.

3.请在有需要的时候才刷新列表,如:翻页、播放到下一页、播放到下一个 文件夹等;

Please refresh the list if you need, for example: page down, play into next folder and so on.

4.请勿一次获取当前文件夹下所有的文件,需要显示哪几个就获取哪几个。

Please do not get all the file names in current folder once, get those you need show in the screen.

二、当前播放文件高亮显示

Active item shows high light.

- 1. 获取当前播放文件的 File Index(即文件的绝对编号), MCU 命令为: 0x96; Get the absolute index of active file, Command: 0x96
- 2.在获取文件(夹)名时 0xD9 命令中有 File (Folder) Index (即绝对编号),获取到文件(夹)名后对比 File Index,当 File Index 为当前正在播放的文件时,将正在播放的歌曲设置为高亮;

Compare the absolute index from Command 0xd9 with that from step 1. Set the active item high light if the absolute index is the current playing file.

三、ID3、CD-Text 信息获取

Get ID3 or CD-Text information

获取 ID3、CD-Text 信息命令为 0x8C;

The command is 0x8c.

注: ID3、CD-Text 信息是分开获取的,一次只能获取一种 ID3/CD-Text 信息。

Note: Get ID3 and CD-Text separately, you can get one type each time.

四、 当前文件所在文件夹名获取

Get the name of current folder


获取命令为 0x97, 可以获取到当前文件所在文件夹的名字

Get the name of current folder using command 0x97

entital For the 附录三: 获取文件系统流程图 Attachment 3 the flow of getting the file system


FOR YOU





附录四: Ripping 流程图 Attachment 4 the flow of ripping





最简单方法: 当选择到 Ripping 模式时,打开 DVD 视频输出,用户根据 DVD 菜 单触摸操作完成 Ripping 功能; 主机只需要发送触摸坐标给 DVD。

The simple way: when ripping mode selected, make the video which outputed by the DVD system to send to the panel, the user touch the menu to ripping; the host only need to send the coordinate to DVD system.