## **Advanced Mechanics of Materials Vocabulary**

## **Stress and Strain**

Vector Transformation:  $\mathbf{a}' = \mathbf{M}\mathbf{a}$ , where  $\mathbf{M}$  is the transformation, or rotation or direction cosine matrix

$$o \quad \mathbf{M} = \begin{bmatrix} x' \cdot x & x' \cdot y & x' \cdot z \\ y' \cdot x & y' \cdot y & y' \cdot z \\ z' \cdot x & z' \cdot y & z' \cdot z \end{bmatrix}$$

Tensor (2<sup>nd</sup> order) Transformation:  $T' = MTM^T$ 

Stress vector on arbitrary surface with normal unit vector  $m{n}$ :  $m{t} = m{T} m{n} = m{ au} + m{\sigma}$ 

## **Material Response**

Hooke's Law (Voigt Notation)

$$\begin{bmatrix} \varepsilon_{XX} \\ \varepsilon_{yy} \\ \varepsilon_{ZZ} \\ \varepsilon_{yZ} \\ \varepsilon_{ZX} \\ \varepsilon_{Xy} \end{bmatrix} = \frac{1}{E} \begin{bmatrix} 1 & -\nu & -\nu & 0 & 0 & 0 \\ -\nu & 1 & -\nu & 0 & 0 & 0 \\ -\nu & -\nu & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1+\nu & 0 & 0 \\ 0 & 0 & 0 & 0 & 1+\nu & 0 \\ 0 & 0 & 0 & 0 & 0 & 1+\nu \end{bmatrix} \begin{bmatrix} \sigma_{XX} \\ \sigma_{Xy} \\ \sigma_{ZZ} \\ \sigma_{ZZ} \\ \sigma_{Xy} \\ \sigma_{Xy} \end{bmatrix}$$

### **Failure Theory**

O Max distortion energy (Von Mises):  $(\sigma_x - \sigma_y)^2 + (\sigma_y - \sigma_z)^2 + (\sigma_z - \sigma_x)^2 + 6(\tau_{xy}^2 + \tau_{yz}^2 + \tau_{xz}^2) = 2\sigma_{vp}^2$ 

Coulomb-Mohr:  $\frac{\sigma_1}{\sigma_{11}} - \frac{\sigma_3}{\sigma_{12}'} = 1$ 

#### **Fracture Mechanics**

Stress intensity factor:  $K = \lambda \sigma \sqrt{\pi a}$ 

### **Fatigue**

$$\circ$$
  $N_{cr}=N_f\left(rac{\sigma_{cf}}{\sigma_f}
ight)^{1/b}$  , where  $b=rac{ln(\sigma_f/\sigma_e)}{ln(N_f/N_e)}$ 

O Soderberg: 
$$\frac{\sigma_a}{\sigma_{cr}} + \frac{\sigma_m}{\sigma_{yp}} = 1$$

$$\circ \quad \text{Gerber: } \frac{\sigma_a}{\sigma_{cr}} + \left(\frac{\sigma_m}{\sigma_u}\right)^2 = 1$$

$$\circ \quad \mathsf{SAE:} \frac{\sigma_a}{\sigma_{cr}} + \frac{\sigma_m}{\sigma_f} = 1$$

# **Dynamic Loading**

Impact factor (vertical drop):  $K = 1 + \sqrt{1 + \frac{2h}{\delta_{ct}}}$ 

#### **Stress Concentrations**

Stress distribution around a hole in a flat plate under uniaxial loading

$$\begin{split} &\sigma_r = \frac{1}{2}\sigma_o \left[ \left( 1 - \frac{a^2}{r^2} \right) + \left( 1 + \frac{3a^4}{r^4} - \frac{4a^2}{r^2} \right) \cos 2\theta \right] \\ &\sigma_\theta = \frac{1}{2}\sigma_o \left[ \left( 1 + \frac{a^2}{r^2} \right) - \left( 1 + \frac{3a^4}{r^4} \right) \cos 2\theta \right] \\ &\tau_{r\theta} = -\frac{1}{2}\sigma_o \left( 1 - \frac{3a^4}{r^4} + \frac{2a^2}{r^2} \right) \sin 2\theta \end{split}$$






Table 3.2. Maximum Pressure Po and Deflection of Two Bodies in Contact

_			
Configuration		Spheres: $p_o = 1.5 \frac{F}{\pi a^2}$	Cylinders: $p_o = \frac{2}{\pi} \frac{F}{aL}$
A	z †	Sphere on a Flat Surface	Cylinder on a Flat Surface
	F	$a=0.880\sqrt[3]{Fr_1\Delta}$	$a = 1.076 \sqrt{\frac{F}{L} r_l \Delta}$
	$\begin{pmatrix} r_1 \end{pmatrix}_{r_2=\infty}$		For $E_1 = E_2 = E$ :
	a F	$\delta = 0.775 \sqrt[3]{F^2 \frac{\Delta^2}{r_1}}$	$\delta = \frac{0.579F}{EL} \left( \frac{1}{3} + \ln \frac{2r_1}{a} \right)$
В	z ţ	Two Spherical Balls	Two Cylindrical Rollers
	F	$a = 0.880 \sqrt[3]{F \frac{\Delta}{m}}$	$a = 1.076 \sqrt{\frac{F\Delta}{Lm}}$
	( + 1)	$\delta = 0.775 \sqrt[3]{F^2 \Delta^2 n} \leftarrow n$	n
	T <sub>F</sub>	,	
С	z †	Sphere on a Spherical Seat	Cylinder on a Cylindrical Seat
	F 12	$a = 0.880 \sqrt[3]{F\frac{\Delta}{n}}$ $\delta = 0.775 \sqrt[3]{F^2 \Delta^2 n}$	$a = 1.076 \sqrt{\frac{F\Delta}{Ln}}$
	a F	$\delta = 0.775 \sqrt[3]{F^2 \Delta^2 n}$	
Note	$\pm \Delta = \frac{1}{E_1} + \frac{1}{E_2},  m =$	$\frac{1}{r_1} + \frac{1}{r_2},  n = \frac{1}{r_1} - \frac{1}{r_2}$ * all	formulae in this table assume $\nu = 0$

<u>Stress distributions</u>: Stresses as a function of the load axis, z (for v = 0.3): (left) two spheres; (right) two parallel cylinders. Note: All normal stresses are compressive and principal ( $\tau$  only non-zero for change of coordinates)





## **Beam Bending**

$$\sigma_x = \frac{(M_y I_z + M_z I_{yz})z - (M_y I_{yz} + M_z I_y)y}{I_y I_z - I_{yz}^2}$$

## **Torsion**

Table 6.2. Shear Stress and Angle of Twist of Various Members in Torsion

				Angle of twist	
Cross section	shearing stress		per unit length		
$ \begin{array}{c c} 2a \\ 2b \\ \hline A \end{array} $ For circular bar: $a=b$	$\tau_A = \frac{2T}{\pi a b^2}$		$\theta = \frac{(a^2 + b^2)T}{\pi a^3 b^3 G}$		
A a a constant a const	$\tau_A = \frac{20T}{a^3}$		$\theta = \frac{46.2T}{a^4 G}$		
	$\tau_A = \frac{T}{\alpha a b^2}$		$\theta = \frac{T}{\beta ab^3 G}$		
	a/b		β	α	
. а .	1.0		0.141	0.208	
<b>←</b>	1.5		0.196	0.231	
<b>1</b> b	2.0		0.229	0.246	
^	2.5		0.249	0.256	
	3.0		0.263	0.267	
	4.0		0.281	0.282	
	5.0		0.291	0.292	
	10.0		0.312	0.312	
	$\infty$		0.333	0.333	
B 1 1 b	$\tau_{A} = \frac{T}{2abt_{1}}$ $\tau_{B} = \frac{T}{2abt}$		$\theta = \frac{(at + bt_1)T}{2tt_1a^2b^2G}$		
For circular tube: $a=b$	$\tau_A = \frac{T}{2\pi aba}$	ī	$\theta = \frac{\sqrt{2(a^2 + b^2)}T}{4\pi a^2 b^2 tG}$		
A a Hexagon	$\tau_A = \frac{5.7T}{a^3} \qquad \qquad \theta = \frac{8.8T}{a^4 G}$		$=\frac{8.8T}{a^4G}$		

Narrow, rectangular cross section


$$\tau_{max} = \frac{3T}{bt^2} \qquad \theta = \frac{3T}{bt^3G}$$

Thin-walled, closed cross sections

$$\tau = \frac{T}{2At} \qquad \theta = \frac{1}{2AG} \oint \tau ds$$

## **Thick-Walled Pressure Vessels**

• Stress equations



$$\sigma_r = \frac{a^2 p_i - b^2 p_o}{b^2 - a^2} - \frac{(p_i - p_o)a^2 b^2}{(b^2 - a^2)r^2}$$

$$\sigma_\theta = \frac{a^2 p_i - b^2 p_o}{b^2 - a^2} + \frac{(p_i - p_o)a^2 b^2}{(b^2 - a^2)r^2}$$

$$\sigma_z = \frac{p_i a^2 - p_o b^2}{b^2 - a^2}$$