



analog ground
ADC ch0
ADC ch1
ADC ch2
ADC ch3

prop. pins
1 3 5 7 9 11
0 2 4 6 8 10

power supply
for photogate
+5V
ground

digital power supply
for prop and SD card
+5V
digital ground