


# Eco Air Humidifier

Written

## Thermostat

### Instruction Manual



## General

The Eco Air Humidifier Thermostat is a thermostat that will help reduce climate change. Climate change is currently a major issue and some places may be seeing greater temperatures, longer heat waves, and more severe rain events. The thermostat will alert you when you go over the recommended setting of heating and cooling with an alert noise and blinking lights for 10 seconds. The red lights are when it's under and over the recommended settings. The temperature, precipitation, humidity, and wind will also display the current temperature outside. The thermostat also include a humidifier which can help during the dry seasons and breathing. After setting the wifi up, the precipitation, humidity, and wind will automatically come alongside the low and high temperature.

## Installing the Eco Air Humidifier Thermostat

- 1) Turn off power to HVAC system.
- 2) Remove the old thermostat
- 3) Label and separate the wires
- 4) Separate wall plate
- 5) Mount wallplate
- 6) Connect the wires
- 7) Install batteries
- 8) Set mode switch
- 10) Install thermostat wallplate
- 11) Restore the power

## Alerts

The batteries need to be replaced when the caution symbol comes on at the top center of the Home screen. When the battery power is very low, the bar will blink once every 2 hours and the colors of the warning symbol will change to inverted colors. When the battery power gets extremely low, the bar will blink once a hour, with the bar changing to inverted colors alongside the warning symbol with a loud noise going off.

## Operation Guide

### Commands

**Hold:** Pressing the "Hold" button your thermostat will lock in the current temperature it's currently at until you decide to change it.

**Set:** Press the "Set" button to set the temperatures you want to set for your home for the times and days. Press or hold the up and down arrow to set the setting you want.

**Run:** By pressing the "Run" button your thermostat will return to its normal schedule.

The mode bar at the bottom displays the settings: cool, off, and heat which can be adjusted by using the piece to move to the left and right for the setting you want. The following settings as followed: "cool" which will change your house to a more cooler setting when it gets hot, "off," turn the setting off when you feel that the temperature is good for, and "heat" is used to heat your house you feel that its too cool.

The built in Air Humidifier can bring water and moisture to a dry environment by turning the nozzle to the desired setting. The side with the darker color is to know what the humidifier setting is. The off button is the circle

### Setting time/date

#### Time

- 1) Hold the SET button and up arrow at the same time to get to the time settings.
- 2) After, pressing the buttons, press the up or down arrow to set the clock time.
- 3) Once finished press the SET button and up arrow to confirm the time.


#### Date

- 1) Hold the SET button and down arrow at the same time to get to the day settings.
- 2) After, pressing the buttons, press the up or down arrow to set the day time.
- 3) Once finished hold the SET button and down arrow to confirm the date.

## Visual

# Eco Air Humidifier Thermostat

## Instruction Manual



### General

The Eco Air Humidifier Thermostat is a thermostat that will help reduce climate change. Climate change is currently a major issue and some places may be seeing greater temperatures, longer heat waves, and more severe rain events. The thermostat will alert you when you go over the recommended setting of heating and cooling with an alert noise and blinking lights for 10 seconds. The red lights are when it's under and over the recommended settings. The temperature, precipitation, humidity, and wind will also display the current temperature outside. The thermostat also include a humidifier which can help during the dry seasons and breathing. After setting the wifi up, the precipitation, humidity, and wind will automatically come alongside the low and high temperature.

## Operation Guide

### Commands



Hold: Pressing the "Hold," button your thermostat will lock in the current temperature it's currently at until you decide to change it.

Set: Press the "Set" button to set the temperatures you want to set for your home for the times and days. Press or hold the up and down arrow to set the setting you want.

Run: By pressing the "Run" button your thermostat will return to its normal schedule.



The mode bar at the bottom displays the settings: cool, off, and heat which can be adjusted by using the piece to move to the left and right for the setting you want. The following settings as followed: "cool" which will changed your house to a more cooler setting when it gets hot, "off," turn the setting off when you feel that the temperature is good for, and "heat" is used to heat your house you feel that its too cool.

The volume button is used to turn the alert noise of thermostat up and down by moving the button to the left for quieter noise and right for a louder noise.

The built in Air Humidifier can bring water and moisture to a dry environment by turning the nozzle to the desired setting. The side with the darker color is to know what the humidifier setting is. The off button is the circle.

### Setting time/date

#### Time



1) Hold the SET button and up arrow at the same time to get to the time settings.

2) After, pressing the buttons, press the up or down arrow to set the clock time.

3) Once finished press the SET button and up arrow to confirm the time.

#### Date



1) Hold the SET button and down arrow at the same time to get to the day settings.

2) After, pressing the buttons, press the up or down arrow to set the day time.

3) Once finished hold the SET button and down arrow to confirm the date.

### Alerts



The batteries need to be replaced when the caution symbol comes on at the top center of the Home screen.

When the battery power is very low, the bar will blink once every 2 hours and the colors of the warning symbol will change to inverted colors alongside the warning symbol with a loud noise going off.

When the battery power gets extremely low, the bar will blink once an hour, with the bar changing to inverted colors alongside the warning symbol with a loud noise going off.

11) Restore the power