

10116

THE CHAPTER STATE OF THE CHAPT	
目录	
关于 NEVC-SimOne API	10
Python API reference(1.0)	10
仿真系统和自动驾驶系统数据通信接口	10
被测车辆 GPS 和底盘信息	10
获取案例主车路径的终点	14
被测车辆周围角色状态	14
被测车辆 Pose 操控	19
被测车辆 Drive 操控	20
设置主车预警信息	21
获取当前环境相关信息(天气、光照、地面等)	22
设置当前环境相关信息(天气、光照、地面等)	24
设置车辆信号灯状态	25
获取 SimOneDriver 状态	26
高精地图运行时接口	27
获取最临近车道	27
获取临近车道列表	28
获取视野范围内所有车道	28
获取离车道左右边缘线的距离	29
获取车道信息	31
获取车道连接信息	32
获取车道类型	33
	A SIMP

S Statement

		SIM OF
ente :	获取车道宽度	34
JIM. C	获取在车道上的 ST 坐标	35
	获取在道路上的 ST 坐标	36
6	查询指定车道是否存在于地图之中	37
:	获取地图中停车位列表	37
:	获取预设规划路径	40
ONE	获取规划路径所途径道路的 ID 列表	40
SIM	根据指定车道 id 和局部坐标获取输入点左右两侧车道标线信息	41
	获取地图中信号灯列表	42
G	获取地图中交通标志列表	43
	获取交通灯给定作用车道的关联停止线列表	44
	获取交通灯给定作用车道的关联人行横道线列表	45
ő	获取指定车道所在道路上的网状线列表	46
A SIMP	获取输入点投影到指定车道中心线上的点和切线方向	47
	得到仿真场景中的交通灯的真值	48
Pyth	on Code Recipes(1.0)	49
	真系统和自动驾驶系统数据通信接口	
M-OME	波测车辆 GPS 和底盘信息	49
	坡测车辆周围角色状态	
4	获取案例主车路径的终点	52
	坡测车辆 Pose 操控	
;	波测车辆 Drive 操控	55
		2

J.116

100	and the same of th	S SID!	.6.	SINION
设置主车	预警信息			57
获取当前	环境相关信息(天气、	光照、地面等)		57
设置当前	环境相关信息(天气、	光照、地面等)		59
设置车辆	信号灯状态			60
获取 Sim	OneDriver 运行状态		<u></u>	61
高精地图运	行时接口			62
查询位置	车道			62
获得附近	车道			63
获得面前	所有车道			65
查询位置	两侧车道边缘			67
查询车道	信息			68
获取车道	连接信息		<u> </u>	71
获取车道	类型	•••••		73
获取车道	宽度			75
获取在车	道上的 ST 坐标	»		77
获取在道	路上的 ST 坐标			78
根据指定	车道 id 和车道上的 ST	坐标获取局部坐	龄 xyz	80
查询指定	车道是否存在于地图之	<u>′</u> 中		82
获取地图	中停车位列表			84
获取预设	规划路径			85
获取规划	路径所途径道路的 ID ?	列表		86
根据指定	车道 id 和局部坐标获取	取局部坐标左右两	对侧车道标线信息	

1116

S Santonie

		DY L
The same	- C	Club Cha
获取地图中交通灯列表		90
获取地图中交通标志牌列表	5	92
获取当前车道所属交通灯管辖的停止线	列表	93
获取当前车道所属交通灯管辖的人行横	道线列表	95
获取当前车道所在道路上的网格线列表		97
根据指定车道 id 和局部坐标获取局部坐	坐标到车道中心线上的投 盟	影点信息 99
得到仿真场景中的交通灯的真值		101
C++ API reference(1.0)		103
仿真系统和自动驾驶系统数据通信接口		103
被测车辆 GPS 和底盘信息		103
被测车辆周围角色状态		106
获取案例主车路径的终点	Sul,	111
被测车辆 Pose 操控		111
被测车辆 Drive 操控		112
设置主车预警消息		114
获取当前环境相关信息 (天气、光照、	地面等)	115
设置当前环境相关信息(天气、光照、	地面等)	117
设置车辆信号灯状态	Chr.	118
获取 SimOneDriver 状态		119
高精地图运行时接口	<u> </u>	120
获取最临近车道		120
获取临近车道列表		121
		4

			DY DESCRIPTION	
	15°	Silly.	SIN-CIVE	
	获取视野范围内所有车道		122	
	获取离车道左右边缘线的距离	5	123	
	获取车道信息			
	获取车道连接信息			
	获取车道类型			
	获取车道宽度			
	获取在车道上的 ST 坐标			
	获取在道路上的 ST 坐标			
	查询指定车道是否存在于地图之中			
	获取地图中停车位列表			
	获取预设规划路径			
	获取规划路径所途径道路的 ID 列表			
	根据指定车道 id 和局部坐标获取输入点			
	获取地图中信号灯列表			
	获取地图中交通标志列表			
	获取交通灯给定作用车道的关联停止线			
	获取交通灯给定作用车道的关联人行横边			
	获取指定车道所在道路上的网状线列表.			
	获取输入点投影到指定车道中心线上的原			
	得到仿真场景中的交通灯的真值			
	- Code Recipes(1.0)			
	真系统和自动驾驶系统数据通信接口			
,, 3		A cylin		
			5	

S SINI-CHIE

				b 7
	W. S.		.40	
被测	车辆 GPS 和底盘信息	,		145
被测	车辆周围角色状态			146
获取	案例主车路径的终点			147
被测	车辆 Pose 操控			148
被测	车辆 Drive 操控		<u></u>	150
设置	主车预警信息			153
获取	当前环境相关信息 (天	气、光照、地面等)		154
设置	当前环境相关信息(天	气、光照、地面等)		155
设置	车辆信号灯状态	· · · · · · · · · · · · · · · · · · ·		156
获取	SimOneDriver 运行状	态		158
高精地	图运行时接口			159
查询	位置车道			159
获得	附近车道			161
获得	面前所有车道			164
查询	位置两侧车道边缘			166
查询	车道信息			168
获取	车道连接信息	5		173
获取	车道类型			176
	车道宽度			
获取	在车道上的 ST 坐标			186
获取	在道路上的 ST 坐标			189
查询	指定车道是否存在于地	图之中	<u>~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~</u>	193

1116

	获取地图中停车位列表	195
	获取预设规划路径	197
	获取规划路径所途径道路的 ID 列表	198
	根据指定车道 id 和局部坐标获取局部坐标左右两侧车道标线信息	199
	获取地图中信号灯列表	201
	获取地图中交通标志列表	201
	获取交通灯给定作用车道的关联停止线列表	202
	获取交通灯给定作用车道的关联人行横道线列表	204
	获取指定车道所在道路上的网状线列表	205
	获取输入点投影到指定车道中心线上的点和切线方向	206
	得到仿真场景中的交通灯的真值	208
RC	OS BRIDGE(1.0)	209
7	标准 ROS Bridge 接口描述	209
	TaskRosControl	209
	TaskRosGps	210
	TaskRosImageBase	211
	TaskRosObstacles	211
	TaskRosPerfectPerception	212
	TaskRosPointCloud	213
	TaskRosPrediction	214
	TaskRosReplayPos	214
	TaskRosRoutingReq	215
		A 5 7

ILB:	CHI.	2 SIN ONL	
TaskRosTrafficLight		215	
TaskRosVehicleInfo			
ROS 文本形式输出验证工具	G. Sult	216	
outputControlInfo		216	
outputGpsInfo		217	
outputVehicleInfo		218	
ROS 可视化格式输出工具		218	
obstacle_box_to_marker	5	218	
perception_to_marker		219	
perception_to_image	W ₀ ,	219	
prediction_to_marker		220	
Restful API(1.0)	- Su.	221	
Terminonlogy		221	
SimOneLauncher		221	
token		221	
案例		221	
任务	»	221	
Test Case		222	
How to create a test case		222	
How to edit a test case	<u> </u>	223	
How to import test cases			
How to create a category		244	
		8	

1716

B' SHI	W. Call
State Of the Control	
How to create a test suite	245
How to delete a test case	246
How to delete a category	246
How to delete a test suite	
Test task	247
How to creat a task	247
How to pause a task	248
How to resume a task	249
How to stop a task	249
How to delete a task	251
Test analysis	252
How to export the report	252
How to export the csv file	253
How to replay a case	253

S SIMPONE

关于 NEVC-SimOne API

NEVC-SimOne 仿真平台提供多种类型的标准 API 实现外部算法系统与仿真平台的通讯机制,目前开放接口允许只接入感知系统进行目标识别和预测的测试,也可以选择直接跳过感知系统从决策系统输入接入,或者将两者同时接入进行整体测试与训练。仿真平台也提供查询类接口,如高精地图车道级别信息和坐标等。在算法接入后,NEVC-SimOne 允许脚本化的批量创建和运行案例,并自动获取测试报告。仿真平台提供 C++,Python 等多种方式的接入。

Python API reference(1.0)

仿真系统和自动驾驶系统数据通信接口

被测车辆 GPS 和底盘信息

获取主车 GPS 信息

def SoApiSetGpsUpdateCB(cb)

参数说明

入参

cb

GPS data update callback function

return(bool)

Get gps data success or not

success:

SimOne Data Gps(class)

GPS data

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)
- float velX:MainVehicle Velocity X on Opendrive (by meter)
- float velY:MainVehicle Velocity Y on Opendrive (by meter)
- float velZ:MainVehicle Velocity Z on Opendrive (by meter)
- float throttle:MainVehicle throttle
- float brake:MainVehicle brake;
- float steering:MainVehicle Steering angle
- int gear:MainVehicle gear position
- float accelX:MainVehicle Acceleration X on Opendrive (by meter)
- float accelY:MainVehicle Acceleration Y on Opendrive (by meter)
- float accelZ:MainVehicle Acceleration Z on Opendrive (by meter)

- float angVelX:MainVehicle Angular Velocity X on Opendrive (by meter)
- float angVelY:MainVehicle Angular Velocity Y on Opendrive (by meter)
- float angVelZ:MainVehicle Angular Velocity Z on Opendrive (by meter)
- float wheelSpeedFL:Speed of front left wheel (by meter/sec)
- float wheelSpeedFR:Speed of front right wheel (by meter/sec)
- float wheelSpeedRL:Speed of rear left wheel (by meter/sec)
- float wheelSpeedRR:Speed of rear right wheel (by meter/sec)

def SoGetGps(mainVehicleId, gpsData)

参数说明

入参

- mainVehicleId(int)
 - Vehicle index, configuration order from scenario editing, starting from 0
- gpsData(class:SimOne_Data_Gps)

GPS data

return(bool)

Get gps data success or not

success:

SimOne_Data_Gps(class)

GPS data

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)
- float velX:MainVehicle Velocity X on Opendrive (by meter)
- float velY:MainVehicle Velocity Y on Opendrive (by meter)
- float velZ:MainVehicle Velocity Z on Opendrive (by meter)
- float throttle:MainVehicle throttle
- float brake:MainVehilce brake;
- float steering:MainVehicle Steering angle
- int gear:MainVehicle gear position
- float accelX:MainVehicle Acceleration X on Opendrive (by meter)
- float accelY:MainVehicle Acceleration Y on Opendrive (by meter)
- float accelZ:MainVehicle Acceleration Z on Opendrive (by meter)
- float angVelX:MainVehicle Angular Velocity X on Opendrive (by meter)
- float angVelY:MainVehicle Angular Velocity Y on Opendrive (by meter)

- float angVelZ:MainVehicle Angular Velocity Z on Opendrive (by meter)
- float wheelSpeedFL:Speed of front left wheel (by meter/sec)
- float wheelSpeedFR:Speed of front right wheel (by meter/sec)
- float wheelSpeedRL:Speed of rear left wheel (by meter/sec)
- float wheelSpeedRR:Speed of rear right wheel (by meter/sec)

获取案例主车路径的终点

获取案例主车的终点

def SoGetTerminalPoint(wayPointsData)

参数说明

入参

SimOne Data WayPoints Entry(struct)

return(bool)

Success or not

success:

- SimOne_Data_WayPoints_Entry(struct)
 - posX
 - posY

被测车辆周围角色状态

得到仿真场景中的物体的真值

def SoApiSetGroundTruthUpdateCB(cb)

参数说明

入参

• cb

Obstacle data fetch callback function

return(bool)

Success or not

success:

SimOne_Data_Obstacle(class)

Obstacle data

- int obstacleSize:Obstacle size
- SimOne_Data_Obstacle_Entry
 obstacle[SOSM_OBSTACLE_SIZE_MAX]:Obstacle, 100 max
 - int id:Obstacle ID
 - SimOne Obstacle Type type:Obstacle Type
 - ESimOne_Obstacle_Type_Unknown = 0
 - ESimOne_Obstacle_Type_Pedestrian = 4
 - ESimOne_Obstacle_Type_Car = 6
 - ESimOne_Obstacle_Type_Static = 7
 - ESimOne_Obstacle_Type_Bicycle = 8

- ESimOne Obstacle Type RoadMark = 12
- ESimOne_Obstacle_Type_TrafficSign = 13
- ESimOne Obstacle Type TrafficLight = 15
- ESimOne_Obstacle_Type_Rider = 17
- ESimOne_Obstacle_Type_Truck = 18
- ESimOne_Obstacle_Type_Bus = 19
- ESimOne_Obstacle_Type_Train = 20
- ESimOne_Obstacle_Type_Motorcycle = 21
- ESimOne_Obstacle_Type_SpeedLimitSign = 26
- ESimOne Obstacle Type BicycleStatic = 27
- ESimOne_Obstacle_Type_RoadObstacle = 29
- float theta:Obstacle vertical rotation (by radian)
- float posX:Obstacle Position X on Opendrive (by meter)
- float posY:Obstacle Position Y on Opendrive (by meter)
- float posZ:Obstacle Position Z on Opendrive (by meter)
- float velX:Obstacle Velocity X on Opendrive (by meter)
- float velY:Obstacle Velocity Y on Opendrive (by meter)
- float velZ:Obstacle Velocity Z on Opendrive (by meter)
- float length:Obstacle length
- float width:Obstacle width

float height:Obstacle height

def SoGetGroundTruth(mainVehicleId, obstacleData)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

obstacleData(class:SimOne_Data_Obstacle)

Obstacle data

return(bool)

Success or not

success:

SimOne_Data_Obstacle(class)

Obstacle data

- int obstacleSize:Obstacle size
- SimOne_Data_Obstacle_Entry
 obstacle[SOSM_OBSTACLE_SIZE_MAX]:Obstacle, 100 max
 - int id:Obstacle ID
 - SimOne_Obstacle_Type type:Obstacle Type
 - ESimOne_Obstacle_Type_Unknown = 0
 - ESimOne_Obstacle_Type_Pedestrian = 4

- ESimOne_Obstacle_Type_Car = 6
- ESimOne_Obstacle_Type_Static = 7
- ESimOne_Obstacle_Type_Bicycle = 8
- ESimOne_Obstacle_Type_RoadMark = 12
- ESimOne_Obstacle_Type_TrafficSign = 13
- ESimOne_Obstacle_Type_TrafficLight = 15
- ESimOne_Obstacle_Type_Rider = 17
- ESimOne_Obstacle_Type_Truck = 18
- ESimOne_Obstacle_Type_Bus = 19
- ESimOne_Obstacle_Type_Train = 20
- ESimOne_Obstacle_Type_Motorcycle = 21
- ESimOne_Obstacle_Type_SpeedLimitSign = 26
- ESimOne_Obstacle_Type_BicycleStatic = 27
- ESimOne_Obstacle_Type_RoadObstacle = 29
- float theta:Obstacle vertical rotation (by radian)
- float posX:Obstacle Position X on Opendrive (by meter)
- float posY:Obstacle Position Y on Opendrive (by meter)
- float posZ:Obstacle Position Z on Opendrive (by meter)
- float velX:Obstacle Velocity X on Opendrive (by meter)
- float velY:Obstacle Velocity Y on Opendrive (by meter)

- float velZ:Obstacle Velocity Z on Opendrive (by meter)
- float length:Obstacle length
- float width:Obstacle width
- float height:Obstacle height

被测车辆 Pose 操控

设置主车位置

def SoApiSetPose(mainVehicleId, poseControl)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

SimOne_Data_Pose_Control(class)

Pose to set

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)
- bool autoZ = false:Automatically set Z according to scene

Success or not

被测车辆 Drive 操控

主车控制

def SoApiSetDrive(mainVehicleId, driveControl)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

• SimOne_Data_Control(class)

vehicle control data

- float throttle
- float brake
- float steering
- bool handbrake = false
- bool isManualGear = false
- EGearMode gear:gear location
 - EGearMode_Neutral = 0
 - EGearMode_Drive = 1:forward gear for automatic gear
 - EGearMode_Reverse = 2

- EGearMode_Parking = 3
- EGearManualMode_1 = 4:forward gear 1 for manual gear
- EGearManualMode 2 = 5
- EGearManualMode 3 = 6
- EGearManualMode 4 = 7
- EGearManualMode 5 = 8
- EGearManualMode 6 = 9
- EGearManualMode 7 = 10
- EGearManualMode 8 = 11

Success or not

设置主车预警信息

设置主车预警信息

def SoApiSetVehicleEvent(mainVehicleId, vehicleEventInfo)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

- SimOne_Data_Vehicle_EventInfo(class)
 - ESimone_Vehicle_EventInfo_Type type

- ESimOne_VehicleEventInfo_Forward_Collision = 0
- ESimOne_VehicleEventInfo_Backward_Collision = 1
- ESimOne_VehicleEventInfo_Left_Turn = 2
- ESimOne_VehicleEventInfo_Right_Turn = 3
- ESimOne_VehicleEventInfo_Forward_Straight = 4
- ESimOne_VehicleEventInfo_Over_Speed = 5

Success or not

获取当前环境相关信息 (天气、光照、地面等)

获取当前环境相关信息 (天气、光照、地面等)

def SoGetEnvironment(pEnvironment)

参数说明

入参

无

return(bool)

Success or not

success:

- SimOne_Data_Environment(class)
 - timeOfDay(float)

time of day [0, 2400]

- heightAngle(float)height angle [0, 90]
- directionalLight(float)light for sun or moon [0, 1]
- ambientLight(float)ambient light [0, 1]
- artificialLight(float)artificial light [0, 1]
- cloudDensity(float)cloud density [0, 1]
- fogDensity(float)fog density [0, 1]
- rainDensity(float)rain density [0, 1]
- snowDensity(float)snow density [0, 1]
- groundHumidityLevel(float)ground humidity level [0, 1]
- groundDirtyLevel(float)ground dirty level [0, 1]

设置当前环境相关信息 (天气、光照、地面等)

设置当前环境相关信息 (天气、光照、地面等)

def SoSetEnvironment(pEnvironment)

参数说明

入参

- SimOne_Data_Environment(class)
 - timeOfDay(float)time of day [0, 2400]
 - heightAngle(float)height angle [0, 90]
 - directionalLight(float)light for sun or moon [0, 1]
 - ambientLight(float)ambient light [0, 1]
 - artificialLight(float)artificial light [0, 1]
 - cloudDensity(float)cloud density [0, 1]
 - fogDensity(float)fog density [0, 1]

- rainDensity(float)
 - rain density [0, 1]
- snowDensity(float)
 - snow density [0, 1]
- groundHumidityLevel(float)
 - ground humidity level [0, 1]
- groundDirtyLevel(float)
 - ground dirty level [0, 1]

Success or not

设置车辆信号灯状态

设置车辆各信号灯的状态

def SoSetSignalLights(mainVehicleId, pSignalLight)

参数说明

入参

- mainVehicleId(int)
 - Vehicle index, configuration order from scenario editing, starting from 0
- SimOne_Data_Signal_Lights(struct)
 - SimOne_Signal_Light(struct)
 - ESimOne_Signal_Light_RightBlinker = 1

- ESimOne_Signal_Light_LeftBlinker = (1 << 1)
- ESimOne_Signal_Light_DoubleFlash = (1 << 2)
- ESimOne Signal Light BrakeLight = (1 << 3)
- ESimOne_Signal_Light_FrontLight = (1 << 4)
- ESimOne_Signal_Light_HighBeam = (1 << 5)
- ESimOne_Signal_Light_BackDrive = (1 << 6)

Success or not

获取 SimOneDriver 状态

获取 SimOneDriver 对于主车的控制状态

def SoGetDriverStatus(mainVehicleId, driverStatusData)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

return(bool)

Success or not

success:

- SimOne_Driver_Status(class)
 - ESimOne_Driver_Status_Unknown = 0

- ESimOne Driver Status Controlling = 1
- ESimOne Driver Status Disabled = 2

高精地图运行时接口

获取最临近车道

获取最接近输入点的车道, 所属车道优先

def getNearMostLane(pos)

参数说明

入参

pos(SimPoint3D)Input 3d location

return

- pyNearMostLane(class)
 - exists(bool)
 - laneId(SimString)

Lane ID of founded lane. ID with this format roadId_sectionIndex_laneId

s, t(double)

The input point's value pair in s-t coordinate system, relative to the found lane

s_toCenterLine, t_toCenterLine(double)

is the input point' s value pair in s-t coordinate system, relative to the found lane' s owner road' s center line.

获取临近车道列表

获取临近车道列表

def getNearLanes(pos, distance)

参数说明

入参

- pos(SimPoint3D)Input 3d location
- distance(double)
 Input range distance

return

- pyNearLanes(class)
 - exists(bool)
 - laneIdList

Lane IDs of founded lanes. Each ID with this format roadId_sectionIndex_laneId

获取视野范围内所有车道

获取视野范围内所有车道

def getNearLanesWithAngle(pos, distance, headingAngle, angleShift)

参数说明

入参

pos(SimPoint3D)

Input 3d location

distance(double)

Input distance range to search

headingAngle(double)

A specified heading direction's angle relative to x-axis in 2d-inertial system. heading Angle is defined as radian

angleShift(double)

To help define the range of angle as [headingAngle - angleShift, headingAngle + angleShift], and angleShift is defined as radian

return

- pyNearLanes(class)
 - exists(bool)
 - laneIdList

Lane IDs of founded lanes. Each ID with this format roadId_sectionIndex_laneId

获取离车道左右边缘线的距离

获取离最近车道的左右边缘线的距离信息

def getDistanceToLaneBoundary(pos)

参数说明

入参

pos(SimPoint3D)

Input 3d location

return

- pyDistanceToLaneBoundary(class)
 - exists(bool)
 - laneId(SimString)

Lane ID of founded lane. ID with this format roadld sectionIndex laneId

distToLeft(double)

The distance to boundaries in 3d space

distToRight(double)

The distance to boundaries in 3d space

distToLeft2D(double)

The distance to boundaries in 3d space

distToRight2D(double)

The distance to boundaries in 3d space

获取车道信息

获取车道信息(包含车道 ID, 左右边缘线,虚拟中心线)

def getLaneSample(laneId)

参数说明

入参

laneId(SimString)
 Input lane ID. ID with this format roadId_sectionIndex_laneId

return

- pyLaneSample(class)
 - exists(bool)
 - laneInfo(MLaneInfo)
 - laneName(SimString)
 formatted as roadId_sectionIndex_laneId
 - leftBoundary(SimPoint3DVector)
 sample point list of left boundary
 - rightBoundary(SimPoint3DVector)
 sample point list of right boundary
 - centerLine(SimPoint3DVector)
 sample point list of center line

获取车道连接信息

获取车道连接信息

def getLaneLink(laneId)

参数说明

入参

laneId(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

return

- pyLaneLink(class)
 - exists(bool)
 - laneLink(MLaneLink)
 - predecessorLaneNameList(SimStringVector)
 lane' s predecessors' laneName list, formatted as roadId_sectionIndex_laneId
 - successorLaneNameList(SimStringVector)
 lane' s successors' laneName list, formatted as roadId sectionIndex laneId
 - leftNeighborLaneName(SimStringVector)
 lane' s left neighbor' s laneName, formatted as roadId_sectionIndex_laneId
 - rightNeighborLaneName(SimStringVector)

lane' s right neighbor' s laneName, formatted as roadId_sectionIndex_laneId

获取车道类型

获取车道类型

def getLaneType(laneId)

参数说明

入参

laneld(SimString)
 Input lane ID. ID with this format roadId_sectionIndex_laneld

return

- pyLaneType(class)
 - exists(bool)
 - laneType(MLaneType)
 Lane type of specified lane
 - none
 - driving
 - stop
 - shoulder
 - biking
 - sidewalk

- border
- restricted
- parking
- bidirectional
- median
- special1
- special2
- special3
- roadWorks
- tram
- rail
- entry
- exit
- offRamp
- onRamp
- mwyEntry
- mwyExit

获取车道宽度

获取车道宽度

def getLaneWidth(laneId, pos)

参数说明

入参

laneId(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

return

- pyLaneWidth(class)
 - exists(bool)
 - width(double)

lane width of specified lane

获取在车道上的 ST 坐标

获取相对于车道虚拟中心线的 ST 坐标

def getLaneST(laneId, pos)

参数说明

入参

laneId(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

return

- pyST(class)
 - exists(bool)
 - s(double)

The input point's value pair in s-t coordinate system, relative to specified lane.

t(double)

The input point's value pair in s-t coordinate system, relative to specified lane.

获取在道路上的 ST 坐标

获取相对于道路参考线的 ST 坐标

def getRoadST(laneId, pos)

参数说明

入参

laneId(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

return

pySTZ(class)

- exists(bool)
- s(double)

[s, t] represents the input point' s value pair in s-t coordinate system

t(double)

[s, t] represents the input point's value pair in s-t coordinate system,

z(double)

z represents the input point's height value in localENU.

查询指定车道是否存在于地图之中

查询指定车道是否存在于地图之中

def containsLane(laneId)

参数说明

入参

laneId(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

return(bool)

True if exists, else returns false

获取地图中停车位列表

获取地图中停车位列表

def getParkingSpaceList()

参数说明

入参

parkingSpaceId(SimString)
 Input parking space ID

return

- parkingSpaceList()
- id
 - 2 pt
 - X
 - y
 - Z
 - heading
 - X
 - y
 - Z
 - boundaryKnots
 - X
 - y
 - 7

- front
 - side

- type
- color
- width
- rear
 - side
 - type
 - color
 - width
- left
 - side
 - type
 - color
 - width
- right
 - side
 - type
 - color
 - width

获取预设规划路径

获取预设规划路径

def getPredefinedRoute

参数说明

入参

无

return(bool)

route

Generated route

- X
- y
- _ 7

获取规划路径所途径道路的 ID 列表

获取规划路径所途径道路的 ID 列表

def navigate

参数说明

入参

inputPts

Input points that to guide generated route should pass over return(bool)

- indexOfValidPoints
 - Pick valid ones from input points. Valid ones will be used for generting route
- roadIdList
 road id list that are throughed by routing path

根据指定车道 id 和局部坐标获取输入点左右两侧车道标线信息

根据指定车道 id 和局部坐标获取输入点左右两侧车道标线信息

def getRoadMark

参数说明

入参

- pos
 Input 3d location
- id
 Input lane ID. ID with this format roadId_sectionIndex_laneId

 return(bool)
- left
 - Left side roadmarks
 - sOffset
 - length
 - width

- type
- color
- right

Right side roadmark

- sOffset
- length
- width
- type
- color

获取地图中信号灯列表

获取地图中信号灯列表

def getTrafficLightList

参数说明

入参

无

return

list

Traffic light object list

- io
- type

- subType
- pt(SimPoint3D)
 - X
 - y
 - z
- heading
- value
- unit
- isDynamic(bool)
- validities(SimVector)

获取地图中交通标志列表

获取地图中交通标志列表

def getTrafficSignList

参数说明

入参

无

return

list

Traffic sign object list

- id

- type
- subType
- pt(SimPoint3D)
 - X
 - V
 - 7
- heading
- value
- ² unit
- isDynamic(bool)
- validities(SimVector)

获取交通灯给定作用车道的关联停止线列表

获取交通灯给定作用车道的关联停止线列表

def getStoplineList

参数说明

入参

- light
 - Traffic light object
- laneld

Input lane ID. ID with this format roadId_sectionIndex_laneId

return

• stoplineList

Stoplines list that is associated

- id
- type
- pt(SimPoint3D)
 - X
 - y
 - Z
- boundaryKnots(SimPoint3DVector)

获取交通灯给定作用车道的关联人行横道线列表

获取交通灯给定作用车道的关联人行横道线列表

def getCrosswalkList

参数说明

入参

light

Traffic light object

laneId

Input lane ID. ID with this format roadId_sectionIndex_laneId

return

crosswalkList

Crosswalks list that is associated

- id
- type
- pt(SimPoint3D)
 - X
 - y
 - Z
- boundaryKnots(SimPoint3DVector)

获取指定车道所在道路上的网状线列表

获取指定车道所在道路上的网状线列表

def getCrossHatchList

参数说明

入参

light

Traffic light object

laneld

Input lane ID. ID with this format roadId_sectionIndex_laneId

return

crossHatchList

Cross hatches list that is associated

- id
- type
- pt(SimPoint3D)
 - X
 - y
 - 7
- boundaryKnots(SimPoint3DVector)

获取输入点投影到指定车道中心线上的点和切线方向

获取输入点投影到指定车道中心线上的点和该点处对应中心线的切线方向

def getInertialFromLaneST

参数说明

入参

- inputPtInput 3d location
- laneId
 Input lane ID. ID with this format roadId_sectionIndex_laneId

 return(bool)
- targetPoint
 The target point that is on specified lane's middle line

- x(double)
- y(double)
- z(double)
- dir

The tangent direction on the target point on lane's middle line

- X
- y
- z

得到仿真场景中的交通灯的真值

得到仿真场景中的交通灯的真值

def SoGetTrafficLights

参数说明

入参

mainVehicleId

Vehicle index, configure order of web UI, starts from 0

opendriveLightId

LightId

return(bool)

SimOne_Data_TrafficLight(struct)

light data

- index(int)
- opendriveLightId(int)
- countDown
- status(SimOne_TrafficLight_Status)
 - ESimOne_TrafficLight_Status_Invalid = 0,
 - ESimOne_TrafficLight_Status_Red = 1,
 - ESimOne_TrafficLight_Status_Green = 2,
 - ESimOne_TrafficLight_Status_Yellow = 3,
 - ESimOne_TrafficLight_Status_RedBlink = 4,
 - ESimOne TrafficLight Status GreenBlink = 5,
 - ESimOne_TrafficLight_Status_YellowBlink = 6,
 - ESimOne_TrafficLight_Status_Black = 7

Python Code Recipes(1.0)

仿真系统和自动驾驶系统数据通信接口

被测车辆 GPS 和底盘信息

import os
import pySimOneSM
import time

from SimOneSMStruct import *

```
# Global
PosX = 0
PosY = 0
PosZ = 0
#方法一:使用回调函数
def SamplegpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
#方法二:直接调用
def SamplegpsByDirect():
  while(1):
    dataGps = SimOne_Data_Gps()
    if SoGetGps(0, dataGps):
      print(dataGps.posX)
      print(dataGps.posY)
      print(dataGps.posZ)
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
```

```
SoApiSetGpsUpdateCB(SamplegpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      time.sleep(2)
  #SamplegpsByDirect()
被测车辆周围角色状态
from SimOneSMStruct import*
import time
#方法一:使用回调函数
def SampleGetGroundTruthByCB():
  def getGroundTruth(mainVehicleId, data):
    # mainVehicleId 默认为 0
    if data:
      ObstacleSize = data[0].obstacleSize
      print(ObstacleSize)
  SoApiStart()
  SoApiSetGroundTruthUpdateCB(getGroundTruth)\\
  time.sleep(0.1)
```

#方法二:直接调用

def SampleGetGroundTruthByByDirect():

```
while (1):
    time.sleep(0.1)
    dataObstacle = SimOne Data Obstacle()
    if SoGetGroundTruth(0, dataObstacle):
      print(dataObstacle.obstacleSize)
if __name__ == '__main__':
  SampleGetGroundTruthByCB()
  # SampleGetGroundTruthByByDirect()
  # SampleGetGroundTruthByByDirect()
获取案例主车路径的终点
from SimOneSMStruct import *
def SampleGetWayPoints():
  while(1):
    wayPoints = SimOne Data WayPoints Entry()
    if SoGetTerminalPoint(wayPoints):
      print(wayPoints.posX)
      print(wayPoints.posY)
if __name__ == '__main__':
  SampleGetWayPoints()
```

被测车辆 Pose 操控

```
import os,sys
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
posX = 0
posY = 0
posZ = 0
timestamp = 0
#方法一:使用回调函数
def SampleSetGpsUpdateCB():
  def SetGpsUpdateData(mainVehicleId, Data Gps ):
    global posX, posY, posZ, timestamp
    posX = Data Gps[0].posX
    posY = Data_Gps[0].posY
    posZ = Data_Gps[0].posZ
    timestamp = Data_Gps[0].timestamp
  SoApiStart()
  SoApiSetGpsUpdateCB(SetGpsUpdateData)
  if posX != 0:
    print("gpsCB: X:{0} Y:{1} Z:{2}".format(posX, posY, posZ))
```

```
time.sleep(2)
    pose.timestamp = timestamp
    pose.posX = posX + 10
    pose.posY = posY + 10
    pose.posZ = posZ
    SoApiSetPose(0, pose)
 方法二:直接调用
def SampleSetGpsByDirect():
  gps = SimOne_Data_Gps()
  pose = SimOne_Data_Pose_Control()
  while (1):
    time.sleep(0.1)
    SoGetGps(0, gps)
    print(gps.posX, gps.posY, gps.posZ)
    pose.timestamp = gps.timestamp
    pose.posX = gps.posX + 10
    pose.posY = gps.posY + 10
    pose.posZ = gps.posZ
    SoApiSetPose(0, pose)
    print(pose.posX, pose.posY, pose.posZ)
if name == ' main ':
  SampleSetGpsUpdateCB()
```

#SampleSetGpsByDirect()

被测车辆 Drive 操控

```
import os,sys
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
posX = 0
timestamp = 0
control = SimOne_Data_Control()
gps = SimOne_Data_Gps()
#方法一:使用回调函数
def SampleSetDriveCB():
  def SetGpsUpdateData(mainVehicleId, Data Gps):
    global posX, timestamp
    posX = Data Gps[0].posX
    timestamp = Data_Gps[0].timestamp
  SoApiStart()
  SoApiSetGpsUpdateCB(SetGpsUpdateData)
  if posX != 0:
    time.sleep(2)
    control.timestamp = timestamp
    control.throttle = 0.1
```

```
control.brake = 0.0
    control.steering = 0.0
    control.handbrake = False
    control.isManualGear = False
    control.gear = EGearMode.EGearManualMode 1
    SoApiSetDrive(0, control)
#方法二:直接调用
def SampleSetDriveByDirect():
  SoApiStart()
  while (1):
    time.sleep(0.1)
    SoGetGps(0, gps)
    control.timestamp = gps.timestamp
    control.throttle = 0.1
    control.brake = 0.0
    control.steering = 0.0
    control.handbrake = False
    control.isManualGear = False
    control.gear = EGearMode.EGearManualMode_1
    SoApiSetDrive(0, control)
if name == ' main ':
  SampleSetDriveCB()
  #SampleSetDriveByDirect()
```

设置主车预警信息

```
import os,sys
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
timestamp = 0
def SampleSetEvent():
  gps = SimOne_Data_Gps()
  vehicleEvent = SimOne Data Vehicle EventInfo()
  SoApiStart()
  while (1):
    SoGetGps(0, gps)
    vehicleEvent.timestamp = gps.timestamp
    vehicleEvent.type = ESimone Vehicle EventInfo Type.ESimOne VehicleEv
entInfo Forward Collision
    SoApiSetVehicleEvent(0, vehicleEvent)
if __name__ == '__main__':
  SampleSetEvent()
获取当前环境相关信息 (天气、光照、地面等)
#!/usr/bin/env python3
# -*- coding: utf-8 -*-
```

```
from SimOneSMStruct import * import json
```

获取天气 def SampleGetEnvironment(): getEnvironmentJson = dict() getEnvironment = SimOne Data Environment() **if** SoGetEnvironment(getEnvironment): getEnvironmentJson.update({'timeOfDay': getEnvironment.timeOfDay}) getEnvironmentJson.update({'directionalLight': getEnvironment.direction alLight}) getEnvironmentJson.update({'artificialLight': getEnvironment.artificialLigh t}) getEnvironmentJson.update({'ambientLight': getEnvironment.ambientLig ht}) getEnvironmentJson.update({'heightAngle': getEnvironment.heightAngle}) getEnvironmentJson.update({'cloudDensity': getEnvironment.cloudDensit y}) getEnvironmentJson.update({'rainDensity': getEnvironment.rainDensity}) getEnvironmentJson.update({'snowDensity': getEnvironment.snowDensit y}) getEnvironmentJson.update({'groundHumidityLevel': getEnvironment.gro undHumidityLevel}) getEnvironmentJson.update({'groundDirtyLevel': getEnvironment.ground DirtyLevel}) print(json.dumps(getEnvironmentJson, ensure ascii=False))

```
if __name__ == '__main__':
  SampleGetEnvironment()
设置当前环境相关信息 (天气、光照、地面等)
#!/usr/bin/env python3
# -*- coding: utf-8 -*-
from SimOneSMStruct import *
import json
import time
# 设置天气
def SampleSetEnvironment():
  setEnvironmentJson = dict()
  setEnvironment = SimOne Data Environment()
  setEnvironment.timeOfDay = 1200
  setEnvironment.snowDensity = 1.0
  SoSetEnvironment(setEnvironment)
  if SoGetEnvironment(setEnvironment):
    setEnvironmentJson.update({'timeOfDay': setEnvironment.timeOfDay})
    setEnvironmentJson.update({'snowDensity': setEnvironment.snowDensity})
  print(json.dumps(setEnvironmentJson, ensure_ascii=False))
```

```
if __name__ == '__main__':
  SampleSetEnvironment()
设置车辆信号灯状态
from SimOneSMStruct import *
import time, sys
control = SimOne_Data_Control()
signal Lights Data = SimOne\_Data\_Signal\_Lights()
gps = SimOne_Data_Gps()
def sampleSoSetSignalLights():
  if SoGetGps(0, gps):
    control.timestamp = gps.timestamp
  control.throttle = 0.5
  control.gear = EGearMode.EGearManualMode_1
  SoApiSetDrive(0, control)
  signal Lights \verb|= SimOne_Signal_Light.ESimOne_Signal_Light|
LeftBlinker
```

SoSetSignalLights(0, signalLightsData)

```
if __name__ == '__main__':
    sampleSetSignalLights()

获取 SimOneDriver 运行状态

#!/usr/bin/env python3
# -*- coding: utf-8 -*-
```

-*- coding: utf-8 -*from SimOneSMStruct import *
import json
import time

```
def SampleSoGetDriverStatus():
    DriverStatus = SimOne_Data_Driver_Status()
    while(1):
        time.sleep(0.1)
        if SoGetDriverStatus(0, driverStatus):
        status = DriverStatus.driverStatus.value
        print(status)
```

```
if __name__ == '__main__':
    SampleSoGetDriverStatus()
```

高精地图运行时接口

查询位置车道

```
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
```

return info.laneld

```
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      SampleGetNearMostLane(pos)
      time.sleep(2)
获得附近车道
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
```

```
global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearLanes(pos, radius):
  print("SampleGetNearLanes:")
  nearLanesInfo = pySimOneSM.getNearLanes(pos, radius)
  if nearLanesInfo.exists == False:
    print("Not exists!")
     return
  lanesInfo = nearLanesInfo.laneIdList
  print("lanesInfo size:", lanesInfo.Size())
  print("lanesInfo id list:")
  for i in range(lanesInfo.Size()):
    element = lanesInfo.GetElement(i)
    print(element.GetString())
     print(",")
if __name__ == '__main__':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(qpsCB)
  while (1):
     if PosX != 0:
```

```
print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      SampleGetNearLanes(pos, 5)
       time.sleep(2)
获得面前所有车道
import os
import pySimOneSM
import time
from SimOneSMStruct import
M_PI = 3.14159265358979323846
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearLanesWithAngle(pos, radius, headingAngle, shiftAngle):
  print("SampleGetNearLanesWithAngle:")
  nearLanesInfo = pySimOneSM.getNearLanesWithAngle(pos, radius, headin
```

```
gAngle, shiftAngle)
  if nearLanesInfo.exists == False:
    print("Not exists!")
     return
  lanesInfo = nearLanesInfo.laneIdList
  print("lanesInfo size:", lanesInfo.Size())
  print("lanesInfo id list:")
  for i in range(lanesInfo.Size()):
     element = lanesInfo.GetElement(i)
    print(element.GetString())
     print(",")
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
     if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       headingAngle = 30 / 180 * M PI
       shiftAngle = 90 / 180 * M PI
       SampleGetNearLanesWithAngle(pos, 5, headingAngle, shiftAngle)
       time.sleep(2)
```

查询位置两侧车道边缘

```
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetDistanceToLaneBoundary(pos):
  print("SampleGetDistanceToLaneBoundary:")
  distanceToLaneBoundaryInfo = pySimOneSM.getDistanceToLaneBoundary
(pos);
  if distanceToLaneBoundaryInfo.exists == False:
    print("Not exists!")
    return
  print("laneld:", distanceToLaneBoundaryInfo.laneld.GetString())
  print("distToLeft:", distanceToLaneBoundaryInfo.distToLeft)
```

```
print("distToRight:", distanceToLaneBoundaryInfo.distToRight)
  print("distToLeft2D:", distanceToLaneBoundaryInfo.distToLeft2D)
  print("distToRight2D:", distanceToLaneBoundaryInfo.distToRight2D)
if name == main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
   if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       Sample Get Distance To Lane Boundary (pos) \\
       time.sleep(2)
查询车道信息
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
```

```
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
   print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def SampleGetLaneSample(laneId):
  print("SampleGetLaneSample:")
  sampleInfo = pySimOneSM.getLaneSample(laneId)
  if sampleInfo.exists == False:
     print("Not exists!")
     return
  leftBoundary = sampleInfo.laneInfo.leftBoundary
  print("leftBoundary knot size:", leftBoundary.Size())
  print("leftBoundary knot list:")
  for i in range(leftBoundary.Size()):
     element = leftBoundary.GetElement(i)
```

```
print("(", element.x, ",", element.y, ",", element.z, "),")
  rightBoundary = sampleInfo.laneInfo.rightBoundary
  print("rightBoundary knot size:", rightBoundary.Size())
  print("rightBoundary knot list:")
  for i in range(rightBoundary.Size()):
     element = rightBoundary.GetElement(i)
     print("(", element.x, ",", element.y, ",", element.z, "),")
  centerLine = sampleInfo.laneInfo.centerLine
  print("centerLine knot size:", centerLine.Size())
  print("centerLine knot list:")
  for i in range(centerLine.Size()):
     element = centerLine.GetElement(i)
     print("(", element.x, ",", element.y, ",", element.z, "),")
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
     if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
```

```
SampleGetLaneSample(laneId) time.sleep(2)
```

获取车道连接信息

```
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
```

return info.laneld

```
def SampleGetLaneLink(laneId):
  print("SampleGetLaneLink:")
  laneLinkInfo = pySimOneSM.getLaneLink(laneId)
  if laneLinkInfo.exists == False:
    print("Not exists!")
    return
  laneLink = laneLinkInfo.laneLink
  predecessorIds = laneLink.predecessorLaneIds
  print("predecessorLaneIds size:", predecessorIds.Size())
  if predecessorIds.Size() > 0:
    print("predecessorLaneIds:")
  for i in range(predecessorlds.Size()):
    element = predecessorIds.GetElement(i)
    print(element.GetString())
  successorIds = laneLink.successorLaneIds
  print("successorLaneIds size:", successorIds.Size())
  if successorIds.Size() > 0:
    print("successorLaneIds:")
  for i in range(successorIds.Size()):
    element = successorIds.GetElement(i)
    print(element.GetString())
  print("leftNeighborLaneId:", laneLink.leftNeighborLaneId.GetString())
  print("rightNeighborLaneId:", laneLink.rightNeighborLaneId.GetString())
if name ==' main ':
```

```
ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      SampleGetLaneLink(laneId)
      time.sleep(2)
获取车道类型
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
```

```
PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def SampleGetLaneType(laneId):
  print("SampleGetLaneType:")
  laneType = pySimOneSM.getLaneType(laneId)
  if laneType.exists == False:
    print("Not exists!")
    return S
  print("lane type:", laneType.laneType)
if __name__ == '__main__':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
```

```
if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      SampleGetLaneType(laneId)
      time.sleep(2)
获取车道宽度
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
```

```
if info.exists == False:
     print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetLaneWidth(laneId, pos):
  print("SampleGetLaneWidth:")
  laneWidthInfo = pySimOneSM.getLaneWidth(laneId, pos)
  if laneWidthInfo.exists == False:
     print("Not exists!")
    return
  print("lane width:", laneWidthInfo.width)
if __name__ == '__main__'
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
     if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
       SampleGetLaneWidth(laneId, pos)
       time.sleep(2)
```

获取在车道上的 ST 坐标

```
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneld
```

```
def SampleGetLaneST(laneId, pos):
  print("SampleGetLaneST:")
  stInfo = pySimOneSM.getLaneST(laneId, pos)
  if stInfo.exists == False:
    print("Not exists!")
    return
  print("[s,t] relative to this lane:", stlnfo.s, ",", stlnfo.t)
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
       SampleGetLaneST(laneId, pos)
       time.sleep(2)
获取在道路上的 ST 坐标
import os
import pySimOneSM
import time
from SimOneSMStruct import *
```

```
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetRoadST(laneId, pos):
  print("SampleGetRoadST:")
  stzInfo = pySimOneSM.getRoadST(laneId, pos)
  if stzInfo.exists == False:
    print("Not exists!")
    return
```

```
print("[s,t] relative to this road:", stzInfo.s, ",", stzInfo.t)
  print("height of input point:", stzInfo.z)
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      SampleGetRoadST(laneId, pos)
       time.sleep(2)
根据指定车道 id 和车道上的 ST 坐标获取局部坐标 xyz
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
```

```
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
   print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def SampleGetInertialFromLaneST(laneId, s, t):
  print("SampleGetInertialFromLaneST:")
  inertialFromLaneSTInfo = pySimOneSM.getInertialFromLaneST(laneId, s, t)
  if inertialFromLaneSTInfo.exists == False:
     print("Not exists!")
     return
  print("inertial vector: (", inertialFromLaneSTInfo.inertial.x, ",", inertialFromLa
neSTInfo.inertial.y, ",", inertialFromLaneSTInfo.inertial.z, "),")
  print("dir vector: (", inertialFromLaneSTInfo.dir.x, ",", inertialFromLaneSTInfo.
dir.y, ",", inertialFromLaneSTInfo.dir.z, "),")
```

```
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      s = 0.1
      t = 3.5
      SampleGetInertialFromLaneST(laneId, s, t)
      time.sleep(2)
查询指定车道是否存在于地图之中
import os
import pySimOneSM
import time
```

Global

from SimOneSMStruct import *

PosX = 0

PosY = 0

PosZ = 0

```
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleContainsLane(laneId):
  print("SampleContainsLane:")
  ret = pySimOneSM.containsLane(laneId)
  print("return state:", ret)
if __name__ == '__main__':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
```

```
if PosX != 0:
  print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
  pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
  laneId = SampleGetNearMostLane(pos)
  SampleContainsLane(laneld)
  time.sleep(2)
```

获取地图中停车位列表

```
import os
import pySimOneSM
import time
from SimOneSMStruct import *
def SampleGetParkingSpaceList():
  print("SampleGetParkingSpaceList:")
  parkingSpaceList = pySimOneSM.getParkingSpaceList()
  print("parkingSpace count:", parkingSpaceList.Size())
  for i in range(parkingSpaceList.Size()):
    parkingSpace = parkingSpaceList.GetElement(i)
     print("parkingSpace id:", parkingSpace.id)
    front = parkingSpace.front
    print("roadMark at which side:", front.side.GetString())
     print("roadMark type:", front.type)
    print("roadMark color:", front.color)
    print("roadMark width:", front.width)
     knots = parkingSpace.boundaryKnots
     print("boundaryKnots count:", knots.Size())
```

```
knot0 = knots.GetElement(0)
    print("knot0 point: (", knot0.x, ",", knot0.y, ",", knot0.z, ")")
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SampleGetParkingSpaceList():
获取预设规划路径
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetPredefinedRoute():
  print("SampleGetPredefinedRoute:")
```

```
routeInfo = pySimOneSM.getPredefinedRoute()
  if routeInfo.exists == False:
    print("Not exists!")
    return
  print("route point count:", routeInfo.route.Size())
  for i in range(routeInfo.route.Size()):
    pt = routeInfo.route.GetElement(i)
    print("route point: (", pt.x, ",", pt.y, ",", pt.z, "),")
if __name___ == '__main__':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  #SoApiSetGpsUpdateCB(gpsCB)
  SampleGetPredefinedRoute()
  time.sleep(2)
获取规划路径所途径道路的 ID 列表
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
```

```
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
   print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def SampleNavigate(inputPoints):
  print("SampleNavigate:")
  navigateInfo = pySimOneSM.navigate(inputPoints)
  if navigateInfo.exists == False:
     print("Not exists!")
     return
  print("roadIdList count:", navigateInfo.roadIdList.Size())
  for i in range(navigateInfo.roadIdList.Size()):
     roadId = navigateInfo.roadIdList.GetElement(i)
     print("roadId:", roadId)
  print("indexOfValidPoints count:", navigateInfo.indexOfValidPoints.Size())
```

```
for i in range(navigateInfo.indexOfValidPoints.Size()):
    index = navigateInfo.indexOfValidPoints.GetElement(i)
    print("index:", index)
if name == main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  inputPoints = pySimOneSM.pySimPoint3DVector()
  pt1 = pySimOneSM.pySimPoint3D(562.7,531.4,0)
  pt2 = pySimOneSM.pySimPoint3D(837.9,618.4,0)
  inputPoints.AddElement(pt1)
  inputPoints.AddElement(pt2)
  SampleNavigate(inputPoints)
  time.sleep(2)
根据指定车道 id 和局部坐标获取局部坐标左右两侧车道标线信息
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
```

```
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetRoadMark(pos, laneId):
  print("SampleGetRoadMark:")
  roadMarkInfo = pySimOneSM.getRoadMark(pos, laneId)
  if roadMarkInfo.exists == False:
    print("Not exists!")
    return
  left = roadMarkInfo.left
```

print("left roadMark sOffset:", left.sOffset)

print("left roadMark type:", left.type)

print("left roadMark color:", left.color)

```
print("left roadMark width:", left.width)
  right = roadMarkInfo.right
  print("right roadMark sOffset:", right.sOffset)
  print("right roadMark type:", right.type)
  print("right roadMark color:", right.color)
  print("right roadMark width:", right.width)
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
       SampleGetRoadMark(pos, laneId)
       time.sleep(2)
获取地图中交通灯列表
import os
import pySimOneSM
import time
```

from SimOneSMStruct import

```
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetTrafficLightList():
  print("SampleGetTrafficLightList:")
  trafficLightList = pySimOneSM.getTrafficLightList()
  print("trafficLight count:", trafficLightList.Size())
  for i in range(trafficLightList.Size()):
     light = trafficLightList.GetElement(i)
     print("light id:", light.id)
     print("light type:", light.type.GetString())
     print("light isDynamic:", light.isDynamic)
     print("validity count:", light.validities.Size())
     for j in range(light.validities.Size()):
       validity = light.validities.GetElement(j)
       print("validity roadId:", validity.roadId)
       print("validity fromLaneId:", validity.fromLaneId)
        print("validity toLaneId:", validity.toLaneId)
```

```
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  SampleGetTrafficLightList()
  time.sleep(2)
获取地图中交通标志牌列表
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
 PosZ = data[0].posZ
def SampleGetTrafficSignList():
```

```
print("SampleGetTrafficSignList:")
  trafficSignList = pySimOneSM.getTrafficSignList()
  print("trafficSign count:", trafficSignList.Size())
  for i in range(trafficSignList.Size()):
     sign = trafficSignList.GetElement(i)
    print("sign id:", sign.id)
    print("sign type:", sign.type.GetString())
     print("sign isDynamic:", sign.isDynamic)
    print("validity count:", sign.validities.Size())
    for j in range(sign.validities.Size()):
       validity = sign.validities.GetElement(j)
       print("validity roadId:", validity.roadId)
       print("validity fromLaneId:", validity.fromLaneId)
       print("validity toLaneId:", validity.toLaneId)
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  SampleGetTrafficSignList()
  time.sleep(2)
获取当前车道所属交通灯管辖的停止线列表
import os
import pySimOneSM
```

```
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetStoplineList(light, laneId):
  print("SampleGetStoplineList:")
  stoplineList = pySimOneSM.getStoplineList(light, laneId)
  print("stopline count:", stoplineList.Size())
```

```
for i in range(stoplineList.Size()):
     stopline = stoplineList.GetElement(i)
    print("stopline id:", stopline.id)
if name == main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  trafficLightList = pySimOneSM.getTrafficLightList()
  if trafficLightList.Size() < 1:</pre>
    print("No traffic light exists!")
     return
  light0 = trafficLightList.GetElement(0)
  while (1):
     if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
       SampleGetStoplineList(light0, laneId)
       time.sleep(2)
```

获取当前车道所属交通灯管辖的人行横道线列表

import os import pySimOneSM

```
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetCrosswalkList(light, laneld):
  print("SampleGetCrosswalkList:")
  crosswalkList = pySimOneSM.getCrosswalkList(light, laneId)
  print("crosswalk count:", crosswalkList.Size())
```

```
for i in range(crosswalkList.Size()):
    crosswalk = crosswalkList.GetElement(i)
    print("crosswalk id:", crosswalk.id)
if name == main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  trafficLightList = pySimOneSM.getTrafficLightList()
  if trafficLightList.Size() < 1:</pre>
    print("No traffic light exists!")
    return
  light0 = trafficLightList.GetElement(0)
  while (1):
    if PosX != 0:
       print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
       pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
       laneId = SampleGetNearMostLane(pos)
       SampleGetCrosswalkList(light0, laneId)
       time.sleep(2)
```

获取当前车道所在道路上的网格线列表

import os import pySimOneSM

```
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
    return
  print("lane id:", info.laneId.GetString())
  return info.laneId
def SampleGetCrossHatchList(laneId):
  print("SampleGetCrossHatchList:")
  crossHatchList = pySimOneSM.getCrossHatchList(laneId)
  print("crossHatch count:", crossHatchList.Size())
```

```
for i in range(crossHatchList.Size()):
    crossHatch = crossHatchList.GetElement(i)
    print("crossHatch id:", crossHatch.id)
if name == main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
   if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      SampleGetCrossHatchList(laneId)
      time.sleep(2)
根据指定车道 id 和局部坐标获取局部坐标到车道中心线上的投影点信息
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
```

```
PosZ = 0

def gpsC

global
```

```
def gpsCB(mainVehicleId, data):
  global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetNearMostLane(pos):
  print("SampleGetNearMostLane:")
  info = pySimOneSM.getNearMostLane(pos)
  if info.exists == False:
    print("Not exists!")
     return
  print("lane id:", info.laneId.GetString())
  return info.laneld
def SampleGetLaneMiddlePoint(pos, laneId):
  print("SampleGetLaneMiddlePoint:")
  laneMiddlePointInfo = pySimOneSM.getLaneMiddlePoint(pos, laneId)
  if laneMiddlePointInfo.exists == False:
     print("Not exists!")
     return
  print("targetPoint vector: (", laneMiddlePointInfo.targetPoint.x, ",", laneMidd
lePointInfo.targetPoint.y, ",", laneMiddlePointInfo.targetPoint.z, "),")
  print("dir vector: (", laneMiddlePointInfo.dir.x, ",", laneMiddlePointInfo.dir.y,
",", laneMiddlePointInfo.dir.z, "),")
```

```
if name == ' main ':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  while (1):
    if PosX != 0:
      print("gpsCB: X:{0} Y:{1} Z:{2}".format(PosX, PosY, PosZ))
      pos = pySimOneSM.pySimPoint3D(PosX, PosY, PosZ)
      laneId = SampleGetNearMostLane(pos)
      SampleGetLaneMiddlePoint(pos, laneId)
      time.sleep(2)
得到仿真场景中的交通灯的真值
import os
import pySimOneSM
import time
from SimOneSMStruct import *
# Global
PosX = 0
PosY = 0
PosZ = 0
def gpsCB(mainVehicleId, data):
```

```
global PosX, PosY, PosZ
  PosX = data[0].posX
  PosY = data[0].posY
  PosZ = data[0].posZ
def SampleGetTrafficLight():
  print("SampleGetTrafficLightList:")
  trafficLightList = pySimOneSM.getTrafficLightList()
  TrafficLight = SimOne Data TrafficLight()
  print("trafficLight count:", trafficLightList.Size())
  for i in range(trafficLightList.Size()):
   light = trafficLightList.GetElement(i)
     print("light id:", light.id)
     if SoGetTrafficLights(0, light.id, TrafficLight):
       print("light status:", TrafficLight.status)
if __name__ == '__main__':
  ret = pySimOneSM.loadHDMap(20)
  print("Load xodr success:", ret)
  SoApiStart()
  SoApiSetGpsUpdateCB(gpsCB)
  SampleGetTrafficLight()
  time.sleep(2)
```

C++ API reference(1.0)

仿真系统和自动驾驶系统数据通信接口

被测车辆 GPS 和底盘信息

获取主车 GPS 信息

SIMONE_SM_API bool SetGpsUpdateCB(void(cb)(int mainVehicleId, SimOne_Data_Gps pGps))

参数说明

入参

cb
 GPS data update callback function

出参

SimOne_Data_Gps(struct)

GPS data

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)

- float velX:MainVehicle Velocity X on Opendrive (by meter)
- float velY:MainVehicle Velocity Y on Opendrive (by meter)
- float velZ:MainVehicle Velocity Z on Opendrive (by meter)
- float throttle:MainVehicle throttle
- float brake:MainVehicle brake
- float steering:MainVehicle Steering angle
- int gear:MainVehicle gear position
- float accelX:MainVehicle Acceleration X on Opendrive (by meter)
- float accelY:MainVehicle Acceleration Y on Opendrive (by meter)
- float accelZ:MainVehicle Acceleration Z on Opendrive (by meter)
- float angVelX:MainVehicle Angular Velocity X on Opendrive (by meter)
- float angVelY:MainVehicle Angular Velocity Y on Opendrive (by meter)
- float angVelZ:MainVehicle Angular Velocity Z on Opendrive (by meter)
- float wheelSpeedFL:Speed of front left wheel (by meter/sec)
- float wheelSpeedFR:Speed of front right wheel (by meter/sec)
- float wheelSpeedRL:Speed of rear left wheel (by meter/sec)
- float wheelSpeedRR:Speed of rear right wheel (by meter/sec)

return(bool)

Success or not

SIMONE_SM_API bool GetGps(int mainVehicleId, SimOne_Data_Gps *pGps)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

出参

SimOne_Data_Gps(struct)

GPS data

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)
- float velX:MainVehicle Velocity X on Opendrive (by meter)
- float velY:MainVehicle Velocity Y on Opendrive (by meter)
- float velZ:MainVehicle Velocity Z on Opendrive (by meter)
- float throttle:MainVehicle throttle
- float brake:MainVehicle brake

- float steering:MainVehicle Steering angle
- int gear:MainVehicle gear position
- float accelX:MainVehicle Acceleration X on Opendrive (by meter)
- float accelY:MainVehicle Acceleration Y on Opendrive (by meter)
- float accelZ:MainVehicle Acceleration Z on Opendrive (by meter)
- float angVelX:MainVehicle Angular Velocity X on Opendrive (by meter)
- float angVelY:MainVehicle Angular Velocity Y on Opendrive (by meter)
- float angVelZ:MainVehicle Angular Velocity Z on Opendrive (by meter)
- float wheelSpeedFL:Speed of front left wheel (by meter/sec)
- float wheelSpeedFR:Speed of front right wheel (by meter/sec)
- float wheelSpeedRL:Speed of rear left wheel (by meter/sec)
- float wheelSpeedRR:Speed of rear right wheel (by meter/sec)

return(bool)

Success or not

被测车辆周围角色状态

得到仿真场景中的物体的真值

SIMONE_SM_API bool SetGroundTruthUpdateCB(void(cb)(int mainVehicleId, SimOne Data Obstacle pObstacle))

参数说明

入参

cb

Obstacle data fetch callback function

出参

SimOne_Data_Obstacle(struct)

Obstacle data

- int obstacleSize:Obstacle size
- SimOne_Data_Obstacle_Entry
 obstacle[SOSM_OBSTACLE_SIZE_MAX]:Obstacle, 100 max
 - int id:Obstacle ID
 - SimOne_Obstacle_Type type:Obstacle Type
 - ESimOne_Obstacle_Type_Unknown = 0
 - ESimOne_Obstacle_Type_Pedestrian = 4
 - ESimOne_Obstacle_Type_Car = 6
 - ESimOne_Obstacle_Type_Static = 7
 - ESimOne_Obstacle_Type_Bicycle = 8
 - ESimOne_Obstacle_Type_RoadMark = 12
 - ESimOne_Obstacle_Type_TrafficSign = 13

- ESimOne_Obstacle_Type_TrafficLight = 15
- ESimOne_Obstacle_Type_Rider = 17
- ESimOne_Obstacle_Type_Truck = 18
- ESimOne_Obstacle_Type_Bus = 19
- ESimOne_Obstacle_Type_Train = 20
- ESimOne_Obstacle_Type_Motorcycle = 21
- ESimOne_Obstacle_Type_SpeedLimitSign = 26
- ESimOne_Obstacle_Type_BicycleStatic = 27
- ESimOne_Obstacle_Type_RoadObstacle = 29
- float theta:Obstacle vertical rotation (by radian)
- float posX:Obstacle Position X on Opendrive (by meter)
- float posY:Obstacle Position Y on Opendrive (by meter)
- float posZ:Obstacle Position Z on Opendrive (by meter)
- float velX:Obstacle Velocity X on Opendrive (by meter)
- float velY:Obstacle Velocity Y on Opendrive (by meter)
- float velZ:Obstacle Velocity Z on Opendrive (by meter)
- float length:Obstacle length
- float width:Obstacle width
- float height:Obstacle height

return(bool)

Success or not

SIMONE_SM_API bool GetGroundTruth(int mainVehicleId, SimOne Data Obstacle *pObstacle)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

出参

SimOne_Data_Obstacle(struct)

Obstacle data

- int obstacleSize:Obstacle size
- SimOne_Data_Obstacle_Entry
 obstacle[SOSM OBSTACLE SIZE MAX]:Obstacle, 100 max
 - int id:Obstacle ID
 - SimOne_Obstacle_Type type:Obstacle Type
 - ESimOne_Obstacle_Type_Unknown = 0
 - ESimOne_Obstacle_Type_Pedestrian = 4
 - ESimOne_Obstacle_Type_Car = 6
 - ESimOne_Obstacle_Type_Static = 7
 - ESimOne_Obstacle_Type_Bicycle = 8
 - ESimOne_Obstacle_Type_RoadMark = 12

- ESimOne_Obstacle_Type_TrafficSign = 13
- ESimOne_Obstacle_Type_TrafficLight = 15
- ESimOne_Obstacle_Type_Rider = 17
- ESimOne_Obstacle_Type_Truck = 18
- ESimOne_Obstacle_Type_Bus = 19
- ESimOne_Obstacle_Type_Train = 20
- ESimOne_Obstacle_Type_Motorcycle = 21
- ESimOne_Obstacle_Type_SpeedLimitSign = 26
- ESimOne_Obstacle_Type_BicycleStatic = 27
- ESimOne_Obstacle_Type_RoadObstacle = 29
- float theta:Obstacle vertical rotation (by radian)
- float posX:Obstacle Position X on Opendrive (by meter)
- float posY:Obstacle Position Y on Opendrive (by meter)
- float posZ:Obstacle Position Z on Opendrive (by meter)
- float velX:Obstacle Velocity X on Opendrive (by meter)
- float velY:Obstacle Velocity Y on Opendrive (by meter)
- float velZ:Obstacle Velocity Z on Opendrive (by meter)
- float length:Obstacle length
- float width:Obstacle width
- float height:Obstacle height

return(bool)

Success or not

获取案例主车路径的终点

获取案例主车的终点

SIMONE_SM_API bool GetTerminalPoint(SimOne_Data_WayPoints_Entry* terminal)

参数说明

入参

• SimOne Data WayPoints Entry(Pointer)

出参

- SimOne_Data_WayPoints_Entry(struct)
 - posX
 - posY

return(bool)

Success or not

被测车辆 Pose 操控

设置主车位置

SIMONE_SM_API bool SetPose(int mainVehicleId, SimOne_Data_Pose_Control *pPose)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

SimOne_Data_Pose_Control(struct)

Pose to set

- float posX:Position X on Opendrive (by meter)
- float posY:Position Y on Opendrive (by meter)
- float posZ:Position Z on Opendrive (by meter)
- float oriX:Rotation X on Opendrive (by radian)
- float oriY:Rotation Y on Opendrive (by radian)
- float oriZ:Rotation Z on Opendrive (by radian)
- bool autoZ = false;// Automatically set Z according to scene

出参

无

return(bool)

Success or not

被测车辆 Drive 操控

主车控制

SIMONE_SM_API bool SetDrive(int mainVehicleId, SimOne_Data_Control *pControl)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

SimOne_Data_Control(struct)

vehicle control data

- float throttle
- float brake
- float steering
- bool handbrake = false
- bool isManualGear = false
- EGearMode gear:gear location
 - EGearMode Neutral = 0
 - EGearMode Drive = 1:forward gear for automatic gear
 - EGearMode Reverse = 2
 - EGearMode Parking = 3
 - EGearManualMode 1 = 4:forward gear 1 for manual gear
 - EGearManualMode 2 = 5

- EGearManualMode 3 = 6
- EGearManualMode 4 = 7
- EGearManualMode 5 = 8
- EGearManualMode 6 = 9
- EGearManualMode 7 = 10
- EGearManualMode 8 = 11

出参

无

return(bool)

Success or not

设置主车预警消息

主车预警消息设置

SIMONE_SM_API bool SetVehicleEvent(int mainVehicleId, SimOne Data Vehicle EventInfo *pVehicleEvent);

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

- SimOne_Data_Vehicle_EventInfo(struct)
 - ESimone_Vehicle_EventInfo_Type(struct)

- ESimOne_VehicleEventInfo_Forward_Collision = 0
- ESimOne_VehicleEventInfo_Backward_Collision = 1
- ESimOne_VehicleEventInfo_Left_Turn = 2
- ESimOne_VehicleEventInfo_Right_Turn = 3
- ESimOne_VehicleEventInfo_Forward_Straight = 4
- ESimOne_VehicleEventInfo_Over_Speed = 5

出参

无

return(bool)

Success or not

获取当前环境相关信息 (天气、光照、地面等)

获取当前环境相关信息 (天气、光照、地面等)

SIMONE_SM_API bool GetEnvironment(SimOne_Data_Environment *pEnvironment)

参数说明

入参

无

出参

- SimOne_Data_Environment(struct)
 - timeOfDay(float)

- time of day [0, 2400]
- heightAngle(float)height angle [0, 90]
- directionalLight(float)light for sun or moon [0, 1]
- ambientLight(float)ambient light [0, 1]
- artificialLight(float)artificial light [0, 1]
- cloudDensity(float)cloud density [0, 1]
- fogDensity(float)fog density [0, 1]
- rainDensity(float)rain density [0, 1]
- snowDensity(float)snow density [0, 1]
- groundHumidityLevel(float)ground humidity level [0, 1]
- groundDirtyLevel(float)

ground dirty level [0, 1]

return(bool)

Success or not

设置当前环境相关信息 (天气、光照、地面等)

设置当前环境相关信息 (天气、光照、地面等)

SIMONE_SM_API bool SetEnvironment(SimOne_Data_Environment *pEnvironment)

参数说明

入参

- SimOne_Data_Environment(struct)
 - timeOfDay(float)time of day [0, 2400]
 - heightAngle(float)height angle [0, 90]
 - directionalLight(float)light for sun or moon [0, 1]
 - ambientLight(float)ambient light [0, 1]
 - artificialLight(float)artificial light [0, 1]

- cloudDensity(float)
 - cloud density [0, 1]
- fogDensity(float)
 - fog density [0, 1]
- rainDensity(float)
 - rain density [0, 1]
- snowDensity(float)
 - snow density [0, 1]
- groundHumidityLevel(float)ground humidity level [0, 1]
- groundDirtyLevel(float)ground dirty level [0, 1]

出参

无

return(bool)

Success or not

设置车辆信号灯状态

设置车辆各信号灯的状态

SIMONE_SM_API bool SetSignalLights(const int mainVehicleId, SimOne Data Signal Lights* pSignalLights)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

出参

- SimOne_Data_Signal_Lights(struct)
 - SimOne_Signal_Light(struct)
 - ESimOne_Signal_Light_RightBlinker = 1
 - ESimOne Signal Light LeftBlinker = (1 << 1)
 - ESimOne_Signal_Light_DoubleFlash = (1 << 2)
 - ESimOne_Signal_Light_BrakeLight = (1 << 3)</pre>
 - ESimOne_Signal_Light_FrontLight = (1 << 4)</pre>
 - ESimOne Signal Light HighBeam = (1 << 5)
 - ESimOne_Signal_Light_BackDrive = (1 << 6)</p>

return(bool)

Success or not

获取 SimOneDriver 状态

获取 SimOneDriver 对于主车的控制状态

SIMONE_SM_API bool GetDriverStatus(const int mainVehicleId, SimOne Data Driver Status* pDriverStatus)

参数说明

入参

mainVehicleId(int)

Vehicle index, configuration order from scenario editing, starting from 0

出参

- SimOne_Data_Driver_Status(struct)
 - SimOne_Driver_Status(struct)
 - ESimOne Driver Status Unknown = 0
 - ESimOne Driver Status Controlling = 1
 - ESimOne Driver Status Disabled = 2

return(bool)

Success or not

高精地图运行时接口

获取最临近车道

获取最接近输入点的车道, 所属车道优先

SIMONE_SM_API bool GetNearMostLane(const SSD::SimPoint3D& pos, SSD::SimString& id, double& s, double& t, double& s_toCenterLine, double& t_toCenterLine)

参数说明

入参

pos(SimPoint3D)Input 3d location

出参

id(SimString)

Lane ID of founded lane. ID with this format roadId_sectionIndex_laneId

• s, t(double)

The input point's value pair in s-t coordinate system, relative to the found lane

s_toCenterLine, t_toCenterLine(double)

is the input point' s value pair in s-t coordinate system, relative to the found lane' s owner road' s center line.

return(bool)

True when any lane is found, else returns false

获取临近车道列表

获取临近车道列表

SIMONE_SM_API bool GetNearLanes(const SSD::SimPoint3D& pos, const double& distance, SSD::SimStringVector& nearLanes)

参数说明

入参

- pos(SimPoint3D)Input 3d location
- distance(double)
 Input range distance

出参

nearLanes(SimStringVector)
 Lane IDs of founded lanes. Each ID with this format roadId_sectionIndex_laneId

return(bool)

True when any lane(lanes) is(are) found, else returns false

获取视野范围内所有车道

获取视野范围内所有车道

SIMONE_SM_API bool GetNearLanesWithAngle(const SSD::SimPoint3D& pos, const double& distance,const double& headingAngle, const double& angleShift, SSD::SimStringVector& nearLanes)

参数说明

入参

pos(SimPoint3D)

Input 3d location

distance(double)

Input distance range to search

headingAngle(double)

A specified heading direction's angle relative to x-axis in 2d-inertial system. heading Angle is defined as radian

angleShift(double)

To help define the range of angle as [headingAngle - angleShift, headingAngle + angleShift], and angleShift is defined as radian

出参

nearLanes(SimStringVector)

Lane IDs of founded lanes. Each ID with this format roadId_sectionIndex_laneId

return(bool)

True when any lane(lanes) is(are) found, else returns false

获取离车道左右边缘线的距离

获取输入点离最近车道的左右边缘线的距离信息

SIMONE_SM_API bool GetDistanceToLaneBoundary(const SSD::SimPoint3D& pos, SSD::SimString& id, double& distToLeft, double& distToRight, double& distToRight2D)

参数说明

入参

pos(SimPoint3D)Input 3d location

出参

id(SimString)

Lane ID of founded lane. ID with this format roadId_sectionIndex_laneId

distToLeft(double)

The distance to boundaries in 3d space

distToRight(double)

The distance to boundaries in 3d space

distToLeft2D(double)

The distance to boundaries in 3d space

distToRight2D(double)

The distance to boundaries in 2d space(ignore height)

return(bool)

True if near most lane is found, else returns false

获取车道信息

获取车道信息(包含车道 ID, 左右边缘线,虚拟中心线)

SIMONE_SM_API bool GetLaneSample(const SSD::SimString &id, HDMapStandalone::MLaneInfo& info)

参数说明

入参

id(SimString)
 Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

info(MLaneInfo)

Lane information(HDMapStandalone::MLaneInfo) of specified lane

- laneName(SimString)
 formatted as roadId sectionIndex laneId
- leftBoundary(SimPoint3DVector)
 sample point list of left boundary
- rightBoundary(SimPoint3DVector)
 sample point list of right boundary
- centerLine(SimPoint3DVector)sample point list of center line

return(bool)

True if specified lane exists in the map, else returns false

获取车道连接信息

获取车道连接信息

SIMONE_SM_API bool GetLaneLink(const SSD::SimString& id, HDMapStandalone::MLaneLink& laneLink)

参数说明

入参

id(SimString)
 Input lane ID. ID with this format roadId sectionIndex laneId

出参

laneLink(MLaneLink)

Lane link information(HDMapStandalone::MLaneLink) of specified lane

- predecessorLaneNameList(SimStringVector)
 lane' s predecessors' laneName list, formatted as roadId_sectionIndex_laneId
- successorLaneNameList(SimStringVector)
 lane' s successors' laneName list, formatted as roadId sectionIndex laneId
- leftNeighborLaneName(SimStringVector)
 lane's left neighbor's laneName, formatted as roadId_sectionIndex_laneId

rightNeighborLaneName(SimStringVector)
 lane' s right neighbor' s laneName, formatted as roadId_sectionIndex_laneId

return(bool)

True if specified lane exists in the map, else returns false

获取车道类型

获取车道类型

SIMONE_SM_API bool GetLaneType(const SSD::SimString& id, HDMapStandalone::MLaneType& laneType)

参数说明

入参

• id(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

laneType(MLaneType)

Lane type of specified lane

- none
- driving
- stop
- shoulder
- biking

- sidewalk
- border
- restricted
- parking
- bidirectional
- median
- special1
- special2
- special3
- roadWorks
- tram
- rail
- entry
- exit
- offRamp
- onRamp
- mwyEntry
- mwyExit

return(bool)

True if specified lane exists in the map, else returns false

获取车道宽度

获取车道宽度

SIMONE_SM_API bool GetLaneWidth(const SSD::SimString& id, const SSD::SimPoint3D& pos, double& width)

参数说明

入参

• id(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

出参

• width(double)

lane width of specified lane

return(bool)

True if specified lane exists in the map, else returns false

获取在车道上的 ST 坐标

获取相对于车道虚拟中心线的 ST 坐标

SIMONE_SM_API bool GetLaneST(const SSD::SimString& id, const SSD::SimPoint3D& pos, double& s, double& t)

参数说明

入参

id(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

出参

s(double)

The input point's value pair in s-t coordinate system, relative to specified lane.

t(double)

The input point's value pair in s-t coordinate system, relative to specified lane.

return(bool)

True if specified lane exists in the map, else returns false

获取在道路上的 ST 坐标

获取相对于道路参考线的 ST 坐标

SIMONE_SM_API bool GetRoadST(const SSD::SimString& id, const SSD::SimPoint3D& pos, double& s, double& t, double& z)

参数说明

入参

id(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

pos(SimPoint3D)

Input 3d location

出参

• s, t, z(double)

[s, t] represents the input point' s value pair in s-t coordinate system, and z represents the input point' s height value in localENU.

查询指定车道是否存在于地图之中

查询指定车道是否存在于地图之中

SIMONE_SM_API bool ContainsLane(const SSD::SimString& id)

参数说明

入参

id(SimString)

Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

无

return(bool)

True if exists, else returns false

获取地图中停车位列表

获取地图中停车位列表

SIMONE_SM_API void

GetParkingSpaceList(SSD::SimVector<HDMapStandalone::MParkingSpace >& parkingSpaceList)

参数说明

入参

• 7.

出参

- parkingSpaceList(SimVector)
- id
 - pt
 - 10

 - 7
 - heading
 - X
 - \
 - Z
 - boundaryKnots
 - X
 - \circ
 - Z

- front
 - side

- type
- color
- width
- rear
 - side
 - type
 - color
 - width
- left
 - side
 - type
 - color
 - width
- right
 - side
 - type
 - color
 - width

True if specified parking space exists in the map, else returns false

获取预设规划路径

获取预设规划路径

SIMONE_SM_API bool GetPredefinedRoute(SSD::SimPoint3DVector&route);

参数说明

入参

无

出参

route

Generated route

- x
- \
- Z

return(bool)

True if exists, else returns false

获取规划路径所途径道路的 ID 列表

获取规划路径所途径道路的 ID 列表

SIMONE_SM_API bool Navigate(const SSD::SimPoint3DVector& inputPoints, SSD::SimVector<int>& indexOfValidPoints, SSD::SimVector<long>& roadIdList)

参数说明

入参

inputPoints
 Input points that to guide generated route should pass over

出参

indexOfValidPoints

Pick valid ones from input points. Valid ones will be used for generting route

roadIdList(SimVector)

road id list that are throughed by routing path

return(bool)

True if exists, else returns false

根据指定车道 id 和局部坐标获取输入点左右两侧车道标线信息

根据指定车道 id 和局部坐标获取输入点左右两侧车道标线信息

SIMONE_SM_API bool GetRoadMark(const SSD::SimPoint3D& pos, const SSD::SimString& id, HDMapStandalone::MRoadMark& left, HDMapStandalone::MRoadMark& right)

参数说明

入参

- pos
 - Input 3d location
- id
 - Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

- left
 - Left side roadmark
 - sOffset
 - length
 - width
 - type
 - color
- right
 - Right side roadmark
 - sOffset
 - length
 - width
 - tvpe
 - color

return(bool)

True if exists, else returns false

获取地图中信号灯列表

获取地图中信号灯列表

SIMONE_SM_API void

GetTrafficLightList(SSD::SimVector<HDMapStandalone::MSignal>& list)

参数说明

入参

无

出参

list

Traffic light object list

- id
- type
- subType
- pt(SimPoint3D)
 - X
 - V
 - Z
- heading

- valueunitisDynamic(bool)
 - validities(SimVector)

获取地图中交通标志列表

获取地图中交通标志列表

SIMONE_SM_API void

GetTrafficSignList(SSD::SimVector<HDMapStandalone::MSignal>& list)

参数说明

入参

无

出参

list

Traffic sign object list

- id
- type
- subType
- pt(SimPoint3D)
 - X
 - y

- heading
- value
- unit
- isDynamic(bool)
- validities(SimVector)

获取交通灯给定作用车道的关联停止线列表

获取交通灯给定作用车道的关联停止线列表

SIMONE_SM_API void GetStoplineList(const HDMapStandalone::MSignal& light, const SSD::SimString& id,

SSD::SimVector<HDMapStandalone::MObject>& stoplineList)

参数说明

入参

- light
 Traffic light object
- id
 Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

stoplineList

Stoplines list that is associated

id

- type
- pt(SimPoint3D)
 - X
 - y
 - z
- boundaryKnots(SimPoint3DVector)

获取交通灯给定作用车道的关联人行横道线列表

获取交通灯给定作用车道的关联人行横道线列表

SIMONE_SM_API void GetCrosswalkList(const

HDMapStandalone::MSignal& light, const SSD::SimString& id,

SSD::SimVector<HDMapStandalone::MObject>& crosswalkList)

参数说明

入参

- light
 Traffic light object
- id
 Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

crosswalkList

Crosswalks list that is associated

io

- type
- pt(SimPoint3D)
 - X
 - y
 - z
- boundaryKnots(SimPoint3DVector)

获取指定车道所在道路上的网状线列表

获取指定车道所在道路上的网状线列表

SIMONE_SM_API void GetCrossHatchList(const SSD::SimString& id, SSD::SimVector<HDMapStandalone::MObject>& crossHatchList)

参数说明

入参

- light
 - Traffic light object
- id

Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

- crossHatchList
 - Cross hatches list that is associated
 - io

- type
- pt(SimPoint3D)
 - X
 - y
 - z
- boundaryKnots(SimPoint3DVector)

获取输入点投影到指定车道中心线上的点和切线方向

获取输入点投影到指定车道中心线上的点和该点处对应中心线的切线方向

SIMONE_SM_API bool GetLaneMiddlePoint(const SSD::SimPoint3D& inputPt, const SSD::SimString& id, SSD::SimPoint3D& targetPoint, SSD::SimPoint3D& dir)

参数说明

入参

- inputPtInput 3d location
- id
 Input lane ID. ID with this format roadId_sectionIndex_laneId

出参

targetPoint

The target point that is on specified lane's middle line

x(double)

- y(double)
- z(double)
- dir

The tangent direction on the target point on lane's middle line

- X
- y
- **–** 7

return(bool)

True if exists, else returns false

得到仿真场景中的交通灯的真值

得到仿真场景中的交通灯的真值

SIMONE_SM_API bool GetTrafficLights(int mainVehicleId, int opendriveLightId, SimOne_Data_TrafficLight* pTrafficLight)

参数说明

入参

mainVehicleId

Vehicle index, configure order of web UI, starts from 0

opendriveLightId

LightId

出参

• SimOne_Data_TrafficLight(struct)

light data

- index(int)
- opendriveLightId(int)
- countDown
- status(SimOne_TrafficLight_Status)
 - ESimOne_TrafficLight_Status_Invalid = 0,
 - ESimOne TrafficLight Status Red = 1,
 - ESimOne_TrafficLight_Status_Green = 2,
 - ESimOne TrafficLight Status Yellow = 3,
 - ESimOne TrafficLight Status RedBlink = 4,
 - ESimOne TrafficLight Status GreenBlink = 5,
 - ESimOne_TrafficLight_Status_YellowBlink = 6,
 - ESimOne_TrafficLight_Status_Black = 7

return(bool)

True if exists, else returns false

C++ Code Recipes(1.0)

仿真系统和自动驾驶系统数据通信接口

被测车辆 GPS 和底盘信息

```
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
  //方法一: 通过回调方法获得数据更新
  SimOneSM::Start();
  SimOneSM::SetGpsUpdateCB([](int mainVehicleId, SimOne Data Gps *pGps)
    printf("gpsCB: V:%d GPS:%d X:%.2f Y:%.2f\n", mainVehicleId, pGps->time
stamp, pGps->posX, pGps->posY);
  });
  while (1)
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
```

```
std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, pGps.get()))
      printf("Fetch GPS failed\n");
    printf("gps: GPS timestamp:%d X:%.2f\n", pGps->timestamp, pGps
->posX, pGps->posY);
  return 0;
被测车辆周围角色状态
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
  //方法一:通过回调方法获得数据更新
  SimOneSM::Start();
  SimOneSM::SetGroundTruthUpdateCB([](int mainVehicleId, SimOne Data O
bstacle *pObstacle){
    printf("GroundTruthUpdateCB: V:%d OBS:%d N:%d\n", mainVehicleId, pO
```

```
bstacle->obstacleSize);
  });
  while (1)
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
  //方法二:直接获取最新的数据
  std::unique_ptr<SimOne_Data_Obstacle = std::make_unique<Si
mOne_Data_Obstacle>();
  while (1)
    if (!SimOneSM::GetGroundTruth(0/*vehicleId*/, pObstacle.get()))
      printf("Get obstacle failed\n");
    printf("GetGroundTruth success: OBS:%d N:%d\n", pObstacle->obstacleSi
ze);
  return 0;
获取案例主车路径的终点
#include "SimOneSMAPI.h"
#include <iostream>
```

```
SimOne Data WayPoints Entry terminal;
int main(int argc, char* argv[])
  if (SimOneSM::GetTerminalPoint(&terminal))
    std::cout < < terminal.posX < < std::endl;
    std::cout < < terminal.posY < < std::endl;
被测车辆 Pose 操控
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
  //方法一: 通过回调方法获得数据更新
  SimOneSM::Start();
  SimOneSM::SetGpsUpdateCB([](int mainVehicleId, SimOne_Data_Gps *pGps)
    printf("gpsCB: V:%d GPS:%d X:%.2f\n", mainVehicleId, pGps->time
stamp, pGps->posX, pGps->posY);
```

```
std::unique_ptr<SimOne_Data_Pose_Control> posePtr = std::make_uniqu
e<SimOne Data Pose Control>();
    // must need
    posePtr->timestamp = pGps->timestamp;
    // Shift along X axis
    posePtr->posX = pGps->posX + 0.01;
    posePtr->posY = pGps->posY;
    posePtr->posZ = pGps->posZ;
    if (!SimOneSM::SetPose(0, posePtr.get()))
       printf("Set Pose failed\n");
  });
  while (1)
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
  //方法二:直接获取最新的数据
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
```

```
// Shift along X axis
    std::unique ptr<SimOne Data Pose Control> posePtr = std::make uniqu
e<SimOne Data Pose Control>();
    // must need
    posePtr->timestamp = gpsPtr->timestamp;
    posePtr->posX = gpsPtr->posX + 0.01;
    posePtr->posY = gpsPtr->posY;
    posePtr->posZ = gpsPtr->posZ;
    if (!SimOneSM::SetPose(0/*vehicleId*/, posePtr.get()))
       printf("Set Pose failed\n");
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
被测车辆 Drive 操控
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
```

```
//方法一:通过回调方法获得数据更新
  SimOneSM::Start();
  SimOneSM::SetGpsUpdateCB([](int mainVehicleId, SimOne Data Gps *pGps)
    printf("gpsCB: V:%d GPS:%d X:%.2f\n", mainVehicleId, pGps->time
stamp, pGps->posX, pGps->posY);
    std::unique ptr<SimOne Data Control> controlPtr = std::make unique<S
imOne Data Control>();
    // must need
    controlPtr->timestamp = pGps->timestamp;
    controlPtr->throttle = 0.5;
    controlPtr->steering = 0.0f;
    controlPtr->gear = EGearMode::EGearManualMode 1;
    if (!SimOneSM::SetDrive(0/*vehicleId*/, controlPtr.get()))
      printf("SetDrive failed\n");
  });
  while (1)
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
```

```
//方法二:直接获取最新的数据
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
   std::unique ptr<SimOne Data Control> controlPtr = std::make unique<S
imOne Data Control>();
    // must need
    controlPtr->timestamp = gpsPtr->timestamp;
    controlPtr->throttle = 0.5;
    controlPtr->steering = 0.0f;
    controlPtr->gear = EGearMode::EGearManualMode_1;
    if (!SimOneSM::SetDrive(0/*vehicleId*/, controlPtr.get()))
       printf("SetDrive failed\n");
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
```

设置主车预警信息

```
#include "SimOneSMAPI.h"
#include <memory>
int main(int argc, char* argv[]) {
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  std::unique ptr<SimOne Data Vehicle EventInfo> vehicleEventPtr = std::ma
ke_unique < SimOne_Data_Vehicle_EventInfo > ();
  while(1){
    if (SimOneSM::GetGps(0, gpsPtr.get())) {
       vehicleEventPtr->timestamp = gpsPtr->timestamp;
    else {
         printf("Fetch GPS failed\n");
    vehicleEventPtr->type = ESimone_Vehicle_EventInfo_Type::ESimOne_Vehi
cleEventInfo Forward Collision;
    SimOneSM::SetVehicleEvent(0, vehicleEventPtr.get());
  return 0;
```

获取当前环境相关信息 (天气、光照、地面等)

```
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
  std::unique ptr<SimOne Data Environment > environmentPtr = std::make
unique < SimOne Data Environment > ();
  while (1)
    if (!SimOneSM::GetEnvironment(environmentPtr.get()))
       std::cout << "Get Environment failed" << std::endl;
       std::this thread::sleep for(std::chrono::milliseconds(100));
       continue;
    std::cout << "timeOfDay:" << environmentPtr->timeOfDay << " heightA
ngle:" << environmentPtr->heightAngle
     << " directionalLight:" << environmentPtr->directionalLight << " ambi</pre>
entLight:" << environmentPtr->ambientLight
       << " artificialLight:" << environmentPtr->artificialLight << " cloudDen
sity:" << environmentPtr->cloudDensity
```

```
<< " fogDensity:" << environmentPtr->fogDensity << " rainDensity:"
<< environmentPtr->rainDensity
      << " snowDensity:" << environmentPtr->snowDensity << " groundHu
midityLevel:" << environmentPtr->groundHumidityLevel
       << " groundDirtyLevel:" << environmentPtr->groundDirtyLevel << st
d::endl;
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
设置当前环境相关信息 (天气、光照、地面等)
#include "SimOneSMAPI.h"
#include <vector>
#include <chrono>
#include <thread>
int main(int argc, char* argv[])
  std::unique ptr<SimOne Data Environment > environmentPtr = std::make
unique < SimOne Data Environment > ();
  while (1)
    if (!SimOneSM::GetEnvironment(environmentPtr.get()))
```

```
std::cout << "Get Environment failed << std::endl;
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    // 设置时间
    environmentPtr->directionalLight += 0.05;
    if (environmentPtr->directionalLight > 1)
       environmentPtr->directionalLight = 0;
    SimOneSM::SetEnvironment(environmentPtr.get()
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
设置车辆信号灯状态
#include "SimOneSMAPI.h"
#include <iostream>
int main(int argc, char* argv[])
  SimOneSM::Start();
```

```
std::unique_ptr<SimOne_Data_Signal_Lights> pSignalLights = std::make_uni
que < SimOne Data Signal Lights > ();
  std::unique ptr<SimOne Data Control> pdriver = std::make unique<SimOn
e Data Control>();
  std::unique ptr<SimOne Data Gps> pGPS = std::make unique<SimOne Da
ta Gps>();
  SimOneSM::GetGps(0, pGPS.get());
  pdriver->timestamp = pGPS->timestamp;
  pdriver->gear = EGearMode::EGearManualMode_1;
  pdriver->throttle = 0.5;
  SimOneSM::SetDrive(0, pdriver.get());
  while (1) {
  //pSignalLights->signalLights |= SimOne Signal Light::ESimOne Signal Li
ght DoubleFlash;
    //pSignalLights->signalLights |= SimOne Signal Light::ESimOne Signal Li
ght FrontLight;
    //pSignalLights->signalLights |= SimOne Signal Light::ESimOne Signal Li
ght HighBeam;
    //pSignalLights->signalLights |= SimOne_Signal_Light::ESimOne_Signal_Li
ght BackDrive;
    //pSignalLights->signalLights |= SimOne Signal Light::ESimOne Signal Li
ght BrakeLight;
    //pSignalLights->signalLights |= SimOne Signal Light::ESimOne Signal Li
ght LeftBlinker;
```

```
pSignalLights->signalLights = SimOne Signal Light::ESimOne Signal Lig
ht RightBlinker;
    SimOneSM::SetSignalLights(0, pSignalLights.get());
获取 SimOneDriver 运行状态
#include "SimOneSMAPI.h"
#include <thread>
#include <iostream>
#include <string>
int main(int argc, char* argv[]) {
  SimOneSM::Start();
  std::unique ptr<SimOne Data Driver Status> pDriverStatus = std::make uni
que < SimOne Data Driver Status > ();
  while (1) {
    if (SimOneSM::GetDriverStatus(0, pDriverStatus.get())) {
       std::cout << "get simoneDriver status" << std::endl;
       std::cout << pDriverStatus->driverStatus<<std::endl;
       std::this_thread::sleep_for(std::chrono::microseconds(2000));
```

}

高精地图运行时接口

查询位置车道

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
#include <thread>
#include <iostream>
using namespace SSD;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneld, s, t, s_toCenterLine, t_toCente
rLine))
    std::cout << "Error: lane is not found." << std::endl;
    return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;
```

```
std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << "," <
< t toCenterLine << std::endl;
  return laneld;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this thread::sleep for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
```

```
<< " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    if (laneId.GetString() != nullptr)
       std::cout << "Get NearMostLane success, laneld:" << laneld.GetString()
<< std::endl;
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
获得附近车道
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
```

```
#include <thread>
#include <iostream>
using namespace SSD;
void SampleGetNearLanes(const SimPoint3D& pos, const double& distance)
  SimStringVector nearLanes;
  if (!SimOneSM::GetNearLanes(pos, distance, nearLanes))
    std::cout << "No lanes(lane) are(is) found." << std::endl;
    return;
  std::cout << "lane id list:";
  for (unsigned int i = 0; i < nearLanes.size(); i++)
    const SimString& laneId = nearLanes[i];
    std::cout << laneld.GetString() << ",";
  std::cout << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
```

```
std::cout << "Failed to load hdmap!" << std::endl;
    return 0;
  std::unique ptr<SimOne Data Gps> gpsPtr = std::make unique<SimOne D
ata Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this thread::sleep for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SampleGetNearLanes(pos, 5);
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
```

获得面前所有车道

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <iostream>
#include <chrono>
#include <thread>
using SSD::SimPoint3D;
using SSD::SimString;
using SSD::SimStringVector;
void SampleGetNearLanesWithAngle(const SimPoint3D& pos,
  const double& distance,
  const double& headingAngle,
  const double& shiftAngle)
  SimStringVector nearLanes;
  if (!SimOneSM::GetNearLanesWithAngle(pos, distance, headingAngle, shiftA
ngle, nearLanes))
    std::cout << "No lanes(lane) are(is) found." << std::endl;
    return;
  std::cout << "lane id list:";
```

```
for (unsigned int i = 0; i < nearLanes.size(); i++)</pre>
     const SimString& laneId = nearLanes[i];
     std::cout << laneId.GetString() << ",";
  std::cout << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
     std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
     if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
```

```
std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    double headingAngle = M PI / 180 * 30;
    double shiftAngle = M_PI / 180 * 90;
    SampleGetNearLanesWithAngle(pos, 5, headingAngle, shiftAngle);
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
查询位置两侧车道边缘
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimPoint3D;
```

using SSD::SimString;

```
void SampleGetDistanceToLaneBoundary(const SimPoint3D& pos)
  SimString laneld;
  double distToLeft, distToRight, distToLeft2D, distToRight2D;
  if (!SimOneSM::GetDistanceToLaneBoundary(pos, laneId, distToLeft, distToR
ight, distToLeft2D, distToRight2D))
     std::cout << "Error: lane is not found." << std::endl;
     return;
  std::cout << "lane id:" << laneId.GetString() << std::endl;</pre>
  std::cout << "[distToLeft, distToLeft]:" << distToLeft << "," << distToLeft <
< std::endl;
  std::cout << "[distToLeft2D, distToRight2D]:" << distToLeft2D << "," << dis
tToRight2D << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
     std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
```

```
std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this thread::sleep for(std::chrono::milliseconds(100));
       continue;
   std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    Sample Get Distance To Lane Boundary (pos);\\
  return 0;
查询车道信息
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
```

```
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include <vector>
#include <iostream>
#include <chrono>
#include <thread>
using namespace HDMapStandalone;
using SSD::SimPoint3D;
using SSD::SimString;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneId, s, t, s toCenterLine, t toCente
rLine))
    std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;
  std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << "," <
< t toCenterLine << std::endl;
  return laneld;
```

```
void SampleGetLaneSample(const SimString& laneId)
  double s, t, s toCenterLine, t toCenterLine;
  MLaneInfo info:
  if (!SimOneSM::GetLaneSample(laneId, info))
    std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "left boundary knot size:" << info.leftBoundary.size() << std::e
ndl;
  std::cout << "left boundary knot list:" << std::endl;
  for (unsigned int i = 0; i < info.leftBoundary.size(); i++)
    const SimPoint3D& knot = info.leftBoundary[i];
     std::cout << "(" << knot.x << ","
       << knot.y << ","
       << knot.z << "),";
  std::cout << std::endl;
  std::cout << "right boundary knot size:" << info.rightBoundary.size() << st
d::endl;
  std::cout << "right boundary knot list:" << std::endl;</pre>
  for (unsigned int i = 0; i < info.rightBoundary.size(); i++)
     const SimPoint3D& knot = info.rightBoundary[i];
```

```
std::cout << "(" << knot.x << ","
       << knot.y << ","
       << knot.z << "),";
  std::cout << std::endl;
  std::cout << "center line knot size:" << info.centerLine.size() << std::endl;
  std::cout << "center line knot list:" << std::endl;
  for (unsigned int i = 0; i < info.centerLine.size(); i++)
     const SimPoint3D& knot = info.centerLine[i];
     std::cout << "(" << knot.x << ","
       << knot.y << ","
       << knot.z << "),";
  std::cout << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
     std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
```

```
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetLaneSample(laneId);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
```

获取车道连接信息

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/MDataStruct.h"
#include <vector>
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimPoint3D;
using SSD::SimString;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneld, s, t, s toCenterLine, t toCente
rLine))
    std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;
  std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine <<
```

```
< t toCenterLine << std::endl;
  return laneld;
void SampleGetLaneLink(const SimString& laneId)
  MLaneLink link;
  if (!SimOneSM::GetLaneLink(laneId, link))
     std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "predecessor lane Id list:" << std::endl;
  for (unsigned int i = 0; i < link.predecessorLaneNameList.size(); i++)
    const SimString& laneId = link.predecessorLaneNameList[i];
     std::cout << laneId.GetString() << ",";</pre>
  std::cout << std::endl;
  std::cout << "successor lane Id list:" << std::endl;
  for (unsigned int i = 0; i < link.successorLaneNameList.size(); i++)
     const SimString& laneId = link.successorLaneNameList[i];
     std::cout << laneId.GetString() << ",";
  std::cout << std::endl;
  std::cout << "left neighbor Id:" << link.leftNeighborLaneName.GetString()</pre>
```

```
< < std::endl;
  std::cout << "right neighbor Id:" << link.rightNeighborLaneName.GetString
() << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
    return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << "pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
```

```
<< "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetLaneLink(laneId);
    std::this thread::sleep for(std::chrono::milliseconds(100));
  return 0;
获取车道类型
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimPoint3D;
using SSD::SimString;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
```

```
SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneId, s, t, s toCenterLine, t toCente
rLine))
     std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;</pre>
  std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << "," <
< t toCenterLine << std::endl;
  return laneld;
void SampleGetLaneType(const SimString& laneId)
  ESimOneLaneType type;
  if (!SimOneSM::GetLaneType(laneId, type))
     std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::string typeStr;
  switch (type)
```

```
case ESimOneLaneType none:
  typeStr = "ESimOneLaneType_none";
break;
case ESimOneLaneType_driving:
  typeStr = "ESimOneLaneType driving";
break;
case ESimOneLaneType_stop:
  typeStr = "ESimOneLaneType_stop";
break;
case ESimOneLaneType_shoulder:
  typeStr = "ESimOneLaneType_shoulder";
break;
case ESimOneLaneType_biking:
  typeStr = "ESimOneLaneType_biking";
break;
case ESimOneLaneType_sidewalk:
```

```
typeStr = "ESimOneLaneType sidewalk";
break;
case ESimOneLaneType border:
  typeStr = "ESimOneLaneType border";
break;
case ESimOneLaneType_restricted:
  typeStr = "ESimOneLaneType_restricted";
break;
case ESimOneLaneType_parking:
  typeStr = "ESimOneLaneType parking";
break;
case ESimOneLaneType_bidirectional:
  typeStr = "ESimOneLaneType_bidirectional";
break;
case ESimOneLaneType median:
  typeStr = "ESimOneLaneType median";
```

```
break;
case ESimOneLaneType_special1:
  typeStr = "ESimOneLaneType special1";
break;
case ESimOneLaneType_special2:
  typeStr = "ESimOneLaneType_special2";
break;
case ESimOneLaneType special3:
  typeStr = "ESimOneLaneType_special3",
break;
case ESimOneLaneType_roadWorks:
 typeStr = "ESimOneLaneType_roadWorks";
break;
case ESimOneLaneType_tram:
  typeStr = "ESimOneLaneType tram";
break;
case ESimOneLaneType_rail:
```

```
typeStr = "ESimOneLaneType_rail";
break;
case ESimOneLaneType entry:
  typeStr = "ESimOneLaneType_entry";
break;
case ESimOneLaneType exit:
  typeStr = "ESimOneLaneType_exit";
break;
case ESimOneLaneType_offRamp:
  typeStr = "ESimOneLaneType_offRamp";
break;
case ESimOneLaneType_onRamp:
  typeStr = "ESimOneLaneType_onRamp";
break;
case ESimOneLaneType mwyEntry:
  typeStr = "ESimOneLaneType_mwyEntry";
```

```
break;
    case ESimOneLaneType mwyExit:
       typeStr = "ESimOneLaneType mwyExit";
    break;
    default:
       typeStr = "ESimOneLaneType_none";
  std::cout << "lane type:" << typeStr.c_str() << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
    return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
```

```
printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetLaneType(laneId);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
获取车道宽度
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
```

```
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimString;
using SSD::SimPoint3D;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneId, s, t, s toCenterLine, t toCente
rLine))
     std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneId.GetString() << std::endl;
  std::cout <<"[s,\,t]:" << s <<"," << t << std::endl;\\
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << ",
< t toCenterLine << std::endl;
  return laneld;
void SampleGetLaneWidth(const SimString& laneld, const SimPoint3D& pos)
  double width;
```

```
if (!SimOneSM::GetLaneWidth(laneId, pos, width))
    std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "lane width at this location(" << pos.x
     << "," << pos.y
     << "," << pos.z
     << ") is:"
     << width
     << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
```

```
printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetLaneWidth(laneId, pos);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
获取在车道上的 ST 坐标
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
```

```
#include <chrono>
#include <thread>
#include <iostream>
using SSD::SimString;
using SSD::SimPoint3D;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneId, s, t, s toCenterLine, t toCente
rLine))
     std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneId.GetString() << std::endl;
  std::cout <<"[s,\,t]:" << s <<"," << t << std::endl;\\
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << '
< t toCenterLine << std::endl;
  return laneld;
void SampleGetLaneST(const SimString& laneld, const SimPoint3D& pos)
  double s, t;
```

```
if (!SimOneSM::GetLaneST(laneId, pos, s, t))
    std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "relative to this lane, this location(" << pos.x
     << "," << pos.y
     << "," << pos.z
     << "'s s-t coordidate position [s, t]:"
     << 5
   << "," << "t"
     << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
    return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata_Gps>();
  while (1)
```

```
if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this thread::sleep for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetLaneST(laneId, pos);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
获取在道路上的 ST 坐标
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
```

```
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimString;
using SSD::SimPoint3D;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneld;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneld, s, t, s_toCenterLine, t_toCente
rLine))
    std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;
  std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s_toCenterLine, t_toCenterLine]:" << s_toCenterLine << "
< t toCenterLine << std::endl;
  return laneld;
```

```
double s, t, z;
  if (!SimOneSM::GetRoadST(laneId, pos, s, t, z))
     std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "relative to this lane's owner road, this location(" << pos.x
     << "," << pos.y
     << "," << pos.z
   << "'s s-t coordidate position [s, t]:"</p>
     << "," << t
     << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
     std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
```

```
ata_Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
       printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleGetRoadST(laneId, pos);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
```

查询指定车道是否存在于地图之中

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
#include <chrono>
#include <iostream>
#include <thread>
using SSD::SimString;
using SSD::SimPoint3D;
SimString SampleGetNearMostLane(const SimPoint3D& pos)
  SimString laneId;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(pos, laneld, s, t, s_toCenterLine, t_toCente
rLine))
     std::cout << "Error: lane is not found." << std::endl;
     return laneld;
  std::cout << "lane id:" << laneld.GetString() << std::endl;
  std::cout << "[s, t]:" << s << "," << t << std::endl;
  std::cout << "[s toCenterLine, t toCenterLine]:" << s toCenterLine << '
< t toCenterLine << std::endl;
```

```
return laneld;
void SampleContainsLane(const SimString& laneId)
  if (!SimOneSM::ContainsLane(laneId))
    std::cout << "Error: lane does not eixst in the map." << std::endl;
     return;
  std::cout << "lane exists in the map." << std::endl;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
     return 0;
  std::unique_ptr<SimOne_Data_Gps> gpsPtr = std::make_unique<SimOne_D
ata Gps>();
  while (1)
    if (!SimOneSM::GetGps(0/*vehicleId*/, gpsPtr.get()))
```

```
printf("Fetch GPS failed\n");
       std::this_thread::sleep_for(std::chrono::milliseconds(100));
       continue;
    std::cout << "GPS:" << gpsPtr->timestamp
       << " pos:(" << gpsPtr->posX
       << "," << gpsPtr->posY
       << "," << gpsPtr->posZ
       << std::endl;
    //HDMap samples based on gps location
    SSD::SimPoint3D pos(gpsPtr->posX, gpsPtr->posY, gpsPtr->posZ);
    SSD::SimString laneId = SampleGetNearMostLane(pos);
    SampleContainsLane(laneId);
    std::this_thread::sleep_for(std::chrono::milliseconds(100));
  return 0;
获取地图中停车位列表
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include <vector>
```

```
#include <chrono>
#include <thread>
#include <iostream>
using SSD::SimPoint3D;
using SSD::SimPoint3DVector;
using SSD::SimString;
using SSD::SimStringVector;
int main(int argc, char* argv[])
  int timeout = 20;
  if (!SimOneSM::LoadHDMap(timeout))
    std::cout << "Failed to load hdmap!" << std::endl;
    return 0;
  SSD::SimVector<HDMapStandalone::MParkingSpace> parkingSpaceList;
  SimOneSM::GetParkingSpaceList(parkingSpaceList);
  std::cout << "GetParkingSpaceIds returns count:" << parkingSpaceList.size()
<< std::endl;
```

获取预设规划路径

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
#include "util/UtilDriver.h"
#include <iostream>
#include <vector>
using namespace HDMapStandalone;
int main()
  int timeout = 20;
  if (SimOneSM::LoadHDMap(timeout))
    SSD::SimPoint3DVector route;
    if (SimOneSM::GetPredefinedRoute(route)) {
       std::cout << "route path size" << route.size() << std::endl;</pre>
```

获取规划路径所途径道路的 ID 列表

```
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  SSD::SimPoint3D startPt, endPt;
  SimOne Data WayPoints Entry terminal;
  SSD::SimPoint3DVector ptList;
  SSD::SimVector<long> naviRoadIdList;
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SSD::SimVector<int> indexOfValidPoints;
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  if (SimOneSM::GetGps(0, pGps.get()))
    startPt.x = pGps->posX;
    startPt.y = pGps->posY;
```

```
startPt.z = pGps->posZ;
  if (SimOneSM::GetTerminalPoint(&terminal))
    endPt.x = terminal.posX;
    endPt.y = terminal.posY;
    endPt.z = 0;
  ptList.push_back(startPt);
  ptList.push back(endPt);
  if (SimOneSM::Navigate(ptList, indexOfValidPoints, naviRoadIdList)) {
    std::cout <<"naviRoadIdList size:"<<naviRoadIdList.size() << std::endl;
    for (auto & pt: naviRoadIdList) {
      std::cout << pt << std::endl;
根据指定车道 id 和局部坐标获取局部坐标左右两侧车道标线信息
```

```
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
```

```
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneId;
  HDMapStandalone::MRoadMark left;
  HDMapStandalone::MRoadMark right;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneId, s, t, s toCenterLi
ne, t toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
  if (SimOneSM::GetRoadMark(MainVehiclePos, laneId, left, right)) {
    std::cout << "Left side roadmark: " << left.length << std::endl;
```

```
std::cout << "right side roadmark: " << right.length << std::endl;
获取地图中信号灯列表
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  SSD::SimVector<HDMapStandalone::MSignal> lightList;
  SimOneSM::GetTrafficLightList(lightList);
  std::cout << "lightList size" << lightList.size() << std::endl;
获取地图中交通标志列表
#include <iostream>
#include <vector>
```

```
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  SSD::SimVector<HDMapStandalone::MSignal> TrafficSignList;
  SimOneSM::GetTrafficSignList(TrafficSignList);
  std::cout << "TrafficSignList size" << TrafficSignList.size() << std::endl;
获取交通灯给定作用车道的关联停止线列表
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneld.h"
int main() {
```

```
int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  std::unique_ptr<SimOne_Data_Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneld, s, t, s_toCenterLi
ne, t toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
  SSD::SimVector<HDMapStandalone::MObject> stoplineList;
  SSD::SimVector<HDMapStandalone::MSignal> TrafficSignList;
  SimOneSM::GetTrafficSignList(TrafficSignList);
  for (auto& pt : TrafficSignList) {
    SimOneSM::GetStoplineList(pt, laneId, stoplineList);
    std::cout << "stoplineList size" << stoplineList.size() << std::endl;
```

获取交通灯给定作用车道的关联人行横道线列表

```
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneId, s, t, s_toCenterLi
ne, t_toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
```

```
std::cout << "laneld: " << laneld.GetString() << std::endl;</pre>
  SSD::SimVector<HDMapStandalone::MObject> crosswalkList;
  SSD::SimVector<HDMapStandalone::MSignal> TrafficLightList;
  SimOneSM::GetTrafficLightList(TrafficLightList);
  for (auto& pt : TrafficLightList) {
    SimOneSM::GetCrosswalkList(pt, laneId, crosswalkList);
    std::cout << "stoplineList size" << crosswalkList.size() << std::endl;
获取指定车道所在道路上的网状线列表
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
```

```
SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneld;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneId, s, t, s toCenterLi
ne, t toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
  SSD::SimVector<HDMapStandalone::MObject> crossHatchList;
  SimOneSM::GetCrossHatchList(laneId, crossHatchList);
  std::cout << "crossHatchList size: " << crossHatchList.size() << std::endl;
获取输入点投影到指定车道中心线上的点和切线方向
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
```

```
SimOneSM::LoadHDMap(timeout);
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneId;
  double s, t, s toCenterLine, t toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneId, s, t, s toCenterLi
ne, t_toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
  SSD::SimPoint3D changeToPoint;
  SSD::SimPoint3D dir;
  if (SimOneSM::GetLaneMiddlePoint(MainVehiclePos, laneId, changeToPoint,
dir))
    std::cout << "changeToPoint x:" << changeToPoint.x << "changeToPoint
y:" << changeToPoint.y << "z:" << changeToPoint.z << std::endl;
```

得到仿真场景中的交通灯的真值

```
#include <iostream>
#include <vector>
#include "SimOneSMAPI.h"
#include "SSD/SimPoint3D.h"
#include "SSD/SimString.h"
#include "public/common/MLaneInfo.h"
#include "public/common/MLaneId.h"
int main() {
  int timeout = 20;
  SimOneSM::LoadHDMap(timeout);
  std::unique ptr<SimOne Data Gps> pGps = std::make unique<SimOne Da
ta Gps>();
  SimOne Data TrafficLight trafficLight;
  SimOneSM::GetGps(0, pGps.get());
  SSD::SimPoint3D MainVehiclePos(pGps->posX, pGps->posY, pGps->posZ);
  SSD::SimString laneld;
  double s, t, s_toCenterLine, t_toCenterLine;
  if (!SimOneSM::GetNearMostLane(MainVehiclePos, laneId, s, t, s toCenterLi
ne, t toCenterLine))
    std::cout << "Error: lane is not found." << std::endl;
```

```
SSD::SimVector<HDMapStandalone::MObject> stoplineList;
SSD::SimVector<HDMapStandalone::MSignal> TrafficLightList;
SimOneSM::GetTrafficLightList(TrafficLightList);

for (auto& pt : TrafficLightList) {

   if (SimOneSM::GetTrafficLights(0, pt.id, &trafficLight)) {
      std::cout << "trafficLight.status:" << trafficLight.status << std::endl;
   }
}
```

ROS BRIDGE(1.0)

标准 ROS Bridge 接口描述

TaskRosControl

仿真引擎通过从无人驾驶系统获取的控制消息驱动主车行驶,基本控制信息包括油门、 刹车和转向

数据来源

- 订阅 ROS Topic: "/control/control_command"
- 接收消息数据类型:cybertrondrive_msgs::ControlCmd
- 接收消息内容:油门、刹车、转向

数据发送

向主车节点发送油门、刹车和转向信息

- 发送消息数据类型:cybertron::proto::sensor::DataVehicleControlState
- 发送频率:60Hz

TaskRosGps

主车位置消息,包括主车当前位置,速度和朝向信息

数据来源1

订阅主车节点车辆底盘信息

• 接收消息数据类型:cybertron::proto::sensor::DataVehicleChassisState

数据来源2

• 从热区获取主车位置和朝向信息(mPos/mRot)

数据发送1

- 发布 ROS Topic: "/localization/odometry"
- 发送消息数据类型:cybertrondrive_msgs::OdometryExt
- 发送消息内容:gps/utm 坐标、heading、euler_angle、linear_velocity、 linear_acceleration、angular_velocity
- 发送频率:由网页端设置

数据发送 2

- 发布 ROS Topic: "/tf"
- 发送消息数据类型:tf2_msgs::TFMessage

- 发送消息内容:主车 utm 坐标
- 发送频率:由网页端设置

TaskRosImageBase

摄像头,输出相机规格参数

数据来源

订阅摄像头传感器节点图像数据

- 接收消息数据类型:cybertron::proto::sensor::ImageWidthGroundTruth
- 接收消息内容:图像部分数据.image()

数据发送

- 发送 ROS Topic:由网页端配置
- 发送消息数据类型:sensor_msgs::Image
- 发送消息内容:图像规格参数(width/height/step)
- 发送频率:有网页端设置

TaskRosObstacles

障碍物消息包括障碍物类型(车、行人等)、位置、朝向、速度和包围盒等信息(仿真系统可绕过感知,直接向无人驾驶系统发送障碍物和红绿灯信息)

数据来源1

- 摄像头设置参数信息:由网页端配置
- 接收数据类型:BridgeConfig::ObstacleSetting

数据来源2

订阅障碍物感知传感器节点探测数据

- 接收数据类型:cybertron::proto::sensor::ObstacleDetect
- 接收消息内容:车辆、行人、交通指示灯及交通道路标识信息

数据发送

- 发送 ROS Topic: "/perception_object/object_detect_results"
- 发送消息数据类型:cybertrondrive msgs::ObjectResults
- 发送消息内容:
 - 车俩:位置坐标、landmark、label(car/truck/bus)
 - 一 行人:位置坐标、landmark、行为信息 (umbrella/call/phone/wave/stading)
 - 交通指示等:位置坐标
 - 交通道路标识:位置坐标
 - 发送频率:30Hz

TaskRosPerfectPerception

将障碍物坐标信息转换为标准 ROS 可视化格式发布

数据来源

订阅完美传感器节点探测数据

• 接收数据类型:cybertron::proto::sensor::ObstacleDetect

数据发送

• 发送 ROS Topic:由网页端设置

- 发送消息数据类型:visualization_msgs::MarkerArray
- 发送消息内容:车辆、行人、自行车、交通指示灯及交通道路标识信息
- 发送频率:由网页端配置

TaskRosPointCloud

激光雷达消息包括点云中每个点的位置和强度信息

数据来源

订阅激光雷达传感器节点数据

• 接收数据类型:cybertron::proto::sensor::PointCloudWithGroundTruth

数据发送1

将激光雷达点云数据转换为标准 ROS 可视化格式发布

- 发布 ROS Topic:有网页端配置
- 发送消息数据类型:sensor_msgs::PointCloud2
- 发送消息内容:point_step、row_step、height、width
- 发送频率:由网页端配置

数据发送 2

将地面真值数据 (障碍物位置、朝向及规格信息) 转换为标准 ROS 可视化格式发布

- 发布 ROS Topic:网页端配置 + "groundtruth"
- 发送消息数据类型:visualization_msgs::MarkerArray
- 发送消息内容:position、orientation、scale、color
- 发送频率:由网页端配置

TaskRosPrediction

预测信息包括车辆和行人在预测时间段内的位置轨迹

数据来源

从热区获取车辆/行人预测轨迹坐标、速度及朝向数据

数据发送1

- 发布 ROS Topic: "/action_prediction/prediction_results"
- 发送消息数据类型:cybertrondrive msgs::PredictionResults
- 发送消息内容:障碍物感知传感器探测到的车辆/行人预测轨迹(每组十个点)
- 发送频率:60H

数据发送 2

- 发布 ROS Topic: "/action_prediction/auxiliary_prediction_results"
- 发送消息数据类型:cybertrondrive msgs::TrafficInfoResult
- 发送消息内容:障碍物感知传感器探测到的车辆/行人当前位置坐标、速度及朝向
- 发送频率:60Hz

TaskRosReplayPos

向 UE 端发送主车的运动姿态 (车体) 数据来驱动主车行驶, 实现案例回放

数据来源

- 订阅 ROS Topic: "/localization/odometry"
- 接收数据类型:cybertrondrive_msgs::OdometryExt

数据发送

向主车节点发送位置、朝向信息

- 发送消息数据类型:cybertron::proto::sensor::DataVehicleBodyState
- 发送消息内容:local 坐标位置,转向坐标
- 发送频率:60Hz

TaskRosRoutingReq

路由信息包括主车起点、途径点和终点,发送给无人驾驶系统规划主车的全局路径数据来源

网页端发送, 经 BridgeConfig 解析

• 接收数据类型:std::pair<float, float>

数据发送

- 发布 ROS Topic: "/hmi/routing_request"
- 发送消息数据类型:cybertrondrive_msgs::WaypointArray
- 发送消息内容:路由点坐标值
- 发送频率:30Hz

TaskRosTrafficLight

交通灯指示状态标记

数据来源

从热区获取交通灯状态消息

数据发送

• 发布 ROS Topic: "/perception/traffic_light"

- 发送消息数据类型:cybertrondrive_msgs::TrafficLightDetection
- 发送消息内容:id、confidence、color
- 发送频率:10Hz

TaskRosVehicleInfo

车辆当前的底盘状态,包括驾驶模式、车速和发动机转速等信息

数据来源

向主车节点订阅底盘状态和车轮状态消息

接收数据类型:cybertron::proto::sensor::DataVehicleChassisState、
 Cybertron::proto::sensor::DataVehicleWheelSpeedState

数据发送

- 发布 ROS Topic: "/canbus/vehicle_info"
- 发送消息数据类型:cybertrondrive_msgs::VehicleInfo
- 发送消息内容:车速、刹车、油门、加速度、转角、偏航角、车轮转速
- 发送频率:60Hz

ROS 文本形式输出验证工具

outputControlInfo

主车控制消息调试工具

- 订阅 ROS Topic: "/control/control command"
- 接收数据类型:cybertrondrive_msgs::ControlCmd
- 输出文件名称格式:cmdInfo_year-mond-day_hour-min-sec

- 输出内容
 - throttle
 - steering angle
 - brake

outputGpsInfo

GPS 消息调试工具

- 订阅 ROS Topic: "/localization/odometry"
- 接收数据类型:cybertrondrive_msgs::OdometryExt
- 输出文件名称格式:gpsInfo_year-mond-day_hour-min-sec
- 输出内容
 - odometry.wgs84: x/y/z
 - odometry.utm: x/y/z
 - odometry.heading:
 - odometry.euler_angle: x/y/z
 - odometry.linear_velocity: x/y/z
 - odometry.linear_acceleration: x/y/z
 - odometry.angular_velocity: x/y/z
 - odometry.header.frame_id
 - odometry.header.stamp:

outputVehicleInfo

主车状态消息调试工具

- 订阅 ROS Topic: "/canbus/vehicle_info"
- 接收数据类型:cybertrondrive_msgs::VehicleInfo
- 输出文件名称格式:vehInfo_year-mond-day_hour-min-sec
- 输出内容
 - speed
 - brake
 - throttle
 - steering angle
 - accel lat
 - accel lon
 - accel vert
 - angular roll
 - angular yaw

ROS 可视化格式输出工具

obstacle_box_to_marker

Obstacle 轨迹调试工具

- 订阅 ROS Topic: "/perception_object/object_detect_results"
- 接收数据类型:cybertrondrive_msgs::ObjectResults

- 接收消息内容:车辆、行人、自行车、交通指示灯、交通标识
- 发布 ROS Topic: "obstacle bbox marker"
- 发送数据类型:visualization_msgs::MarkerArray
- Rviz 设置
 - Fixed Frame: "obstacle box frame"
 - 添加 visualization: "Add" -> "By topic" -> "obstacle bbox marker"
 - 图示:车辆(蓝色)、行人(红色)、自行车(黄色)

perception_to_marker

障碍物感知 BBox 调试工具

- 订阅 ROS Topic: "/perception object/object detect results"
- 接收数据类型:cybertrondrive_msgs::ObjectResults
- 发布 ROS Topic: "/perception object/vis marker"
- 发送数据类型:visualization msgs::MarkerArray
- Rviz 设置
 - Fixed Frame: "perception_frame"
 - 添加 visualization: "Add" -> "By topic" -> "perception_object vis_marker"
 - 图示:车辆(蓝色)、行人(红色)、交通指示灯(紫色)、交通标识(黄色)

perception_to_image

障碍物感知 BBox 合成调试工具

将感知障碍物 BBox 合成到摄像头图像数据中

- 订阅 1 ROS Topic: "/perception_object/object_detect_results"
- 接收数据 1 类型:cybertrondrive_msgs::ObjectResults
- 订阅 2 ROS Topic: "/camera identifier"
- 接收数据 2 类型:sensor msgs::Image
- 发布 ROS Topic: "/perception object/vis image"
- 发送数据类型:sensor_msgs::lmage
- Rqt_image_view 设置
 - 消息订阅选项: "perception object/vis image"

prediction to marker

车辆/行人预测轨迹调试工具

- 订阅 ROS Topic: "/action_prediction/prediction_results"
- 接收数据类型:cybertrondrive_msgs::PredictionResults
- 发布 ROS Topic: "visualization_marker"
- 发送数据类型:visualization_msgs::MarkerArray
- Rviz 设置
 - Fixed Frame: "prediction_frame"
 - 添加 visualization: "Add" -> "By topic" -> "visualization_marker"
 - 图示:车辆(蓝色)、行人(红色)

Restful API(1.0)

Terminonlogy

该文档使用 python(3.6+)介绍了 Sim-One 目前可调用的主要 API 信息,及 API 调用的请求参,返回参

SimOneLauncher

定义

基于分布式运行方式,用于配置用户个人属性的操作界面

操作

默认 Api 调用默认 URL 为 http://localhost:8088(以下样例使用默认端口号,简称Sim-One host)

其中端口号 8088,可通过修改 CZ_WEB_PORT 实现

token

定义

Api 调用过程中,向服务端请求认证的凭证

案例

用户基于内置资源可自主选择编辑用于测试的交通流

任务

运行案例即创建一个任务

Test Case

How to create a test case

创建默认案例仅包含案例标准设置,其他参数需调用编辑案例实现

request

URL:为 Sim-One host 与创建案例方法组合,如下

http://localhost:8088/api/cases

Methods:Post

Headers:Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

mapId(string)

element is set to be the name (without file extention) of the OpenDrive file for

which we use together with this test case.

categoryld(string)

element is a uuid for a case group, which we use to group a couple of related

cases

opponent(string)

element is to identify the type of the case, which can have the following values:

- case (opponent is expressed with points in caseData object)
- trafficflow (opponent is controlled by traffic simulation)
- record (opponent is from recordings)

set it to "case" if your data is waypoints

• name(string)

element is the display name of the test case

standards(list)

element is to define several validation rules for a case run. For now, we support "timeout", "collision", "crossLane", "speedLimitation" and "stopSign".

response

返回新创建案例的 caseid 信息

How to edit a test case

对创建的案例进行参数编辑,或修改已配置的案例信息

request

URL:为 Sim-One host与编辑案例方法组合,如下

http://localhost:8088/api/cases/update

Methods: Post

Headers: Content-Type,cookie

Content-Type: application/json

Cookie: siderFlex=flex; token=token

Body:

The SIMONE case file mainly has two parts, a "caseDef" object to define some high-level information for this case, and a "caseData" object to define the case data.

- caseDef object
 - schema:element is fixed to be "casedef"
 - id: element is a uuid for this case, need to be different for different test cases.
 - opponent:element is to identify the type of the case, which can have the following values:
 - case (opponent is expressed with points in caseData object) o
 trafficflow (opponent is controlled by traffic simulation)
 - record (opponent is from recordings)set it to "case" if your data is waypoints
 - userId:element is to identify the user who own this test case, set it
 to "default" for single pc case.
 - mapId:element is set to be the name (without file extention) of the
 OpenDrive file for which we use together with this test case.
 - categoryld:element is a uuid for a case group, which we use to group a couple of related cases.

- name:element is the display name of the test case.
- tags:element is an array of string tags, which we can use to further filter the cases.
- created:element is the timestamp (UNIX time) to identify the creation time of this test case.
- lastModified:element is the timestamp (UNIX time) to identify the
 last modification time of this test case.
- selected:element is for internal use only, can be simply set to be false.

caseData object

- schema:element is fixed to be "casedata".
- caseId:element is a uuid for this case, need to be the same as id element in caseDef object.
- mapId:element is set to be the name (without file extention) of the
 OpenDrive file for which we use together with this test case. It
 needs to be the same as mapId element in caseDef object.
- loop:element is deprecated, simply set it to false, please.
- timeout:element is deprecated, simply set it to 300000.0, please.
- speed:element is deprecated, simply set it to 1.0, please
- observer:element is deprecated, simply set it to "none", please
- opponent:element is to identify the type of the case, which can have following values:

- case (opponent is expressed with points in caseData object) o
 trafficflow (opponent is controlled by traffic simulation)
- record (opponent is from recordings)
 set it to "case" if your data is waypoints. It needs to be
 same as opponent element in caseDef object.
- oncollision:element is deprecated, simply set it to be "stop",
 please.
- ongoal:elemet is deprecated, simply set it to be "stop", please.
- routes element is to describe the ego car data. At higher level, it has two parts, a "byld" object to contain all the ego car objects' detail information, and an "allIds" array to hold all the ego car ids only. Each element within "byld" object has a uuid name, which is used as the identity of an ego car instance, each ego car instance has these details:
 - id:element is the uuid for this ego car instance, it must be the same as the ego car object name.
 - vehicleld:element is also a uuid, it's used to reference the
 pre-defined ego car model in NEVC-SimOne simulator, for
 that model, we define the car model, vehicle dynamics,
 controllers and sensor setups.
 - name:element is the display name for this ego car instance.
 - points:element is the waypoints for this ego car instance,
 each waypoint has these details:

- position:element for position of this ego car instance,
 in local ENU space, unit(m).
- heading:element for heading of this ego car instance,
 in quaternion.
- interval:element for time interval from previous waypoint, unit(s).
- distance:element for distance from previous waypoint, unit(m). It will be calculated automatically internally if set to 0.0.
- speed:element for speed of this ego car instance, unit
 (km/h).
- accel:element for acceleration of this ego car instance, unit (m/s^2). It will be calculated automatically internally if set to 0.0.
- driver:element is used to define the ego behavior, for now it can be:
 - ai:after setting to "ai", the behavior of ego car instance is totally controlled by external controllers, like an AD package.
 - maneuver:after setting to "maneuver", NEVC-SimOne is in charge of controlling the movement of this ego car instance. One thing to note is that different waypoints can be set to have different driving behaviors, this is normally

used to implement a way to switch control. E.g. we can follow the waypoints using "maneuver" behavior first, and then pass the control to an AD package at some point.

- level:element is used to identify the driving levels, for now "L2" and "L4" are supported:
 - L2:To use maneuver driver mode, or to mix maneuver driver mode with ai driver mode.
 - L4:The driver mode for each waypoint is ignored and set default to be "ai". One thing to note is that when using an AD package, how to use these waypoints are totally decided by the AD package, for Apollo case, these waypoints are used as routing request, so sometimes only two waypoints is enough for an Apollo ego car to drive.
- elements:element is to describe the non-ego car data, at higher level, it has two parts, a "byld" object to contain all the non-ego car object, and an "allIds" array to hold all the non-ego car ids only. Each element within "byld" object has a uuid name, which is used as the identity of a non-ego car instance, each non-ego car instance has these details:
 - id:element is the uuid for this non-ego car instance, it must be the same as the non-ego car object name.

- category:element is to describe the category for this non-ego car instance, it can be set to "vehicle", "bicycle", "pedestrian" and "static".
- type:element is to define the type of this non-ego car instance, for now set it to "universal/obstalce".
- name:element is the display name for this non-ego car instance.
- style:element is used to reference the pre-defined non-ego car preset, each preset includes car models, vehicle dynamics, etc.
- interop:element is used to define the interpolation method between waypoints, for now set it to "clothoid" .
- points:element is the waypoints for this non-ego car instance,
 each waypoint has these details:
 - position:element for position of this ego car instance,
 in local ENU space, unit(m).
 - heading:element for heading of this ego car instance,
 in quaternion.
 - interval:element for time interval from previous waypoint, unit(s).
 - distance:element for distance from previous waypoint,
 unit(m). It will be calculated automatically if set to 0.0.

- speed:element for speed of this ego car instance, unit (km/h).
- accel:element for acceleration of this ego car, unit
 (m/s^2). It will be calculated automatically if set to 0.0.
- reversed:element is for reverse case, for now set it to be "false"
- trigger element is to reference the trigger object (defines later) which links to this non-ego element.
- triggers:element is to define the trigger object, at higher level, it has two parts, a "byld" object to contain all the trigger object, and an "allIds" array to hold all the trigger object ids only. Each element within "byld" object has a uuid name, which is used as the identity of a trigger object instance, each trigger object instance has these details:
 - id:element is the uuid for this trigger object instance, it must be the same as the trigger object name.
 - name:element is the display name for this trigger object instance.
 - type:element is to define the type of this trigger object, for now set it to "general".
 - triggerBox:element is to define the shape of this trigger object. It has these details:
 - position:element for position of this trigger object, in local ENU space, unit(m).

- heading:element for heading of this trigger object, in quaternion.
- size:element for the size of this trigger object, unit(m)
- environment:element is to define several environment conditions,
 including time, weather conditions, etc.
 - timeOfDay:element is to describe the time of day, in "hhmm"
 - lightIntensity:element is to describe the intensity of the day light, rage from 0.0 to 1.0.
 - heightAngle:element is to describe the height angle of the sun, range from 0.0 to 1.0.
 - cloudDensity:element is to describe the density of the cloud,
 range from 0.0 to 1.0.
 - rainDensity:element is to describe the density of the rain,
 range from 0.0 to 1.0.
 - fogDensity:element is to describe the density of the fog,
 range from 0.0 to 1.0.
 - snowDensity:element is to describe the density of the snow, range from 0.0 to 1.0.
 - ground:element is to describe the ground information, set it to { "enable" : false} for now.

- passStandard:element is to define several validation rules for a case run. For now, we support "timeout", "collision", "crossLane", "speedLimitation" and "stopSign". Each rule has these details:
 - checked:element. Whether this rule is activated.
 - action:element. What action to take after violating the rule.
 - message:element. Message level.
 - minute:element. For timeout element only, use to describe the timeout value, in minutes.

```
json sample:
   "caseDef": {
     "schema": "casedef",
     "id": "438d1810-f09e-11e9-bca5-c981f86e1c6e",
     "opponent": "case",
     "userId": "default",
     "categoryld": "93848190-72e6-11e9-90db-5fc67123c3b1
     "mapId": "FourLanes",
     "tags": [],
     "name": "test",
     "lastModified": 1571289910095,
     "created": 1571289814034
   "caseData": {
     "schema": "casedata",
     "caseld": "438d1810-f09e-11e9-bca5-c981f86e1c6e",
```

```
"mapId": "FourLanes",
"loop": false,
"timeout": 300000,
"speed": 1,
"observer": "default",
"opponent": "case",
"oncollision": "stop",
"ongoal": "stop",
"routes": {
  "byId": {
     "631af1c0-f09e-11e9-8a14-cfd25f6811c5": {
       "id": "631af1c0-f09e-11e9-8a14-cfd25f6811c5",
       "vehicleId": "apollo",
       "name": "Apollo 决策",
       "points": [
            "position": {
               "x": -941.2,
               "y": -11.852581688921054,
               "z": 0
            "heading": {
               "x": 0,
               "y": 0,
               "z": 0,
```

```
"speed": 25,
     "accel": 0,
     "interval": 0,
     "driver": "ai"
     "position": {
       "x": -786.3999999999999,
        "y": -11.912263592034197,
     "heading": {
        "x": 0,
        "y": 0,
        "z": 0,
     },
     "speed": 25,
     "accel": 0,
     "interval": 22.291201946164218,
  "driver": "ai",
     "distance": 154.8000135150293
],
"level": "L4"
```

```
"allIds": [
          "631af1c0-f09e-11e9-8a14-cfd25f6811c5"
     "elements": {
       "byId": {
          "70131ab0-f09e-11e9-8a14-cfd25f6811c5": {
            "id": "70131ab0-f09e-11e9-8a14-cfd25f6811c5",
            "category": "vehicle",
            "name": "ObsJeep 1",
            "type": "universal/obstacle",
            "style": "ObsJeep_1",
            "bp": "/Game/WIP/Shiqiang/Vehicles/Vehicle002BP_Obstacle.Vehi
cle002BP_Obstacle_C",
            "interpo": "clothoid",
            "points": [
                 "position": {
                    "x": -923.2,
                    "y": -15.32514241443737,
                 "heading": {
                    "x": 0,
                    "y": 0,
                    "z": 0,
```

```
"reversed": false,
  "distance": 0,
  "interval": 0,
  "speed": 25,
   "accel": 0
},
   "position": {
     "x": -859.999999999999,
     "y": -15.51136125415851,
  "heading": {
     "x": 0,
     "y": 0,
     "z": -0.001060358667964879,
     "w": 0.9999994378195897
  "reversed": false,
"distance": 63.200319803845915,
  "interval": 9.100846051753813,
  "speed": 25,
  "accel": 0
   "position": {
```

```
"x": -792.4,
               "y": -15.511361254158691,
            "heading": {
               "x": 0,
               "y": 0,
            "reversed": false,
            "distance": 67.60002689371615,
            "interval": 9.734403872695125,
            "speed": 25,
            "accel": 0
       ],
       "trigger": "77738830-f09e-11e9-8a14-cfd25f6811c5"
  },
  "allIds": [
     "70131ab0-f09e-11e9-8a14-cfd25f6811c5"
"triggers": {
  "byId": {
     "77738830-f09e-11e9-8a14-cfd25f6811c5": {
```

```
"id": "77738830-f09e-11e9-8a14-cfd25f6811c5",
    "name": "通用触发器",
    "type": "general",
    "triggerBox": {
       "type": "box",
       "position": {
         "x": -933.2,
         "y": -12.05,
         "z": 0
       "heading": {
         "x": 0,
       "size": {
         "x": 3.59999999999999,
         "y": 17.908203071594585,
"allids": [
  "77738830-f09e-11e9-8a14-cfd25f6811c5"
```

```
"environment": {
  "timeOfDay": 1000,
  "lightIntensity": 0.5,
  "heightAngle": 0.5,
  "cloudDensity": 0.2,
  "rainDensity": 0,
  "fogDensity": 0,
  "snowDensity": 0,
  "ground": {
    "enable": false
"sumoConfig": {
  "Config": "${SUMO_ROOT}/FourLanes/fourlanes.sumocfg",
  "RemotePort": 58289,
  "StepLength": 0.03,
  "Resolution": 0.8,
  "AdditionalRoutes": "${SUMO_ROOT}/FourLanes/fourlanes.rou.xml"
"geoReference": {
  "originAlt": 0,
  "vendor": "",
  "RnkMinorVersion": "1",
  "RnkMajorVersion": "1"
  "originLat": 0,
  "originHdg": 0,
```

```
"localEnuExt": "6378137,0,0;0,1,0;0,0,1;1,0,0",
  "originLong": 0
"passStandard": {
  "timeout": {
     "checked": true,
     "action": "stop",
     "message": "error",
     "minute": 10
  "stopSign": {
     "checked": true,
     "action": "stop",
     "message": "error"
  },
  "speedLimitation": {
     "checked": true,
     "action": "stop",
     "message": "error"
  "crossLane": {
     "checked": true,
     "action": "stop",
     "message": "error"
  "collision": {
   "checked": true,
```

```
"action": "stop",

"message": "error'
}
}
}
```

response

返回创建该案例更新的具体信息

How to import test cases

导入案例根据本地是否已上传案例文件,分别调用不同的 api, 共使用三个 api 完成

judge whether it has been imported

request

URL: 为 Sim-One host + 判断文件是否已导入(/api/files/) + 文件的 md5 值

http://localhost:8088/api/files/文件 md5 值

Methods: Get

Headers: Cookie

Cookie:siderFlex=flex;token=token

response

返回该文件的 md5 值,以及文件大小

根据以上请求返回码,再进行第二步 api 调用

import .sim files

若 judge whether it has been imported 返回状态码为 200 且 size 等于 0, 说明该文件未曾导入,先进行导入文件 api 调用

request

URL: 为 Sim-One host +判断文件是否已导入(/api/files/)+文件的 md5 值+导入方法(/upload)

http://localhost:8088/api/files/文件 md5 值/upload

Methods:Post

Headers:Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex; token=token 信息

Body:

- filename(string)
 target file name
- catagory(string)
 category name
- index(string)

file index

- chunks(int)
 chunk about file
- filesize(int)
 size of file

- uploadId(string)
- uuid about target file
- files(binary)target file

response

返回码: code, 成功 0, 其他不成功

upload to case library

将文件导入后,再调用 import 方法上传至导入的案例库中

并且若 judge whether it has been imported 返回状态码为 200 且 size 大于 0,

说明该文件已导入,则直接调用 import 方法 api

request

URL:为 Sim-One host +上传方法(/import)

http://localhost:8088/api/cases/import

Methods:Post

Headers:Content-Type, cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

- id(string)
 uuid about upload file
- category(string)

uuid about category

• file(string)

Md5 of the file

includes(list)

caseid

includesVehicle(bool)

include vehicle informatione or not

response

返回导入文件的 id 信息,若请求时未传,则返回为空

How to create a category

新建案例库类别

request

URL:为 Sim-One host + 创建方法(api/categories)

http://localhost:8088/api/categories

Methods:使用 Post 方法

Headers:Content-Type, 以及 cookie 信息

Content-Type:application/json

Cookie: sider Flex=flex; token=token

Body:

parentld(string)

uuid about parent case

• name(string)

case name

response

返回创建的案例类的 id 信息, 以及该案例名称

How to create a test suite

新建测试集

request

URL: 为 Sim-One host + api/suites

http://localhost:8088/api/suites

Methods:Post

Headers:Content-Type, 以及 cookie 信息

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

- parentld(string)
 - uuid about parent case
- name(string)

case suits name

response

返回新建测试集的 id 以及名称

How to delete a test case

删除测试案例

request

URL:为 Sim-One host +api/cases/delete

http://localhost:8088/api/cases/delete

Methods:Post

Headers:Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

caselds(list)

caseid

response

返回删除任务 taskid 信息

How to delete a category

删除指定的案例库

request

URL:为 Sim-One host +api/categories/案例库 id

http://localhost:8088/api/categories/案例库 id

Methods:DELETE

Headers:cookie

Cookie:siderFlex=flex;token=token

response

返回删除的案例库id

How to delete a test suite

删除指定的测试集

request 🚿

URL:为 Sim-One host +api/suites/测试集 id

http://localhost:8088/api/suites/测试集 id

Methods:DELETE

Headers:cookie

Cookie:siderFlex=flex;token=token

response

返回删除的案例库id

Test task

How to creat a task

运行选中的案例, 创建任务

requests

URL:为 Sim-One host+api/tasks

http://localhost:8088/api/tasks

Methods:Post

Headers:Content-Type, cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

caselds(list)

caseid

taskName(string)

task name

response

返回创建该任务的 sessionId 信息

How to pause a task

暂停正在运行的用例

request

URL:为 Sim-One host +api/sessions/sessionid/pause

http://localhost:8088/api/sessions/sessionid/pause

Methods:Post

Headers:cookie

Cookie:siderFlex=flex;token=token

response

返回为空

How to resume a task

继续已暂停的用例

request

URL:为 Sim-One host +api/sessions/sessionid/resume

http://localhost:8088/api/sessions/sessionid/resume

Methods:Post

Headers:cookie

Cookie:siderFlex=flex; token=token 信息

response

返回为空

How to stop a task

停止任务,分为停止正在运行的一个案例,与停止整个任务,二者仅入参不同

stop the running case

request

URL: 为 Sim-One host +停止方法(/api/tasks/stop)

http://localhost:8088/api/tasks/stop

Methods:使用 Post 方法

Headers:Content-Type, cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

tasklds(string)

uuid about this task

response

返回为空

stop the session

request

URL: 为 Sim-One host +停止方法(/api/sessions/stop)

http://localhost:8088/api/sessions/stop

Methods:Post

Headers:Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body

sessionId(string)

uuid about this session

response

返回为空

How to delete a task

删除已/未完成的任务分为两个 api 请求,删除 taskid,以及删除 sessionid

delete taskid

request

URL:为 Sim-One host +api/tasks/delete

http://localhost:8088/api/tasks/delete

Methods:Post

Headers:Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

tasklds(list)

taskid

response

返回删除任务 taskid 信息

delete sessionid

request

URL: 为 Sim-One host +api/sessions/delete

http://localhost:8088/api/sessions/delete

Methods: Post

Headers: Content-Type,cookie

Content-Type:application/json

Cookie:siderFlex=flex;token=token

Body:

taskSessionIds(list)

sessionid

response

返回删除任务 sessionid 信息

Test analysis

How to export the report

导出报告查看运行结果

request

URL:为 Sim-One host +api/sessions/+该任务的 sessionid+/report

http://localhost:8088/api/sessions/sessionid/report

Methods:Get

Headers:Cookie

Cookie:siderFlex=flex;token=token

response

返回该任务执行的测试结果

How to export the csv file

针对已运行后的案例, 到处关于主车运行轨迹的 csv 文件

request

URL: 为 Sim-One host +api/tasks/taskid 信息/data

http://localhost:8088/api/tasks/taskid/data

Methods:Get

Headers:cookie

Cookie:siderFlex=flex; token=token

response

返回请求结果信息

How to replay a case

已完成任务中重新测试该案例

request

URL: 为 Sim-One host +api/tasks/taskid 信息/replay

http://localhost:8088/api/tasks/taskid/replay

Methods:Post

Headers:cookie

Cookie:siderFlex=flex;token=token

response

返回 sessionid 信息

A.C.I.E S SILLOW Sundiff 59 S SIMILE SHILDHE S SINTONE S SHILOHE S Sintone 254