Using your Audibox

The **USB-DI** *VC* is a Direct Injection, or Direct, box. It is a self contained, stand alone stereo unit designed to interface stereo digital audio with professional balanced low impedance inputs. It will convert computer audio signals into ones that are happy to travel down a long line into a mixing console at the other end. It has many applications for Live Sound, Studio or Broadcast use.

Plug and Play

If you are running Win XP or Vista, as soon as you plug the USB-DI VC into a spare USB port on the computer it will be recognised as a USB Audio Device, and will be ready straight away. With Win 98SE, as soon as you plug the USB-DI VC into a spare USB port on the computer it will be recognised as a USB Composite Device, and the Add New Hardware Wizard screen will pop up. Click NEXT on the first 2 screens, put in the 98SE CD Rom, then select CD Rom drive on the search screen and click NEXT. Click Next on the following pop up screen, then FINISH on the final screen.

It will then install the USB Device drivers, and repeat the install process for a USB Audio Device.

A complete set of pop up installation screens can be found on the ARX website at:


www.arx.com/audibox_usb_di.htm

IMPORTANT #1

The Windows default volume setting for USB Audio Devices is 50% of maximum. In many cases this will be too low, inducing noise and hum as excessive gain may need to be applied to deliver the level required. We suggest increasing this volume setting to 100%.

No matter which operating system you are using, once the **USB-DI** is installed, go to Control Panel, then Sounds and Audio Devices, then USB Audio Device, then the Volume tab, and move the slider to the right, reading 100%. This will give you the optimum signal to noise ratio.

Please Note: Even if you reduce the overall output with the Volume control on the unit, you still need to do this step!



Page 4

IMPORTANT #2

Computers are very electrically noisy environments, and USB is a very popular Plug and Play protocol for lots of Windows devices.

For fastest and quietest audio operation you *must* plug the USB-DI *VC* into its own USB port, **not a hub**. Experiment on your computer to find the quietest USB port, and keep it only for the USB-DI *VCI* - don't have anything else on the same bus.

Otherwise you may get a hissing and clicking noise every time you move the mouse, touch the keyboard, or click on the screen.

IMPORTANT #3

Keep mobile/cellular phones well away (at least 2 metres/8 feet) from the computer and the USB-DI. The "Dut dut-dah-dut dut-dah-dut dut-dah-dut" sound of a mobile phone connecting is not one that audiences care to hear!

Operating instructions Input Connections

Connect the USB connector to the USB-DI VC and to the USB port on the computer. On XP and Vista it will be available immediately and the LED on the front of the USB-DI will start to flash. On 98SE follow the previous instructions. You **will** need the 98 SE install CD Rom.

Adjust the Audio Level as described in the Important #1 note on the previous page.

Output Connections

Connect a balanced microphone lead from each 3 pin XLR connector on the **USB-DI VC** to a pair of input channels on the mixing console. Set the Output volume control on the **USB-DI VC** to 0db (hard right) at first - you can reduce it later if necessary. Set the Input Gains on the channels, and Pan the channels Left or Right as required.

To check that the **USB-DI** *VC* is set up correctly, open your audio software, ensure that USB Audio Device is selected as the default audio device, open a music file and play.

If the output level is causing the input channels to clip even when the input gain is reduced, you can use the Volume control on the **USB-DI VC** to reduce the output level

That's all there is to it.

Put simply, the **USB-DI** *VC* is the USB pro audio interface that Audio Professionals have been waiting for!

Latest information updates are always available on the comprehensive ARX website:

www.arx.com.au

Page 5

Did you know...

As well as the **USB-DI**, ARX manufacture other products in the unique Audibox range:

The ISO-Balancer for balancing unbalanced signals, and also the ISO De-Balancer, which will de-balance a signal when required to connect to an unbalanced input.

The ISO-Later is a Dual channel Unbalanced to Balanced Low Impedance transformer isolated converter, and the ISO Splitter is a transformer isolated 1 input to 2 outputs splitter for splitting 1 input 2 ways in applications where complete Galvanic isolation is required.

Both available in Single Channel or Double Header format.

The Ear Driver is a Headphone Amplifier with 2 pairs of Stereo inputs each feeding two channels of headphone level outputs. It has individual Level controls plus a 12 - 15VDC power connector. A compact, flexible unit

The **Pro-DI** is an ultra compact Active Direct box, with normal High Impedance input as well as a separate speaker level input for connection to instrument amplifiers.

Other features include –20dB Pad and Audio Ground Lift switches, plus Phantom or DC power options.

Available in Single Channel or Double Header format

The **DI-Pre** is an Ultra compact Microphone Pre amp with XLR input, balanced jack output and 10 to 60dB Gain control. Other features include –20dB Pad switch, Clip LED and Phantom Power switch, plus DC power connector.

Available in Single Channel or Double Header format

For the latest information on the complete Audibox range, visit our website:

www.arx.com.au/audibox.htm

©2008 ARX Systems Pty.Ltd. ACN 006 471 825. All rights reserved. ARX Systems® is a Registered Trade Mark.



INTERNATIONAL LIFETIME WARRANTY

ARX Systems (ARX) warrants to the first purchaser of this Audibox product that it is free from defects in materials and workmanship under normal use and service. ARX's sole obligation under this warranty shall be to provide, without charge, parts and labour necessary to remedy defects, if any, which appear within twelve (12) months from date of purchase; and to supply parts only (where possible) for the life of the product to the original purchaser.

This is our sole warranty. It does not cover finish or appearance items, nor does it apply if the Audibox has been, in ARX's sole judgement:

- Subjected to misuse, abuse, negligence or accident;
- Repaired, worked on, or altered by persons not authorized by ARX,
- Connected, installed, adjusted or used otherwise than in accordance with the instructions supplied by ARX.

This warranty gives you and us specific legal rights, and you may also have other rights which can vary from state to state.

To obtain warranty service for your Audibox, call, write, or Email to ARX or the dealer you purchased it from. They will give you the correct address to send your unit to. Have your sales receipt showing date of purchase handy, and include a copy of it with your Audibox. Please pack the unit well - we are not responsible for any damage caused by unsuitable packing during shipment. Send the unit to us pre-paid, by a delivery service like FedEx, UPS, or any other service that can track the shipment. We will return it to you freight paid. If you have any questions, or any part of this is unclear, please write to ARX Systems in the country of purchase, or to the address below.

PO Box 15, Moorabbin, Victoria 3189, Australia. Phone: +61 (0)3 9555 7859 Fax: +61 (0)3 9555 6747

You can also Email the factory at: info@arx.com.au

Page 6 Page 7

other interaction noise and distortion.

USB connection.

ble mounting kit.

rubber foot pads.

in' before shipping.

eliminates earth loops / ground hum and

Full transformer balanced output isolation

fors supply Balanced audio output from a

Transformer isolated dual XLR connec-

The USB-DI VC is a true Plug-and-Play

up to 3 units plus power supply in 1 RU.

A rack mount kit is also available to rack

lock, and the option of a permanent ta-

features including a slot for a computer

ment we've added numerous security

pact and portable; to protect your invest-

By their very nature these units are com-

screen printing and large slip resistant

powdercoat, with hardwearing epoxy

sis finished in attractive matt blue textured

fnie the same heavy duty all-steel chas-

-feat agar range fea-

please familiarise yourself with the con-

To ensure continued trouble free use,

gone extensive factory testing and 'burn

tents of this manual before using.

Digital to Analog audio interface

About the USB-DI VC

- install driver. of moA GD llstari sti been lliw 3289 •
 - Audio software
 - - + USB bort
 - or Vista (98SE, ME supported)

AX swobniW gninnn JR swobniW •

System Requirements slip-resistant rubber feet

fibreglass PCB, epoxy printing, All-steel powdercoated chassis,

Construction

Pin 3 - Cold. Pin 1 Chassis

2 x Male XLR, wired Pin 2 + Hot,

Output Connectors

Operating current via USB Port 80mA Power

> $20 - 20 \text{ KHz} \pm 0.5 \text{ dB}$ Frequency Response

ISO trans - Enviroment sensitive

USB - System dependent

Output Noise

0dB with output volume control Nominal output level variable ω to

Output Level

300 Ohms Transformer Balanced

Output Impedance

from chassis

USB type B port, ground isolated

Input Connector **USB-DI VC** Specifications

As with all ARX equipment, it has under-Audibox product from ARX. Thank you for choosing this unique

No external power is required - all power

put stages, powered speakers or similar VC in order to match it up with mixer inuate the signal coming out of the USB DI The Output volume control lets you atten-

work of qu ethgil GEL substa lens q front A

when it is operating. the USB-DI VC is connected and will flash

the 98SE CD Rom for driver installation as a USB composite device. You will need SE is also supported and can be installed driver program installation. Windows 98 USB audio device, requiring no special VC is instantly recognised as a generic der Windows XP and Vista. The USB-DI No drivers are required for operation unfor the **USB-DI** is supplied by the USB bus.

mixer input stages and for directly driving powered speakers and similar items. you attenuate the signal coming out of the USB DI VV in order to match it up with when the unit is connected and flashes when in use. An Output volume control lets Type B USB input port; Transformer Balanced XLR Outputs. Status LED illuminates Connections and Controls:

Page 3

N2B-DI NC

"!not gnitisw изле рееи professionals that Audio audio interface "The USB pro



Panaformer Isolated Udb Audio Interface With Output Level IortnoD **3/1**"10" ₹-**(*)** Ž+(**) andano

> Now you can register your product warranty online at:

www.arx.com.au



ARX Systems Pty Ltd, PO Box 15, Moorabbin, Victoria 3189, Australia Phone: (03) 9555 7859 Fax: (03) 9555 6747 International Fax: +61-3 -9555 6747 On the Net: www.arx.com.au

Email: info@arx.com.au

Audipox

Owner's Manual