SONY

Television


4-696-733-01(1)




GB Setup Guide	RU Руководство по установке
CS 设定指南	TH คู่มือการตั้งค่า
CT 安裝指南	ID Panduan Pemasangan
VN Hướng dẫn cài đặt	AR دليل الإعداد
FR Guide d'installation	راهنمای نصب


**BRAVIA** 


KD-70X6700E / 60X6700E





Setup Guide


















1.5 N·m/1,5 N·m {15 kgf·cm}



**Connections** Refer to "Connection Diagram" in the Operating Instructions for additional connection information.

连接 更多连接信息,请参考使用说明书中的"连接示意图"。

**連接** 如需更多連接資訊,請參閱《使用說明書》中的"連接圖"。

Kết nối Tham khảo mục "Sơ đồ Kết nối" trong Hướng dẫn vận hành để biết thêm thông tin kết nối khác.

**Raccordements** Reportez-vous à la section « Schéma des raccordements » du mode d'emploi pour en savoir plus sur les raccordements.

**Подключения** Дополнительную информацию о подключении см. в разделе "Схема подключения" в инструкциях по эксплуатации.


**การเชื่อมต่อ** กรุณาคู "แผนผังการเชื่อมต่อ" ในคู่มือการใช้งานสำหรับข้อมูลการเชื่อมต่อเพิ่มเติม


**Koneksi** Lihat "Diagram Sambungan" di Petunjuk Pengoperasian untuk informasi koneksi tambahan.

التوصيلات يرجى الرجوع إلى « الرسم التخطيطي للتوصيل » في تعليمات التشغيل للحصول على معلومات إضافية تتعلق بالتوصيل.

اتصالات براى اطلاعات بیشتر درباره اتصال به "نمودار اتصال" از دستورالعمل هاى عملكرد مراجعه كنید.

3





4

