SONY

Television

4-690-893-11(1)


* 4 6 9 0 8 9 3 1 1 * (1)

4 6 9 0 8 9 3 1 1 1 (

GB Setup Guide	RU Руководство по установке
CS 设定指南	TH คู่มือการตั้งค่า
CT 安裝指南	ID Panduan Penyetelan
VN Hướng dẫn cài đặt	AR ليل الإعداد
FR Guide d'installation	اهنمای نصب PR

BRAVIA

KD-75X8500E / 65X8500E / 55X8500E FW-65X8501E / 55X8501E



Setup Guide



★ Only on limited region/country/TV model. 仅针对有限的地区/国家/电视机型号。 僅限於限定地區/國家/電視機機型。

Chỉ có ở khu vực/quốc gia giới hạn/kiểu TV.

Uniquement dans certains pays ou certaines regions/modèle de téléviseur.

มีเฉพาะในบางภูมิภาค/ประเทศ/รุ่นทีวีเท่านั้น

Hanya untuk kawasan/negara/model TV tertentu.

في منطقة/بلد محدودة فقط/موديل التلفزيون.

فقط در منطقه کشور محدود شده/منطقه شما فرق داشته باش.

