ILHA DA TRINDADE (BRASIL) - 2021 Longitude 029° 18'.6 W

Latitude 20° 30'.5 S DHN

22 Componentes

Nível Médio 0.67 m

Fuso +02.0 horas Carta 21

ı			OHN			22	Comp	onen	ites			Níve	l Médi	io 0.6	7 m			Ca	rta 21					
		eiro			Fevereiro							Março						Abril						
HOR	HORA ALT (m) HORA ALT (m)							(m)		A ALT		HOR	A ALT			A ALT		HOR	A ALT	` ′		A ALT		
01 SEX	0000 0604 1208 1802	0.1 1.2 0.3 1.2	17 DOM	0111 0715 1319 1915	0.1 1.1 0.3 1.1	01 SEG		0.1 1.2 0.3 1.2	17 QUA	0136 0739 1343 1956	0.3 1.0 0.3 1.0	01 SEG	0600 1204 1808	1.3 0.1 1.3	17 QUA	0028 0630 1236 1849	0.2 1.1 0.2 1.1	01 QUI	0049 0651 1300 1917	0.2 1.2 0.2 1.2	17 SAB	0058 0706 1321 1951	1.0 0.3	
02 SAB	0026 0647 1247 1843	0.1 1.2 0.3 1.1	18 SEG	0151 0754 1358 1956	0.2 1.0 0.4 1.1	02 TER	0136 0749 1353 1956	0.1 1.1 0.3 1.1	18 QUI	0813 1424	0.4 0.9 0.4 0.9	02 TER	0030 0639 1243 1851	0.0 1.2 0.2 1.3	18 QUI	0054 0700 1304 1921	0.3 1.1 0.3 1.0	02 SEX	0134 0730 1351 2011	1.1 0.2	18 DOM	0143 0751 1419 2054	0.9 0.4	
03 DOM	0108 0728 1330 1926	0.1 1.1 0.4 1.1	19 TER	0232 0834 1443 2045	0.3 1.0 0.4 1.0	03 QUA	0224 0834 1443 2053	1.0 0.4	19 SEX	0904 1530	0.5 0.9 0.5 0.9	03 QUA	0111 0715 1323 1936		19 SEX	1339	0.4 1.0 0.4 0.9	03 SAB	0232 0819 1500 2130		19 SEG	0302 0856 1553 2234	0.9 0.4	
04 SEG	0158 0815 1421 2017	0.2 1.1 0.4 1.1	20 QUA	0321 0921 1541 2145	0.4 0.9 0.5 0.9	04 QUI	0326 0932 1553 2204	1.0 0.4	20 SAB	0417 1023 1709 2341	0.5 0.8 0.5 0.8	04 QUI	0158 0800 1411 2028	0.2 1.1 0.3 1.1	20 SAB	0813 1436	0.5 0.9 0.4 0.9	04 DOM	0402 0934 1643 2332	0.9 0.4	20 TER	0502 1038 1732	0.8	
05 TER	0254 0911 1523 2119	0.2 1.0 0.4 1.0	21 QUI	0424 1026 1656 2306	0.4 0.9 0.5 0.9	05 SEX	0447 1049 1717 2343	0.9	21 DOM		0.5 0.9 0.4	05 SEX	0256 0853 1519 2143	1.0 0.4	DOM C		0.6 0.8 0.5 0.8	05 SEG	0554 1126 1821	0.6 0.9 0.3	21 QUA	0009 0624 1208 1841	0.5 0.9	
06 QUA	0402 1019 1636 2239	1.0 0.4	22 SEX	0539 1145 1813	0.5 0.9 0.4	06 SAB	0613 1215 1845	0.4 0.9 0.3	22 SEG	0111 0724 1319 1947	0.5 0.9	06 SAB	0419 1006 1658 2338	0.5 0.9 0.4 0.9	22 SEG	1117	0.6 0.8 0.4	06 TER	0108 0711 1256 1928	1.0 0.5 0.9 0.3	22 QUI	0109 0719 1309 1934	0.4 1.0	
07 QUI	0517 1134 1749	1.0	23 SAB	0032 0651 1254 1919	0.9 0.5 0.9 0.4	07 DOM	0113 0734 1328 1954		23 TER	0819 1411	1.0 0.4 1.0 0.2	07 DOM	0608 1156 1838		23 TER	0049 0702 1251 1919		07 QUA		1.0 0.4 1.0 0.2	23 SEX	0156 0802 1400 2017	0.3 1.1	
08 SEX	0002 0630 1241 1856	1.0 0.3 1.0 0.3	24 DOM	0139 0751 1351 2011	1.0 0.4 1.0 0.3	08 SEG	0219 0834 1423 2051	1.1 0.4 1.0 0.2	24 QUA	0254 0902 1456 2117	0.3 1.1	08 SEG	0119 0732 1317 1951	1.0 0.5 0.9 0.3	24 QUA	1345	1.0 0.4 1.0 0.2	08 QUI	0238 0841 1430 2058	1.1 0.3 1.1 0.1	24 SAB	0236 0843 1443 2100	0.2 1.2	
09 SAB	0113 0736 1339 1956	1.1 0.3 1.0 0.2	25 SEG	0228 0839 1436 2058	1.0 0.4 1.0 0.2	09 TER	0309 0921 1508 2138	1.1 0.3 1.1 0.1	25 QUI	1536	1.2 0.2 1.2 0.0	09 TER	0219 0826 1411 2043	0.4 1.0	25 QUI	0228 0836 1428 2051	1.1 0.3 1.1 0.1	09 SEX	0308 0911 1506 2132	1.1 0.3 1.2 0.1	25 DOM	0313 0921 1524 2143	0.1 1.3	
10 DOM	0215 0832 1430 2053	0.3 1.1	26 TER	0313 0923 1517 2139	0.3 1.1	10 QUA	0354 1002 1551 2219	1.2	26 SEX	0409 1017 1613 2236	0.2 1.3	10 QUA	0302 0908 1456 2124	0.3 1.1	26 SEX	0306 0911 1508 2128	0.2 1.2	10 SAB	0338 0943 1541 2202	1.2	26 SEG	0354 1000 1608 2224	0.1 1.4	
11 SEG	0309 0923 1515 2141	0.3 1.2	27 QUA	0354 1002 1558 2219	0.3 1.2	QUI	0432 1038 1626 2258	0.3 1.2	27 SAB	0449 1054 1653 2311	0.1 1.3	11 QUI	0339 0943 1534 2202	0.3 1.2	27 SAB	0345 0951 1551 2208	0.1 1.3	11 DOM	0404 1011 1613 2234	0.2 1.3	²⁷ TER	0432 1041 1653 2306	0.0 1.4	
12 TER	0358 1008 1600 2228	0.3 1.2	28 QUI	0434 1041 1636 2258	0.2 1.2	12 SEX	0506 1109 1702 2334	1.3		0524 1128 1730 2352	0.1 1.4	12 SEX	0409 1013 1606 2236	0.2 1.3	28 DOM	0419 1024 1628 2247	0.1 1.4	12 SEG	0434 1041 1647 2302	1.3		0509 1121 1736 2351	0.0 1.3	
13 QUA	0445 1053 1643 2311	0.3 1.2	29 SEX	0509 1117 1711 2336	0.2 1.2	SAR	0539 1141 1738	0.2				13 SAB	0439 1045 1641 2306	0.2 1.3	29 SEG	0458 1102 1708 2326	0.1 1.4	13 TER	0502 1109 1717 2330	0.1 1.2	29 QUI	0551 1204 1821	0.1	
14 QUI	0524 1132 1721 2354	0.3 1.2	30 SAB	0551 1154 1751	0.2	14 DOM	0006 0608 1209 1809	1.2 0.2				14 DOM	0508 1111 1711 2336	0.2 1.3	30 TER	0534 1139 1751	0.1	14 QUA	0530 1139 1753 2356	1.2	30 SEX	0034 0628 1253 1909	1.1 0.1	
15 SEX	0604 1208 1800	0.3	31 DOM	0013 0626 1230 1828	0.2	SEG	0038 0639 1239 1845	1.1 0.3				15 SEG	0536 1141 1745	0.2	31 QUA	0006 0609 1219 1832	1.3 0.1	15 QUI	0600 1209 1824	0.2				
16 SAB	0034 0641 1245 1838	1.1 0.3				16 TER	0106 0706 1308 1917	1.1 0.3				16 TER	0002 0602 1206 1815	1.2 0.2				16 SEX	0024 0632 1241 1902	1.1 0.3				
						<u> </u>						<u> </u>						<u> </u>						

ILHA DA TRINDADE (BRASIL) - 2021 Longitude 029° 18'.6 W

Latitude 20° 30'.5 S 22 Componentes Fuso +02.0 horas Carta 21

Latitude 20° 30'.5 S DHN						22	Comp	onen		ongituo	ie 02	9° 18'.6 V Níve	v :l Médi	io 0.6	57 m		uso +02.0 horas Carta 21												
Maio								Ju	nho					Jul	ho					Ag	osto	HORA ALT (m)							
HOR	HORA ALT (m)			A ALT	• •	HORA ALT (m)						HOR	A ALT	` /	HOR.	A ALT (HOR	A ALT		HOR.								
01 SAB	0123 0709 1347 2008	0.4 1.1 0.2 1.0	17 SEG	0134 0736 1408 2041	0.5 1.0 0.3 0.9	01 TER	0321 0853 1558 2224	0.5 1.0 0.3 0.9	17 QUI	0326 0915 1600 2226	0.5 1.0 0.3 1.0	01 QUI	0330 0913 1609 2221	0.5 1.0 0.3 0.9	17 SAB	0353 0954 1634 2251	0.4 1.0 0.3 1.0	01 DOM	0428 1034 1711 2317	0.5 0.9 0.5 0.9	17 TER		0.4 1.0 0.4						
02 DOM	0223 0802 1458 2124	0.5 1.0 0.3 0.9	18 TER	0245 0836 1523 2158	0.5 0.9 0.3 0.9	02 QUA	0436 1008 1709 2341	0.5 0.9 0.3 0.9	18 SEX	0439 1032 1709 2336	0.4 1.0 0.3 1.0	02 SEX	0436 1024 1711 2326	0.5 0.9 0.4 0.9	18 DOM	0506 1113 1749	0.4 1.0 0.3	02 SEG	0553 1204 1828	0.5 0.9 0.5	18 QUA	0100 0728 1354 2006	1.0 0.3 1.0 0.4						
03 SEG	0349 0911 1626 2313	0.6 0.9 0.3 0.9	19 QUA	0413 0956 1645 2319	0.5 0.9 0.3 1.0	03 QUI	0545 1128 1811	0.5 0.9 0.3	19 SAB	1147	0.4 1.0 0.2	03 SAB	0541 1141 1813	0.5 0.9 0.4	19 SEG	0621 1238	1.0 0.3 1.0 0.3	03 TER	0036 0704 1319 1932	0.9 0.4 0.9 0.4	19 QUI	0828 1451	1.0 0.2 1.1 0.3						
04 TER	0524 1053 1754	0.6 0.9 0.3	20 QUI	0534 1119 1756	0.5 1.0 0.3	04 SEX	0039 0641 1236 1904	0.9 0.5 1.0 0.3	20 DOM	0647 1254	1.1 0.3 1.1 0.2	04 DOM	0026 0643 1249 1908	0.9 0.4 0.9 0.4	20 TER	0108 0726 1347 2002	1.0 0.3 1.1 0.3	04 QUA	0136 0802 1415 2023	1.0 0.3 1.0 0.4	20 SEX	0251 0917 1536 2141	1.1 0.1 1.2 0.3						
05 QUA	0039 0638 1219 1858	0.9 0.5 0.9 0.3	21 SEX	0024 0634 1228 1854	1.0 0.4 1.0 0.2	05 SAB	0119 0726 1326 1949	1.0 0.4 1.0 0.3	21 SEG	0130 0741 1354 2008	1.1 0.2 1.2 0.2	05 SEG	0115 0736 1345 1956	1.0 0.4 1.0 0.4	21 QUA		1.1 0.2 1.1 0.3	05 QUI	0221 0849 1500 2106	1.0 0.3 1.0 0.3	21 SAB	0332 1002 1613 2219							
06 QUI	0128 0726 1315 1947	1.0 0.4 1.0 0.2	22 SAB	0115 0723 1324 1945	1.1 0.3 1.1 0.1	06 DOM	0156 0806 1408 2024	1.0 0.3 1.1 0.3	22 TER	0217 0834 1449 2102	1.2 0.1 1.2 0.2	06 TER	0200 0821 1432 2039	1.0 0.3 1.0 0.4	22 QUI	0254 0919 1538 2147	1.1 0.1 1.2 0.3	06 SEX	0304 0930 1541 2147	1.1 0.2 1.1 0.3	22 DOM	0409 1043 1653 2256	1.3 0.0 1.2 0.2						
07 SEX	0202 0804 1400 2023	1.0 0.4 1.1 0.2	23 DOM	0202 0809 1415 2034	1.2 0.2 1.2 0.1	07 SEG	0228 0843 1449 2100	1.1 0.3 1.1 0.3	23 QUA	0923 1541	1.2 0.1 1.3 0.2	07 QUA	0241 0904 1513 2121	1.1	23 SEX	0341 1009 1624 2232	1.2 0.0 1.2 0.3	07 SAB	0343 1008 1617 2224	1.2 0.1 1.2 0.3	23 SEG	1121 1724	1.3 0.0 1.2 0.2						
08 SAB	0232 0838 1438 2058	1.1 0.3 1.1 0.2	24 SEG	0245 0854 1504 2119	1.2 0.1 1.3 0.1	08 TER	0917 1526	1.1 0.2 1.1 0.3	24 QUI	0353 1013 1630 2241	1.2 0.0 1.3 0.2	08 QUI	0319 0945 1556 2200	1.1 0.2 1.1 0.3	24 SAB	0423 1056 1708 2313	1.2 0.0 1.2 0.3	08 DOM	0419 1045 1656 2300	1.2 0.1 1.2 0.2	24 TER	1156	1.3 0.0 1.2						
09 DOM	0300 0908 1511 2128	1.1 0.2 1.2 0.2	25 TER	0326 0939 1553 2206	1.3 0.1 1.3 0.1	09 QUA	0336 0954 1604 2209	1.1 0.2 1.1 0.3	25 SEX		1.2 0.0 1.2 0.2	09 SEX	0358 1023 1636 2239	1.1 0.2 1.1 0.3	25 DOM	0504 1139 1751 2354	1.3 0.0 1.2 0.3	09 SEG	0456 1121 1732 2336	1.2 0.0 1.2 0.2	25 QUA	1228	0.2 1.3 0.1 1.1						
10 SEG	0330 0941 1547 2200	1.2	26 QUA	0408 1024 1639 2253	0.0 1.3	10 QUI	0409 1030 1643 2247	1.1	26 SAB	0519 1153 1806	0.0	10 SAB	0436 1100 1711 2317	0.1 1.1	26 SEG	0545 1221 1828	0.0	10 TER	0532 1156 1808	0.0	26 QUI	0028 0632 1258 1858	1.2 0.2						
11 TER	0400 1011 1621 2230	0.2 1.2	27 QUI	0453 1109 1726 2339	0.0 1.3	11 SEX	0447 1106 1721 2321	0.2 1.1	27 DOM	0013 0602 1241 1854	1.2 0.1	11 DOM	0511 1138 1753 2354	0.1 1.2	27 TER	0030 0623 1300 1904	1.2 0.1	11 QUA	0009 0608 1234 1847	1.3 0.1	27 SEX	0058 0704 1330 1928	1.1 0.3						
12 QUA	0432 1045 1658 2300	0.2 1.2	28 SEX	0534 1200 1815	0.0	12 SAB	0521 1143 1800	0.2	28 SEG	0058 0647 1328 1941	1.2 0.1	12 SEG	0551 1215 1830	0.1	28 QUA	0106 0700 1339 1941	1.2 0.2	12 QUI	0047 0649 1313 1923	1.2 0.1	28 SAB	0130 0743 1402 2002	1.0 0.4						
13 QUI	0504 1117 1732 2332	0.2 1.1	29 SAB	0026 0615 1251 1906	1.2 0.1	13 DOM	0000 0558 1221 1843	1.1 0.2	29 TER	0145 0730 1417 2028	1.1 0.2	13 TER	0030 0626 1254 1909	1.2 0.1	29 QUI	0143 0741 1419 2019	1.1 0.3	13 SEX	0124 0730 1358 2008	1.2 0.2	29 DOM	0209 0824 1447 2051	0.9 0.5						
14 SEX	0538 1151 1808	0.2	30 DOM	0117 0700 1345 2002	1.1 0.2	14 SEG	0039 0639 1304 1926	1.1 0.2	30 QUA	0234 0819 1511 2121	1.0 0.3	14 QUA	0109 0706 1338 1954	1.1 0.2	30 SEX	0224 0823 1504 2104	1.0 0.4	14 SAB	0211 0819 1454 2100	1.1 0.3	30 SEG	0315 0934 1608 2206	0.8 0.5						
15 SAB	0006 0609 1228 1853	1.1 0.2	31 SEG	0213 0753 1449 2106	1.0 0.2	15 TER	0124 0721 1354 2017	1.0 0.2				15 QUI	0154 0753 1424 2043	1.1 0.2	31 SAB	0317 0917 1600 2202	0.9 0.4	15 DOM	0315 0926 1606 2209	0.4	31 TER	0506 1126 1800 2359	0.8 0.5						
16 DOM	0045 0651 1311 1939	1.0 0.3				16 QUA	0219 0811 1453 2117	1.0 0.3				16 SEX	0247 0847 1524 2141	1.0 0.3				16 SEG	0439 1058 1736 2339	1.0 0.4									
						<u> </u>						<u> </u>																	

ILHA DA TRINDADE (BRASIL) - 2021 Longitude 029° 18'.6 W

Latitude 20° 30'.5 S

Fuso +02.0 horas

ı	OHN	20 30		22	Comp	onen				Níve	l Médi	o 0.6	7 m	Carta 21														
Setembro HORA ALT (m) HORA ALT (m)									ubro						mbro						embro	HORA ALT (m)						
	A ALT 0645	(m) 0.5		A ALT 0153	(m) 1.0		A ALT 0051	(m)	HOR 17	A ALT 0213	(m)		0145	` /		0302	(m) 1.2	_	A ALT 0156	• •		A ALT 0319						
01 QUA	1306 1919	0.9	17 SEX	0819 1441 2047	0.2 1.1	01 SEX	0717 1339		DOM	0843 1454	0.1 1.1 0.3	01 SEG	0804	0.1 1.2	17 QUA	0921	0.2 1.1	01 QUA	0811 1423 2032	0.1 1.2	SEX	0932 1526 2147	0.3 1.1					
02 QUI	0745 1402	0.9 0.4 1.0 0.4	18 SAB	0238 0904 1519 2123	1.1 0.1 1.2 0.3	02 SAB	0139 0800 1417 2024	1.1	18 SEG	0917 1523	1.2 0.1 1.2 0.2	02 TER	0226 0845 1456 2102	0.1 1.2	18 QUI	0953 1551	1.2 0.2 1.1 0.2	02 QUI		1.3 0.1 1.2 0.1	18 SAB	0358 1006 1602 2223	0.3 1.1					
03 SEX	0204 0828 1443 2051	0.3 1.1	19 DOM	1554	1.2 0.0 1.2 0.2	03 DOM	0217 0839 1453 2058	0.1 1.2	19 TER	0951	1.2	03 QUA	0306 0924 1534 2141	0.0 1.3	19 SEX	0409 1023 1619 2234	0.2 1.1	03 SEX	0332 0945 1549 2202	0.1 1.3	19 DOM	0436 1043 1638 2258	0.3 1.1					
04 SAB	0906	1.1 0.2 1.1 0.3	20 SEG	0353 1019 1624 2226	1.3 0.0 1.2 0.2	04 SEG	0915	1.2 0.1 1.2 0.2	QUA	1021 1619	1.3 0.1 1.2 0.1	04 QUI	0351 1006 1609 2219	1.4 0.0 1.3 0.0	20 SAB	1054 1653	1.2 0.3 1.1 0.2	04 SAB	0417 1032 1630 2249	0.1 1.3	20 SEG	0511 1117 1711 2334	0.3					
05 DOM	0321 0943 1554 2200	1.2 0.1 1.2 0.2	21 TER	0426 1054 1654 2258	1.3 0.0 1.2 0.2	05 TER	1600	1.3 0.0 1.3 0.1	21 QUI	1649	1.3 0.1 1.2 0.1	05 SEX	0432 1049 1651 2300	0.1 1.3	21 DOM	1723	1.1 0.3 1.1 0.2	05 DOM	0506 1119 1713 2338	1.2	21 TER	0551 1153 1749	0.3					
06 SEG	0358 1017 1630 2234	1.3 0.0 1.3 0.2	22 QUA	0500 1124 1723 2326	1.3 0.1 1.2 0.2	06 QUA	1028 1638	1.3 0.0 1.3 0.1	22 SEX	0506 1119 1717 2324		06 SAB	0513 1130 1728 2343		22 SEG	1156	1.1 0.4 1.1	06 SEG	0556 1206 1758	1.3 0.2 1.2	22 QUA	0009 0626 1226 1823	1.1 0.4					
07 TER	0434 1054 1704 2306	0.0	23 QUI	0532 1154 1753 2356	1.3 0.1 1.1 0.2	07 QUI	0449 1106 1711 2317	0.0 1.3	23 SAB	1147 1749	1.2 0.3 1.1 0.2	07 DOM	0600 1215 1809	0.2	23 TER	1234	0.2 1.0 0.4 1.0	07 TER	0026 0645 1256 1845	1.2 0.3	23 QUI	0047 0706 1306 1902	1.1 0.4					
08 QUA	0509 1130 1741 2341	1.3 0.0 1.3 0.1	24 SEX	0604 1221 1819	1.2 0.2 1.1	08 SEX	0528 1147 1751 2354	1.4 0.1 1.2 0.1	24 DOM		1.1 0.3 1.1	08 SEG	0030 0651 1304 1854	0.1 1.2 0.3 1.1	24 QUA			08 QUA	0119 0738 1351 1932	0.1 1.1 0.4 1.1	24 SEX	0130 0751 1353 1949	1.0					
09 QUI	0549 1208 1815	1.3 0.0 1.2	25 SAB	0024 0638 1249 1851	0.2 1.1 0.3 1.0	09 SAB		1.3 0.2 1.2	25 SEG		0.3 1.0 0.4 1.0	09 TER	0124 0747 1404 1947	1.1 0.4	25 QUI	0147 0811 1419 2011	0.9 0.5	09 QUI	0219 0838 1453 2030	0.2 1.0 0.5 1.0	25 SAB	0219 0841 1449 2045	1.0 0.5					
10 SEX	0017 0626 1247 1854	1.3 0.1	26 DOM	0054 0709 1317 1921	1.0 0.4	10 DOM	0036 0656 1311 1908	1.2 0.3	26 TER	0108 0736 1332 1938	0.9 0.5	10 QUA	0234 0858 1524 2054	1.0 0.5	26 SEX	0254 0923 1543 2126	0.9 0.5	10 SEX	0326 0949 1602 2141	0.9 0.5	26 DOM	0321 0943 1556 2154	1.0 0.5					
11 SAB	0056 0708 1330 1936	1.2 0.2	27 SEG	0130 0754 1358 2004	0.9 0.5	11 SEG	0124 0749 1408 1958	1.1 0.4	27 QUA	0206 0838 1451 2043	0.9 0.6	oui C	0400 1038 1658 2228	0.9 0.5	27 SAB	0417 1045 1704 2253	0.9 0.5	11 SAB	0441 1106 1713 2302	0.9 0.5	27 SEG	0434 1054 1708 2311	1.0 0.4					
12 DOM	0143 0800 1424 2023	1.1 0.3	28 TER	0228 0858 1521 2115		12 TER	0232 0900 1534 2108	1.0 0.5	28 QUI	0343 1013 1651 2224	0.8 0.6	12 SEX	0528 1211 1813	0.9	28 DOM	0532 1156 1808	1.0	12 DOM	0551 1215 1817	0.9	28 TER	0545 1202 1813	1.0					
13 SEG	0247 0908 1545 2136	1.0 0.5	29 QUA	0428 1058 1741 2321	0.8	13 QUA	0413 1056 1724 2300	0.9 0.5	29 SEX	0523 1156 1811	0.9	13 SAB	0000 0639 1309 1909	0.3 1.0	29 SEG	0004 0632 1253 1900	0.3 1.1	13 SEG	0017 0651 1306 1909	0.3 1.0	29 QUA	0026 0651 1302 1913	0.3 1.0					
14 TER	0421 1054 1732 2319	0.9 0.5	30 QUI	0615 1247 1900	0.9	14 QUI	0556 1243 1851	0.9	30 SAB	0000 0632 1256 1906	0.3 1.0	14 DOM	0102 0732 1351 1953	0.2 1.0	30 TER	0104 0724 1339 1947	0.2 1.1	14 TER	0115 0739 1347 1954	0.3 1.0	30 QUI	0130 0749 1356 2008	0.2 1.1					
15 QUA	0606 1247 1902	1.0				15 SEX	0034 0708 1341 1943	0.3 1.0	31 DOM	0058 0721 1341 1947	0.2 1.1	15 SEG	0149 0813 1421 2024	0.2 1.1				15 QUA	0202 0819 1419 2034	0.3 1.0	31 SEX	0226 0843 1445 2100	0.2 1.2					
16 QUI	0053 0723 1356 2000	0.3 1.0				16 SAB	0132 0800 1419 2021	0.2 1.1				16 TER	0226 0851 1453 2058	0.2 1.1				16 QUI	0243 0858 1454 2109	0.3 1.1								
DG6-58												<u> </u>										<u> </u>	oinal					