


Burroughs Panaflex II BR 16252

Pin	Purpose
1	Cathode a
2	Anode 16
3	Cathode b
4	Anode 15
5	Cathode c
6	Anode 14
7	Cathode h
8	Anode 13
9	Cathode l
10	Anode 12
11	Cathode j
12	Anode 11
13	Not connected
14	Anode 10
15	Not connected
16	Anode 9
17	Not connected
18	Anode 8
19	Not connected
20	Anode 7
21	Not connected
22	Anode 6
23	Not connected
24	Anode 5
25	Not connected
26	Anode 4
27	Cathode d
28	Anode 3
29	Cathode e
30	Anode 2
31	Cathode g
32	Anode 1
33	Cathode f



Brett Hallen, Jan 2026