

IBM 5324 KEYBOARD MATRIX

	Column A	Column B	Column C	Column D	Column E	Column F	Column G	Column H	Column I	Column J	Column K
Row 1	CMD	~ ` [PROC]	@ 2 [LINK]	\$ 4	^ 6 [SAVE]	*) 0	+= [COPY D]		*+ *	
Row 2	ERASE [ATTN]	 1 [LOAD]	# 3 [RUN]	% 5	& 7		(9 [DIR]	- -	CURSOR LEFT CURSOR BACKSPACE	8	/ -
Row 3	HOLD	FIELD ADVANCE FIELD BACKSPACE	W	R	Y		I	P	 \	7	9
Row 4	INQ	SHIFT LOCK	Q	E	T	U	O	!¢ ENTER		4	FIELD -
Row 5	ERROR RESET	LH SHIFT	A	D	G	J	L	" , { } ;		5	6
Row 6	TEST	SCROLL DOWN	S	F	H		K	: ; NEWLINE		1	3
Row 7	SCROLL UP	CURSOR RIGHT [INS]	> <	C	B	N	M	· · RH SHIFT		2	FIELD +
Row 8	CURSOR LEFT CURSOR BACKSPACE [DEL]	ALT	Z	X	V	SPACE	,	?/ FIELD EXIT		0	.