

Sharp MZ-80B Keyboard Matrix

Key	Pin 1	Row	Pin 2	Column
EJECT	J1-1		J1-6	
STOP	J1-2		J1-3	
REW	J1-4		J1-6	
FF	J1-5		J1-6	
]	J2-10	1	J2-1	0
CLR HOME	J2-10	1	J2-3	2
INST DEL	J2-10	1	J2-4	3
8	J2-11	2	J2-1	0
9	J2-11	2	J2-2	1
:	J2-11	2	J2-3	2
;	J2-11	2	J2-4	3
-	J2-11	2	J2-5	4
@	J2-11	2	J2-6	5
[J2-11	2	J2-7	6
0	J2-12	3	J2-1	0
1	J2-12	3	J2-2	1
2	J2-12	3	J2-3	2
3	J2-12	3	J2-4	3
4	J2-12	3	J2-5	4
5	J2-12	3	J2-6	5
6	J2-12	3	J2-7	6
7	J2-12	3	J2-8	7
X	J2-13	4	J2-1	0
Y	J2-13	4	J2-2	1
Z	J2-13	4	J2-3	2
^	J2-13	4	J2-4	3
\	J2-13	4	J2-5	4
?	J2-13	4	J2-6	5
.	J2-13	4	J2-7	6
,	J2-13	4	J2-8	7
P	J2-14	5	J2-1	0
Q	J2-14	5	J2-2	1
R	J2-14	5	J2-3	2
S	J2-14	5	J2-4	3
T	J2-14	5	J2-5	4
U	J2-14	5	J2-6	5
V	J2-14	5	J2-7	6
W	J2-14	5	J2-8	7
I	J2-15	6	J2-1	0
H	J2-15	6	J2-2	1
J	J2-15	6	J2-3	2
K	J2-15	6	J2-4	3
L	J2-15	6	J2-5	4
M	J2-15	6	J2-6	5
N	J2-15	6	J2-7	6
O	J2-15	6	J2-8	7
/	J2-16	7	J2-1	0
A	J2-16	7	J2-2	1

Key	Pin 1	Row	Pin 2	Column
B	J2-16	7	J2-3	2
C	J2-16	7	J2-4	3
D	J2-16	7	J2-5	4
E	J2-16	7	J2-6	5
F	J2-16	7	J2-7	6
G	J2-16	7	J2-8	7
TAB	J2-17	8	J2-1	0
SPACE	J2-17	8	J2-2	1
CR	J2-17	8	J2-3	2
NP ENT	J2-17	8	J2-3	2
UP	J2-17	8	J2-4	3
DOWN	J2-17	8	J2-5	4
LEFT	J2-17	8	J2-6	5
RIGHT	J2-17	8	J2-7	6
BREAK	J2-17	8	J2-8	7
NP 0	J2-18	9	J2-1	0
NP 1	J2-18	9	J2-2	1
NP 2	J2-18	9	J2-3	2
NP 3	J2-18	9	J2-4	3
NP 4	J2-18	9	J2-5	4
NP 5	J2-18	9	J2-6	5
NP 6	J2-18	9	J2-7	6
NP 7	J2-18	9	J2-8	7
F9	J2-19	10	J2-1	0
F10	J2-19	10	J2-2	1
NP 8	J2-19	10	J2-3	2
NP 9	J2-19	10	J2-4	3
NP 00	J2-19	10	J2-5	4
NP DOT	J2-19	10	J2-6	5
NP PLUS	J2-19	10	J2-7	6
NP MINUS	J2-19	10	J2-8	7
F1	J2-20	11	J2-1	0
F2	J2-20	11	J2-2	1
F3	J2-20	11	J2-3	2
F4	J2-20	11	J2-4	3
F5	J2-20	11	J2-5	4
F6	J2-20	11	J2-6	5
F7	J2-20	11	J2-7	6
F8	J2-20	11	J2-8	7
GRPH	J2-9	0	J2-1	0
SFT LOCK	J2-9	0	J2-2	1
LH SHIFT	J2-9	0	J2-3	2
RH SHIFT	J2-9	0	J2-3	2
力ナ RVS	J2-9	0	J2-4	3