

Precautions When Using

1. When selecting and using graphics from the menu screen, please do not use the game cartridge while it is inserted.
(please remove the game cartridge from the console before use)
2. BASIC will be displayed on the menu screen, but to use it, please insert the separately sold BASIC 1 cartridge.
(please note that BASIC 1 is not included in the main unit, but will be displayed on the menu screen)

*G-BASIC for game creation is built into the unit.
(Please refer to the instruction manual)